



Development Solutions

iC-96 Compiler User's Guide for DOS Systems

iC-96

Compiler User's Guide
for DOS Systems

Typographical Conventions

This manual uses the following conventions:

This type style indicates an element of syntax, a reserved word, a keyword, a filename, computer output, or part of a program example. The text appears in lowercase unless uppercase is significant.

l is lowercase letter L in examples.

1 is the number 1 in examples.

O is the uppercase O in examples.

0 is the number 0 in examples.

This type style indicates the exact characters you type as input.

This type style indicates a placeholder for an identifier, an expression, a string, a symbol, or a value. Substitute one of these items for the placeholder.











Index

Service Information

For service or assistance with Intel products, call:

- **1-800-843-4481** - in the United States and Canada
- Your local Intel sales office - in Europe or Japan
- Your Intel distributor - in any other area

Intel stands behind its products with a world-wide service and support organization. If you have problems, need assistance, or have a question, Intel can provide:

- On-site or carry-in service for hardware products
- Phone support for all Intel products
- On-site consulting for designing with Intel products or using Intel products in your designs
- Customer training workshops
- Updates to software products

To get more information on these services or to take advantage of them, call the number listed above.

All Intel products have a minimum warranty of 90 days, and all warranties include one or more of the services listed above. Talk with your Intel salesperson or call 1-800-843-4481 to determine the warranty services available for this product and how to register for them.

Intel is committed to continuing service for all its products.



INTEL CORPORATION, 2200 Mission College Drive, Santa Clara, California 95052-8119 (408) 987-8080

Printed in U.S.A.

DEVELOPMENT TOOLS AND SOFTWARE