



# **i960<sup>®</sup> Jx Microprocessor Developer's Manual**

Release Date: December, 1997

Order Number: 272483-002

Information in this document is provided in connection with Intel products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document. Except as provided in Intel's Terms and Conditions of Sale for such products, Intel assumes no liability whatsoever, and Intel disclaims any express or implied warranty, relating to sale and/or use of Intel products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right. Intel products are not intended for use in medical, life saving, or life sustaining applications.

Intel may make changes to specifications and product descriptions at any time, without notice.

Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them.

The i960<sup>®</sup> Jx Processor may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Contact your local Intel sales office or your distributor to obtain the latest specifications and before placing your product order.


Copies of documents which have an ordering number and are referenced in this document, or other Intel literature may be obtained by calling 1-800-548-4725 or by visiting Intel's website at <http://www.intel.com>.

Copyright © Intel Corporation, 1997

\*Third-party brands and names are the property of their respective owners.



# i960<sup>®</sup> Jx Microprocessor Developer's Manual



## CHAPTER 1 INTRODUCTION

1.1	Product Features.....	1-4
1.1.1	Instruction Cache .....	1-4
1.1.2	Data Cache .....	1-4
1.1.3	On-chip (Internal) Data RAM .....	1-4
1.1.4	Local Register Cache .....	1-5
1.1.5	Interrupt Controller .....	1-5
1.1.6	Timer Support .....	1-6
1.1.7	Memory-Mapped Control Registers (MMR) .....	1-6
1.1.8	External Bus .....	1-6
1.1.9	Complete Fault Handling and Debug Capabilities .....	1-7
1.2	ABOUT THIS MANUAL.....	1-7
1.3	NOTATION AND TERMINOLOGY.....	1-8
1.3.1	Reserved and Preserved .....	1-8
1.3.2	Specifying Bit and Signal Values .....	1-9
1.3.3	Representing Numbers .....	1-9
1.3.4	Register Names .....	1-9
1.4	Related Documents.....	1-10

## CHAPTER 2 DATA TYPES AND MEMORY ADDRESSING MODES

2.1	DATA TYPES.....	2-1
2.1.1	Integers .....	2-2
2.1.2	Ordinals .....	2-2
2.1.3	Bits and Bit Fields .....	2-3
2.1.4	Triple- and Quad-Words .....	2-3
2.1.5	Register Data Alignment .....	2-3
2.1.6	Literals .....	2-4
2.2	BIT AND BYTE ORDERING IN MEMORY.....	2-4
2.2.1	Bit Ordering .....	2-4
2.2.2	Byte Ordering .....	2-4
2.3	MEMORY ADDRESSING MODES .....	2-6
2.3.1	Absolute .....	2-7
2.3.2	Register Indirect .....	2-7
2.3.3	Index with Displacement .....	2-8
2.3.4	IP with Displacement .....	2-8
2.3.5	Addressing Mode Examples .....	2-8



## CHAPTER 3

### PROGRAMMING ENVIRONMENT

3.1	OVERVIEW .....	3-1
3.2	REGISTERS AND LITERALS AS INSTRUCTION OPERANDS.....	3-1
3.2.1	Global Registers .....	3-2
3.2.2	Local Registers .....	3-3
3.2.3	Register Scoreboarding .....	3-4
3.2.4	Literals .....	3-4
3.2.5	Register and Literal Addressing and Alignment .....	3-4
3.3	MEMORY-MAPPED CONTROL REGISTERS.....	3-6
3.3.1	Memory-Mapped Registers (MMR) .....	3-6
3.3.1.1	Restrictions on Instructions that Access Memory-Mapped Registers .....	3-6
3.3.1.2	Access Faults .....	3-7
3.4	ARCHITECTURALLY DEFINED DATA STRUCTURES.....	3-11
3.5	MEMORY ADDRESS SPACE.....	3-13
3.5.1	Memory Requirements .....	3-14
3.5.2	Data and Instruction Alignment in the Address Space .....	3-15
3.5.3	Byte, Word and Bit Addressing .....	3-15
3.5.4	Internal Data RAM .....	3-16
3.5.5	Instruction Cache .....	3-16
3.5.6	Data Cache .....	3-17
3.6	LOCAL REGISTER CACHE.....	3-17
3.7	PROCESSOR-STATE REGISTERS.....	3-17
3.7.1	Instruction Pointer (IP) Register .....	3-17
3.7.2	Arithmetic Controls (AC) Register .....	3-18
3.7.2.1	Initializing and Modifying the AC Register .....	3-18
3.7.2.2	Condition Code (AC.cc) .....	3-19
3.7.3	Process Controls (PC) Register .....	3-21
3.7.3.1	Initializing and Modifying the PC Register .....	3-22
3.7.4	Trace Controls (TC) Register .....	3-23
3.8	USER-SUPERVISOR PROTECTION MODEL .....	3-23
3.8.1	Supervisor Mode Resources .....	3-23
3.8.2	Using the User-Supervisor Protection Model .....	3-24

## CHAPTER 4

### CACHE AND ON-CHIP DATA RAM

4.1	INTERNAL DATA RAM.....	4-1
4.2	LOCAL REGISTER CACHE.....	4-2
4.3	BIG ENDIAN ACCESSES TO INTERNAL RAM AND DATA CACHE.....	4-4
4.4	INSTRUCTION CACHE .....	4-4
4.4.1	Enabling and Disabling the Instruction Cache .....	4-4
4.4.2	Operation While the Instruction Cache Is Disabled .....	4-5
4.4.3	Loading and Locking Instructions in the Instruction Cache .....	4-5





4.4.4	Instruction Cache Visibility .....	4-5
4.4.5	Instruction Cache Coherency .....	4-5
4.5	DATA CACHE .....	4-6
4.5.1	Enabling and Disabling the Data Cache .....	4-6
4.5.2	Multi-Word Data Accesses that Partially Hit the Data Cache .....	4-7
4.5.3	Data Cache Fill Policy .....	4-8
4.5.4	Data Cache Write Policy .....	4-8
4.5.5	Data Cache Coherency and Non-Cacheable Accesses .....	4-9
4.5.6	External I/O and Bus Masters and Cache Coherency .....	4-10
4.5.7	Data Cache Visibility .....	4-10

**CHAPTER 5  
INSTRUCTION SET OVERVIEW**

5.1	INSTRUCTION FORMATS .....	5-1
5.1.1	Assembly Language Format .....	5-1
5.1.2	Instruction Encoding Formats .....	5-2
5.1.3	Instruction Operands .....	5-3
5.2	INSTRUCTION GROUPS .....	5-4
5.2.1	Data Movement .....	5-5
5.2.1.1	Load and Store Instructions .....	5-5
5.2.1.2	Move .....	5-6
5.2.1.3	Load Address .....	5-6
5.2.2	Select Conditional .....	5-6
5.2.3	Arithmetic .....	5-7
5.2.3.1	Add, Subtract, Multiply, Divide, Conditional Add, Conditional Subtract .....	5-8
5.2.3.2	Remainder and Modulo .....	5-8
5.2.3.3	Shift, Rotate and Extended Shift .....	5-9
5.2.3.4	Extended Arithmetic .....	5-10
5.2.4	Logical .....	5-10
5.2.5	Bit, Bit Field and Byte Operations .....	5-11
5.2.5.1	Bit Operations .....	5-11
5.2.5.2	Bit Field Operations .....	5-11
5.2.5.3	Byte Operations .....	5-11
5.2.6	Comparison .....	5-12
5.2.6.1	Compare and Conditional Compare .....	5-12
5.2.6.2	Compare and Increment or Decrement .....	5-13
5.2.6.3	Test Condition Codes .....	5-13
5.2.7	Branch .....	5-14
5.2.7.1	Unconditional Branch .....	5-14
5.2.7.2	Conditional Branch .....	5-15
5.2.7.3	Compare and Branch .....	5-15
5.2.8	Call/Return .....	5-16
5.2.9	Faults .....	5-17
5.2.10	Debug .....	5-18
5.2.11	Atomic Instructions .....	5-18

5.2.12	Processor Management .....	5-19
5.3	PERFORMANCE OPTIMIZATION .....	5-20
5.3.1	Instruction Optimizations .....	5-20
5.3.1.1	Load / Store Execution Model .....	5-20
5.3.1.2	Compare Operations .....	5-20
5.3.1.3	Microcoded Instructions .....	5-21
5.3.1.4	Multiply-Divide Unit Instructions .....	5-21
5.3.1.5	Multi-Cycle Register Operations .....	5-21
5.3.1.6	Simple Control Transfer .....	5-22
5.3.1.7	Memory Instructions .....	5-22
5.3.1.8	Unaligned Memory Accesses .....	5-23
5.3.2	Miscellaneous Optimizations .....	5-23
5.3.2.1	Masking of Integer Overflow .....	5-23
5.3.2.2	Avoid Using PFP, SP, R3 As Destinations for MDU Instructions .....	5-23
5.3.2.3	Use Global Registers (g0 - g14) As Destinations for MDU Instructions .....	5-23
5.3.2.4	Execute in Imprecise Fault Mode .....	5-24

**CHAPTER 6**  
**INSTRUCTION SET REFERENCE**

6.1	NOTATION .....	6-1
6.1.1	Alphabetic Reference .....	6-2
6.1.2	Mnemonic .....	6-2
6.1.3	Format .....	6-2
6.1.4	Description .....	6-3
6.1.5	Action .....	6-3
6.1.6	Faults .....	6-5
6.1.7	Example .....	6-5
6.1.8	Opcode and Instruction Format .....	6-6
6.1.9	See Also .....	6-6
6.1.10	Side Effects .....	6-6
6.1.11	Notes .....	6-6
6.2	INSTRUCTIONS .....	6-6
6.2.1	ADD<cc> .....	6-7
6.2.2	addc .....	6-10
6.2.3	addi, addo .....	6-11
6.2.4	alterbit .....	6-12
6.2.5	and, andnot .....	6-13
6.2.6	atadd .....	6-14
6.2.7	atmod .....	6-15
6.2.8	b, bx .....	6-16
6.2.9	bal, balx .....	6-17
6.2.10	bbc, bbs .....	6-19
6.2.11	BRANCH<cc> .....	6-21
6.2.12	bswap .....	6-23
6.2.13	call .....	6-24



6.2.14	calls	6-25
6.2.15	callx	6-27
6.2.16	chkbit	6-29
6.2.17	clrbt	6-30
6.2.18	cmpdeci, cmpdeco	6-31
6.2.19	cmpinci, cmpinco	6-32
6.2.20	COMPARE	6-33
6.2.21	COMPARE AND BRANCH<cc>	6-35
6.2.22	concmpi, concmpo	6-38
6.2.23	dcctl	6-40
6.2.24	divi, divo	6-47
6.2.25	ediv	6-48
6.2.26	emul	6-49
6.2.27	eshro	6-50
6.2.28	extract	6-51
6.2.29	FAULT<cc>	6-52
6.2.30	flushreg	6-54
6.2.31	fmark	6-55
6.2.32	halt	6-56
6.2.33	icctl	6-58
6.2.34	intctl	6-66
6.2.35	intdis	6-68
6.2.36	inten	6-69
6.2.37	LOAD	6-70
6.2.38	lda	6-73
6.2.39	mark	6-74
6.2.40	modac	6-75
6.2.41	modi	6-76
6.2.42	modify	6-77
6.2.43	modpc	6-78
6.2.44	modtc	6-80
6.2.45	MOVE	6-81
6.2.46	muli, mulo	6-84
6.2.47	nand	6-85
6.2.48	nor	6-86
6.2.49	not, notand	6-87
6.2.50	notbit	6-88
6.2.51	notor	6-89
6.2.52	or, ornot	6-90
6.2.53	remi, remo	6-91
6.2.54	ret	6-92
6.2.55	rotate	6-94
6.2.56	scanbit	6-95
6.2.57	scanbyte	6-96

6.2.58	SEL<cc> .....	6-97
6.2.59	setbit .....	6-99
6.2.60	SHIFT .....	6-100
6.2.61	spanbit .....	6-103
6.2.62	STORE .....	6-104
6.2.63	subc .....	6-108
6.2.64	SUB<cc> .....	6-109
6.2.65	subi, subo .....	6-112
6.2.66	syncf .....	6-113
6.2.67	sysctl .....	6-114
6.2.68	TEST<cc> .....	6-118
6.2.69	xnor, xor .....	6-120

## CHAPTER 7

### PROCEDURE CALLS

7.1	CALL AND RETURN MECHANISM .....	7-2
7.1.1	Local Registers and the Procedure Stack .....	7-2
7.1.2	Local Register and Stack Management .....	7-4
7.1.2.1	Frame Pointer .....	7-4
7.1.2.2	Stack Pointer .....	7-4
7.1.2.3	Considerations When Pushing Data onto the Stack .....	7-4
7.1.2.4	Considerations When Popping Data off the Stack .....	7-5
7.1.2.5	Previous Frame Pointer .....	7-5
7.1.2.6	Return Type Field .....	7-5
7.1.2.7	Return Instruction Pointer .....	7-5
7.1.3	Call and Return Action .....	7-5
7.1.3.1	Call Operation .....	7-6
7.1.3.2	Return Operation .....	7-7
7.1.4	Caching Local Register Sets .....	7-7
7.1.4.1	Reserving Local Register Sets for High Priority Interrupts .....	7-8
7.1.5	Mapping Local Registers to the Procedure Stack .....	7-11
7.2	MODIFYING THE PFP REGISTER .....	7-11
7.3	PARAMETER PASSING .....	7-12
7.4	LOCAL CALLS .....	7-14
7.5	SYSTEM CALLS .....	7-15
7.5.1	System Procedure Table .....	7-15
7.5.1.1	Procedure Entries .....	7-17
7.5.1.2	Supervisor Stack Pointer .....	7-17
7.5.1.3	Trace Control Bit .....	7-17
7.5.2	System Call to a Local Procedure .....	7-18
7.5.3	System Call to a Supervisor Procedure .....	7-18
7.6	USER AND SUPERVISOR STACKS .....	7-19
7.7	INTERRUPT AND FAULT CALLS .....	7-19
7.8	RETURNS .....	7-20





7.9	BRANCH-AND-LINK .....	7-21
-----	-----------------------	------

**CHAPTER 8  
FAULTS**

8.1	FAULT HANDLING OVERVIEW .....	8-1
8.2	FAULT TYPES .....	8-3
8.3	FAULT TABLE .....	8-4
8.4	STACK USED IN FAULT HANDLING .....	8-6
8.5	FAULT RECORD .....	8-6
8.5.1	Fault Record Description .....	8-7
8.5.2	Fault Record Location .....	8-8
8.6	MULTIPLE AND PARALLEL FAULTS .....	8-9
8.6.1	Multiple Non-Trace Faults on the Same Instruction .....	8-9
8.6.2	Multiple Trace Fault Conditions on the Same Instruction .....	8-9
8.6.3	Multiple Trace and Non-Trace Fault Conditions on the Same Instruction .....	8-9
8.6.4	Parallel Faults .....	8-9
8.6.4.1	Faults on Multiple Instructions Executed in Parallel .....	8-10
8.6.4.2	Fault Record for Parallel Faults .....	8-11
8.6.5	Override Faults .....	8-11
8.6.6	System Error .....	8-12
8.7	FAULT HANDLING PROCEDURES .....	8-12
8.7.1	Possible Fault Handling Procedure Actions .....	8-13
8.7.2	Program Resumption Following a Fault .....	8-13
8.7.2.1	Faults Happening Before Instruction Execution .....	8-13
8.7.2.2	Faults Happening During Instruction Execution .....	8-14
8.7.2.3	Faults Happening After Instruction Execution .....	8-14
8.7.3	Return Instruction Pointer (RIP) .....	8-14
8.7.4	Returning to the Point in the Program Where the Fault Occurred .....	8-15
8.7.5	Returning to a Point in the Program Other Than Where the Fault Occurred .....	8-15
8.7.6	Fault Controls .....	8-15
8.8	FAULT HANDLING ACTION .....	8-16
8.8.1	Local Fault Call .....	8-17
8.8.2	System-Local Fault Call .....	8-17
8.8.3	System-Supervisor Fault Call .....	8-17
8.8.4	Faults and Interrupts .....	8-18
8.9	PRECISE AND IMPRECISE FAULTS .....	8-19
8.9.1	Precise Faults .....	8-19
8.9.2	Imprecise Faults .....	8-19
8.9.3	Asynchronous Faults .....	8-19
8.9.4	No Imprecise Faults (AC.nif) Bit .....	8-20
8.9.5	Controlling Fault Precision .....	8-20
8.10	FAULT REFERENCE .....	8-21
8.10.1	ARITHMETIC Faults .....	8-22
8.10.2	CONSTRAINT Faults .....	8-23

8.10.3	OPERATION Faults .....	8-24
8.10.4	OVERRIDE Faults .....	8-26
8.10.5	PARALLEL Faults .....	8-27
8.10.6	PROTECTION Faults .....	8-28
8.10.7	TRACE Faults .....	8-29
8.10.8	TYPE Faults .....	8-32

## CHAPTER 9

### TRACING AND DEBUGGING

9.1	TRACE CONTROLS .....	9-1
9.1.1	Trace Controls (TC) Register .....	9-2
9.1.2	PC Trace Enable Bit and Trace-Fault-Pending Flag .....	9-3
9.2	TRACE MODES .....	9-3
9.2.1	Instruction Trace .....	9-3
9.2.2	Branch Trace .....	9-4
9.2.3	Call Trace .....	9-4
9.2.4	Return Trace .....	9-4
9.2.5	Prereturn Trace .....	9-4
9.2.6	Supervisor Trace .....	9-5
9.2.7	Mark Trace .....	9-5
9.2.7.1	Software Breakpoints .....	9-5
9.2.7.2	Hardware Breakpoints .....	9-5
9.2.7.3	Requesting Modification Rights to Hardware Breakpoint Resources .....	9-6
9.2.7.4	Breakpoint Control Register .....	9-7
9.2.7.5	Data Address Breakpoint (DAB) Registers .....	9-9
9.2.7.6	Instruction Breakpoint (IPB) Registers .....	9-10
9.3	GENERATING A TRACE FAULT .....	9-11
9.4	HANDLING MULTIPLE TRACE EVENTS .....	9-11
9.5	TRACE FAULT HANDLING PROCEDURE .....	9-12
9.5.1	Tracing and Interrupt Procedures .....	9-12
9.5.2	Tracing on Calls and Returns .....	9-12
9.5.2.1	Tracing on Explicit Call .....	9-13
9.5.2.2	Tracing on Implicit Call .....	9-14
9.5.2.3	Tracing on Return from Explicit Call .....	9-15
9.5.2.4	Tracing on Return from Implicit Call: Fault Case .....	9-15
9.5.2.5	Tracing on Return from Implicit Call: Interrupt Case .....	9-16

## CHAPTER 10

### TIMERS

10.1	TIMER REGISTERS .....	10-2
10.1.1	Timer Mode Registers (TMR0, TMR1) .....	10-3
10.1.1.1	Bit 0 - Terminal Count Status Bit (TMRx.tc) .....	10-4
10.1.1.2	Bit 1 - Timer Enable (TMRx.enable) .....	10-4
10.1.1.3	Bit 2 - Timer Auto Reload Enable (TMRx.reload) .....	10-5
10.1.1.4	Bit 3 - Timer Register Supervisor Read/Write Control (TMRx.sup) .....	10-5





10.1.1.5	Bits 4, 5 - Timer Input Clock Select (TMRx.csel1:0) .....	10-6
10.1.2	Timer Count Register (TCR0, TCR1) .....	10-6
10.1.3	Timer Reload Register (TRR0, TRR1) .....	10-7
10.2	TIMER OPERATION .....	10-7
10.2.1	Basic Timer Operation .....	10-7
10.2.2	Load/Store Access Latency for Timer Registers .....	10-9
10.3	TIMER INTERRUPTS .....	10-11
10.4	POWERUP/RESET INITIALIZATION .....	10-11
10.5	UNCOMMON TCRX AND TRRX CONDITIONS .....	10-12
10.6	TIMER STATE DIAGRAM .....	10-13

**CHAPTER 11  
INTERRUPTS**

11.1	OVERVIEW .....	11-1
11.1.1	The i960 <sup>®</sup> Jx Processor Interrupt Controller .....	11-2
11.2	SOFTWARE REQUIREMENTS FOR INTERRUPT HANDLING .....	11-3
11.3	INTERRUPT PRIORITY .....	11-3
11.4	INTERRUPT TABLE .....	11-4
11.4.1	Vector Entries .....	11-5
11.4.2	Pending Interrupts .....	11-5
11.4.3	Caching Portions of the Interrupt Table .....	11-6
11.5	INTERRUPT STACK AND INTERRUPT RECORD .....	11-7
11.6	MANAGING INTERRUPT REQUESTS .....	11-8
11.6.1	External Interrupts .....	11-8
11.6.2	Non-Maskable Interrupt ( $\overline{NMI}$ ) .....	11-8
11.6.3	Timer Interrupts .....	11-9
11.6.4	Software Interrupts .....	11-9
11.6.5	Posting Interrupts .....	11-9
11.6.5.1	Posting Software Interrupts via sysctl .....	11-9
11.6.5.2	Posting Software Interrupts Directly in the Interrupt Table .....	11-11
11.6.5.3	Posting External Interrupts .....	11-11
11.6.5.4	Posting Hardware Interrupts .....	11-11
11.6.6	Resolving Interrupt Priority .....	11-11
11.6.7	Sampling Pending Interrupts in the Interrupt Table .....	11-12
11.6.8	Interrupt Controller Modes .....	11-14
11.6.8.1	Dedicated Mode .....	11-14
11.6.8.2	Expanded Mode .....	11-15
11.6.8.3	Mixed Mode .....	11-17
11.6.9	Saving the Interrupt Mask .....	11-17
11.7	EXTERNAL INTERFACE DESCRIPTION .....	11-18
11.7.1	Pin Descriptions .....	11-18
11.7.2	Interrupt Detection Options .....	11-19
11.7.3	Memory-Mapped Control Registers .....	11-21
11.7.4	Interrupt Control Register (ICON) .....	11-22

11.7.5	Interrupt Mapping Registers (IMAP0-IMAP2) .....	11-23
11.7.5.1	Interrupt Mask (IMSK) and Interrupt Pending (IPND) Registers .....	11-25
11.7.5.2	Interrupt Controller Register Access Requirements .....	11-27
11.7.5.3	Default and Reset Register Values .....	11-28
11.8	INTERRUPT OPERATION SEQUENCE.....	11-28
11.8.1	Setting Up the Interrupt Controller .....	11-31
11.8.2	Interrupt Service Routines .....	11-31
11.8.3	Interrupt Context Switch .....	11-32
11.8.3.1	Servicing an Interrupt from Executing State .....	11-32
11.8.3.2	Servicing an Interrupt from Interrupted State .....	11-33
11.9	OPTIMIZING INTERRUPT PERFORMANCE.....	11-33
11.9.1	Interrupt Service Latency .....	11-35
11.9.2	Features to Improve Interrupt Performance .....	11-35
11.9.2.1	Vector Caching Option .....	11-35
11.9.2.2	Caching Interrupt Routines and Reserving Register Frames .....	11-36
11.9.2.3	Caching the Interrupt Stack .....	11-36
11.9.3	Base Interrupt Latency .....	11-37
11.9.4	Maximum Interrupt Latency .....	11-38
11.9.4.1	Avoiding Certain Destinations for MDU Operations .....	11-42
11.9.4.2	Masking Integer Overflow Faults for syncf .....	11-42

## CHAPTER 12

### INITIALIZATION AND SYSTEM REQUIREMENTS

12.1	OVERVIEW .....	12-1
12.2	INITIALIZATION .....	12-2
12.2.1	Reset State Operation .....	12-3
12.2.2	Self Test Function (STEST, $\overline{\text{FAIL}}$ ) .....	12-6
12.2.2.1	The STEST Pin .....	12-7
12.2.2.2	External Bus Confidence Test .....	12-7
12.2.2.3	The Fail Pin ( $\overline{\text{FAIL}}$ ) .....	12-7
12.2.2.4	IMI Alignment Check and System Error .....	12-8
12.2.2.5	FAIL Code .....	12-8
12.3	Architecturally Reserved Memory Space .....	12-9
12.3.1	Initial Memory Image (IMI) .....	12-10
12.3.1.1	Initialization Boot Record (IBR) .....	12-13
12.3.1.2	Process Control Block (PRCB) .....	12-16
12.3.2	Process PRCB Flow .....	12-18
12.3.2.1	AC Initial Image .....	12-19
12.3.2.2	Fault Configuration Word .....	12-19
12.3.2.3	Instruction Cache Configuration Word .....	12-19
12.3.2.4	Register Cache Configuration Word .....	12-19
12.3.3	Control Table .....	12-20
12.4	DEVICE IDENTIFICATION ON RESET .....	12-22
12.4.1	Reinitializing and Relocating Data Structures .....	12-22
12.5	Startup Code Example .....	12-23





12.6	SYSTEM REQUIREMENTS.....	12-34
12.6.1	Input Clock (CLKIN) .....	12-34
12.6.2	Power and Ground Requirements ( $V_{CC}$ , $V_{SS}$ ) .....	12-34
12.6.3	$V_{CC5}$ Pin Requirements .....	12-35
12.6.4	Power and Ground Planes .....	12-35
12.6.5	Decoupling Capacitors .....	12-36
12.6.6	I/O Pin Characteristics .....	12-36
12.6.6.1	Output Pins .....	12-37
12.6.6.2	Input Pins .....	12-37
12.6.7	High Frequency Design Considerations .....	12-38
12.6.8	Line Termination .....	12-38
12.6.9	Latchup .....	12-39
12.6.10	Interference .....	12-40

## CHAPTER 13

### MEMORY CONFIGURATION

13.1	Memory Attributes .....	13-1
13.1.1	Physical Memory Attributes .....	13-1
13.1.2	Logical Memory Attributes .....	13-2
13.2	Differences With Previous i960 Processors .....	13-3
13.3	Programming the Physical Memory Attributes (PMCON Registers) .....	13-4
13.3.1	Bus Width .....	13-5
13.4	Physical Memory Attributes at Initialization .....	13-5
13.4.1	Bus Control (BCON) Register .....	13-6
13.5	Boundary Conditions for Physical Memory Regions .....	13-7
13.5.1	Internal Memory Locations .....	13-7
13.5.2	Bus Transactions Across Region Boundaries .....	13-7
13.5.3	Modifying the PMCON Registers .....	13-7
13.6	Programming the Logical Memory Attributes .....	13-8
13.6.1	Defining the Effective Range of a Logical Data Template .....	13-11
13.6.2	Selecting the Byte Order .....	13-12
13.6.3	Data Caching Enable .....	13-12
13.6.4	Enabling the Logical Memory Template .....	13-12
13.6.5	Initialization .....	13-13
13.6.6	Boundary Conditions for Logical Memory Templates .....	13-13
13.6.6.1	Internal Memory Locations .....	13-13
13.6.6.2	Overlapping Logical Data Template Ranges .....	13-13
13.6.6.3	Accesses Across LMT Boundaries .....	13-14
13.6.7	Modifying the LMT Registers .....	13-14
13.6.8	Dynamic Byte Order Changing .....	13-14

## CHAPTER 14

### EXTERNAL BUS

14.1	OVERVIEW .....	14-1
------	----------------	------

14.2	BUS OPERATION .....	14-1
14.2.1	Basic Bus States .....	14-2
14.2.2	Bus Signal Types .....	14-4
14.2.2.1	Clock Signal .....	14-4
14.2.2.2	Address/Data Signal Definitions .....	14-4
14.2.2.3	Control/Status Signal Definitions .....	14-4
14.2.3	Bus Accesses .....	14-6
14.2.3.1	Bus Width .....	14-7
14.2.3.2	Basic Bus Accesses .....	14-9
14.2.3.3	Burst Transactions .....	14-11
14.2.3.4	Wait States .....	14-17
14.2.3.5	Recovery States .....	14-19
14.2.4	Bus and Control Signals During Recovery and Idle States .....	14-22
14.2.5	Data Alignment .....	14-22
14.2.6	Byte Ordering and Bus Accesses .....	14-28
14.2.7	Atomic Bus Transactions .....	14-30
14.2.8	Bus Arbitration .....	14-31
14.2.8.1	HOLD/HOLDA Protocol .....	14-32
14.2.8.2	BSTAT Signal .....	14-33
14.3	BUS APPLICATIONS .....	14-34
14.3.1	System Block Diagrams .....	14-34
14.3.1.1	Memory Subsystems .....	14-37
14.3.1.2	I/O Subsystems .....	14-37

## CHAPTER 15

### TEST FEATURES

15.1	ON-CIRCUIT EMULATION (ONCE).....	15-1
15.1.1	Entering/Exiting ONCE Mode .....	15-1
15.2	BOUNDARY SCAN (JTAG).....	15-2
15.2.1	Boundary Scan Architecture .....	15-2
15.2.1.1	TAP Controller .....	15-2
15.2.1.2	Instruction Register .....	15-2
15.2.1.3	Test Data Registers .....	15-2
15.2.1.4	TAP Elements .....	15-3
15.3	TAP REGISTERS.....	15-5
15.3.1	Instruction Register (IR) .....	15-5
15.3.2	TAP Test Data Registers .....	15-6
15.3.2.1	Device Identification Register .....	15-6
15.3.2.2	Bypass Register .....	15-6
15.3.2.3	RUNBIST Register .....	15-7
15.3.2.4	Boundary-Scan Register .....	15-7
15.3.3	Boundary Scan Instruction Set .....	15-8
15.3.4	IEEE Required Instructions .....	15-8
15.3.5	TAP Controller .....	15-9
15.3.5.1	Test Logic Reset State .....	15-10
15.3.5.2	Run-Test/Idle State .....	15-10





15.3.5.3	Select-DR-Scan State .....	15-10
15.3.5.4	Capture-DR State .....	15-10
15.3.5.5	Shift-DR State .....	15-11
15.3.5.6	Exit1-DR State .....	15-11
15.3.5.7	Pause-DR State .....	15-11
15.3.5.8	Exit2-DR State .....	15-11
15.3.5.9	Update-DR State .....	15-12
15.3.5.10	Select-IR Scan State .....	15-12
15.3.5.11	Capture-IR State .....	15-12
15.3.5.12	Shift-IR State .....	15-12
15.3.5.13	Exit1-IR State .....	15-13
15.3.5.14	Pause-IR State .....	15-13
15.3.5.15	Exit2-IR State .....	15-13
15.3.5.16	Update-IR State .....	15-13
15.3.6	Boundary-Scan Register .....	15-14
15.3.6.1	Example .....	15-15
15.3.7	Boundary Scan Description Language Example .....	15-18

**APPENDIX A  
CONSIDERATIONS FOR WRITING PORTABLE CODE**

A.1	CORE ARCHITECTURE .....	A-1
A.2	ADDRESS SPACE RESTRICTIONS .....	A-2
A.2.1	Reserved Memory .....	A-2
A.2.2	Initialization Boot Record .....	A-2
A.2.3	Internal Data RAM .....	A-2
A.2.4	Instruction Cache .....	A-2
A.3	Data and Data Structure Alignment.....	A-3
A.4	RESERVED LOCATIONS IN REGISTERS AND DATA STRUCTURES.....	A-4
A.5	INSTRUCTION SET .....	A-4
A.5.1	Instruction Timing .....	A-4
A.5.2	Implementation-Specific Instructions .....	A-5
A.6	EXTENDED REGISTER SET.....	A-5
A.7	INITIALIZATION .....	A-5
A.8	MEMORY CONFIGURATION .....	A-6
A.9	INTERRUPTS .....	A-6
A.10	OTHER i960 Jx PROCESSOR IMPLEMENTATION-SPECIFIC FEATURES.....	A-6
A.10.1	Data Control Peripheral Units .....	A-7
A.10.2	Timers .....	A-7
A.10.3	Fault Implementation .....	A-7
A.11	BREAKPOINTS.....	A-7

**APPENDIX B  
OPCODES AND EXECUTION TIMES**

B.1	INSTRUCTION REFERENCE BY OPCODE .....	B-1
-----	---------------------------------------	-----

**APPENDIX C**

**MACHINE-LEVEL INSTRUCTION FORMATS**

C.1	GENERAL INSTRUCTION FORMAT .....	C-1
C.2	REG FORMAT .....	C-2
C.3	COBR FORMAT .....	C-3
C.4	CTRL FORMAT .....	C-4
C.5	MEM FORMAT .....	C-4
C.5.1	MEMA Format Addressing .....	C-5
C.5.2	MEMB Format Addressing .....	C-6

**APPENDIX D**

**REGISTER AND DATA STRUCTURES**

D.1	REGISTERS .....	D-3
-----	-----------------	-----

**GLOSSARY**

**INDEX**





## FIGURES

Figure 1-1.	i960 <sup>®</sup> Jx Microprocessor Functional Block Diagram .....	1-3
Figure 2-1.	Data Types and Ranges .....	2-1
Figure 2-2.	Data Placement in Registers .....	2-6
Figure 3-1.	i960 <sup>®</sup> Jx Processor Programming Environment Elements .....	3-2
Figure 3-2.	Memory Address Space .....	3-13
Figure 3-3.	Arithmetic Controls (AC) Register .....	3-18
Figure 3-4.	Process Controls (PC) Register .....	3-21
Figure 4-1.	Internal Data RAM and Register Cache .....	4-2
Figure 5-1.	Machine-Level Instruction Formats .....	5-3
Figure 6-1.	dcctl <i>src1</i> and <i>src/dst</i> Formats .....	6-41
Figure 6-2.	Store Data Cache to Memory Output Format .....	6-42
Figure 6-3.	D-Cache Tag and Valid Bit Formats .....	6-43
Figure 6-4.	icctl <i>src1</i> and <i>src/dst</i> Formats .....	6-59
Figure 6-5.	Store Instruction Cache to Memory Output Format .....	6-61
Figure 6-6.	I-Cache Set Data, Tag and Valid Bit Formats .....	6-62
Figure 6-7.	Src1 Operand Interpretation .....	6-114
Figure 6-8.	<i>src/dst</i> Interpretation for Breakpoint Resource Request .....	6-115
Figure 7-1.	Procedure Stack Structure and Local Registers .....	7-3
Figure 7-2.	Frame Spill .....	7-9
Figure 7-3.	Frame Fill .....	7-10
Figure 7-4.	System Procedure Table .....	7-16
Figure 7-5.	Previous Frame Pointer Register (PFP) (r0) .....	7-20
Figure 8-1.	Fault-Handling Data Structures .....	8-1
Figure 8-2.	Fault Table and Fault Table Entries .....	8-5
Figure 8-3.	Fault Record .....	8-7
Figure 8-4.	Storage of the Fault Record on the Stack .....	8-8
Figure 9-1.	80960Jx Trace Controls (TC) Register .....	9-2
Figure 9-2.	Breakpoint Control Register (BPCON) .....	9-8
Figure 9-3.	Data Address Breakpoint (DAB) Register Format .....	9-10
Figure 9-4.	Instruction Breakpoint (IPB) Register Format .....	9-10
Figure 10-1.	Timer Functional Diagram .....	10-1
Figure 10-2.	Timer Mode Register (TMR0, TMR1) .....	10-3
Figure 10-3.	Timer Count Register (TCR0, TCR1) .....	10-6
Figure 10-4.	Timer Reload Register (TRR0, TRR1) .....	10-7
Figure 10-5.	Timer Unit State Diagram .....	10-13
Figure 11-1.	Interrupt Handling Data Structures .....	11-2
Figure 11-2.	Interrupt Table .....	11-4
Figure 11-3.	Storage of an Interrupt Record on the Interrupt Stack .....	11-7
Figure 11-4.	Dedicated Mode .....	11-14




Figure 11-5.	Expanded Mode .....	11-15
Figure 11-6.	Implementation of Expanded Mode Sources.....	11-16
Figure 11-7.	Interrupt Sampling .....	11-20
Figure 11-8.	Interrupt Control (ICON) Register.....	11-22
Figure 11-9.	Interrupt Mapping (IMAP0-IMAP2) Registers .....	11-24
Figure 11-10.	Interrupt Pending (IPND) Register.....	11-25
Figure 11-11.	Interrupt Mask (IMSK) Registers .....	11-26
Figure 11-12.	Interrupt Controller.....	11-30
Figure 11-13.	Interrupt Service Flowchart.....	11-34
Figure 12-1.	Processor Initialization Flow .....	12-2
Figure 12-2.	Cold Reset Waveform .....	12-4
Figure 12-3.	FAIL Sequence.....	12-8
Figure 12-4.	Initial Memory Image (IMI) and Process Control Block (PRCB) .....	12-12
Figure 12-5.	PMCON14_15 Register Bit Description in IBR.....	12-15
Figure 12-6.	Process Control Block Configuration Words.....	12-17
Figure 12-7.	Control Table .....	12-21
Figure 12-8.	IEEE 1149.1 Device Identification Register.....	12-22
Figure 12-9.	V <sub>CC5</sub> Current-Limiting Resistor.....	12-35
Figure 12-10.	Reducing Characteristic Impedance.....	12-36
Figure 12-11.	Series Termination .....	12-39
Figure 12-12.	AC Termination.....	12-39
Figure 12-13.	Avoid Closed-Loop Signal Paths .....	12-41
Figure 13-1.	PMCON and LMCON Example .....	13-2
Figure 13-2.	PMCON Register Bit Description.....	13-5
Figure 13-3.	Bus Control Register (BCON).....	13-6
Figure 13-4.	Logical Memory Template Starting Address Registers (LMADR0-1) .....	13-8
Figure 13-5.	Logical Memory Template Mask Registers (LMMR0-1) .....	13-9
Figure 13-6.	Default Logical Memory Configuration Register (DLMCON) .....	13-10
Figure 14-1.	Bus States with Arbitration .....	14-3
Figure 14-2.	Data Width and Byte Encodings.....	14-7
Figure 14-3.	Non-Burst Read and Write Transactions Without Wait States, 32-Bit Bus.....	14-10
Figure 14-4.	32-Bit Wide Data Bus Bursts .....	14-12
Figure 14-5.	16-Bit Wide Data Bus Bursts .....	14-12
Figure 14-6.	8-Bit Wide Data Bus Bursts .....	14-13
Figure 14-7.	Unaligned Write Transaction .....	14-14
Figure 14-8.	Burst Read and Write Transactions w/o Wait States, 32-bit Bus.....	14-15
Figure 14-9.	Burst Read and Write Transactions w/o Wait States, 8-bit Bus.....	14-16
Figure 14-10.	Burst Write Transactions With 2,1,1,1 Wait States, 32-bit Bus.....	14-18
Figure 14-11.	Burst Read/Write Transactions with 1,0 Wait States - Extra Tr State on Read, 16-Bit Bus .....	14-20



Figure 14-12.	Burst Read/Write Transactions with 1,0 Wait States, Extra Tr State on Read, 16-Bit Bus	14-21
Figure 14-13.	Summary of Aligned and Unaligned Accesses (32-Bit Bus)	14-25
Figure 14-14.	Summary of Aligned and Unaligned Accesses (32-Bit Bus) (Continued)	14-26
Figure 14-15.	Accesses Generated by Double Word Read Bus Request, Misaligned One Byte From Quad Word Boundary, 32-Bit Bus, Little Endian	14-27
Figure 14-16.	Multi-Word Access to Big-Endian Memory Space	14-29
Figure 14-17.	The $\overline{\text{LOCK}}$ Signal	14-31
Figure 14-18.	Arbitration Timing Diagram for a Bus Master	14-33
Figure 14-19.	Generalized 80960Jx System with 80960 Local Bus	14-35
Figure 14-20.	Generalized 80960Jx System with 80960 Local Bus and Backplane Bus	14-35
Figure 14-21.	80960Jx System with 80960 Local Bus, PCI Local Bus and Local Bus for High End Microprocessor	14-36
Figure 15-1.	Test Access Port Block Diagram	15-3
Figure 15-2.	TAP Controller State Diagram	15-4
Figure 15-3.	JTAG Example	15-16
Figure 15-4.	Timing diagram illustrating the loading of Instruction Register	15-17
Figure 15-5.	Timing diagram illustrating the loading of Data Register	15-18
Figure C-1.	Instruction Formats	C-1
Figure D-1.	AC (Arithmetic Controls) Register	D-3
Figure D-2.	PC (Process Controls) Register	D-4
Figure D-3.	Procedure Stack Structure and Local Registers	D-5
Figure D-4.	System Procedure Table	D-6
Figure D-5.	PFP (Previous Frame Pointer) Register (r0)	D-7
Figure D-6.	Fault Table and Fault Table Entries	D-8
Figure D-7.	Fault Record	D-9
Figure D-8.	TC (Trace Controls) Register	D-10
Figure D-9.	BPCON (Breakpoint Control) Register	D-10
Figure D-10.	DAB (Data Address Breakpoint) Register Format	D-11
Figure D-11.	IPB (Instruction Breakpoint) Register Format	D-11
Figure D-12.	TMR0-1 (Timer Mode Register)	D-12
Figure D-13.	TCR0-1 (Timer Count Register)	D-12
Figure D-14.	TRR0-1 (Timer Reload Register)	D-13
Figure D-15.	Interrupt Table	D-14
Figure D-16.	Storage of an Interrupt Record on the Interrupt Stack	D-15
Figure D-17.	ICON (Interrupt Control) Register	D-16
Figure D-18.	IMAP0-IMAP2 (Interrupt Mapping) Registers	D-17
Figure D-19.	IMSK (Interrupt Mask) Registers	D-18
Figure D-20.	Interrupt Pending (IPND) Register	D-19
Figure D-21.	Initial Memory Image (IMI) and Process Control Block (PRCB)	D-20
Figure D-22.	Process Control Block Configuration Words	D-21



Figure D-23.	Control Table .....	D-22
Figure D-24.	IEEE 1149.1 Device Identification Register.....	D-23
Figure D-25.	PMCON Register Bit Description.....	D-23
Figure D-26.	BCON (Bus Control) Register.....	D-24
Figure D-27.	DLMCON (Default Logical Memory Configuration) Register .....	D-24
Figure D-28.	LMADR0:1 Logical Memory Template Starting Address Registers .....	D-25
Figure D-29.	LMMR0:1 (Logical Memory Mask Registers).....	D-25





**TABLES**

Table 1-1. Register Terminology Conventions ..... 1-10

Table 2-1. Memory Contents for Little and Big Endian Example ..... 2-5

Table 2-2. Byte Ordering for Little and Big Endian Accesses ..... 2-5

Table 2-3. Memory Addressing Modes ..... 2-6

Table 3-1. Registers and Literals Used as Instruction Operands ..... 3-3

Table 3-2. Allowable Register Operands ..... 3-5

Table 3-3. Access Types ..... 3-8

Table 3-4. Supervisor Space Family Registers ..... 3-9

Table 3-5. User Space Family Registers and Tables ..... 3-11

Table 3-6. Data Structure Descriptions ..... 3-12

Table 3-7. Alignment of Data Structures in the Address Space ..... 3-15

Table 3-8. Condition Codes for True or False Conditions ..... 3-19

Table 3-9. Condition Codes for Equality and Inequality Conditions ..... 3-19

Table 3-10. Condition Codes for Carry Out and Overflow ..... 3-19

Table 5-1. Instruction Encoding Formats ..... 5-2

Table 5-2. 80960Jx Instruction Set ..... 5-4

Table 5-3. Arithmetic Operations ..... 5-7

Table 6-1. Pseudo-Code Symbol Definitions ..... 6-4

Table 6-2. Faults Applicable to All Instructions ..... 6-4

Table 6-3. Common Faulting Conditions ..... 6-5

Table 6-4. Condition Code Mask Descriptions ..... 6-7

Table 6-5. Condition Code Mask Descriptions ..... 6-21

Table 6-6. Condition Code Settings ..... 6-31

Table 6-7. Condition Code Settings ..... 6-32

Table 6-8. Condition Code Settings ..... 6-33

Table 6-9. Condition Code Mask Descriptions ..... 6-36

Table 6-10. concmpo example: register ordering and CC ..... 6-39

Table 6-11. dcctl Operand Fields ..... 6-40

Table 6-12. DCCTL Status Values and D-Cache Parameters ..... 6-42

Table 6-13. Condition Code Mask Descriptions ..... 6-52

Table 6-15. icctl Operand Fields ..... 6-58

Table 6-16. ICCTL Status Values and Instruction Cache Parameters ..... 6-60

Table 6.17. Condition Code Mask Descriptions ..... 6-97

Table 6-18. sysctl Field Definitions ..... 6-114

Table 6-19. Cache Mode Configuration ..... 6-115

Table 6-20. Condition Code Mask Descriptions ..... 6-118

Table 7-1. Encodings of Entry Type Field in System Procedure Table ..... 7-17

Table 7-2. Encoding of Return Status Field ..... 7-21

Table 8-1. i960<sup>®</sup> Jx Processor Fault Types and Subtypes ..... 8-3




Table 8-2.	Fault Control Bits and Masks .....	8-16
Table 9-1.	<i>src/dst</i> Encoding .....	9-7
Table 9-2.	Configuring the Data Address Breakpoint (DAB) Registers.....	9-8
Table 9-3.	Programming the Data Address Breakpoint (DAB) Modes.....	9-8
Table 9-4.	Instruction Breakpoint Modes .....	9-11
Table 9-5.	Tracing on Explicit Call .....	9-13
Table 9-6.	Tracing on Implicit Call .....	9-14
Table 9-7.	Tracing on Return from Explicit Call .....	9-15
Table 9-8.	Tracing on Return from Fault .....	9-15
Table 9-9.	Tracing on Return from Interrupt .....	9-16
Table 10-1.	Timer Performance Ranges.....	10-2
Table 10-2.	Timer Registers .....	10-2
Table 10-3.	Timer Input Clock (TCLOCK) Frequency Selection.....	10-6
Table 10-4.	Timer Mode Register Control Bit Summary .....	10-8
Table 10-5.	Timer Responses to Register Bit Settings .....	10-9
Table 10-6.	Timer Powerup Mode Settings .....	10-11
Table 10-7.	Uncommon TMRx Control Bit Settings .....	10-12
Table 11-1.	Interrupt Control Registers Memory-Mapped Addresses.....	11-21
Table 11-2.	Location of Cached Vectors in Internal RAM .....	11-36
Table 11-3.	Base Interrupt Latency.....	11-37
Table 11-4.	Worst-Case Interrupt Latency Controlled by <i>divo</i> to Destination <i>r15</i> .....	11-38
Table 11-5.	Worst-Case Interrupt Latency Controlled by <i>divo</i> to Destination <i>r3</i> .....	11-39
Table 11-6.	Worst-Case Interrupt Latency Controlled by calls.....	11-39
Table 11-7.	Worst-Case Interrupt Latency When Delivering a Software Interrupt.....	11-40
Table 11-8.	Worst-Case Interrupt Latency Controlled by <i>flushreg</i> of One Stack Frame.....	11-41
Table 12-1.	Reset States .....	12-5
Table 12-2.	Register Values After Reset .....	12-5
Table 12-3.	Fail Codes For BIST (bit 7 = 1) .....	12-9
Table 12-4.	Remaining Fail Codes (bit 7 = 0) .....	12-9
Table 12-5.	Initialization Boot Record .....	12-13
Table 12-6.	PRCB Configuration .....	12-16
Table 12-7.	Input Pins.....	12-37
Table 13-1.	PMCON Address Mapping .....	13-4
Table 13-2.	DLMCON Values at Reset.....	13-13
Table 14-1.	Summary of i960 Jx Processor Bus Signals.....	14-5
Table 14-2.	8-Bit Bus Width Byte Enable Encodings.....	14-8
Table 14-3.	16-Bit Bus Width Byte Enable Encodings.....	14-8
Table 14-4.	32-Bit Bus Width Byte Enable Encodings.....	14-8
Table 14-5.	Natural Boundaries for Load and Store Accesses.....	14-23
Table 14-6.	Summary of Byte Load and Store Accesses .....	14-23



Table 14-7.	Summary of Short Word Load and Store Accesses .....	14-23
Table 14-8.	Summary of n-Word Load and Store Accesses (n = 1, 2, 3, 4) .....	14-24
Table 14-9.	Byte Ordering on Bus Transfers, Word Data Type .....	14-28
Table 14-10.	Byte Ordering on Bus Transfers, Short-Word Data Type .....	14-29
Table 14-11.	Byte Ordering on Bus Transfers, Byte Data Type .....	14-29
Table 15-1.	TAP Controller Pin Definitions .....	15-5
Table 15-2.	Boundary Scan Instruction Set .....	15-8
Table 15-3.	Boundary Scan Register Bit Order .....	15-14
Table B-1.	Miscellaneous Instruction Encoding Bits .....	B-1
Table B-2.	REG Format Instruction Encodings .....	B-2
Table B-3.	COBR Format Instruction Encodings .....	B-6
Table B-4.	CTRL Format Instruction Encodings .....	B-7
Table B-5.	Cycle Counts for sysctl Operations .....	B-7
Table B-6.	Cycle Counts for icctl Operations .....	B-8
Table B-7.	Cycle Counts for dcctl Operations .....	B-8
Table B-8.	Cycle Counts for intctl Operations .....	B-8
Table B-9.	MEM Format Instruction Encodings .....	B-9
Table B-10.	Addressing Mode Performance .....	B-10
Table C-1.	Instruction Field Descriptions .....	C-2
Table C-2.	Encoding of <i>src1</i> and <i>src2</i> in REG Format .....	C-3
Table C-3.	Encoding of <i>src/dst</i> in REG Format .....	C-3
Table C-4.	Encoding of <i>src1</i> in COBR Format .....	C-3
Table C-5.	Encoding of <i>src2</i> in COBR Format .....	C-4
Table C-6.	Addressing Modes for MEM Format Instructions.....	C-5
Table C-7.	Encoding of Scale Field .....	C-6
Table D-1.	Register and Data Structures .....	D-1









1

# INTRODUCTION





The i960<sup>®</sup> Jx microprocessor provides a new set of essential enhancements for an emerging class of high-performance embedded applications. Based on the i960 core architecture, it is implemented in a proven 0.6 micron, three-layer metal process. Figure 1-1 identifies the processor's most notable features, each of which is described in subsections that follow the figure. These features include:

- instruction cache
- on-chip data RAM
- timer units
- data cache
- local register cache
- memory-mapped control registers
- bus controller unit
- interrupt controller
- external bus




Figure 1-1. i960<sup>®</sup> Jx Microprocessor Functional Block Diagram

## INTRODUCTION

### 1.1 PRODUCT FEATURES

The i960 Jx processor brings many enhancements to the i960 microprocessor family, including:

- Improvements to the core architecture
- Low power mode
- New instructions
- Improved cache design
- Enhanced bus control unit
- Improved interrupt performance
- JTAG testability

#### 1.1.1 Instruction Cache

The i960 JT processor features a 16 Kbyte two-way set-associative instruction cache. The i960 JF and JD processors employ a 4-Kbyte, two-way set-associative instruction cache. i960 JA processors feature a 2-Kbyte instruction cache. A mechanism is provided that allows software to lock critical code within each “way” of the cache. The cache can be disabled and is managed by use of the **icctl** and **sysctl** instructions, as described in [section 4.4, “INSTRUCTION CACHE”](#) (pg. 4-4).

#### 1.1.2 Data Cache

The i960 JT processor features a 4 Kbyte direct-mapped data cache. The i960 JF and JD processors feature a 2-Kbyte, direct-mapped data cache that is write-through and write-allocate. i960 JA processors feature a 1-Kbyte direct-mapped data cache. These processors have a line size of four words and implement a “natural” fill policy. Each line in the cache has a valid bit; to reduce fetch latency on cache misses, each word within a line also has a valid bit. See [section 4.5, “DATA CACHE”](#) (pg. 4-6) for details.

The data cache is managed through the **dcctl** instruction; see [section 6.2.23, “dcctl”](#) (pg. 6-40).

#### 1.1.3 On-chip (Internal) Data RAM

The processor’s 1 Kbyte internal data RAM is accessible to software with an access time of 1 cycle per word. This RAM is mapped to the physical address range of 0 to 3FFH. The first 64 bytes are reserved for the caching of dedicated-mode interrupt vectors; this reduces interrupt latency for these interrupts. In addition, write-protection for the first 64 bytes is provided to guard against the effects of using null pointers in ‘C’ and to protect the cached interrupt vectors.



The i960 processor compilers can take advantage of the internal data RAM; profiling compilers can allocate the most frequently used variables into this RAM. See [Section 4.1, INTERNAL DATA RAM \(pg. 4-1\)](#) for more detail.

#### 1.1.4 Local Register Cache

The processor provides fast storage of local registers for call and return operations by using an internal local register cache. This cache can store up to seven local register sets; additional register sets must be saved in external memory.

The processor uses a 128-bit wide bus to store local register sets quickly to the register cache. To reduce interrupt latency for high-priority interrupts, the number of sets that can be used by code that is running at a lower priority or that is not interrupted can be restricted by programming the register configuration word in the PRCB. This ensures that there are always sets available for high-priority interrupt code without needing to save sets in external memory first. See [Section 4.2, LOCAL REGISTER CACHE \(pg. 4-2\)](#) for more details.

#### 1.1.5 Interrupt Controller

The interrupt controller unit (ICU) provides a flexible, low-latency means for requesting interrupts. It handles the posting of interrupts requested by hardware and software sources. Acting independently from the core, the interrupt controller compares the priorities of posted interrupts with the current process priority, off-loading this task from the core. The interrupt controller is compatible with i960 CA/CF processors.

The interrupt controller provides the following features for handling hardware-requested interrupts:

- Support of up to 240 external sources.
- Eight external interrupt pins, one non-maskable interrupt ( $\overline{\text{NMI}}$ ) pin for detection of hardware-requested interrupts and two internal timer sources.
- Edge or level detection on external interrupt pins.
- Debounce option on external interrupt pins.

The application program interfaces to the interrupt controller with six memory-mapped control registers. The interrupt control register (ICON) and interrupt map control registers (IMAP0-IMAP2) provide configuration information. The interrupt pending (IPND) register posts hardware-requested interrupts. The interrupt mask (IMSK) register selectively masks hardware-requested interrupts.

The interrupt inputs can be configured to be triggered on level-low or falling-edge signals. Sampling of the input pins can be either debounced sampling or fast sampling.

## INTRODUCTION

The i960 Jx processor has approximately 5 to 10 times faster interrupt servicing than the i960 Kx processor. This is accomplished through a number of features:

- a hardware priority resolver removes the need to access the external interrupt table to resolve interrupts
- caching of dedicated-mode interrupt vectors in the internal data RAM
- reserving frames in the local register cache for high-priority interrupts
- the ability to lock the code of interrupt service routines in the instruction-cache reduces the fetch latency for starting up these routines

[CHAPTER 11, INTERRUPTS](#) discusses this in more detail.

### 1.1.6 Timer Support

The i960 Jx processor provides two identical 32-bit timers. Access to the timers is through memory-mapped registers. The timers have a single-shot mode and auto-reload capabilities for continuous operation. Each timer has an independent interrupt request to the i960 Jx processor interrupt controller. See [CHAPTER 10, TIMERS](#) for a complete description.

### 1.1.7 Memory-Mapped Control Registers (MMR)

Control registers in the i960 Jx processor are memory-mapped to allow for visibility to application software. This includes registers for memory configuration, internally cached PRCB data, breakpoint registers, and interrupt control. These registers are mapped to the architecturally reserved address space range of FF00 0000H to FFFF FFFFH. The processor ensures that accesses to the MMRs generate no external bus cycles.

[Section 3.3, MEMORY-MAPPED CONTROL REGISTERS \(pg. 3-6\)](#) discusses this in more detail.

### 1.1.8 External Bus

The 32-bit multiplexed external bus connects the i960 Jx processor to memory and I/O. This high bandwidth bus provides burst transfer capability allowing up to four successive 32-bit data word transfers at a maximum rate of one word every clock cycle. In addition to the bus signals, the i960 Jx processor provides signals to allow external bus masters. Lastly, the processor provides variable bus-width support (8-, 16-, and 32-bit).



### 1.1.9 Complete Fault Handling and Debug Capabilities

To aid in program development, the i960 Jx processor detects faults (exceptions). When a fault is detected, the processors make an implicit call to a fault handling routine. Information collected for each fault allows a program developer to quickly correct faulting code. The processors also allow automatic recovery from most faults.

To support system debug, the i960 architecture provides a mechanism for monitoring processor activities through a software tracing facility. This processor can be configured to detect as many as seven different trace events, including breakpoints, branches, calls, supervisor calls, returns, prereturns and the execution of each instruction (for single-stepping through a program). The processors also provide four breakpoint registers that allow break decisions to be made based upon instruction or data addresses.

## 1.2 ABOUT THIS MANUAL

This *i960® Jx Microprocessor User's Manual* provides detailed programming and hardware design information for the i960 Jx microprocessors. It is written for programmers and hardware designers who understand the basic operating principles of microprocessors and their systems.

This manual does not provide electrical specifications such as DC and AC parametrics, operating conditions and packaging specifications. Such information is found in the product's data sheets:

- *80960JA/JF Embedded 32-bit Microprocessor Data Sheet (272504)*
- *80960JD Embedded 32-bit Microprocessor Data Sheet (272596)*
- *80L960JA/JF 3.3 V Embedded 32-bit Microprocessor Data Sheet (272744)*
- *80960JA/JF 3.3 V Embedded 32-bit Microprocessor Data Sheet (273146)*
- *80960JD 3.3 V Embedded 32-bit Microprocessor Data Sheet (272971)*
- *80960JT 3.3 V Embedded 32-bit Microprocessor Data Sheet (273109)*

Each document has a corresponding Specification Update document. These contain the latest technical information about the product and documentation, and are available from Intel's website. For information on other i960 processor family products or the architecture in general, refer to Intel's *Solutions960® Development Tools Catalog (270791)*. It lists all current i960 microprocessor family-related documents, support components, boards, software development tools, debug tools and more.

This manual is organized in three parts; each part comprises multiple chapters and/or appendices. The following briefly describes each part:

- *Part I - Programming the i960 Jx Microprocessor* (chapters 2-10) details the programming environment for the i960 Jx devices. Described here are the processor's registers, instruction set, data types, addressing modes, interrupt mechanism, external interrupt interface and fault mechanism.

## INTRODUCTION

- *Part II - System Implementation* (chapters 11-17) identifies requirements for designing a system around the i960 Jx components, such as external bus interface and interrupt controller. Also described are programming requirements for the bus controller and processor initialization.
- *Part III - Appendices* includes quick references for hardware design and programming. Appendices are also provided which describe the internal architecture, how to write assembly-level code to exploit the parallelism of the processor and considerations for writing software that is portable among all members of the i960 microprocessor family.

### 1.3 NOTATION AND TERMINOLOGY

This section defines terminology and textual conventions that are used throughout the manual.

#### 1.3.1 Reserved and Preserved

Certain fields in registers and data structures are described as being either *reserved* or *preserved*:

- A reserved field is one that may be used by other i960 architecture implementations. Correct treatment of reserved fields ensures software compatibility with other i960 processors. The processor uses these fields for temporary storage; as a result, the fields sometimes contain unusual values.
- A preserved field is one that the processor does not use. Software may use preserved fields for any function.

Reserved fields in certain data structures should be cleared (set to zero) when the data structure is created. Clear the reserved fields when creating the Interrupt Table, Fault Table and System Procedure Table. Software should not modify or rely on these reserved field values after a data structure is created. When the processor creates the Interrupt or Fault Record data structure on the stack, software should not depend on the value of the reserved fields within these data structures.

Some bits or fields in data structures and registers are shown as requiring specific encoding. These fields should be treated as if they were reserved fields. They should be set to the specified value when the data structure is created or when the register is initialized and software should not modify or rely on the value after that.

Reserved bits in the Arithmetic Controls (AC) register can be cleared after initialization to ensure compatibility with other i960 processor implementations. Reserved bits in the Process Controls (PC) register and Trace Controls (TC) register should not be initialized. When the AC, PC and TC registers are modified using **modac**, **modpc** or **modtc** instructions, the reserved locations in these registers must be masked.





Certain areas of memory may be referred to as *reserved memory* in this reference manual. Reserved — when referring to memory locations — implies that an implementation of the i960 architecture may use this memory for some special purpose. For example, memory-mapped peripherals might be located in reserved memory areas on future implementations.

### 1.3.2 Specifying Bit and Signal Values

The terms *set* and *clear* in this manual refer to bit values in register and data structures. When a bit is set, its value is 1; when the bit is clear, its value is 0. Likewise, setting a bit means giving it a value of 1 and clearing a bit means giving it a value of 0.

The terms *assert* and *deassert* refer to the logically active or inactive value of a signal or bit, respectively. A signal is specified as an active 0 signal by an overbar. For example, the input is active low and is asserted by driving the signal to a logic 0 value.

### 1.3.3 Representing Numbers

All numbers in this manual can be assumed to be base 10 unless designated otherwise. In text, binary numbers are sometimes designated with a subscript 2 (for example,  $001_2$ ). When it is obvious from the context that a number is a binary number, the “2” subscript may be omitted.

Hexadecimal numbers are designated in text with the suffix H (for example, FFFF FF5AH). In pseudo-code action statements in the instruction reference section and occasionally in text, hexadecimal numbers are represented by adding the C-language convention “0x” as a prefix. For example “FF7AH” appears as “0xFF7A” in the pseudo-code.

### 1.3.4 Register Names

Memory-mapped registers and several of the global and local registers are referred to by their generic register names, as well as descriptive names which describe their function. The global register numbers are g0 through g15; local register numbers are r0 through r15. However, when programming the registers in user-generated code, make sure to use the *instruction operand*. i960 microprocessor compilers recognize only the instruction operands listed in [Table 1-1](#). Throughout this manual, the registers’ descriptive names, numbers, operands and acronyms are used interchangeably, as dictated by context.

Groups of bits and single bits in registers and control words are called either *bits*, *flags* or *fields*. These terms have a distinct meaning in this manual:

bit	Controls a processor function; programmed by the user.
flag	Indicates status. Generally set by the processor; certain flags are user programmable.
field	A grouping of bits (bit field) or flags (flag field).

Table 1-1. Register Terminology Conventions

Register Descriptive Name	Register Number	Instruction Operand	Acronym
Global Registers	g0 - g15	g0 - g14	
<i>Frame Pointer</i>	g15	fp	FP
Local Registers	r0 - r15	r3 - r15	
<i>Previous Frame Pointer</i>	r0	pfp	PFP
<i>Stack Pointer</i>	r1	sp	SP
<i>Return Instruction Pointer</i>	r2	rip	RIP

Specific bits, flags and fields in registers and control words are usually referred to by a register abbreviation (in upper case) followed by a bit, flag or field name (in lower case). These items are separated with a period. A position number designates individual bits in a field. For example, the return type (rt) field in the previous frame pointer (PFP) register is designated as “PFP.rt”. The least significant bit of the return type field is then designated as “PFP.rt0”.

## 1.4 RELATED DOCUMENTS

The following documents are useful when designing with and programming the i960 microprocessor. Check the Intel website or contact your local sales representative for more information on obtaining Intel documents, including Specification Updates.

- *80960JA/JF Embedded 32-bit Microprocessor Data Sheet (272504)*
- *80960JD Embedded 32-bit Microprocessor Data Sheet (272596)*
- *80L960JA/JF 3.3 V Embedded 32-bit Microprocessor Data Sheet (272744)*
- *80960JA/JF 3.3 V Embedded 32-bit Microprocessor Data Sheet (273146)*
- *80960JD 3.3 V Embedded 32-bit Microprocessor Data Sheet (272971)*
- *80960JT 3.3 V Embedded 32-bit Microprocessor Data Sheet (273109)*
- *Solutions960® Development Tools Catalog (270791)*





# 2

## DATA TYPES AND MEMORY ADDRESSING MODES






# CHAPTER 2 DATA TYPES AND MEMORY ADDRESSING MODES

## 2.1 DATA TYPES

The instruction set references or produces several data lengths and formats. The i960<sup>®</sup> Jx processor supports the following data types:

- Integer (signed 8, 16 and 32 bits)
- Long-Word (64 bits)
- Quad-Word (128 bits)
- Bit
- Ordinal (unsigned integer 8, 16, 32 and 64 bits)
- Triple-Word (96 bits)
- Bit Field

Figure 2-1 illustrates the class, data type and length of each type supported by i960 processors.



**Figure 2-1. Data Types and Ranges**





**2.1.1 Integers**

Integers are signed whole numbers that are stored and operated on in two’s complement format by the integer instructions. Most integer instructions operate on 32-bit integers. Byte and short integers are referenced by the byte and short classes of the load, store and compare instructions only.

Integer load or store size (byte, short or word) determines how sign extension or data truncation is performed when data is moved between registers and memory.

For instructions **ldib** (load integer byte) and **ldis** (load integer short), a byte or short word in memory is considered a two’s complement value. The value is sign-extended and placed in the 32-bit register that is the destination for the load.

<p><b>ldib</b></p> <p>7AH is loaded into a register as 0000 007AH</p> <p>FAH is loaded into a register as FFFF FFFAH</p> <p><b>ldis</b></p> <p>05A5H is loaded into a register as 0000 05A5H</p> <p>85A5H is loaded into a register as FFFF 85A5H</p>
---

**Example 2-1. Sign Extensions on Load Byte and Load Short**

For instructions **stib** (store integer byte) and **stis** (store integer short), a 32-bit two’s complement number in a register is stored to memory as a byte or short word. When register data is too large to be stored as a byte or short word, the value is truncated and the integer overflow condition is signalled. When an overflow occurs, either an AC register flag is set or the ARITHMETIC.INTEGER\_OVERFLOW fault is generated, depending on the Integer Overflow Mask bit (AC.om) in the AC register. [CHAPTER 8, FAULTS](#) describes the integer overflow fault.

For instructions **ld** (load word) and **st** (store word), data is moved directly between memory and a register with no sign extension or data truncation.

**2.1.2 Ordinals**

Ordinals or unsigned integer data types are stored and treated as positive binary values. [Figure 2-1](#) shows the supported ordinal sizes.

The large number of instructions that perform logical, bit manipulation and unsigned arithmetic operations reference 32-bit ordinal operands. When ordinals are used to represent Boolean values, 1 = TRUE and 0 = FALSE. Most extended arithmetic instructions reference the long ordinal data type. Only load (**ldob** and **ldos**), store (**stob** and **stos**), and compare ordinal instructions reference the byte and short ordinal data types.



Sign and sign extension are not considered when ordinal loads and stores are performed; the values may, however, be zero-extended or truncated. A short word or byte load to a register causes the value loaded to be zero-extended to 32 bits. A short word or byte store to memory truncates an ordinal value in a register to fit the size of the destination memory. No overflow condition is signalled in this case.

### 2.1.3 Bits and Bit Fields

The processor provides several instructions that perform operations on individual bits or bit fields within register operands. An individual bit is specified for a bit operation by giving its bit number and register. Internal registers always follow little endian byte order; the least significant bit corresponds to bit 0 and the most significant bit corresponds to bit 31.

A bit field is any contiguous group of bits (up to 32 bits long) in a 32-bit register. Bit fields do not span register boundaries. A bit field is defined by giving its length in bits (1-32) and the bit number of its lowest numbered bit (0-31).

Loading and storing bit and bit-field data is normally performed using the ordinal load (**ldo**) and store (**sto**) instructions. When an **ldi** instruction loads a bit or bit field value into a 32-bit register, the processor appends sign extension bits. A byte or short store can signal an integer overflow condition.

### 2.1.4 Triple- and Quad-Words

Triple- and quad-words refer to consecutive words in memory or in registers. Triple- and quad-word load, store and move instructions use these data types to accomplish block movements. No data manipulation (sign extension, zero extension or truncation) is performed in these instructions.

Triple- and quad-word data types can be considered a superset of the other data types described. The data in each word subset of a quad-word is likely to be the operand or result of an ordinal, integer, bit or bit field instruction.

### 2.1.5 Register Data Alignment

Several of the processor's instructions operate on multiple-word operands. For example, the load-long instruction (**ldl**) loads two words from memory into two consecutive registers. The least significant data word is loaded into the lower order register. The most significant data word is loaded into the higher order register.

## DATA TYPES AND MEMORY ADDRESSING MODES

In cases where an instruction specifies a register number (and multiple, consecutive registers are implied), the register number must be even when two registers are accessed (e.g., g0, g2) and an integral multiple of four when three or four registers are accessed (e.g., g0, g4). When a register reference for a source value is not properly aligned, the registers that the processor writes to are undefined.

The i960 Jx processor does not require data alignment in external memory; the processor hardware handles unaligned memory accesses automatically. Optionally, user software can configure the processor to generate a fault on unaligned memory accesses.

### 2.1.6 Literals

The architecture defines a set of 32 literals that can be used as operands in many instructions. These literals are ordinal (unsigned) values that range from 0 to 31 (5 bits). When a literal is used as an operand, the processor expands it to 32 bits by adding leading zeros. When the instruction requires an operand larger than 32 bits, the processor zero-extends the value to the operand size. When a literal is used in an instruction that requires integer operands, the processor treats the literal as a positive integer value.

## 2.2 BIT AND BYTE ORDERING IN MEMORY

All occurrences of numeric and non-numeric data types, except bits and bit fields, must start on a byte boundary. Any data item occupying multiple bytes is stored as big endian or little endian. The following sections further describe byte ordering.

### 2.2.1 Bit Ordering

Bits within bytes are numbered such that when the byte is viewed as a value, bit 0 is the least significant bit and bit 7 is the most significant bit. For numeric values spanning several bytes, bit numbers higher than 7 indicate successively higher bit numbers in bytes with higher addresses. Unless otherwise noted, bits in illustrations in this manual are ordered such that the higher-numbered bits are to the left.

### 2.2.2 Byte Ordering

The i960 Jx processor can be programmed to use little or big endian byte ordering for memory accesses. Byte ordering refers to how data items larger than one byte are assembled:


- For little endian byte order, the byte with the lowest address in a multi-byte data item has the *least* significance.
- For big endian byte order, the byte with the lowest address in a multi-byte data item has the *most* significance.





For example, [Table 2-1](#) shows eight bytes of data in memory. [Table 2-2](#) shows the differences between little and big endian accesses for byte, short, word and long-word data. [Figure 2-2](#) shows the resultant data placement in registers.

Once data is read into registers, byte order is no longer relevant. The lowest significant bit is always bit 0. The most significant bit is always bit 31 for words, bit 15 for short words, and bit 7 for bytes.



Byte ordering affects the way the i960 Jx processor handles bus accesses. See [section 13.6.2, “Selecting the Byte Order”](#) (pg. 13-12) for more information.

**Table 2-1. Memory Contents for Little and Big Endian Example**

ADDRESS	DATA
1000H	12H
1001H	34H
1002H	56H
1003H	78H
1004H	9AH
1005H	BCH
1006H	DEH
1007H	FOH

**Table 2-2. Byte Ordering for Little and Big Endian Accesses**

Access	Example	Register Contents (Little Endian)	Register Contents (Big Endian)
Byte at 1000H	ldob 0x1000, r3	12H	12H
Short at 1002H	ldos 0x1002, r3	7856H	5678H
Word at 1000H	ld 0x1000, r3	78563412H	12345678H
Long-Word at 1000H	ldl 0x1000, r4	78563412H (r4) F0DEBC9AH (r5)	12345678H (r4) 9ABCDEF0H (r5)






Figure 2-2. Data Placement in Registers

2.3 MEMORY ADDRESSING MODES

The processor provides nine modes for addressing operands in memory. Each addressing mode is used to reference a byte location in the processor's address space. Table 2-3 shows the memory addressing modes and a brief description of each mode's address elements and assembly code syntax.

Table 2-3. Memory Addressing Modes

Mode	Description	Assembler Syntax	Inst. Type
Absolute <i>offset</i>	offset (smaller than 4096)	exp	MEMA
<i>displacement</i>	displacement (larger than 4095)	exp	MEMB
Register Indirect	abase	(reg)	MEMB
<i>with offset</i>	abase + offset	exp (reg)	MEMA
<i>with displacement</i>	abase + displacement	exp (reg)	MEMB
<i>with index</i>	abase + (index*scale)	(reg) [reg*scale]	MEMB
<i>with index and displacement</i>	abase + (index*scale) + displacement	exp (reg) [reg*scale]	MEMB
Index with displacement	(index*scale) + displacement	exp [reg*scale]	MEMB
instruction pointer (IP) with displacement	IP + displacement + 8	exp (IP)	MEMB

**NOTE:** *reg* is register, *exp* is an expression or symbolic label, and IP is the Instruction Pointer.



See [Table B-9](#) in [APPENDIX B](#) for more on addressing modes. For purposes of this memory addressing modes description, MEMA format instructions require one word of memory and MEMB usually require two words and therefore consume twice the bus bandwidth to read. Otherwise, both formats perform the same functions.

### 2.3.1 Absolute

Absolute addressing modes allow a memory location to be referenced directly as an offset from address 0H. At the instruction encoding level, two absolute addressing modes are provided: absolute offset and absolute displacement, depending on offset size.

- For the absolute offset addressing mode, the offset is an ordinal number ranging from 0 to 4095. The absolute offset addressing mode is encoded in the MEMA machine instruction format.
- For the absolute displacement addressing mode, the offset value ranges from 0 to  $2^{32}-1$ . The absolute displacement addressing mode is encoded in the MEMB format.

Addressing modes and encoding instruction formats are described in [CHAPTER 6, INSTRUCTION SET REFERENCE](#).

At the assembly language level, the two absolute addressing modes use the same syntax. Typically, development tools allow absolute addresses to be specified through arithmetic expressions (e.g.,  $x + 44$ ) or symbolic labels. After evaluating an address specified with the absolute addressing mode, the assembler converts the address into an offset or displacement and selects the appropriate instruction encoding format and addressing mode.

### 2.3.2 Register Indirect

Register indirect addressing modes use a register's 32-bit value as a base for address calculation. The register value is referred to as the address base (designated "abase" in [Table 2-3](#)). Depending on the addressing mode, an optional scaled index and offset can be added to this address base.

Register indirect addressing modes are useful for addressing elements of an array or record structure. When addressing array elements, the abase value provides the address of the first array element. An offset (or displacement) selects a particular array element.

In register-indirect-with-index addressing mode, the index is specified using a value contained in a register. This index value is multiplied by a scale factor. Allowable factors are 1, 2, 4, 8 and 16. The register-indirect-with-index addressing mode is encoded in the MEMB format.

The two versions of register-indirect-with-offset addressing mode at the instruction encoding level are register-indirect-with-offset and register-indirect-with-displacement. As with absolute addressing modes, the mode selected depends on the size of the offset from the base address.

At the assembly language level, the assembler allows the offset to be specified with an expression or symbolic label, then evaluates the address to determine whether to use register-indirect-with-offset (MEMA format) or register-indirect-with-displacement (MEMB format) addressing mode.

Register-indirect-with-index-and-displacement addressing mode adds both a scaled index and a displacement to the address base. There is only one version of this addressing mode at the instruction encoding level, and it is encoded in the MEMB instruction format.

### 2.3.3 Index with Displacement

A scaled index can also be used with a displacement alone. The index is contained in a register and multiplied by a scaling constant before displacement is added. This mode uses MEMB format.

### 2.3.4 IP with Displacement

This addressing mode is used with load and store instructions to make them instruction pointer (IP) relative. IP-with-displacement addressing mode references the next instruction's address plus the displacement. This mode uses MEMB format.

### 2.3.5 Addressing Mode Examples

The following examples show how i960 processor addressing modes are encoded in assembly language. [Example 2-2](#) shows addressing mode mnemonics. [Example 2-3](#) illustrates the usefulness of scaled index and scaled index plus displacement addressing modes. In this example, a procedure named `array_op` uses these addressing modes to fill two contiguous memory blocks separated by a constant offset. A pointer to the top of the block is passed to the procedure in `g0`, the block size is passed in `g1` and the fill data in `g2`.

For more details on encoding formats, refer to [APPENDIX C, MACHINE-LEVEL INSTRUCTION FORMATS](#).



```

st    g4,xyz          # Absolute; word from g4 stored at memory
                        # location designated with label xyz.
ldob  (r3),r4        # Register indirect; ordinal byte from
                        # memory location given in r3 loaded
                        # into register r4 and zero extended.
stl   g6,xyz(g5)     # Register indirect with displacement;
                        # double word from g6,g7 stored at memory
                        # location xyz + g5.
ldq   (r8)[r9*4],r4  # Register indirect with index; quad-word
                        # beginning at memory location r8 + (r9
                        # scaled by 4) loaded into r4 through r7.
st    g3,xyz(g4)[g5*2] # Register indirect with index and
                        # displacement; word in g3 stored to mem
                        # location g4 + xyz + (g5 scaled by 2).
ldis  xyz[r12*2],r13 # Index with displacement; load short
                        # integer at memory location xyz + r12
                        # into r13 and sign extended.
st    r4,xyz(ip)     # ip with displacement; store word in r4
                        # at memory location IP + xyz + 8.

```

### Example 2-2. Addressing Mode Mnemonics

```

array_op:
  mov    g0,r4        # Pointer to array is copied to r4.
  subi   1,g1,r3      # Calculate index for the last array
  b      .I33         # element to be filled
.I34:
  st     g2,(r4)[r3*4] # Fill element at index
  st     g2,0x30(r4)[r3*4] # Fill element at index+constant offset
  subi   1,r3,r3      # Decrement index
.I33:
  cmpible 0,r3,.I34   # Store next array elements if
  ret                                # index is not 0

```

### Example 2-3. Scaled Index and Scaled Index Plus Displacement Addressing Modes





3

# PROGRAMMING ENVIRONMENT







## CHAPTER 3 PROGRAMMING ENVIRONMENT

This chapter describes the i960® Jx processor's programming environment including global and local registers, control registers, literals, processor-state registers and address space.

### 3.1 OVERVIEW

The i960 architecture defines a programming environment for program execution, data storage and data manipulation. [Figure 3-1](#) shows the programming environment elements that include the following:

- 4 Gbyte ( $2^{32}$  byte) flat address space
- instruction cache
- data cache
- global and local general-purpose registers
- register cache
- set of literals
- control registers
- set of processor state registers

The processor includes several architecturally-defined data structures located in memory as part of the programming environment. These data structures handle procedure calls, interrupts and faults and provide configuration information at initialization. These data structures are:

- interrupt stack
- local stack
- supervisor stack
- control table
- fault table
- interrupt table
- system procedure table
- process control block
- initialization boot record

### 3.2 REGISTERS AND LITERALS AS INSTRUCTION OPERANDS

With the exception of a few special instructions, the i960 Jx processor uses load and store instructions to access memory. All operations take place at the register level. The processor uses 16 global registers, 16 local registers and 32 literals (constants 0-31) as instruction operands.

The global register numbers are g0 through g15; local register numbers are r0 through r15. Several of these registers are used for dedicated functions. For example, register r0 is the previous frame pointer, often referred to as *ppp*. The i960 processor compilers and assemblers recognize only the instruction operands listed in [Table 3-1](#). Throughout this manual, the registers' descriptive names, numbers, operands and acronyms are used interchangeably, as dictated by context.




Figure 3-1. i960<sup>®</sup> Jx Processor Programming Environment Elements

### 3.2.1 Global Registers

Global registers are general-purpose 32-bit data registers that provide temporary storage for a program’s computational operands. These registers retain their contents across procedure boundaries. They provide a fast and efficient means of passing parameters between procedures.



**Table 3-1. Registers and Literals Used as Instruction Operands**

Instruction Operand	Register Name (number)	Function	Acronym
g0 - g14	global (g0-g14)	general purpose	
fp	global (g15)	frame pointer	FP
pfp	local (r0)	previous frame pointer	PFP
sp	local (r1)	stack pointer	SP
rip	local (r2)	return instruction pointer	RIP
r3 - r15	local (r3-r15)	general purpose	
0-31		literals	

3

The i960 architecture supplies 16 global registers, designated g0 through g15. Register g15 is reserved for the current Frame Pointer (FP), which contains the address of the first byte in the current (topmost) stack frame in memory. See [CHAPTER 7, PROCEDURE CALLS](#) for a description of the FP and procedure stack.

After the processor is reset, register g0 contains device identification and stepping information (DeviceID). Refer to [Section 1.4, "Related Documents"](#) (pg. 1-10). Further information on Device IDs can be found in these documents. The information is retained in g0 until it is written over by the user program. The device identification and stepping information is also stored in the memory-mapped DEVICEID register located at FF00 8710H.

### 3.2.2 Local Registers

The i960 architecture provides a separate set of 32-bit local data registers (r0 through r15) for each active procedure. These registers provide storage for variables that are local to a procedure. Each time a procedure is called, the processor allocates a new set of local registers and saves the calling procedure's local registers. When the application returns from the procedure, the local registers are released for the next procedure call. The processor performs local register management; a program need not explicitly save and restore these registers.

Local registers r3 through r15 are general purpose registers; r0 through r2 are reserved for special functions; r0 contains the Previous Frame Pointer (PFP); r1 contains the Stack Pointer (SP); r2 contains the Return Instruction Pointer (RIP). These are discussed in [CHAPTER 7, PROCEDURE CALLS](#).

The processor does not always clear or initialize the set of local registers assigned to a new procedure. Also, the processor does not initialize the local register save area in the newly created stack frame for the procedure. User software should not rely on the initial values of local registers.



### 3.2.3 Register Scoreboarding

Register scoreboarding maintains register coherency by preventing parallel execution units from accessing registers for which there is an outstanding operation. When an instruction that targets a destination register or group of registers executes, the processor sets a register-scoreboard bit to indicate that this register or group of registers is being used in an operation. When the instructions that follow do not require data from registers already in use, the processor can execute those instructions before the prior instruction completes execution.

Software can use this feature to execute one or more single-cycle instructions concurrently with a multi-cycle instruction (e.g., multiply or divide). [Example 3-1](#) shows a case where register scoreboarding prevents a subsequent instruction from executing. It also illustrates overlapping instructions that do not have register dependencies.

#### Example 3-1. Register Scoreboarding

```
muli r4,r5,r6    # r6 is scoreboarded
addi r6,r7,r8    # addi must wait for the previous multiply
                 # to complete
.
.
.
muli r4,r5,r10   # r10 is scoreboarded
and r6,r7,r8     # and instruction is executed concurrently with multiply
```

### 3.2.4 Literals

The architecture defines a set of 32 literals that can be used as operands in many instructions. These literals are ordinal (unsigned) values that range from 0 to 31 (5 bits). When a literal is used as an operand, the processor expands it to 32 bits by adding leading zeros. When the instruction requires an operand larger than 32 bits, the processor zero-extends the value to the operand size. When a literal is used in an instruction that requires integer operands, the processor treats the literal as a positive integer value.

### 3.2.5 Register and Literal Addressing and Alignment

Several instructions operate on multiple-word operands. For example, the load long instruction (**ldl**) loads two words from memory into two consecutive registers. The register for the less significant word is specified in the instruction. The more significant word is automatically loaded into the next higher-numbered register.



In cases where an instruction specifies a register number and multiple consecutive registers are implied, the register number must be even when two registers are accessed (e.g., g0, g2) and an integral multiple of 4, when 3 or 4 registers are accessed (e.g., g0, g4). When a register reference for a source value is not properly aligned, the source value is undefined and an OPERATION.INVALID\_OPERAND fault is generated. When a register reference for a destination value is not properly aligned, the registers to which the processor writes and the values written are undefined. The processor then generates an OPERATION.INVALID\_OPERAND fault. The assembly language code in [Example 3-2](#) shows an example of correct and incorrect register alignment.

**Example 3-2. Register Alignment**

```

movl g3,g8          # Incorrect alignment - resulting value
.                  # in registers g8 and g9 is
.                  # unpredictable (non-aligned source)
.
movl g4,g8          # Correct alignment
    
```

Global registers, local registers and literals are used directly as instruction operands. [Table 3-2](#) lists instruction operands for each machine-level instruction format and the positions that can be filled by each register or literal.

**Table 3-2. Allowable Register Operands**

Instruction Encoding	Operand Field	Operand (1)		
		Local Register	Global Register	Literal
REG	<i>src1</i>	X	X	X
	<i>src2</i>	X	X	X
	<i>src/dst (as src)</i>	X	X	
	<i>src/dst (as dst)</i>	X	X	
	<i>src/dst (as both)</i>	X	X	
MEM	<i>src/dst</i>	X	X	
	<i>abase</i>	X	X	
	<i>index</i>	X	X	
COBR	<i>src1</i>	X	X	X
	<i>src2</i>	X	X	
	<i>dst</i>	X (2)	X (2)	

**NOTES:**

1. "X" denotes the register can be used as an operand in a particular instruction field.
2. The **COBR** destination operands apply only to **TEST** instructions.



### 3.3 MEMORY-MAPPED CONTROL REGISTERS

The i960 Jx processor gives software the interface to easily read and modify internal control registers. Each of these registers is accessed as a 32-bit memory-mapped register (MMR) with a unique memory address. The processor ensures that accesses to MMRs do not generate external bus cycles.

#### 3.3.1 Memory-Mapped Registers (MMR)

Portions of the i960 Jx processor address space (addresses FF00 0000H through FFFF FFFFH) are reserved for memory-mapped registers (see [section 12.3, “Architecturally Reserved Memory Space”](#) (pg. 12-9)). These memory-mapped registers (MMRs) are accessed through word-operand memory instructions (**ld** and **st** instructions) and some register class instructions (**atmod**, **atadd** and **sysctl**). Accesses to the MMRs do not generate external bus cycles. The latency in accessing each of these registers is one cycle for **ld** and **st** and multiple cycles for others.

Each register has an associated access mode (user and supervisor modes) and access type (read and write accesses). [Table 3-4](#) and [Table 3-5](#) show all the memory-mapped registers and the application modes of access.

The registers are partitioned into user and supervisor spaces based on their addresses. Addresses FF00 0000H through FF00 7FFFH are allocated to user space memory-mapped registers; addresses FF00 8000H to FFFF FFFFH are allocated to supervisor space registers.

##### 3.3.1.1 Restrictions on Instructions that Access Memory-Mapped Registers

The majority of memory-mapped registers can be accessed by both load (**ld**) and store (**st**) instructions. However some registers have restrictions on the types of access they allow. To ensure correct operation, the access type restrictions for each register should be followed. The access type columns of [Table 3-4](#) and [Table 3-5](#) indicate the allowed access types for each register.

Unless otherwise indicated by its access type, the modification of a memory-mapped register by a **st** instruction takes effect completely before the next instruction starts execution.

Some operations require an atomic-read-modify-write sequence to a register, most notably IPND and IMSK. The **atmod** and **atadd** instructions provide a special mechanism to quickly modify the IPND and IMSK registers in an atomic manner on the i960 Jx processor. Do not use these instruction on any other memory-mapped registers.

The **sysctl** instruction can also modify the contents of a memory-mapped register *atomically*; in addition, **sysctl** is the only method to read the breakpoint registers on the i960 Jx processor; the breakpoints cannot be read using a **ld** instruction.



At initialization, the control table automatically loads into the on-chip control registers. This action simplifies the user's start-up code by providing a transparent setup of the processor's peripherals. See [CHAPTER 12, INITIALIZATION AND SYSTEM REQUIREMENTS](#).

### 3.3.1.2 Access Faults

**3**

Memory-mapped registers are meant to be accessed only as aligned, word-size registers with adherence to the appropriate access mode. Accessing these registers in any other way results in faults or undefined operation. An access is performed using the following fault model:

1. The access must be a word-sized, word-aligned access; otherwise, the processor generates an OPERATION.UNIMPLEMENTED fault.
2. When the access is a store in user mode to an implemented supervisor location, a TYPE.MISMATCH fault occurs. It is unpredictable whether a store to an unimplemented supervisor location causes a fault.
3. When the access is neither of the above, the access is attempted. Note that an MMR may generate faults based on conditions specific to that MMR. (Example: trying to write the timer registers in user mode when they have been allocated to supervisor mode only.)
4. When a store access to an MMR faults, the processor ensures that the store does not take effect.
5. A load access of a reserved location returns an unpredictable value.
6. Avoid any store accesses to reserved locations. Such a store can result in undefined operation of the processor when the location is in supervisor space.

Instruction fetches from the memory-mapped register space are not allowed and result in an OPERATION.UNIMPLEMENTED fault.

Table 3-3. Access Types

Access Type	Description	
R	Read	Read ( <b>ld</b> instruction) accesses are allowed.
RO	Read Only	Only Read ( <b>ld</b> instruction) accesses are allowed. Write ( <b>st</b> instruction) accesses are ignored.
W	Write	Write ( <b>st</b> instruction) accesses allowed.
R/W	Read/Write	<b>ld</b> , <b>st</b> , and <b>sysctl</b> instructions are allowed access.
WwG	Write when Granted	Writing or Modifying (through a <b>st</b> or <b>sysctl</b> instruction) the register is only allowed when modification-rights to the register have been granted. An OPERATION.UNIMPLEMENTED fault occurs when an attempt is made to write the register before rights are granted. See <a href="#">section 9.2.7.2, “Hardware Breakpoints” (pg. 9-5)</a> for details about getting modification rights to breakpoint registers.
Sysctl-RwG	<b>sysctl</b> Read when Granted	The value of the register can only be read by executing a <b>sysctl</b> instruction issued with the modify memory-mapped register message type. Modification rights to the register must be granted first or an OPERATION.UNIMPLEMENTED fault occurs when the <b>sysctl</b> is executed. A <b>ld</b> instruction to the register returns unpredictable results.
AtMod	<b>atmod</b> update	Register can be updated quickly through the <b>atmod</b> instruction. The <b>atmod</b> ensures correct operation by performing the update of the register in an atomic manner which provides synchronization with previous and subsequent operations. This is a faster update mechanism than <b>sysctl</b> and is optimized for a few special registers.





Table 3-4. Supervisor Space Family Registers (Sheet 1 of 2)

Register Name	Memory-Mapped Address	Access Type
<i>Reserved</i>	FF00 8000H to FF00 80FFH	—
(DLMCON) Default Logical Memory Configuration Register	FF00 8100H	R/W
<i>Reserved</i>	FF00 8104H	—
(LMADR0) Logical Memory Address Register 0	FF00 8108H	R/W
(LMMR0) Logical Memory Mask Register 0	FF00 810CH	R/W
(LMADR1) Logical Memory Address Register 1	FF00 8110H	R/W
(LMMR1) Logical Memory Mask Register 1	FF00 8114H	R/W
<i>Reserved</i>	FF00 8118H to FF00 83FFH	—
(IPB0) Instruction Address Breakpoint Register 0	FF00 8400H	Sysctl- R/G/WwG
(IPB1) Instruction Address Breakpoint Register 1	FF00 8404H	Sysctl- R/G/WwG
<i>Reserved</i>	FF00 8408H to FF00 841FH	—
(DAB0) Data Address Breakpoint Register 0	FF00 8420H	R/W, WwG
(DAB1) Data Address Breakpoint Register 1	FF00 8424H	R/W, WwG
<i>Reserved</i>	FF00 8428H to FF00 843FH	—
(BPCON) Breakpoint Control Register	FF00 8440H	R/W, WwG
<i>Reserved</i>	FF00 8444H to FF00 84FFH	—
(IPND) Interrupt Pending Register	FF00 8500H	AtMod
(IMSK) Interrupt Mask Register	FF00 8504H	AtMod
<i>Reserved</i>	FF00 8508H to FF00 850FH	—
(ICON) Interrupt Control Word	FF00 8510H	R/W
<i>Reserved</i>	FF00 8514H to FF00 851FH	—
(IMAP0) Interrupt Map Register 0	FF00 8520H	R/W
(IMAP1) Interrupt Map Register 1	FF00 8524H	R/W
(IMAP2) Interrupt Map Register 2	FF00 8528H	R/W
<i>Reserved</i>	FF00 852CH to FF00 85FFH	—

3



Table 3-4. Supervisor Space Family Registers (Sheet 2 of 2)

Register Name	Memory-Mapped Address	Access Type
(PMCON0_1) Physical Memory Control Register 0	FF00 8600H	R/W
<i>Reserved</i>	FF00 8604H	—
(PMCON2_3) Physical Memory Control Register 1	FF00 8608H	R/W
<i>Reserved</i>	FF00 860CH	—
(PMCON4_5) Physical Memory Control Register 2	FF00 8610H	R/W
<i>Reserved</i>	FF00 8614H	—
(PMCON6_7) Physical Memory Control Register 3	FF00 8618H	R/W
<i>Reserved</i>	FF00 861CH	—
(PMCON8_9) Physical Memory Control Register 4	FF00 8620H	R/W
<i>Reserved</i>	FF00 8624H	—
(PMCON10_11) Physical Memory Control Register 5	FF00 8628H	R/W
<i>Reserved</i>	FF00 862CH	—
(PMCON12_13) Physical Memory Control Register 6	FF00 8630H	R/W
<i>Reserved</i>	FF00 8634H	—
(PMCON14_15) Physical Memory Control Register 7	FF00 8638H	R/W
<i>Reserved</i>	FF00 863CH to FF00 86F8H	—
(BCON) Bus Configuration Control Register	FF00 86FCH	R/W
(PRCB) Processor Control Block Pointer	FF00 8700H	RO
(ISP) Interrupt Stack Pointer	FF00 8704H	R/W
(SSP) Supervisor Stack Pointer	FF00 8708H	R/W
<i>Reserved</i>	FF00 870CH	—
(DEVICEID) i960 Jx processor Device ID	FF00 8710H	RO
<i>Reserved</i>	FF00 8714H to FFFF FFFFH	—



Table 3-5. User Space Family Registers and Tables

Register Name	Memory-Mapped Address	Access Type
<b>Timers</b>		
<i>Reserved</i>	FF00 0000H to FF00 02FFH	—
(TRR0) Timer Reload Register 0	FF00 0300H	R/W
(TCR0) Timer Count Register 0	FF00 0304H	R/W
(TMR0) Timer Mode Register 0	FF00 0308H	R/W
<i>Reserved</i>	FF00 030CH	—
(TRR1) Timer Reload Register 1	FF00 0310H	R/W
(TCR1) Timer Count Register 1	FF00 0314H	R/W
(TMR1) Timer Mode Register 1	FF00 0318H	R/W
<i>Reserved</i>	FF00 031CH to FF00 7FFFH	—

3

### 3.4 ARCHITECTURALLY DEFINED DATA STRUCTURES

The architecture defines a set of data structures including stacks, interfaces to system procedures, interrupt handling procedures and fault handling procedures. Table 3-6 defines the data structures and references other sections of this manual where detailed information can be found.

The i960 Jx processor defines two initialization data structures: the Initialization Boot Record (IBR) and the Process Control Block (PRCB). These structures provide initialization data and pointers to other data structures in memory. When the processor is initialized, these pointers are read from the initialization data structures and cached for internal use.

Pointers to the system procedure table, interrupt table, interrupt stack, fault table and control table are specified in the processor control block. Supervisor stack location is specified in the system procedure table. User stack location is specified in the user’s startup code. Of these structures, only the system procedure table, fault table, control table and initialization data structures may be in ROM; the interrupt table and stacks must be in RAM. The interrupt table must be located in RAM to allow posting of software interrupts.




Table 3-6. Data Structure Descriptions

Structure (see also)	Description
<b>User and Supervisor Stacks</b> section 7.6, "USER AND SUPERVISOR STACKS" (pg. 7-19)	The processor uses these stacks when executing application code.
<b>Interrupt Stack</b> section 11.5, "INTERRUPT STACK AND INTERRUPT RECORD" (pg. 11-7)	A separate interrupt stack is provided to ensure that interrupt handling does not interfere with application programs.
<b>System Procedure Table</b> section 3.8, "USER-SUPERVISOR PROTECTION MODEL" (pg. 3-23) section 7.5, "SYSTEM CALLS" (pg. 7-15)	Contains pointers to system procedures. Application code uses the system call instruction ( <b>calls</b> ) to access system procedures through this table. A system supervisor call switches execution mode from user mode to supervisor mode. When the processor switches modes, it also switches to the supervisor stack.
<b>Interrupt Table</b> section 11.4, "INTERRUPT TABLE" (pg. 11-4)	The interrupt table contains vectors (pointers) to interrupt handling procedures. When an interrupt is serviced, a particular interrupt table entry is specified.
<b>Fault Table</b> section 8.3, "FAULT TABLE" (pg. 8-4)	Contains pointers to fault handling procedures. When the processor detects a fault, it selects a particular entry in the fault table. The architecture does not require a separate fault handling stack. Instead, a fault handling procedure uses the supervisor stack, user stack or interrupt stack, depending on the processor execution mode in which the fault occurred and the type of call made to the fault handling procedure.
<b>Control Table</b> section 12.3.3, "Control Table" (pg. 12-20)	Contains on-chip control register values. Control table values are moved to on-chip registers at initialization or with <b>sysctl</b> .



### 3.5 MEMORY ADDRESS SPACE

The i960 Jx processor's address space is byte-addressable with addresses running contiguously from 0 to  $2^{32}-1$ . Some memory space is reserved or assigned special functions as shown in [Figure 3-2](#).



3

**Figure 3-2. Memory Address Space**

Physical addresses can be mapped to read-write memory, read-only memory and memory-mapped I/O. The architecture does not define a dedicated, addressable I/O space. There are no subdivisions of the address space such as segments. For memory management, an external memory management unit (MMU) may subdivide memory into pages or restrict access to certain areas of memory to protect a kernel's code, data and stack. However, the processor views this address space as linear.



An address in memory is a 32-bit value in the range 0H to FFFF FFFFH. Depending on the instruction, an address can reference in memory a single byte, short-word (2 bytes), word (4 bytes), double-word (8 bytes), triple-word (12 bytes) or quad-word (16 bytes). Refer to load and store instruction descriptions in [CHAPTER 6, INSTRUCTION SET REFERENCE](#) for multiple-byte addressing information.

### 3.5.1 Memory Requirements

The architecture requires that external memory have the following properties:

- Memory must be byte-addressable.
- Physical memory must not be mapped to reserved addresses that are specifically used by the processor implementation.
- Memory must guarantee indivisible access (read or write) for addresses that fall within 16-byte boundaries.
- Memory must guarantee atomic access for addresses that fall within 16-byte boundaries.

The latter two capabilities, *indivisible* and *atomic* access, are required only when multiple processors or other external agents, such as DMA or graphics controllers, share a common memory.

**indivisible access** Guarantees that a processor, reading or writing a set of memory locations, complete the operation before another processor or external agent can read or write the same location. The processor requires indivisible access within an aligned 16-byte block of memory.

**atomic access** A read-modify-write operation. Here the external memory system must guarantee that once a processor begins a read-modify-write operation on an aligned, 16-byte block of memory it is allowed to complete the operation before another processor or external agent can access to the same location. An atomic memory system can be implemented by using the **LOCK** signal to qualify hold requests from external bus agents. The processor asserts **LOCK** for the duration of an atomic memory operation.

The upper 16 Mbytes of the address space (addresses FF00 0000H through FFFF FFFFH) are reserved for implementation-specific functions. Programs written for the i960 Jx processor cannot use this address space except for accesses to memory-mapped registers. As shown in [Figure 3-2](#), the initialization boot record is located just below the i960 Jx processor's reserved memory.

The i960 Jx processor requires some special consideration when using the lower 1 Kbyte of address space (addresses 0000H to 03FFH). Loads and stores directed to these addresses access internal memory; instruction fetches from these addresses are not allowed by the processor. See [section 4.1, "INTERNAL DATA RAM" \(pg. 4-1\)](#). No external bus cycles are generated to this address space.



### 3.5.2 Data and Instruction Alignment in the Address Space

Instructions, program data and architecturally defined data structures can be placed anywhere in non-reserved address space while adhering to these alignment requirements:

- Align instructions on word boundaries.
- Align all architecturally defined data structures on the boundaries specified in [Table 3-7](#).
- Align instruction operands for the atomic instructions (**atadd**, **atmod**) to word boundaries in memory.

3

The i960 Jx processor can perform unaligned load or store accesses. The processor handles a non-aligned load or store request by:

- Automatically servicing a non-aligned memory access with microcode assistance as described in [section 13.5.2, “Bus Transactions Across Region Boundaries”](#) (pg. 13-7).
- After the access is completed, the processor can generate an OPERATION.UNALIGNED fault, when directed to do so.

Unaligned fault handling is enabled at initialization based on the value of the Fault Configuration Word in the Process Control Block. See [section 12.3.1.2, “Process Control Block \(PRCB\)”](#) (pg. 12-16).

**Table 3-7. Alignment of Data Structures in the Address Space**

Data Structure	Alignment Boundary
System Procedure Table	4 byte
Interrupt Table	4 byte
Fault Table	4 byte
Control Table	16 byte
User Stack	16 byte
Supervisor Stack	16 byte
Interrupt Stack	16 byte
Process Control Block	16 byte
Initialization Boot Record	Fixed at FEFF FF30H

### 3.5.3 Byte, Word and Bit Addressing

The processor provides instructions for moving data blocks of various lengths from memory to registers (**ld**) and from registers memory (**st**). Supported sizes for blocks are bytes, short-words, words, double-words, triple-words and quad-words. For example, **stl** (store long) stores an 8-byte (double-word) data block in memory.



## PROGRAMMING ENVIRONMENT

The most efficient way to move data blocks longer than 16 bytes is to move them in quad-word increments, using quad-word instructions **ldq** and **stq**.

Normally when a data block is stored in memory, the block's least significant byte is stored at a base memory address and the more significant bytes are stored at successively higher byte addresses. This method of ordering bytes in memory is referred to as "little endian" ordering.

The i960 Jx processor also provides an option for ordering bytes in the opposite manner in memory. The block's most significant byte is stored at the base address and the less significant bytes are stored at successively higher addresses. This byte-ordering scheme, referred to as "big endian", applies to data blocks which are short-words or words. For more about byte ordering, see [section 13.6.2, "Selecting the Byte Order"](#) (pg. 13-12).

When loading a byte, short-word or word from memory to a register, the block's least significant bit is always loaded in register bit 0. When loading double-words, triple-words and quad-words, the least significant word is stored in the base register. The more significant words are then stored at successively higher-numbered registers. Individual bits can be addressed only in data that resides in a register: bit 0 in a register is the least significant bit, bit 31 is the most significant bit.

### 3.5.4 Internal Data RAM

Internal data RAM is mapped to the lower 1 Kbyte (0000H to 03FFH) of the address space. Loads and stores, with target addresses in internal data RAM, operate directly on the internal data RAM; no external bus activity is generated. Data RAM allows time-critical data storage and retrieval without dependence on external bus performance. The lower 1 Kbyte of memory is data memory only. Instructions cannot be fetched from the internal data RAM. Instruction fetches directed to the data RAM cause a OPERATION.UNIMPLEMENTED fault to occur. For more specific information refer to [Section 4.1, "INTERNAL DATA RAM"](#) (pg. 4-1)

### 3.5.5 Instruction Cache

The instruction cache enhances performance by reducing the number of instruction fetches from external memory. The cache provides fast execution of cached code and loop functions in addition to providing more bus bandwidth for data operations in external memory. The i960 JT processor instruction cache is a 16 Kbyte two-way set-associative. The i960 JF and JD processor instruction cache is a 4 Kbyte, two-way set-associative, organized in two sets of four-word lines. The i960 JA processors feature a 2 Kbyte instruction cache two-way set-associative.





### 3.5.6 Data Cache

The i960 JT processor features a 4 Kbyte write-through direct-mapped data cache. The i960 JF and JD processors feature a 2 Kbyte write-through direct-mapped data cache. The i960 JA processor features a 1 Kbyte write-through direct-mapped data cache. For more information, see [CHAPTER 4, CACHE AND ON-CHIP DATA RAM](#).

3

### 3.6 LOCAL REGISTER CACHE

The i960 Jx processor provides fast storage of local registers for call and return operations by using an internal local register cache (also known as a *stack frame cache*). Up to 7 local register sets can be contained in the cache before sets must be saved in external memory. The register set is all the local registers (i.e., r0 through r15).

### 3.7 PROCESSOR-STATE REGISTERS

The architecture defines four 32-bit registers that contain status and control information:

- Instruction Pointer (IP) register
- Arithmetic Controls (AC) register
- Process Controls (PC) register
- Trace Controls (TC) register

#### 3.7.1 Instruction Pointer (IP) Register

The IP register contains the address of the instruction currently being executed. This address is 32 bits long; however, since instructions are required to be aligned on word boundaries in memory, the IP's two least-significant bits are always 0 (zero).

All i960 processor instructions are either one or two words long. The IP gives the address of the lowest-order byte of the first word of the instruction.

The IP register cannot be read directly. However, the IP-with-displacement addressing mode lets software use the IP as an offset into the address space. This addressing mode can also be used with the **lda** (load address) instruction to read the current IP value.

When a break occurs in the instruction stream due to an interrupt, procedure call or fault, the processor stores the IP of the next instruction to be executed in local register r2, which is usually referred to as the return IP or RIP register. Refer to [CHAPTER 7, PROCEDURE CALLS](#) for further discussion.

### 3.7.2 Arithmetic Controls (AC) Register

The AC register (Figure 3-3) contains condition code flags, integer overflow flag, mask bit and a bit that controls faulting on imprecise faults. Unused AC register bits are reserved.




Figure 3-3. Arithmetic Controls (AC) Register

#### 3.7.2.1 Initializing and Modifying the AC Register

At initialization, the AC register is loaded from the Initial AC image field in the Process Control Block. The user must set reserved bits to 0 in the AC Register Initial Image. Refer to [CHAPTER 12, INITIALIZATION AND SYSTEM REQUIREMENTS](#).

After initialization, software must not modify or depend on the AC register’s initial image in the PRCB. Software can use the modify arithmetic controls (**modac**) instruction to examine and/or modify any of the register bits. This instruction provides a mask operand that lets user software limit access to the register’s specific bits or groups of bits, such as the reserved bits.

The processor automatically saves and restores the AC register when it services an interrupt or handles a fault. The processor saves the current AC register state in an interrupt record or fault record, then restores the register upon returning from the interrupt or fault handler.



### 3.7.2.2 Condition Code (AC.cc)

The processor sets the AC register's *condition code flags* (bits 0-2) to indicate the results of certain instructions, such as compare instructions. Other instructions, such as conditional branch instructions, examine these flags and perform functions as dictated by the state of the condition code flags. Once the processor sets the condition code flags, the flags remain unchanged until another instruction executes that modifies the field.

Condition code flags show true/false conditions, inequalities (greater than, equal or less than conditions) or carry and overflow conditions for the extended arithmetic instructions. To show true or false conditions, the processor sets the flags as shown in [Table 3-8](#). To show equality and inequalities, the processor sets the condition code flags as shown in [Table 3-9](#).

3

**Table 3-8. Condition Codes for True or False Conditions**

Condition Code	Condition
010 <sub>2</sub>	true
000 <sub>2</sub>	false

**Table 3-9. Condition Codes for Equality and Inequality Conditions**

Condition Code	Condition
000 <sub>2</sub>	unordered
001 <sub>2</sub>	greater than
010 <sub>2</sub>	equal
100 <sub>2</sub>	less than

The term *unordered* is used when comparing floating point numbers. The i960 Jx processor does not implement on-chip floating point processing.

To show carry out and overflow, the processor sets the condition code flags as shown in [Table 3-10](#).

**Table 3-10. Condition Codes for Carry Out and Overflow**

Condition Code	Condition
01X <sub>2</sub>	carry out
0X1 <sub>2</sub>	overflow

Certain instructions, such as the branch-if instructions, use a 3-bit mask to evaluate the condition code flags. For example, the branch-if-greater-or-equal instruction (**bge**) uses a mask of  $011_2$  to determine if the condition code is set to either greater-than or equal. Conditional instructions use similar masks for the remaining conditions such as: greater-or-equal ( $011_2$ ), less-or-equal ( $110_2$ ) and not-equal ( $101_2$ ). The mask is part of the instruction opcode; the instruction performs a bitwise AND of the mask and condition code.

The AC register *integer overflow flag* (bit 8) and *integer overflow mask bit* (bit 12) are used in conjunction with the ARITHMETIC.INTEGER\_OVERFLOW fault. The mask bit disables fault generation. When the fault is masked and integer overflow is encountered, the processor sets the integer overflow flag instead of generating a fault. When the fault is not masked, the fault is allowed to occur and the flag is not set.

Once the processor sets this flag, the flag remains set until the application software clears it. Refer to the discussion of the ARITHMETIC.INTEGER\_OVERFLOW fault in [CHAPTER 8, FAULTS](#) for more information about the integer overflow mask bit and flag.

The *no imprecise faults (AC.nif) bit* (bit 15) determines whether or not faults are allowed to be imprecise. When set, all faults are required to be precise; when clear, certain faults can be imprecise. See [section 8.9, “PRECISE AND IMPRECISE FAULTS” \(pg. 8-19\)](#) for more information. When set, the AC.nif bit disables the parallel instruction execution feature of the processor; therefore, no imprecise faults mode should be invoked only during debugging when maximum processor performance is not necessary.



### 3.7.3 Process Controls (PC) Register

The PC register (Figure 3-4) is used to control processor activity and show the processor's current state. The PC register *execution mode flag* (bit 1) indicates that the processor is operating in either user mode (0) or supervisor mode (1). The processor automatically sets this flag on a system call when a switch from user mode to supervisor mode occurs and it clears the flag on a return from supervisor mode. (User and supervisor modes are described in section 3.8, "USER-SUPERVISOR PROTECTION MODEL" (pg. 3-23).

3




Figure 3-4. Process Controls (PC) Register

PC register *state flag* (bit 13) indicates the processor state: executing (0) or interrupted (1). When the processor is servicing an interrupt, its state is interrupted. Otherwise, the processor's state is executing.

While in the interrupted state, the processor can receive and handle additional interrupts. When nested interrupts occur, the processor remains in the interrupted state until all interrupts are handled, then switches back to the executing state on the return from the initial interrupt procedure.

The PC register *priority field* (bits 16 through 20) indicates the processor's current executing or interrupted priority. The architecture defines a mechanism for prioritizing execution of code, servicing interrupts and servicing other implementation-dependent tasks or events. This mechanism defines 32 priority levels, ranging from 0 (the lowest priority level) to 31 (the highest). The priority field always reflects the current priority of the processor. Software can change this priority by use of the **modpc** instruction.



The processor uses the priority field to determine whether to service an interrupt immediately or to post the interrupt. The processor compares the priority of a requested interrupt with the current process priority. When the interrupt priority is greater than the current process priority or equal to 31, the interrupt is serviced; otherwise it is posted. When an interrupt is serviced, the process priority field is automatically changed to reflect interrupt priority. See [CHAPTER 11, INTERRUPTS](#).

The PC register *trace enable bit* (bit 0) and *trace fault pending flag* (bit 10) control the tracing function. The trace enable bit determines whether trace faults are globally enabled (1) or globally disabled (0). The trace fault pending flag indicates that a trace event has been detected (1) or not detected (0). The tracing functions are further described in [CHAPTER 9, TRACING AND DEBUGGING](#).

### 3.7.3.1 Initializing and Modifying the PC Register

Any of the following three methods can be used to change bits in the PC register:

- Modify process controls instruction (**modpc**)
- Alter the saved process controls prior to a return from an interrupt handler or fault handler

The **modpc** instruction reads and modifies the PC register directly. A TYPE.MISMATCH fault results when software executes **modpc** in user mode with a non-zero mask. As with **modac**, **modpc** provides a mask operand that can be used to limit access to specific bits or groups of bits in the register. In user mode, software can use **modpc** to read the current PC register.

In the latter two methods, the interrupt or fault handler changes process controls in the interrupt or fault record that is saved on the stack. Upon return from the interrupt or fault handler, the modified process controls are copied into the PC register. The processor must be in supervisor mode prior to return for modified process controls to be copied into the PC register.

When process controls are changed as described above, the processor recognizes the changes immediately except for one situation: when **modpc** is used to change the trace enable bit, the processor may not recognize the change before the next four non-branch instructions are executed.

After initialization (hardware reset), the process controls reflect the following conditions:

- priority = 31
- trace enable = disabled
- trace fault pending = 0
- execution mode = supervisor
- state = interrupted

When the processor is reinitialized with a **sysctl** reinitialize message, the PC register returns to its reset value. See [Table 12-2 on page 5](#).

Software should not use **modpc** to modify execution mode or trace fault state flags except under special circumstances, such as in initialization code. Normally, execution mode is changed through the call and return mechanism. See [section 6.2.43, “modpc” \(pg. 6-78\)](#) for more details.



### 3.7.4 Trace Controls (TC) Register

The TC register, in conjunction with the PC register, controls processor tracing facilities. It contains trace mode enable bits and trace event flags that are used to enable specific tracing modes and record trace events, respectively. Trace controls are described in [CHAPTER 9, TRACING AND DEBUGGING](#).

## 3.8 USER-SUPERVISOR PROTECTION MODEL

The processor can be in either of two execution modes: user or supervisor. The capability of a separate user and supervisor execution mode creates a code and data protection mechanism referred to as the user-supervisor protection model. This mechanism allows code, data and stack for a kernel (or system executive) to reside in the same address space as code, data and stack for the application. The mechanism restricts access to all or parts of the kernel by the application code. This protection mechanism prevents application software from inadvertently altering the kernel.

### 3.8.1 Supervisor Mode Resources

Supervisor mode is a privileged mode that provides several additional capabilities over user mode.

- When the processor switches to supervisor mode, it also switches to the supervisor stack. Switching to the supervisor stack helps maintain a kernel's integrity. For example, it allows access to system debugging software or a system monitor, even when an application's program destroys its own stack.
- In supervisor mode, the processor is allowed access to a set of supervisor-only functions and instructions. For example, the processor uses supervisor mode to handle interrupts and trace faults. Operations that can modify interrupt controller behavior or reconfigure bus controller characteristics can be performed only in supervisor mode. These functions include modification of control registers and internal data RAM that is dedicated to interrupt controllers. A fault is generated when supervisor-only operations are attempted while the processor is in user mode.

The PC register execution mode flag specifies processor execution mode. The processor automatically sets and clears this flag when it switches between the two execution modes.

- |   |   |
|---|---|
| • <b>dcctl</b> (data cache control)                   | • <b>inten</b> (global interrupt enable)                    |
| • <b>icctl</b> (instruction cache control)            | • <b>modpc</b> (modify process controls w/ non-zero mask)   |
| • <b>intctl</b> (global interrupt enable and disable) | • <b>sysctl</b> (system control)                            |
| • <b>intdis</b> (global interrupt disable)            | • Protected internal data RAM or Supervisor MMR space write |
| • <b>halt</b> (halt CPU)                              | • Protected timer unit registers                            |

Note that all of these instructions return a TYPE.MISMATCH fault when executed in user mode.

### 3.8.2 Using the User-Supervisor Protection Model

A program switches from user mode to supervisor mode by making a system-supervisor call (also referred to as a supervisor call). A system-supervisor call is a call executed with the call-system instruction (**calls**). With **calls**, the IP for the called procedure comes from the system procedure table. An entry in the system procedure table can specify an execution mode switch to supervisor mode when the called procedure is executed. The instruction **calls** and the system procedure table thus provide a tightly controlled interface to procedures that can execute in supervisor mode. Once the processor switches to supervisor mode, it remains in that mode until a return is performed to the procedure that caused the original mode switch.

Interrupts and faults can cause the processor to switch from user to supervisor mode. When the processor handles an interrupt, it automatically switches to supervisor mode. However, it does not switch to the supervisor stack. Instead, it switches to the interrupt stack. Fault table entries determine when a particular fault transitions the processor from user to supervisor mode.

When an application does not require a user-supervisor protection mechanism, the processor can always execute in supervisor mode. At initialization, the processor is placed in supervisor mode prior to executing the first instruction of the application code. The processor then remains in supervisor mode indefinitely, as long as no action is taken to change execution mode to user mode. The processor does not need a user stack in this case.







4

# CACHE AND ON-CHIP DATA RAM





## CHAPTER 4

# CACHE AND ON-CHIP DATA RAM

This chapter describes the structure and user configuration of all forms of on-chip storage, including caches (data, local register and instruction) and data RAM.


### 4.1 INTERNAL DATA RAM

Internal data RAM is mapped to the lower 1 Kbyte (0 to 03FFH) of the address space. Loads and stores with target addresses in internal data RAM operate directly on the internal data RAM; no external bus activity is generated. Data RAM allows time-critical data storage and retrieval without dependence on external bus performance. Only data accesses are allowed to the internal data RAM; instructions cannot be fetched from the internal data RAM. Instruction fetches directed to the data RAM cause an OPERATION.UNIMPLEMENTED fault to occur.

Internal data RAM locations are never cached in the data cache. Logical Memory Template bits controlling caching are ignored for data RAM accesses. However, the byte ordering of the internal data RAM is controlled by the byte-endian control bit in the DLMCON register.

Some internal data RAM locations are reserved for functions other than general data storage. The first 64 bytes of data RAM may be used to cache interrupt vectors, which reduces latency for these interrupts. The word at location 0000H is always reserved for the cached NMI vector. With the exception of the cached NMI vector, other reserved portions of the data RAM can be used for data storage when the alternate function is not used. All locations of the internal data RAM can be read in both supervisor and user mode.

The first 64 bytes (0000H to 003FH) of internal RAM are always user-mode write-protected. This portion of data RAM can be read while executing in user or supervisor mode; however, it can be only modified in supervisor mode. This area can also be write-protected from supervisor mode writes by setting the BCON.sirp bit. See [section 13.4.1, “Bus Control \(BCON\) Register”](#) (pg. 13-6). Protecting this portion of the data RAM from user and supervisor writes preserves the interrupt vectors that may be cached there. See [section 11.9.2.1, “Vector Caching Option”](#) (pg. 11-35).



**Figure 4-1. Internal Data RAM and Register Cache**

The remainder of the internal data RAM can always be written from supervisor mode. User mode write protection is optionally selected for the rest of the data RAM (40H to 3FFH) by setting the Bus Control Register RAM protection bit (BCON.irq). Writes to internal data RAM locations while they are protected generate a TYPE.MISMATCH fault. See [section 13.4.1, “Bus Control \(BCON\) Register”](#) (pg. 13-6), for the format of the BCON register.

Some versions of i960<sup>®</sup> processor compilers can take advantage of internal data RAM. Profiling compilers, such as those offered by Intel, can allocate the most frequently used variables into this RAM.

**4.2 LOCAL REGISTER CACHE**

The i960 Jx processor provides fast storage of local registers for call and return operations by using an internal local register cache (also known as a *stack frame cache*). Up to 7 local register sets can be contained in the cache before sets must be saved in external memory. The register set is all the local registers (i.e., r0 through r15). The processor uses a 128-bit wide bus to store local register sets quickly to the register cache. An integrated procedure call mechanism saves the current local register set when a call is executed. A local register set is saved into a frame in the local register cache, one frame per register set. When the eighth frame is saved, the oldest set of local registers is flushed to the procedure stack in external memory, which frees one frame.

[Section 7.1.4, Caching Local Register Sets](#) (pg. 7-7) and [section 7.1.5, “Mapping Local Registers to the Procedure Stack”](#) (pg. 7-11) further discuss the relationship between the internal register cache and the external procedure stack.



The branch-and-link (**bal** and **balx**) instructions do not cause the local registers to be stored.

The entire internal register cache contents can be copied to the external procedure stack through the **flushreg** instruction. [Section 6.2.30, flushreg \(pg. 6-54\)](#) explains the instruction and [section 7.2, “MODIFYING THE PFP REGISTER” \(pg. 7-11\)](#) offers a practical example when **flushreg** must be used.

To decrease interrupt latency, software can reserve a number of frames in the local register cache solely for high priority interrupts (interrupted state and process priority greater than or equal to 28). The remaining frames in the cache can be used by all code, including high-priority interrupts. When a frame is reserved for high-priority interrupts, the local registers of the code interrupted by a high-priority interrupt can be saved to the local register cache without causing a frame flush to memory, providing the local register cache is not already full. Thus, the register allocation for the implicit interrupt call does not incur the latency of a frame flush.

4

Software can reserve frames for high-priority interrupt code by writing bits 10 through 8 of the register cache configuration word in the PRCB. This value indicates the number of free frames within the register cache that can be used by high-priority interrupts only. Any attempt by non-critical code to reduce the number of free frames below this value results in a frame flush to external memory. The free frame check is performed only when a frame is pushed, which occurs only for an implicit or explicit call. The following pseudo-code illustrates the operation of the register cache when a frame is pushed:

#### Example 4-1. Register Cache Operation

```
frames_for_non_critical = 7- RCW[10:8];
if (interrupt_request)
    set_interrupt_handler_PC;
push_frame;
number_of_frames = number_of_frames + 1;
if (number_of_frames = 8) {
    flush_register_frame(oldest_frame);
    number_of_frames = number_of_frames - 1; }
else if ( number_of_frames = (frames_for_non_critical + 1) &&
(PC.priority < 28 || PC.state != interrupted) ) {
    flush_register_frame(oldest_frame);
    number_of_frames = number_of_frames - 1; }
```

The valid range for the number of reserved free frames is 0 to 7. Setting the value to 0 reserves no frames for exclusive use by high-priority interrupts. Setting the value to 1 reserves 1 frame for high-priority interrupts and 6 frames to be shared by all code. Setting the value to 7 causes the register cache to become disabled for non-critical code. When the number of reserved high-priority frames exceeds the allocated size of the register cache, the entire cache is reserved for high-priority interrupts. In that case, all low-priority interrupts and procedure calls cause frame spills to external memory.

### 4.3 BIG ENDIAN ACCESSES TO INTERNAL RAM AND DATA CACHE

The i960 Jx processor supports big-endian accesses to the internal data RAM and data cache. The default byte order for data accesses is programmed in DLMCON.be as either little or big-endian. The DLMCON.be controls the default byte-order for all internal (i.e., on-chip data RAM and data cache) and external accesses. See [section 13.6, “Programming the Logical Memory Attributes” \(pg. 13-8\)](#) for more details.

### 4.4 INSTRUCTION CACHE

The i960 JT processor features a 16 Kbyte, 2-way set-associative instruction cache (I-cache). The i960 JF and JD processors feature a 4-Kbyte, 2-way set-associative I-cache organized in lines of four 32-bit words. The JA processor features a 2 Kbyte, 2-way set associative instruction cache. The cache provides fast execution of cached code and loops of code and provides more bus bandwidth for data operations in external memory. To optimize cache updates when branches or interrupts are executed, each word in the line has a separate valid bit. When requested instructions are found in the cache, the instruction fetch time is one cycle for up to four words. A mechanism to load and lock critical code within a way of the cache is provided along with a mechanism to disable the cache. The cache is managed through the **icctl** or **sysctl** instruction. Using **icctl** is the preferred and more versatile method for controlling the instruction cache on the i960 Jx processor. Future i960 processors may not support **sysctl** instruction.

Cache misses cause the processor to issue a double-word or a quad-word fetch, based on the location of the Instruction Pointer:

- When the IP is at word 0 or word 1 of a 16-byte block, a four-word fetch is initiated.
- When the IP is at word 2 or word 3 of a 16-byte block, a two-word fetch is initiated.

#### 4.4.1 Enabling and Disabling the Instruction Cache

Enabling the instruction cache is controlled on reset or initialization by the instruction cache configuration word in the Process Control Block (PRCB); see [Figure 12-6 \(pg. 12-17\)](#). When bit 16 in the instruction cache configuration word is set, the instruction cache is disabled and all instruction fetches are directed to external memory. Disabling the instruction cache is useful for tracing execution in a software debug environment.

The instruction cache remains disabled until one of three operations is performed:

- **icctl** is issued with the enable instruction cache operation (preferred method)
- **sysctl** is issued with the configure-instruction-cache message type and cache configuration mode other than disable cache (not the preferred method for i960 Jx processor).
- The processor is reinitialized with a new value in the instruction cache configuration word



#### 4.4.2 Operation While the Instruction Cache Is Disabled

Disabling the instruction cache *does not* disable the instruction buffering that may occur within the instruction fetch unit. A four-word instruction buffer is always enabled, even when the cache is disabled.

There is one tag and four word-valid bits associated with the buffer. Because there is only one tag for the buffer, any “miss” within the buffer causes the following:

- All four words of the buffer are invalidated.
- A new tag value for the required instruction is loaded.
- The required instruction(s) are fetched from external memory.

4

Depending on the alignment of the “missed” instruction, either two or four words of instructions are fetched and only the valid bits corresponding to the fetched words are set in the buffer. No external instruction fetches are generated until a “miss” occurs within the buffer, even in the presence of forward and backward branches.

#### 4.4.3 Loading and Locking Instructions in the Instruction Cache

The processor can be directed to load a block of instructions into one-way of the cache and then lock out all normal updates to this one-way of the cache. This cache load-and-lock mechanism is provided to minimize latency on program control transfers to key operations such as interrupt service routines. The block size that can be loaded and locked on the i960 Jx processor is one way of the cache. Any code can be locked into the cache, not just interrupt routines.

An **icctl** or **sysctl** instruction is issued with a configure-instruction-cache message type to select the load-and-lock mechanism. When the lock option is selected, the processor loads the cache starting at an address specified as an operand to the instruction.

#### 4.4.4 Instruction Cache Visibility

Instruction cache status can be determined by issuing **icctl** with an instruction-cache status message. To facilitate debugging, the instruction cache contents, instructions, tags and valid bits can be written to memory. This is done by issuing **icctl** with the store cache operation.

#### 4.4.5 Instruction Cache Coherency

The i960 Jx processor does not snoop the bus to prevent instruction cache incoherency. The cache does not detect modification to program memory by loads, stores or actions of other bus masters. Several situations may require program memory modification, such as uploading code at initialization or loading from a backplane bus or a disk drive.

The application program is responsible for synchronizing its own code modification and cache invalidation. In general, a program must ensure that modified code space is not accessed until modification and cache-invalidate are completed. To achieve cache coherency, instruction cache contents should be invalidated after code modification is complete. The **icctl** instruction invalidates the instruction cache for the i960 Jx processor. Alternately, legacy software can use the **sysctl** instruction.

## 4.5 DATA CACHE

The i960 JT processor features a 4 Kbyte direct-mapped data cache. The i960 JF and JD processors feature a 2-Kbyte, direct-mapped cache that enhances performance by reducing the number of data load and store accesses to external memory. The i960 JA processors have a 1 Kbyte direct-mapped data cache. The cache is write-through and write-allocate. It has a line size of 4 words and each line in the cache has a valid bit. To reduce fetch latency on cache misses, each word within a line also has a valid bit. Caches are managed through the **dcctl** instruction.

User settings in the memory region configuration registers LMCON0-1 and DLMCON determine which data accesses are cacheable or non-cacheable based on memory region.

### 4.5.1 Enabling and Disabling the Data Cache

To cache data, two conditions must be met:

1. The data cache must be enabled. A **dcctl** instruction issued with an enable data cache message enables the cache. On reset or initialization, the data cache is always disabled and all valid bits are cleared (set to zero).
2. Data caching for a location must be enabled by the corresponding logical memory template, or by the default logical memory template, when no other template applies. See [section 13.6, “Programming the Logical Memory Attributes”](#) (pg. 13-8) for more details on logical memory templates.

When the data cache is disabled, all data fetches are directed to external memory. Disabling the data cache is useful for debugging or monitoring a system. To disable the data cache, issue a **dcctl** with a disable data cache message. The enable and disable status of the data cache and various attributes of the cache can be determined by a **dcctl** issued with a data-cache status message.





### 4.5.2 Multi-Word Data Accesses that Partially Hit the Data Cache

The following applies only when data caching is enabled for an access.

For a multi-word load access (**ldl**, **ldt**, **ldq**) in which none of the requested words hit the data cache, an external bus transaction is started to acquire all the words of the access.

For a multi-word load access that partially hits the data cache, the processor may either:

- Load or reload all words of the access (even those that hit) from the external bus
- Load only missing words from the external bus and interleave them with words found in the data cache



The multi-word alignment determines which of the above methods is used:

- Naturally aligned multi-word accesses cause all words to be reloaded
- An unaligned multi-word access causes only missing words to be loaded

When any words accessed by a **ldl**, **ldt**, or **ldq** instruction miss the data cache, every word accessed by that load instruction is updated in the cache.

**Table 4.1.**

Load Instruction	Number of Updated Words
<b>ldq</b>	4 words
<b>ldt</b>	3 words
<b>ldl</b>	2 words

In each case, the external bus accesses used to acquire the data may consist of none, one, or several burst accesses based on the alignment of the data and the bus-width of the memory region that contains the data. See [CHAPTER 14, EXTERNAL BUS](#) for more details.

A multi-word load access that completely hits in the data cache does not cause external bus accesses.

For a multi-word store access (**stl**, **stt**, **stq**) an external bus transaction is started to write all words of the access regardless when any or all words of the access hit the data cache. External bus accesses used to write the data may consist of either one or several burst accesses based on data alignment and the bus-width of the memory region that receives the data. (See [CHAPTER 14, EXTERNAL BUS](#) for more details.) The cache is also updated accordingly as described earlier in this chapter.



### 4.5.3 Data Cache Fill Policy

The i960 Jx processor always uses a “natural” fill policy for cacheable loads. The processor fetches only the amount of data that is requested by a load (i.e., a word, long-word, etc.) on a data cache miss. Exceptions are byte and short-word accesses, which are always promoted to words. This allows a complete word to be brought into the cache and marked valid. When the data cache is disabled and loads are done from a cacheable region, promotions from bytes and short-words still take place.

### 4.5.4 Data Cache Write Policy

The write policy determines what happens on cacheable writes (stores). The i960 Jx processor always uses a write-through policy. Stores are always seen on the external bus, thus maintaining coherency between the data cache and external memory.

The i960 Jx processor always uses a write-allocate policy for data. For a cacheable location, data is always written to the data cache regardless of whether the access is a hit or miss. The following cases are relevant to consider:

1. In the case of a hit for a word or multi-word store, the appropriate line and word(s) are updated with the data.
2. In the case of a miss for a word or multi-word store, a tag and cache line are allocated, when needed, and the appropriate valid bits, line, and word(s) are updated.
3. In the case of byte or short-word data that hits a valid word in the cache, both the word in cache and external memory are updated with the data; the cache word remains valid.
4. In the case of byte or short-word data that falls within a valid line but misses because the appropriate word is invalid, both the word and external memory are updated with the data; however, the cache word remains invalid.
5. In the case of byte or short-word data that does not fall within a valid line, the external memory is updated with the data. For data writes less than a word, the D-cache is not updated; the tags and valid bits are not changed.

A byte or short-word is always invalid in the D-cache since valid bits only apply to words.

For cacheable stores that are equal to or greater than a word in length, cache tags and appropriate valid bits are updated whenever data is written into the cache. Consider a word store that misses as an example. The tag is always updated and its valid bit is set. The appropriate valid bit for that word is always set and the other three valid bits are always cleared. When the word store hits the cache, the tag bits remain unchanged. The valid bit for the stored word is set; all other valid bits are unchanged.



Cacheable stores that are less than a word in length are handled differently. Byte and short-word stores that hit the cache (i.e., are contained in valid words within valid cache lines) do not change the tag and valid bits. The processor writes the data into the cache and external memory as usual. A byte or short-word store to an invalid word within a valid cache line leaves the word valid bit cleared because the rest of the word is still invalid. In these two cases the processor simultaneously writes the data into the cache and the external memory.

#### 4.5.5 Data Cache Coherency and Non-Cacheable Accesses

4

The i960 Jx processor ensures that the data cache is always kept coherent with accesses that it initiates and performs. The most visible application of this requirement concerns non-cacheable accesses discussed below. However, the processor does not provide data-cache coherency for accesses on the external bus that it did not initiate. Software is responsible for maintaining coherency in a multi-processor environment.

An access is defined as non-cacheable when any of the following is true:

1. The access falls into an address range mapped by an enabled LMCON or DLMCON and the data-caching enabled bit in the matching LMCON is clear.
2. The entire data cache is disabled.
3. The access is a read operation of the read-modify-write sequence performed by an **atmod** or **atadd** instruction.
4. The access is an implicit read access to the interrupt table to post or deliver a software interrupt.

When the memory location targeted by an **atmod** or **atadd** instruction is currently in the data cache, it is invalidated.

When the address for a non-cacheable store matches a tag (“tag hit”), the corresponding cache line is marked invalid. This is because the word is not actually updated with the value of the store. This behavior ensures that the data cache never contains stale data in a single-processor system. A simple case illustrates the necessity of this behavior: a read of data previously stored by a non-cacheable access must return the new value of the data, not the value in the cache. Because the processor invalidates the appropriate word in the cache line on a store hit when the cache is disabled, coherency can be maintained when the data cache is enabled and disabled dynamically.

Data loads or stores invalidate the corresponding lines of the cache even when data caching is disabled. This behavior further ensures that the cache does not contain stale data.

#### 4.5.6 External I/O and Bus Masters and Cache Coherency

The i960 Jx processor implements a single processor coherency mechanism. There is no hardware mechanism, such as bus snooping, to support multiprocessing. When another bus master can change shared memory, there is no guarantee that the data cache contains the most recent data. The user must manage such data coherency issues in software.

A suggested practice is to program the LMCON0-1 registers such that I/O regions are non-cacheable. Partitioning the system in this fashion eliminates I/O as a source of coherency problems. See [section 13.6, “Programming the Logical Memory Attributes” \(pg. 13-8\)](#) for more information on this subject.

#### 4.5.7 Data Cache Visibility

The data cache status can be determined by a **dcctl** instruction issued with a data-cache status message. Data cache contents, data, tags and valid bits can be written to memory as an aid for debugging. This operation is accomplished by a **dcctl** instruction issued with the dump cache operand. See [section 6.2.23, “dcctl” \(pg. 6-40\)](#) for more information.





5

# INSTRUCTION SET OVERVIEW





## CHAPTER 5

# INSTRUCTION SET OVERVIEW

This chapter provides an overview of the i960<sup>®</sup> microprocessor family's instruction set and i960 Jx processor-specific instruction set extensions. Also discussed are the assembly-language and instruction-encoding formats, various instruction groups and each group's instructions.

Chapter 6, [INSTRUCTION SET REFERENCE](#) describes each instruction, including assembly language syntax, and the action taken when the instruction executes and examples of how to use the instruction.

5

### 5.1 INSTRUCTION FORMATS

The i960 Jx processor instructions may be described in two formats: assembly language and instruction encoding. The following subsections briefly describe these formats.

#### 5.1.1 Assembly Language Format

Throughout this manual, instructions are referred to by their assembly language mnemonics. For example, the add ordinal instruction is referred to as **addo**. The Intel 80960 assembly language syntax consists of the instruction mnemonic followed by zero to three operands, separated by commas. In the following assembly language statement, ordinal operands in global registers g5 and g9 are added together, and the result is stored in g7:

```
addo g5, g9, g7      # g7 = g9 + g5
```

In the assembly language listings in this chapter, the following symbols are used:

**g** global register  
**r** local register  
**#** precedes a comment

All numbers used as literals or in address expressions are assumed to be decimal. Hexadecimal numbers are denoted with a "0x" prefix (e.g., 0xffff0012). Several assembly language instruction statement examples follow. Additional assembly language examples are given in [section 2.3.5, "Addressing Mode Examples"](#) (pg. 2-8).

```
subi r3, r5, r6      #r6 = r5 - r3
setbit 13, g4, g5    #g5 = g4 with bit 13 set
lda 0xfab3, r12     #r12 = 0xfab3
ld (r4), g3         #g3 = the value at memory location that r4 points to
st g10, (r6)[r7*2] #the value at memory location that r6+2*r7 points to = g10
```



5.1.2 Instruction Encoding Formats


All instructions are encoded in one 32-bit machine language instruction — also known as an *opword* — which must be word aligned in memory. An opword’s most significant eight bits contain the opcode field. The opcode field determines the instruction to be performed and how the remainder of the machine language instruction is interpreted. Instructions are encoded in opwords in one of four formats (see [Figure 5-1](#)). For more information on instruction formats, see [APPENDIX C, MACHINE-LEVEL INSTRUCTION FORMATS](#).

Table 5-1. Instruction Encoding Formats

Instruction Type	Format	Description
register	REG	Most instructions are encoded in this format. Used primarily for instructions which perform register-to-register operations.
compare and branch	COBR	An encoding optimization which combines compare and branch operations into one opword. Other compare and branch operations are also provided as REG and CTRL format instructions.
control	CTRL	Used for branches and calls that do not depend on registers for address calculation.
memory	MEM	Used for referencing an operand which is a memory address. Load and store instructions — and some branch and call instructions — use this format. MEM format has two encodings: MEMA or MEMB. Usage depends upon the addressing mode selected. Some MEMB-formatted addressing modes use the word in memory immediately following the instruction opword as a 32-bit constant. MEMA format uses one word and MEMB uses one or two words.







5

Figure 5-1. Machine-Level Instruction Formats

### 5.1.3 Instruction Operands

This section identifies and describes operands that can be used with the instruction formats.

Format	Operand(s)	Description
REG	<i>src1, src2, src/dst</i>	<i>src1</i> and <i>src2</i> can be global registers, local registers or literals. <i>src/dst</i> is either a global or a local register.
CTRL	<i>displacement</i>	CTRL format is used for branch and call instructions. <i>displacement</i> value indicates the target instruction of the branch or call.
COBR	<i>src1, src2, displacement</i>	<i>src1, src2</i> indicate values to be compared; <i>displacement</i> indicates branch target. <i>src1</i> can specify a global register, local register or a literal. <i>src2</i> can specify a global or local register.
MEM	<i>src/dst, efa</i>	Specifies source or destination register and an effective address ( <i>efa</i> ) formed by using the processor's addressing modes as described in <a href="#">section 2.3, "MEMORY ADDRESSING MODES"</a> (pg. 2-6). Registers specified in a MEM format instruction must be either a global or local register.



## INSTRUCTION SET OVERVIEW

### 5.2 INSTRUCTION GROUPS

The following sections provide an overview of the instructions in each group. For detailed information about each instruction, refer to [CHAPTER 6, INSTRUCTION SET REFERENCE](#). The i960 processor instruction set can be categorized into functional groups shown in [Table 5-2](#). The actual number of instructions is greater than those shown in this list because, for some operations, several unique instructions are provided to handle various operand sizes, data types or branch conditions.

**Table 5-2. 80960Jx Instruction Set**

<b>Data Movement</b>	<b>Arithmetic</b>	<b>Logical</b>	<b>Bit, Bit Field and Byte</b>
Load Store Move *Conditional Select Load Address	Add Subtract Multiply Divide Remainder Modulo Shift Extended Shift Extended Multiply Extended Divide Add with Carry Subtract with Carry *Conditional Add *Conditional Subtract Rotate	And Not And And Not Or Exclusive Or Not Or Or Not Nor Exclusive Nor Not Nand	Set Bit Clear Bit Not Bit Alter Bit Scan For Bit Span Over Bit Extract Modify Scan Byte for Equal *Byte Swap
<b>Comparison</b>	<b>Branch</b>	<b>Call/Return</b>	<b>Fault</b>
Compare Conditional Compare Compare and Increment Compare and Decrement Test Condition Code Check Bit	Unconditional Branch Conditional Branch Compare and Branch Branch Extended	Call Call Extended Call System Return Branch and Link Branch and Link Extended	Conditional Fault Synchronize Faults
<b>Debug</b>	<b>Processor Management</b>	<b>Atomic</b>	
Modify Trace Controls Mark Force Mark	Flush Local Registers Modify Arithmetic Controls Modify Process Controls *Halt System Control *Cache Control *Interrupt Control	Atomic Add Atomic Modify	

\* Denotes new instructions unavailable on 80960CA/CF, 80960KA/KB and 80960SA/SB implementations.

**5.2.1 Data Movement**

These instructions are used to:

- move data from memory to global and local registers
- from global and local registers to memory
- between local and global registers

Rules for register alignment must be followed when using load, store and move instructions that move 8, 12 or 16 bytes at a time. See [section 3.5, “MEMORY ADDRESS SPACE”](#) (pg. 3-13) for alignment requirements for code portability across implementations.



**5.2.1.1 Load and Store Instructions**

Load instructions copy data from memory to local or global registers. Each load instruction has a corresponding store instruction to memory. All load and store instructions use the MEM format.

<b>ld</b>	load word	<b>st</b>	store word
<b>ldob</b>	load ordinal byte	<b>stob</b>	store ordinal byte
<b>ldos</b>	load ordinal short	<b>stos</b>	store ordinal short
<b>ldib</b>	load integer byte	<b>stib</b>	store integer byte
<b>ldis</b>	load integer short	<b>stis</b>	store integer short
<b>ldl</b>	load long	<b>stl</b>	store long
<b>ldt</b>	load triple	<b>stt</b>	store triple
<b>ldq</b>	load quad	<b>stq</b>	store quad

**ld** copies 4 bytes from memory into a register; **ldl** copies 8 bytes into 2 successive registers; **ldt** copies 12 bytes into 3 successive registers; **ldq** copies 16 bytes into 4 successive registers.

**st** copies 4 bytes from a register into memory; **stl** copies 8 bytes from 2 successive registers; **stt** copies 12 bytes from 3 successive registers; **stq** copies 16 bytes from 4 successive registers.

For **ld**, **ldob**, **ldos**, **ldib** and **ldis**, the instruction specifies a memory address and register; the memory address value is copied into the register. The processor automatically extends byte and short (half-word) operands to 32 bits according to data type. Ordinals are zero-extended; integers are sign-extended.



## INSTRUCTION SET OVERVIEW

For **st**, **stob**, **stos**, **stib** and **stis**, the instruction specifies a memory address and register; the register value is copied into memory. For byte and short instructions, the processor automatically reformats the source register's 32-bit value for the shorter memory location. For **stib** and **stis**, this reformatting can cause integer overflow when the register value is too large for the shorter memory location. When integer overflow occurs, either an integer-overflow fault is generated or the integer-overflow flag in the AC register is set, depending on the integer-overflow mask bit setting in the AC register.

For **stob** and **stos**, the processor truncates the register value and does not create a fault when truncation resulted in the loss of significant bits.

### 5.2.1.2 Move

Move instructions copy data from a local or global register or group of registers to another register or group of registers. These instructions use the REG format.

<b>mov</b>	move word
<b>movl</b>	move long word
<b>movt</b>	move triple word
<b>movq</b>	move quad word

### 5.2.1.3 Load Address

The Load Address instruction (**lda**) computes an effective address in the address space from an operand presented in one of the addressing modes. **lda** is commonly used to load a constant into a register. This instruction uses the MEM format and can operate upon local or global registers.

## 5.2.2 Select Conditional

Given the proper condition code bit settings in the Arithmetic Controls register, these instructions move one of two pieces of data from its source to the specified destination.

<b>selno</b>	Select Based on Unordered
<b>selg</b>	Select Based on Greater
<b>sele</b>	Select Based on Equal
<b>selge</b>	Select Based on Greater or Equal
<b>sell</b>	Select Based on Less
<b>selne</b>	Select Based on Not Equal
<b>selle</b>	Select Based on Less or Equal
<b>selo</b>	Select Based on Ordered



5.2.3 Arithmetic

Table 5-3 lists arithmetic operations and data types for which the i960 Jx processor provides instructions. “X” in this table indicates that the microprocessor provides an instruction for the specified operation and data type. All arithmetic operations are carried out on operands in registers or literals. Refer to section 5.2.11, “Atomic Instructions” (pg. 5-18) for instructions which handle specific requirements for in-place memory operations.

All arithmetic instructions use the REG format and can operate on local or global registers. The following subsections describe arithmetic instructions for ordinal and integer data types.

Table 5-3. Arithmetic Operations

Arithmetic Operations	Data Types	
	Integer	Ordinal
Add	X	X
Add with Carry	X	X
Conditional Add	X	X
Subtract	X	X
Subtract with Carry	X	X
Conditional Subtract	X	X
Multiply	X	X
Extended Multiply		X
Divide	X	X
Extended Divide		X
Remainder	X	X
Modulo	X	
Shift Left	X	X
Shift Right	X	X
Extended Shift Right		X
Shift Right Dividing Integer	X	



## INSTRUCTION SET OVERVIEW

**5.2.3.1 Add, Subtract, Multiply, Divide, Conditional Add, Conditional Subtract**

These instructions perform add, subtract, multiply or divide operations on integers and ordinals:

<b>addi</b>	Add Integer
<b>addo</b>	Add Ordinal
<b>ADD &lt;cc&gt;</b>	conditional add
<b>subi</b>	Subtract Integer
<b>subo</b>	Subtract Ordinal
<b>SUB&lt;cc&gt;</b>	Conditional Subtract
<b>muli</b>	Multiply Integer
<b>mulo</b>	Multiply Ordinal
<b>divi</b>	Divide Integer
<b>divo</b>	Divide Ordinal

**addi**, **ADDI<cc>**, **subi**, **SUBI<cc>**, **muli** and **divi** generate an integer-overflow fault when the result is too large to fit in the 32-bit destination. **divi** and **divo** generate a zero-divide fault when the divisor is zero.

**5.2.3.2 Remainder and Modulo**

These instructions divide one operand by another and retain the remainder of the operation:

<b>remi</b>	remainder integer
<b>remo</b>	remainder ordinal
<b>modi</b>	modulo integer

The difference between the remainder and modulo instructions lies in the sign of the result. For **remi** and **remo**, the result has the same sign as the dividend; for **modi**, the result has the same sign as the divisor.



### 5.2.3.3 Shift, Rotate and Extended Shift

These shift instructions shift an operand a specified number of bits left or right:

<b>shlo</b>	shift left ordinal
<b>shro</b>	shift right ordinal
<b>shli</b>	shift left integer
<b>shri</b>	shift right integer
<b>shrdi</b>	shift right dividing integer
<b>rotate</b>	rotate left
<b>eshro</b>	extended shift right ordinal

**5**

Except for **rotate**, these instructions discard bits shifted beyond the register boundary.

**shlo** shifts zeros in from the least significant bit; **shro** shifts zeros in from the most significant bit. These instructions are equivalent to **mulo** and **divo** by the power of 2, respectively.

**shli** shifts zeros in from the least significant bit. When the shift operation results in an overflow, an integer-overflow fault is generated (when enabled). The destination register is written with the source shifted as much as possible without overflow and an integer-overflow fault is signaled.

**shri** performs a conventional arithmetic shift right operation by extending the sign bit. However, when this instruction is used to divide a negative integer operand by the power of 2, it may produce an incorrect quotient. (Discarding the bits shifted out has the effect of rounding the result toward negative.)

**shrdi** is provided for dividing integers by the power of 2. With this instruction, 1 is added to the result when the bits shifted out are non-zero and the operand is negative, which produces the correct result for negative operands. **shli** and **shrdi** are equivalent to **muli** and **divi** by the power of 2, respectively, except in cases where an overflow error occurs.

**rotate** rotates operand bits to the left (toward higher significance) by a specified number of bits. Bits shifted beyond the register's left boundary (bit 31) appear at the right boundary (bit 0).

The **eshro** instruction performs an ordinal right shift of a source register pair (64 bits) by as much as 32 bits and stores the result in a single (32-bit) register. This instruction is equivalent to an extended divide by a power of 2, which produces no remainder. The instruction is also the equivalent of a 64-bit extract of 32 bits.

## INSTRUCTION SET OVERVIEW

## 5.2.3.4 Extended Arithmetic

These instructions support extended-precision arithmetic; i.e., arithmetic operations on operands greater than one word in length:

<b>addc</b>	add ordinal with carry
<b>subc</b>	subtract ordinal with carry
<b>emul</b>	extended multiply
<b>ediv</b>	extended divide

**addc** adds two word operands (literals or contained in registers) plus the AC Register condition code bit 1 (used here as a carry bit). When the result has a carry, bit 1 of the condition code is set; otherwise, it is cleared. This instruction's description in [CHAPTER 6, INSTRUCTION SET REFERENCE](#) gives an example of how this instruction can be used to add two long-word (64-bit) operands together.

**subc** is similar to **addc**, except it is used to subtract extended-precision values. Although **addc** and **subc** treat their operands as ordinals, the instructions also set bit 0 of the condition codes when the operation would have resulted in an integer overflow condition. This facilitates a software implementation of extended integer arithmetic.

**emul** multiplies two ordinals (each contained in a register), producing a long ordinal result (stored in two registers). **ediv** divides a long ordinal by an ordinal, producing an ordinal quotient and an ordinal remainder (stored in two adjacent registers).

## 5.2.4 Logical

These instructions perform bitwise Boolean operations on the specified operands:

<b>and</b>	<i>src2</i> AND <i>src1</i>
<b>notand</b>	(NOT <i>src2</i> ) AND <i>src1</i>
<b>andnot</b>	<i>src2</i> AND (NOT <i>src1</i> )
<b>xor</b>	<i>src2</i> XOR <i>src1</i>
<b>or</b>	<i>src2</i> OR <i>src1</i>
<b>nor</b>	NOT ( <i>src2</i> OR <i>src1</i> )
<b>xnor</b>	<i>src2</i> XNOR <i>src1</i>
<b>not</b>	NOT <i>src1</i>
<b>notor</b>	(NOT <i>src2</i> ) or <i>src1</i>
<b>ornot</b>	<i>src2</i> or (NOT <i>src1</i> )
<b>nand</b>	NOT ( <i>src2</i> AND <i>src1</i> )

All logical instructions use the REG format and can operate on literals or local or global registers.





## 5.2.5 Bit, Bit Field and Byte Operations

These instructions perform operations on a specified bit or bit field in an ordinal operand. All Bit, Bit Field and Byte instructions use the REG format and can operate on literals or local or global registers.

### 5.2.5.1 Bit Operations

These instructions operate on a specified bit:

<b>setbit</b>	set bit
<b>clrbt</b>	clear bit
<b>notbit</b>	invert bit
<b>alterbit</b>	alter bit
<b>scanbit</b>	scan for bit
<b>spanbit</b>	span over bit

**5**

- **setbit**, **clrbt** and **notbit** set, clear or complement (toggle) a specified bit in an ordinal.
- **alterbit** alters the state of a specified bit in an ordinal according to the condition code. When the condition code is 010<sub>2</sub>, the bit is set; when the condition code is 000<sub>2</sub>, the bit is cleared.
- **chkbit**, described in [section 5.2.6, “Comparison” \(pg. 5-12\)](#), can be used to check the value of an individual bit in an ordinal.
- **scanbit** and **spanbit** find the most significant set bit or clear bit, respectively, in an ordinal.

### 5.2.5.2 Bit Field Operations

The two bit field instructions are **extract** and **modify**.

- **extract** converts a specified bit field, taken from an ordinal value, into an ordinal value. In essence, this instruction shifts right a bit field in a register and fills in the bits to the left of the bit field with zeros. (**eshro** also provides the equivalent of a 64-bit extract of 32 bits).
- **modify** copies bits from one register into another register. Only masked bits in the destination register are modified. **modify** is equivalent to a bit field move.

### 5.2.5.3 Byte Operations

- **scanbyte** performs a byte-by-byte comparison of two ordinals to determine when any two corresponding bytes are equal. The condition code is set based on the results of the comparison. **scanbyte** uses the REG format and can specify literals or local or global registers as arguments.
- **bswap** alters the order of bytes in a word, reversing its “endianess.” For more information on this subject, see [section 13.6.2, “Selecting the Byte Order” \(pg. 13-12\)](#).

## INSTRUCTION SET OVERVIEW

## 5.2.6 Comparison

The processor provides several types of instructions for comparing two operands, as described in the following subsections.

## 5.2.6.1 Compare and Conditional Compare

These instructions compare two operands then set the condition code bits in the AC register according to the results of the comparison:

<b>cmpi</b>	Compare Integer
<b>cmpib</b>	Compare Integer Byte
<b>cmpis</b>	Compare Integer Short
<b>cmpo</b>	Compare Ordinal
<b>concmpi</b>	Conditional Compare Integer
<b>concmpo</b>	Conditional Compare Ordinal
<b>chkbit</b>	Check Bit

These all use the REG format and can specify literals or local or global registers. The condition code bits are set to indicate whether one operand is less than, equal to, or greater than the other operand. See [section 3.7.2, “Arithmetic Controls \(AC\) Register” \(pg. 3-18\)](#) for a description of the condition codes for conditional operations.

**cmpi** and **cmpo** simply compare the two operands and set the condition code bits accordingly. **concmpi** and **concmpo** first check the status of condition code bit 2:

- When not set, the operands are compared as with **cmpi** and **cmpo**.
- When set, no comparison is performed and the condition code flags are not changed.

The conditional-compare instructions are provided specifically to optimize two-sided range comparisons to check when A is between B and C (i.e.,  $B \leq A \leq C$ ). Here, a compare instruction (**cmpi** or **cmpo**) checks one side of the range (e.g.,  $A \geq B$ ) and a conditional compare instruction (**concmpi** or **concmpo**) checks the other side (e.g.,  $A \leq C$ ) according to the result of the first comparison. The condition codes following the conditional comparison directly reflect the results of both comparison operations. Therefore, only one conditional branch instruction is required to act upon the range check; otherwise, two branches would be needed.

**chkbit** checks a specified bit in a register and sets the condition code flags according to the bit state. The condition code is set to  $010_2$  when the bit is set and  $000_2$  otherwise.



### 5.2.6.2 Compare and Increment or Decrement

These instructions compare two operands, set the condition code bits according to the compare results, then increment or decrement one of the operands:

<b>cmpinci</b>	compare and increment integer
<b>cmpinco</b>	compare and increment ordinal
<b>cmpdeci</b>	compare and decrement integer
<b>cmpdeco</b>	compare and decrement ordinal

These all use the REG format and can specify literals or local or global registers. They are an architectural performance optimization which allows two register operations (e.g., compare and add) to execute in a single cycle. The intended use of these instructions is at the end of iterative loops.

**5**

### 5.2.6.3 Test Condition Codes

These test instructions allow the state of the condition code flags to be tested:

<b>teste</b>	test for equal
<b>testne</b>	test for not equal
<b>testl</b>	test for less
<b>testle</b>	test for less or equal
<b>testg</b>	test for greater
<b>testge</b>	test for greater or equal
<b>testo</b>	test for ordered
<b>testno</b>	test for unordered

When the condition code matches the instruction-specified condition, a TRUE (0000 0001H) is stored in a destination register; otherwise, a FALSE (0000 0000H) is stored. All use the COBR format and can operate on local and global registers.

## 5.2.7 Branch

Branch instructions allow program flow direction to be changed by explicitly modifying the IP. The processor provides three branch instruction types:

- unconditional branch
- conditional branch
- compare and branch

Most branch instructions specify the target IP by specifying a signed *displacement* to be added to the current IP. Other branch instructions specify the target IP's memory address, using one of the processor's addressing modes. This latter group of instructions is called extended addressing instructions (e.g., branch extended, branch-and-link extended).

### 5.2.7.1 Unconditional Branch

These instructions are used for unconditional branching:

<b>b</b>	Branch
<b>bx</b>	Branch Extended
<b>bal</b>	Branch and Link
<b>balx</b>	Branch and Link Extended

**b** and **bal** use the CTRL format. **bx** and **balx** use the MEM format and can specify local or global registers as operands. **b** and **bx** cause program execution to jump to the specified target IP. These two instructions perform the same function; however, their determination of the target IP differs. The target IP of a **b** instruction is specified at link time as a relative *displacement* from the current IP. The target IP of the **bx** instruction is the absolute address resulting from the instruction's use of a memory-addressing mode during execution.

**bal** and **balx** store the next instruction's address in a specified register, then jump to the specified target IP. (For **bal**, the RIP is automatically stored in register g14; for **balx**, the RIP location is specified with an instruction operand.) As described in [section 7.9, "BRANCH-AND-LINK" \(pg. 7-21\)](#), branch and link instructions provide a method of performing procedure calls that do not use the processor's integrated call/return mechanism. Here, the saved instruction address is used as a return IP. Branch and link is generally used to call leaf procedures (that is, procedures that do not call other procedures).

**bx** and **balx** can make use of any memory-addressing mode.



### 5.2.7.2 Conditional Branch

With conditional branch (**BRANCH IF**) instructions, the processor checks the AC register condition code flags. When these flags match the value specified with the instruction, the processor jumps to the target IP. These instructions use the *displacement-plus-ip* method of specifying the target IP:

<b>be</b>	branch if equal/true
<b>bne</b>	branch if not equal
<b>bl</b>	branch if less
<b>ble</b>	branch if less or equal
<b>bg</b>	branch if greater
<b>bge</b>	branch if greater or equal
<b>bo</b>	branch if ordered
<b>bno</b>	branch if unordered/false

5

All use the CTRL format. **bo** and **bno** are used with real numbers. **bno** can also be used with the result of a **chkbit** or **scanbit** instruction. Refer to [section 3.7.2.2, “Condition Code \(AC.cc\)”](#) (pg. 3-19) for a discussion of the condition code for conditional operations.

### 5.2.7.3 Compare and Branch

These instructions compare two operands then branch according to the comparison result. Three instruction subtypes are compare integer, compare ordinal and branch on bit:

<b>cmpibe</b>	compare integer and branch if equal
<b>cmpibne</b>	compare integer and branch if not equal
<b>cmpibl</b>	compare integer and branch if less
<b>cmpible</b>	compare integer and branch if less or equal
<b>cmpibg</b>	compare integer and branch if greater
<b>cmpibge</b>	compare integer and branch if greater or equal
<b>cmpibo</b>	compare integer and branch if ordered
<b>cmpibno</b>	compare integer and branch if unordered
<b>cmpobe</b>	compare ordinal and branch if equal
<b>cmpobne</b>	compare ordinal and branch if not equal
<b>cmpobl</b>	compare ordinal and branch if less
<b>cmpoble</b>	compare ordinal and branch if less or equal
<b>cmpobg</b>	compare ordinal and branch if greater
<b>cmpobge</b>	compare ordinal and branch if greater or equal
<b>bbs</b>	check bit and branch if set
<b>bbc</b>	check bit and branch if clear

## INSTRUCTION SET OVERVIEW

All use the COBR machine instruction format and can specify literals, local or global registers as operands. With compare ordinal and branch (**compob\***) and compare integer and branch (**compib\***) instructions, two operands are compared and the condition code bits are set as described in [section 5.2.6, “Comparison” \(pg. 5-12\)](#). A conditional branch is then executed as with the conditional branch (**BRANCH IF**) instructions.

With check bit and branch instructions (**bbs, bbc**), one operand specifies a bit to be checked in the second operand. The condition code flags are set according to the state of the specified bit:  $010_2$  (true) when the bit is set and  $000_2$  (false) when the bit is clear. A conditional branch is then executed according to condition code bit settings.

These instructions can be used to optimize execution performance time. When it is not possible to separate adjacent compare and branch instructions from other unrelated instructions, replacing two instructions with a single compare and branch instruction increases performance.

### 5.2.8 Call/Return

The i960 Jx processor offers an on-chip call/return mechanism for making procedure calls. Refer to [section 7.1, “CALL AND RETURN MECHANISM” \(pg. 7-2\)](#). The following instructions support this mechanism:

<b>call</b>	call
<b>callx</b>	call extended
<b>calls</b>	call system
<b>ret</b>	return

**call** and **ret** use the CTRL machine-instruction format. **callx** uses the MEM format and can specify local or global registers. **calls** uses the REG format and can specify local or global registers.

**call** and **callx** make local calls to procedures. A local call is a call that does not require a switch to another stack. **call** and **callx** differ only in the method of specifying the target procedure’s address. The target procedure of a call is determined at link time and is encoded in the opword as a signed *displacement* relative to the call IP. **callx** specifies the target procedure as an absolute 32-bit address calculated at run time using any one of the addressing modes. For both instructions, a new set of local registers and a new stack frame are allocated for the called procedure.

**calls** is used to make calls to system procedures — procedures that provide a kernel or system-executive service. This instruction operates similarly to **call** and **callx**, except that it gets its target-procedure address from the system procedure table. An index number included as an operand in the instruction provides an entry point into the procedure table.



Depending on the type of entry being pointed to in the system procedure table, **calls** can cause either a system-supervisor call or a system-local call to be executed. A system-supervisor call is a call to a system procedure that switches the processor to supervisor mode and switches to the supervisor stack. A system-local call is a call to a system procedure that does not cause an execution mode or stack change. Supervisor mode is described throughout [CHAPTER 7, PROCEDURE CALLS](#).

**ret** performs a return from a called procedure to the calling procedure (the procedure that made the call). **ret** obtains its target IP (return IP) from linkage information that was saved for the calling procedure. **ret** is used to return from all calls — including local and supervisor calls — and from implicit calls to interrupt and fault handlers.

### 5.2.9 Faults

Generally, the processor generates faults automatically as the result of certain operations. Fault handling procedures are then invoked to handle various fault types without explicit intervention by the currently running program. These conditional fault instructions permit a program to explicitly generate a fault according to the state of the condition code flags. All use the CTRL format.

<b>faulte</b>	fault if equal
<b>faultne</b>	fault if not equal
<b>faultl</b>	fault if less
<b>faultle</b>	fault if less or equal
<b>faultg</b>	fault if greater
<b>faultge</b>	fault if greater or equal
<b>faulto</b>	fault if ordered
<b>faultno</b>	fault if unordered

The **syncf** instruction ensures that any faults that occur during the execution of prior instructions occur before the instruction that follows the **syncf**. **syncf** uses the REG format and requires no operands.

### 5.2.10 Debug

The processor supports debugging and monitoring of program activity through the use of trace events. The following instructions support these debugging and monitoring tools:

<b>modtc</b>	modify trace controls
<b>mark</b>	mark
<b>fmark</b>	force mark

These all use the REG format. Trace functions are controlled with bits in the Trace Control (TC) register which enable or disable various types of tracing. Other TC register flags indicate when an enabled trace event is detected. Refer to [CHAPTER 9, TRACING AND DEBUGGING](#).

**modtc** permits trace controls to be modified. **mark** causes a breakpoint trace event to be generated when breakpoint trace mode is enabled. **fmark** generates a breakpoint trace independent of the state of the breakpoint trace mode bits.

Other instructions that are helpful in debugging include **modpc** and **sysctl**. The **modpc** instruction can enable/disable trace fault generation. The **sysctl** instruction also provides control over breakpoint trace event generation. This instruction is used, in part, to load and control the i960 Jx processor's breakpoint registers.

### 5.2.11 Atomic Instructions

Atomic instructions perform an atomic read-modify-write operation on operands in memory. An atomic operation is one in which other memory operations are forced to occur before or after, but not during, the accesses that comprise the atomic operation. These instructions are required to enable synchronization between interrupt handlers and background tasks in any system. They are also particularly useful in systems where several agents — processors, coprocessors or external logic — have access to the same system memory for communication.

The atomic instructions are atomic add (**atadd**) and atomic modify (**atmod**). **atadd** causes an operand to be added to the value in the specified memory location. **atmod** causes bits in the specified memory location to be modified under control of a mask. Both instructions use the REG format and can specify literals or local or global registers as operands. These instructions assert the LOCK signal.





### 5.2.12 Processor Management

These instructions control processor-related functions:

<b>modpc</b>	Modify the Process Controls register
<b>flushreg</b>	Flush cached local register sets to memory
<b>modac</b>	Modify the Arithmetic Controls register
<b>sysctl</b>	Perform system control function
<b>halt</b>	Halt processor
<b>inten</b>	Global interrupt enable
<b>intdis</b>	Global interrupt disable
<b>intctl</b>	Global interrupt enable and disable
<b>icctl</b>	instruction cache control
<b>dcctl</b>	data cache control

**5**

All use the REG format and can specify literals or local or global registers.

**modpc** provides a method of reading and modifying PC register contents. Only programs operating in supervisor mode may modify the PC register; however, any program may read it.

The processor provides a flush local registers instruction (**flushreg**) to save the contents of the cached local registers to the stack. The flush local registers instruction automatically stores the contents of all the local register sets — except the current set — in the register save area of their associated stack frames.

The modify arithmetic controls instruction (**modac**) allows the AC register contents to be copied to a register and/or modified under the control of a mask. The AC register cannot be explicitly addressed with any other instruction; however, it is implicitly accessed by instructions that use the condition codes or set the integer overflow flag.

**sysctl** is used to configure the interrupt controller, breakpoint registers and instruction cache. It also permits software to signal an interrupt or cause a processor reset and reinitialization. **sysctl** may be executed only by programs operating in supervisor mode.

**halt** puts the processor in low-power Halt mode. **intctl**, **inten** and **intdis** are used to enable and disable interrupts and to determine current interrupt enable status.

**icctl** and **dcctl** provide cache control functions including: enabling, disabling, loading and locking (instruction cache only), invalidating, getting status and storing cache information out to memory.

### 5.3 PERFORMANCE OPTIMIZATION

Performance optimization are categorized into two sections: instructions optimizations and miscellaneous optimizations.

#### 5.3.1 Instruction Optimizations

The instruction optimizations are broken down by the instruction classification.

##### 5.3.1.1 Load / Store Execution Model

Because the i960 Jx processor has a 32-bit external data bus, multiple word accesses require multiple cycles. The processor uses microcode to sequence the multi-word accesses. Because the microcode can ensure that aligned multi-words are bursted together on the external bus, software should not substitute multiple single-word instructions for one multi-word instruction for data that is not likely to be in cache. For example a **ldq** provides better bus performance than four **ld** instructions.

Once a load is issued, the processor attempts to execute other instructions while the load is outstanding. It is important to note that when the load misses the data cache, the processor does not stall the issuing of subsequent instructions (other than stores) that do not depend on the load.

Software should avoid following a load with an instruction that depends on the result of the load. For a load that hits the data cache, there is a one-cycle stall when the instruction immediately after the load requires the data. When the load fails to hit the data cache, the instruction depending on the load stalls until the outstanding load request is resolved.

Multiple, back-to-back load instructions do not stall the processor until the bus queue becomes full.

The processor delays issuing a store instruction until all previously-issued load instructions complete. This happens regardless of whether the store is dependent on the load. This ordering between loads and stores ensures that the return data from a previous cache-read miss does not overwrite the cache line updated by a subsequent store.

##### 5.3.1.2 Compare Operations

Byte and short word data is more efficiently compared using the new byte and short compare instructions (**cmpob**, **cmpib**, **cmpos**, **cmpis**), rather than shifting the data and using a word compare instruction.



**5.3.1.3 Microcoded Instructions**

While the majority of instructions on the i960 Jx processor are single cycle and are executed directly by processor hardware, some require microcode emulation. Entry into a microcode routine requires two cycles. Exit from microcode typically requires two cycles. For some routines, one cycle of the exit process can execute in parallel with another instruction, thus saving one cycle of execution time.

**5.3.1.4 Multiply-Divide Unit Instructions**

The Multiply-Divide Unit (MDU) of the i960 Jx processor performs a number of multi-cycle arithmetic operations. These can range from 2 cycles for a 16-bitx32-bit **mulo**, 4 cycles for a 32-bitx32-bit **mulo**, to 30+ cycles for an **ediv**.

5

Once issued, these MDU instructions are executed in parallel with other non-MDU instructions that do not depend on the result of the MDU operation. Attempting to issue another MDU instruction while a current MDU instruction is executing, stalls the processor until the first one completes.

**5.3.1.5 Multi-Cycle Register Operations**

A few register operations can also take multiple cycles. The following instructions are all performed in microcode:

- **bswap**      • **extract**      • **eshro**      • **modify**      • **movl**      • **movt**
- **movq**      • **shrldi**      • **scanbit**      • **spanbit**      • **testno**      • **testo**
- **testl**      • **testle**      • **teste**      • **testne**      • **testg**      • **testge**

On the i960 Jx processor, **test<cc> dst** is microcoded and takes many more cycles than **SEL<cc> 0,1,dst**, which is executed in one cycle directly by processor hardware.

Multi-register move operation execution time can be decreased at the expense of cache utilization and code density by using **mov** the appropriate number of times instead of **movl**, **movt** and **movq** instructions.



## INSTRUCTION SET OVERVIEW

**5.3.1.6 Simple Control Transfer**

There is no branch lookahead or branch prediction mechanism on the i960 Jx processor. Simple branch instructions take one cycle to execute, and one more cycle is needed to fetch the target instruction when the branch is actually taken.

**b, bal, bno, bo, bl, ble, be, bne, bg, bge**

One mode of the **bx** (branch-extended) instruction, **bx** (base), is also a simple branch and takes one cycle to execute and one cycle to fetch the target.

As a result, a **bal (g14)** or **bx (g14)** sequence provides a two-cycle call and return mechanism for efficient leaf procedure implementation.

Compare-and-branch instructions have been optimized on the i960 Jx processor. They require 2 cycles to execute, and one more cycle to fetch the target instruction when the branch is actually taken. The instructions are:

- **cmpobno**    • **cmpobo**    • **cmpobl**    • **cmpoble**    • **cmpobe**    • **cmpobne**
- **cmpobg**    • **cmpobge**    • **cmpibno**    • **cmpibo**    • **cmpibl**    • **cmpible**
- **cmpibe**    • **cmpibg**    • **cmpibne**    • **cmpibge**    • **bbc**    • **bbs**

**5.3.1.7 Memory Instructions**

The i960 Jx processor provides efficient support for naturally aligned byte, short, and word accesses that use one of 6 optimized addressing modes. These accesses require only 1 to 2 cycles to execute; additional cycles are needed for a load to return its data.

The byte, short and word memory instructions are:

**ldob, ldib, ldos, ldis, ld, lda stob, stib, stos, stis, st**

The remainder of accesses require multiple cycles to execute. These include:

- Unaligned short, and word accesses
- Byte, short, and word accesses that do not use one of the 6 optimized addressing modes
- Multi-word accesses

The multi-word accesses are:

**ldl, ldt, ldq, stl, stt, stq**



### 5.3.1.8 Unaligned Memory Accesses

Unaligned memory accesses are performed by microcode. Microcode sequences the access into smaller aligned pieces and merges the data as needed. As a result, these accesses are not as efficient as aligned accesses. In addition, no bursting on the external bus is performed for these accesses. Whenever possible, unaligned accesses should be avoided.

### 5.3.2 Miscellaneous Optimizations

#### 5.3.2.1 Masking of Integer Overflow

The i960 core architecture inserts an implicit **syncf** before performing a call operation or delivering an interrupt so that a fault handler can be dispatched first, when necessary. The **syncf** can require a number of cycles to complete when a multi-cycle integer-multiply (**multi**) or integer-divide (**divi**) instruction was issued previously and integer-overflow faults are unmasked (allowed to occur). Call performance and interrupt latency can be improved by masking integer-overflow faults (AC.om = 1), which allows the implicit **syncf** to complete more quickly.

5

#### 5.3.2.2 Avoid Using PFP, SP, R3 As Destinations for MDU Instructions

When performing a call operation or delivering an interrupt, the processor typically attempts to push the first four local registers (pfp, sp, rip, and r3) onto the local register cache as early as possible. Because of register-interlock, this operation stalls until previous instructions return their results to these registers. In most cases, this is not a problem; however, in the case of multi-cycle instructions (**divo**, **divi**, **ediv**, **modi**, **remo**, and **remi**), the processor could be stalled for many cycles waiting for the result and unable to proceed to the next step of call processing or interrupt delivery.

Call performance and interrupt latency can be improved by avoiding the first four registers as the destination for a MDU instruction. Generally, registers pfp, sp, and rip should be avoided they are used for procedure linking.

#### 5.3.2.3 Use Global Registers (g0 - g14) As Destinations for MDU Instructions

Using the same rationale as in the previous item, call processing and interrupt performance are improved even further by using global registers (g0-g14) as the destination for multi-cycle MDU instructions. This is because there is no dependency between g0-g14 and implicit or explicit call operations (i.e., global registers are not pushed onto the local register cache).

#### 5.3.2.4 Execute in Imprecise Fault Mode

Significant performance improvement is possible by allowing imprecise faults ( $AC.nif = 0$ ). In precise fault mode ( $AC.nif = 1$ ), the processor does not issue a new instruction until the previous one has completed. This ensures that a fault from the previous instruction is delivered before the next instruction can begin execution. Imprecise fault mode allows new instructions to be issued before previous ones have completed, thus increasing the instruction issue rate. Many applications can tolerate the imprecise fault reporting for the performance gain. When necessary, a **syncf** can be used in imprecise fault mode to isolate faults at desired points of execution.





6

# INSTRUCTION SET REFERENCE









# CHAPTER 6

## INSTRUCTION SET REFERENCE

This chapter provides detailed information about each instruction available to the i960<sup>®</sup> Jx processor. Instructions are listed alphabetically by assembly language mnemonic. Format and notation used in this chapter are defined in [section 6.1, “NOTATION”](#) (pg. 6-1).

Information in this chapter is oriented toward programmers who write assembly language code for the i960 Jx processor. Information provided for each instruction includes:

- Alphabetic listing of all instructions
- Assembly language mnemonic, name and format
- Description of the instruction’s operation
- Opcode and instruction encoding format
- Faults that can occur during execution
- Action (or algorithm) and other side effects of executing an instruction
- Assembly language example
- Related instructions



Additional information about the instruction set can be found in the following chapters and appendices in this manual:

- [CHAPTER 5, INSTRUCTION SET OVERVIEW](#) - Summarizes the instruction set by group and describes the assembly language instruction format.
- [APPENDIX B, OPCODES AND EXECUTION TIMES](#) - A quick-reference listing of instruction encodings assists debugging with a logic analyzer.
- [APPENDIX C, MACHINE-LEVEL INSTRUCTION FORMATS](#) - Describes instruction set opword encodings.
- [i960 Jx PROCESSOR INSTRUCTION SET QUICK REFERENCE](#) (order number 272597) A pocket-sized quick reference to all instructions.

### 6.1 NOTATION

In general, notation in this chapter is consistent with usage throughout the manual; however, there are a few exceptions. Read the following subsections to understand notations that are specific to this chapter.



## INSTRUCTION SET REFERENCE

### 6.1.1 Alphabetic Reference

Instructions are listed alphabetically by assembly language mnemonic. When several instructions are related and fall together alphabetically, they are described as a group on a single page.

The instruction's assembly language mnemonic is shown in bold at the top of the page (e.g., **subc**). Occasionally, it is not practical to list all mnemonics at the page top. In these cases, the name of the instruction group is shown in capital letters (e.g., **BRANCH<cc>** or **FAULT<cc>**).

The i960 Jx processor-specific extensions to the i960 microprocessor instruction set are indicated in the header text for each such instruction. This type of notation is also used to indicate new core architecture instructions. Sections describing new core instructions provide notes as to which i960-series processors do not implement these instructions.

Generally, instruction set extensions are not portable to other i960 processor implementations. Further, new core instructions are not typically portable to earlier i960 processor family implementations such as the i960 Kx microprocessors.

### 6.1.2 Mnemonic

The *Mnemonic* section gives the mnemonic (in boldface type) and instruction name for each instruction covered on the page, for example:

**subi** Subtract Integer

This mnemonic is the actual assembly language instruction name recognized by assemblers.

### 6.1.3 Format

The *Format* section gives the instruction's assembly language format and allowable operand types. Format is given in two or three lines. The following is a two-line format example:

<b>sub*</b>	<i>src1</i>	<i>src2</i>	<i>dst</i>
	reg/lit	reg/lit	reg

The first line gives the assembly language mnemonic (boldface type) and operands (italics). When the format is used for two or more instructions, an abbreviated form of the mnemonic is used. An \* (asterisk) at the end of the mnemonic indicates a variable: in the above example, **sub\*** is either **subi** or **subo**. Capital letters indicate an instruction class. For example, **ADD<cc>** refers to the class of conditional add instructions (e.g., **addio**, **addig**, **addoo**, **addog**).

Operand names are designed to describe operand function (e.g., *src*, *len*, *mask*).

The second line shows allowable entries for each operand. Notation is as follows:



reg Global (g0 ... g15) or local (r0 ... r15) register  
 lit Literal of the range 0 ... 31  
 disp Signed displacement of range  $(-2^{22} \dots 2^{22} - 1)$   
 mem Address defined with the full range of addressing modes

In some cases, a third line is added to show register or memory location contents. For example, it may be useful to know that a register is to contain an address. The notation used in this line is as follows:

addr Address  
 efa Effective Address

#### 6.1.4 Description

6

The *Description* section is a narrative description of the instruction's function and operands. It also gives programming hints when appropriate.

#### 6.1.5 Action

The *Action* section gives an algorithm written in a "C-like" pseudo-code that describes direct effects and possible side effects of executing an instruction. Algorithms document the instruction's net effect on the programming environment; they do not necessarily describe how the processor actually implements the instruction. The following is an example of the action algorithm for the **alterbit** instruction:

```
if((AC.cc & 0102)==0)
    dst = src2 & ~(2**(src1%32));
else
    dst = src2 | 2**(src1%32);
```

[Table 6-1](#) defines each abbreviation used in the instruction reference pseudo-code. The pseudo-code has been written to comply as closely as possible with standard C programming language notation.

**Table 6-1. Pseudo-Code Symbol Definitions**

=	Assignment
==, !=	Comparison: equal, not equal
<, >	less than, greater than
<=, >=	less than or equal to, greater than or equal to
<<, >>	Logical Shift
**	Exponentiation
&, &&	Bitwise AND, logical AND
,	Bitwise OR, logical OR
^	Bitwise XOR
~	One's Complement
%	Modulo
+, -	Addition, Subtraction
*	Multiplication (Integer or Ordinal)
/	Division (Integer or Ordinal)
#	Comment delimiter

**Table 6-2. Faults Applicable to All Instructions**

<b>Fault Type</b>	<b>Subtype</b>	<b>Description</b>
TRACE	MARK	A Mark Trace Event is signaled after completion of an instruction for which there is a hardware breakpoint condition match. A Trace fault is generated when TC.mk is set.
	INSTRUCTION	An Instruction Trace Event is signaled after instruction completion. A Trace fault is generated when both PC.te and TC.i=1.



**Table 6-3. Common Faulting Conditions**

Fault Type	Subtype	Description
OPERATION	UNALIGNED	Any instruction that causes an unaligned memory access causes an operation aligned fault when unaligned faults are not masked in the fault configuration word in the Processor Control Block (PRCB).
	INVALID_OPCODE	This fault is generated when the processor attempts to execute an instruction containing an undefined opcode or addressing mode.
	INVALID_OPERAND	This fault is caused by a non-defined operand in a supervisor mode only instruction or by an operand reference to an unaligned long-, triple- or quad-register group.
	UNIMPLEMENTED	This fault can occur due to an attempt to perform a non-word or unaligned access to a memory-mapped region or when trying to fetch instructions from MMR space or internal data RAM.
TYPE	MISMATCH	Any instruction that attempts to write to supervisor protected internal data RAM or a memory-mapped register in supervisor space while not in supervisor mode causes a TYPE.MISMATCH fault.

6

**6.1.6 Faults**

The *Faults* section lists faults that can be signaled as a direct result of instruction execution. [Table 6-2](#) shows the possible faulting conditions that are common to the entire instruction set and could directly result from any instruction. These fault types are not included in the instruction reference. [Table 6-3](#) shows the possible faulting conditions that are common to large subsets of the instruction set. When an instruction can generate a fault, it is noted in that instruction’s *Faults* section. In these sections, “Standard” refers to the faults shown in [Table 6-2](#) and [Table 6-3](#).

**6.1.7 Example**

The *Example* section gives an assembly language example of an application of the instruction.



## INSTRUCTION SET REFERENCE

### 6.1.8 Opcode and Instruction Format

The *Opcode and Instruction Format* section gives the opcode and instruction format for each instruction, for example:

```
subi 593H REG
```

The opcode is given in hexadecimal format. The format is one of four possible formats: REG, COBR, CTRL and MEM. Refer to [APPENDIX C, MACHINE-LEVEL INSTRUCTION FORMATS](#) for more information on the formats.

### 6.1.9 See Also

The *See Also* section gives the mnemonics of related instructions which are also alphabetically listed in this chapter.

### 6.1.10 Side Effects

This section indicates whether the instruction causes changes to the condition code bits in the Arithmetic Controls.

### 6.1.11 Notes

This section provides additional information about an instruction such as whether it is implemented in other i960 processor families.

## 6.2 INSTRUCTIONS

The processor's instructions are arranged alphabetically by instruction or instruction group.



6.2.1 ADD<cc>

Mnemonic:     **addono**     Add Ordinal if Unordered  
                   **addog**        Add Ordinal if Greater  
                   **addoe**        Add Ordinal if Equal  
                   **addoge**     Add Ordinal if Greater or Equal  
                   **addol**        Add Ordinal if Less  
                   **addone**     Add Ordinal if Not Equal  
                   **addole**     Add Ordinal if Less or Equal  
                   **addoo**        Add Ordinal if Ordered  
                   **addino**     Add Integer if Unordered  
                   **addig**        Add Integer if Greater  
                   **addie**        Add Integer if Equal  
                   **addige**     Add Integer if Greater or Equal  
                   **addil**        Add Integer if Less  
                   **addine**     Add Integer if Not Equal  
                   **addile**     Add Integer if Less or Equal  
                   **addio**        Add Integer if Ordered

Format:         **add\***        *src1*,            *src2*,            *dst*  
                                   reg/lit            reg/lit            reg

Description:    Conditionally adds *src2* and *src1* values and stores the result in *dst* based on the AC register condition code. When for Unordered the condition code is 0, or when for all other cases the logical AND of the condition code and the mask part of the opcode is not 0, then the values are added and placed in the destination. Otherwise the destination is left unchanged. [Table 6-4](#) shows the condition code mask for each instruction. The mask is in opcode bits 4-6.



**Table 6-4. Condition Code Mask Descriptions**

Instruction	Mask	Condition
<b>addono</b>	000 <sub>2</sub>	Unordered
<b>addino</b>		
<b>addog</b>	001 <sub>2</sub>	Greater
<b>addig</b>		
<b>addoe</b>	010 <sub>2</sub>	Equal
<b>addie</b>		
<b>addoge</b>	011 <sub>2</sub>	Greater or equal
<b>addige</b>		
<b>addol</b>	100 <sub>2</sub>	Less
<b>addil</b>		



Table 6-4. Condition Code Mask Descriptions

Instruction	Mask	Condition
<b>addone</b>	101 <sub>2</sub>	Not equal
<b>addine</b>		
<b>addole</b>	110 <sub>2</sub>	Less or equal
<b>addile</b>		
<b>addoo</b>	111 <sub>2</sub>	Ordered
<b>addio</b>		

Action:

**addo<cc>:**

```
if((mask & AC.cc) || (mask == AC.cc))
    dst = (src1 + src2)[31:0];
```

**addi<cc>:**

```
if((mask & AC.cc) || (mask == AC.cc))
{
    {   true_result = (src1 + src2);
        dst = true_result[31:0];
    }
    if((true_result > (2**31) - 1) || (true_result < -2**31))
        # Check for overflow
    {   if(AC.om == 1)
        AC.of = 1;
        else
            generate_fault(ARITHMETIC.OVERFLOW);
    }
}
```

Faults:

STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).  
 ARITHMETIC.OVERFLOW Occurs only with **addi<cc>**.

Example:

```
# Assume (AC.cc AND 0012) ≠ 0.
addig r4, r8, r10    # r10 = r8 + r4

# Assume (AC.cc AND 1012) = 0.
addone r4, r8, r10   # r10 is not changed.
```







Opcode:	<b>addno</b>	780H	REG
	<b>addog</b>	790H	REG
	<b>addoe</b>	7A0H	REG
	<b>addoge</b>	7B0H	REG
	<b>addol</b>	7C0H	REG
	<b>addone</b>	7D0H	REG
	<b>addole</b>	7E0H	REG
	<b>addoo</b>	7F0H	REG
	<b>addino</b>	781H	REG
	<b>addig</b>	791H	REG
	<b>addie</b>	7A1H	REG
	<b>addige</b>	7B1H	REG
	<b>addil</b>	7C1H	REG
	<b>addine</b>	7D1H	REG
	<b>addile</b>	7E1H	REG
	<b>addio</b>	7F1H	REG



See Also: **addc, SUB<cc>, addi, addo**

Notes: This class of core instructions is not implemented on 80960Cx, Kx and Sx processors.



**6.2.2 addc**

Mnemonic: **addc** Add Ordinal With Carry

Format: **addc** *src1*, *src2*, *dst*  
 reg/lit reg/lit reg

Description: Adds *src2* and *src1* values and condition code bit 1 (used here as a carry-in) and stores the result in *dst*. When ordinal addition results in a carry out, condition code bit 1 is set; otherwise, bit 1 is cleared. When integer addition results in an overflow, condition code bit 0 is set; otherwise, bit 0 is cleared. Regardless of addition results, condition code bit 2 is always set to 0.

**addc** can be used for ordinal or integer arithmetic. **addc** does not distinguish between ordinal and integer source operands. Instead, the processor evaluates the result for both data types and sets condition code bits 0 and 1 accordingly.

An integer overflow fault is never signaled with this instruction.

Action:  $dst = (src1 + src2 + AC.cc[1])[31:0];$   
 $AC.cc[2:0] = 000_2;$   
 $if((src2[31] == src1[31]) \&\& (src2[31] != dst[31]))$   
      $AC.cc[0] = 1;$  # Set overflow bit.  
 $AC.cc[1] = (src2 + src1 + AC.cc[1])[32];$  # Carry out.

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: # Example of double-precision arithmetic.  
 # Assume 64-bit source operands  
 # in g0,g1 and g2,g3  
 cmpo 1, 0 # Clears Bit 1 (carry bit) of  
           # the AC.cc.  
 addc g0, g2, g0 # Add low-order 32 bits:  
                   # g0 = g2 + g0 + carry bit  
 addc g1, g3, g1 # Add high-order 32 bits:  
                   # g1 = g3 + g1 + carry bit  
                   # 64-bit result is in g0, g1.

Opcode: **addc** 5B0H REG

See Also: **ADD<cc>**, **SUB<cc>**, **subc**, **addi**, **addo**

Side Effects: Sets the condition code in the arithmetic controls.

6.2.3 **addi, addo**

Mnemonic:       **addo**       Add Ordinal  
                   **addi**       Add Integer

Format:           **add\***       *src1*,           *src2*,           *dst*  
                                       reg/lit            reg/lit            reg

Description:       Adds *src2* and *src1* values and stores the result in *dst*. The binary results from these two instructions are identical. The only difference is that **addi** can signal an integer overflow.

Action:           **addo:**  
                       dst = (src2 +src1)[31:0];

**addi:**  
 true\_result = (src1 + src2);  
 dst = true\_result[31:0];  
 if((true\_result > (2\*\*31) - 1) || (true\_result < -2\*\*31))# Check for overflow  
 {    if(AC.om == 1)  
       AC.of = 1;  
       else  
           generate\_fault(ARITHMETIC.OVERFLOW);  
       }  
 }



Faults:           STANDARD                   Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).  
                   ARITHMETIC.OVERFLOW   Occurs only with **addi**.

Example:          **addi** r4, g5, r9       # r9 = g5 + r4

Opcode:           **addo**       590H           REG  
                   **addi**       591H           REG

See Also:         **addc, subi, subo, subc, ADD<cc>**



## INSTRUCTION SET REFERENCE

### 6.2.4 alterbit

Mnemonic:	<b>alterbit</b>	Alter Bit		
Format:	<b>alterbit</b>	<i>bitpos</i> , reg/lit	<i>src</i> , reg/lit	<i>dst</i> reg
Description:	Copies <i>src</i> value to <i>dst</i> with one bit altered. <i>bitpos</i> operand specifies bit to be changed; condition code determines the value to which the bit is set. When condition code is $X1X_2$ , bit 1 = 1, the selected bit is set; otherwise, it is cleared. Typically this instruction is used to set the <i>bitpos</i> bit in the <i>targ</i> register when the result of a compare instruction is the equal condition code ( $010_2$ ).			
Action:	<pre>if((AC.cc &amp; 010<sub>2</sub>)==0)     dst = src &amp; ~(2**(bitpos%32)); else     dst = src   2**(bitpos%32);</pre>			
Faults:	STANDARD	Refer to <a href="#">section 6.1.6, "Faults"</a> (pg. 6-5).		
Example:	<pre># Assume AC.cc = 010<sub>2</sub> alterbit 24, g4,g9 # g9 = g4, with bit 24 set.</pre>			
Opcode:	<b>alterbit</b>	58FH	REG	
See Also:	<b>chkbit, clrbit, notbit, setbit</b>			

**6.2.5 and, andnot**

Mnemonic: **and** And  
**andnot** And Not

Format: **and** *src1*, *src2*, *dst*  
reg/lit reg/lit reg  
**andnot** *src1*, *src2*, *dst*  
reg/lit reg/lit reg

Description: Performs a bitwise AND (**and**) or AND NOT (**andnot**) operation on *src2* and *src1* values and stores result in *dst*. Note in the action expressions below, *src2* operand comes first, so that with **andnot** the expression is evaluated as:

{*src2* and not (*src1*)}  
rather than  
{*src1* and not (*src2*)}.



Action: **and:**  
dst = src2 & src1;

**andnot:**  
dst = src2 & ~src1;

Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example: and 0x7, g8, g2 # Put lower 3 bits of g8 in g2.  
andnot 0x7, r12, r9 # Copy r12 to r9 with lower  
# three bits cleared.

Opcode: **and** 581H REG  
**andnot** 582H REG

See Also: **nand, nor, not, notand, notor, or, ornot, xnor, xor**



**6.2.6 atadd**

Mnemonic: **atadd** Atomic Add

Format: **atadd** *addr*, *src*, *dst*  
 reg reg/lit reg

Description: Adds *src* value (full word) to value in the memory location specified with *addr* operand. This read-modify-write operation is performed on the actual data in memory and never on a cached value on chip. Initial value from memory is stored in *dst*.

Memory read and write are done atomically (i.e., other bus masters must be prevented from accessing the word of memory containing the word specified by *src/dst* operand until operation completes). See [section 3.5.1, “Memory Requirements”](#) (pg. 3-14) or more information on atomic accesses.

Memory location in *addr* is the word’s first byte (LSB) address. Address is automatically aligned to a word boundary. (Note that *addr* operand maps to *src1* operand of the REG format.)

Action: `implicit_syncf();`  
`tempa = addr & 0xFFFFFFFFFC;`  
`temp = atomic_read(tempa);`  
`atomic_write(tempa, temp+src);`  
`dst = temp;`

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: `atadd r8, r3, r11` # r8 contains the address of  
 # memory location.  
 # r11 = (r8)  
 # (r8) = r11 + r3.

Opcode: **atadd** 612H REG

See Also: **atmod**

**6.2.7 atmod**

Mnemonic: **atmod** Atomic Modify

Format: **atmod** *addr*, *mask*, *src/dst*  
 reg reg/lit reg

Description: Copies the selected bits of *src/dst* value into memory location specified in *addr*. The read-modify-write operation is performed on the actual data in memory and never on a cached value on chip. Bits set in *mask* operand select bits to be modified in memory. Initial value from memory is stored in *src/dst*. See [section 3.5.1, “Memory Requirements”](#) (pg. 3-14) or more information on atomic accesses.

Memory read and write are done atomically (i.e., other bus masters must be prevented from accessing the word of memory containing the word specified with the *src/dst* operand until operation completes).



Memory location in *addr* is the modified word’s first byte (LSB) address. Address is automatically aligned to a word boundary.

Action: `implicit_syncf();`  
`tempa = addr & 0xFFFFFFFFFC;`  
`tempb = atomic_read(tempa);`  
`temp = (tempb & ~ mask) | (src_dst & mask);`  
`atomic_write(tempa, temp);`  
`src_dst = tempb;`

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: `atmod g5, g7, g10 # tempb = (g5)`  
`# temp = (tempb and not g7) or`  
`# (g10 and g7)`  
`# (g5) = temp`  
`# g10 = tempb`

Opcode: **atmod** 610H REG

See Also: **atadd**



## INSTRUCTION SET REFERENCE

### 6.2.8 **b, bx**

Mnemonic:     **b**           Branch  
                   **bx**          Branch Extended

Format:        **b**            *targ*  
                                   disp  
                   **bx**          *targ*  
                                   mem

Description:    Branches to the specified target.

With the **b** instruction, IP specified with *targ* operand can be no farther than  $-2^{23}$  to  $(2^{23} - 4)$  bytes from current IP. When using the Intel i960 processor assembler, *targ* operand must be a label which specifies target instruction's IP.

**bx** performs the same operation as **b** except the target instruction can be farther than  $-2^{23}$  to  $(2^{23} - 4)$  bytes from current IP. Here, the target operand is an effective address, which allows the full range of addressing modes to be used to specify target instruction's IP. The "IP + displacement" addressing mode allows the instruction to be IP-relative. Indirect branching can be performed by placing target address in a register then using a register-indirect addressing mode.

Refer to [section 2.3, "MEMORY ADDRESSING MODES"](#) (pg. 2-6) for information on this subject.

Action:        **b:**  
                   temp[31:2] = sign\_extension(targ[23:2]);  
                   IP[31:2] = IP[31:2] + temp[31:2];  
                   IP[1:0] = 0;

**bx:**  
                   IP[31:2] = effective\_address(targ[31:2]);  
                   IP[1:0] = 0;

Faults:        STANDARD                    Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example:        **b** xyz                    # IP = xyz;  
                   **bx** 1332 (ip)            # IP = IP + 8 + 1332;  
                   # this example uses IP-relative addressing

Opcode:        **b**            08H            CTRL  
                   **bx**          84H            MEM

See Also:       **bal, balx, BRANCH<cc>, COMPARE AND BRANCH<cc>, bbc, bbs**





6.2.9 **bal, balx**

Mnemonic:     **bal**           Branch and Link  
                   **balx**         Branch and Link Extended

Format:         **bal**           *targ*  
                                   disp  
                   **balx**         *targ*,            *dst*  
                                   mem                reg

Description:     Stores address of instruction following **bal** or **balx** in a register then branches to the instruction specified with the *targ* operand.

The **bal** and **balx** instructions are used to call leaf procedures (procedures that do not call other procedures). The IP saved in the register provides a return IP that the leaf procedure can branch to (using a **bx** instruction) to perform a return from the procedure. Note that these instructions do not use the processor's call-and-return mechanism, so the calling procedure shares its local-register set with the called (leaf) procedure.

With **bal**, address of next instruction is stored in register g14. *targ* operand value can be no farther than  $-2^{23}$  to  $(2^{23} - 4)$  bytes from current IP. When using the Intel i960 processor assembler, *targ* must be a label which specifies the target instruction's IP.

**balx** performs same operation as **bal** except next instruction address is stored in *dst* (allowing the return IP to be stored in any available register). With **balx**, the full address space can be accessed. Here, the target operand is an effective address, which allows full range of addressing modes to be used to specify target IP. "IP + displacement" addressing mode allows instruction to be IP-relative. Indirect branching can be performed by placing target address in a register and then using a register-indirect addressing mode.

See [section 2.3, "MEMORY ADDRESSING MODES"](#) (pg. 2-6) for a complete discussion of addressing modes available with memory-type operands.

Action:         **bal:**  
                   g14 = IP + 4;  
                   temp[31:2] = sign\_extension(targ[23:2]);  
                   IP[31:2] = IP[31:2] + temp[31:2];  
                   IP[1:0] = 0;

**balx:**  
                   dst = IP + instruction\_length;  
                   # Instruction\_length = 4 or 8 depending on the addressing mode used.  
                   IP[31:2] = effective\_address(targ[31:2]);    # Resume execution at new IP.  
                   IP[1:0] = 0;

## INSTRUCTION SET REFERENCE

Faults:           STANDARD                   Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example:        **bal** xyz                   # g14 = IP + 4  
                   # IP = xyz  
                   **balx** (g2), g4         # g4 = IP + 4  
                   # IP = (g2)

Opcode:         **bal**           0BH           CTRL  
                   **balx**         85H           MEM

See Also:       **b, bx, BRANCH<cc>, COMPARE AND BRANCH<cc>, bbc, bbs**





## INSTRUCTION SET REFERENCE

Example:           # Assume bit 10 of r6 is clear.  
          bbc 10, r6, xyz   # Bit 10 of r6 is checked  
                          # and found clear:  
                          # AC.cc = 000  
                          # IP = xyz;

Opcode:           **bbc**           30H           COBR  
                  **bbs**           37H           COBR

See Also:         **chkbit, COMPARE AND BRANCH<cc>, BRANCH<cc>**

Side Effects:     Sets the condition code in the arithmetic controls.



6.2.11 BRANCH<cc>

Mnemonic: **be** Branch If Equal  
**bne** Branch If Not Equal  
**bl** Branch If Less  
**ble** Branch If Less Or Equal  
**bg** Branch If Greater  
**bge** Branch If Greater Or Equal  
**bo** Branch If Ordered  
**bno** Branch If Unordered

Format: **b\*** *targ*  
disp

Description: Branches to instruction specified with *targ* operand according to AC register condition code state.



For all branch<cc> instructions except **bno**, the processor branches to instruction specified with *targ*, when the logical AND of condition code and mask part of opcode is not zero. Otherwise, it goes to next instruction.

For **bno**, the processor branches to instruction specified with *targ* when the condition code is zero. Otherwise, it goes to next instruction.

For instance, **bno** (unordered) can be used as a branch when false instruction when coupled with **chkbit**. For **bno**, branch is taken when condition code equals 000<sub>2</sub>. **be** can be used as branch-if true instruction.

The *targ* operand value can be no farther than -2<sup>23</sup> to (2<sup>23</sup> - 4) bytes from current IP.

The following table shows condition code mask for each instruction. The mask is in opcode bits 0-2.

**Table 6-5. Condition Code Mask Descriptions**

Instruction	Mask	Condition
<b>bno</b>	000 <sub>2</sub>	Unordered
<b>bg</b>	001 <sub>2</sub>	Greater
<b>be</b>	010 <sub>2</sub>	Equal
<b>bge</b>	011 <sub>2</sub>	Greater or equal
<b>bl</b>	100 <sub>2</sub>	Less
<b>bne</b>	101 <sub>2</sub>	Not equal
<b>ble</b>	110 <sub>2</sub>	Less or equal
<b>bo</b>	111 <sub>2</sub>	Ordered



## INSTRUCTION SET REFERENCE

Action:            if((mask & AC.cc) || (mask == AC.cc))  
                   {    temp[31:2] = sign\_extension(targ[23:2]);  
                       IP[31:2] = IP[31:2] + temp[31:2];  
                       IP[1:0] = 0;  
                   }

Faults:            STANDARD                           Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example:           # Assume (AC.cc AND 100<sub>2</sub>) ≠ 0  
                   bl xyz                               # IP = xyz;

Opcode:           **be**           12H           CTRL  
                   **bne**          15H           CTRL  
                   **bl**            14H           CTRL  
                   **ble**          16H           CTRL  
                   **bg**           11H           CTRL  
                   **bge**          13H           CTRL  
                   **bo**           17H           CTRL  
                   **bno**          10H           CTRL

See Also:           **b, bx, bbc, bbs, COMPARE AND BRANCH<cc>, bal, balx**



**6.2.12 bswap**

Mnemonic: **bswap** Byte Swap

Format: **bswap** *src*, *dst*  
reg/lit reg

Description: Alters the order of bytes in a word, reversing its “endianess.”

Copies bytes 3:0 of *src* to *dst* reversing order of the bytes. Byte 0 of *src* becomes byte 3 of *dst*, byte 1 of *src* becomes byte 2 of *dst*, etc.

Action:  $dst = (rotate\_left(src\ 8) \& 0x00FF00FF) + (rotate\_left(src\ 24) \& 0xFF00FF00);$

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: `bswap g8, g10`  
# g8 = 0x89ABCDEF  
# Reverse byte order.  
# g10 = 0xEFCDAB89

Opcode: **bswap** 5ADH REG

See Also: **scanbyte, rotate**

Notes: This core instruction is not implemented on Cx, Kx and Sx 80960 processors.



**6.2.13 call**Mnemonic: **call** CallFormat: **call** *targ*  
*disp*

Description: Calls a new procedure. *targ* operand specifies the IP of called procedure's first instruction. When using the Intel i960 processor assembler, *targ* must be a label.

In executing this instruction, the processor performs a local call operation as described in [section 7.1.3.1, "Call Operation"](#) (pg. 7-6). As part of this operation, the processor saves the set of local registers associated with the calling procedure and allocates a new set of local registers and a new stack frame for the called procedure. Processor then goes to the instruction specified with *targ* and begins execution.

*targ* can be no farther than  $-2^{23}$  to  $(2^{23} - 4)$  bytes from current IP.

Action: # Wait for any uncompleted instructions to finish.  
implicit\_synchf();  
temp = (SP + (SALIGN\*16 - 1)) & ~(SALIGN\*16 - 1)  
# Round stack pointer to next boundary.  
# SALIGN=1 on i960 Jx processors.  
RIP = IP;  
if (register\_set\_available)  
allocate\_new\_frame( );  
else  
{ save\_register\_set( ); # Save register set in memory at its FP.  
allocate\_new\_frame( );  
}  
# Local register references now refer to new frame.  
temp[31:2] = sign\_extension(targ[23:2]);  
IP[31:2] = IP[31:2] + temp[31:2];  
IP[1:0] = 0;  
PFP = FP;  
FP = temp;  
SP = temp + 64;

Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example: call xyz # IP = xyz

Opcode: **call** 09H CTRL

See Also: **bal, calls, callx**





**6.2.14 calls**

Mnemonic: **calls** Call System

Format: **calls** *targ*  
reg/lit

Description: Calls a system procedure. The *targ* operand gives the number of the procedure being called. For **calls**, the processor performs system call operation described in [section 7.5, “SYSTEM CALLS” \(pg. 7-15\)](#). *targ* provides an index to a system procedure table entry from which the processor gets the called procedure’s IP.

The called procedure can be a local or supervisor procedure, depending on system procedure table entry type. When it is a supervisor procedure, the processor switches to supervisor mode (when not already in this mode).

As part of this operation, the processor also allocates a new set of local registers and a new stack frame for the called procedure. When the processor switches to supervisor mode, the new stack frame is created on the supervisor stack.

Action: # Wait for any uncompleted instructions to finish.  
implicit\_syncf();  
If (targ > 259)  
    generate\_fault(PROTECTION.LENGTH);  
temp = get\_sys\_proc\_entry(sptbase + 48 + 4\*targ);  
    # sptbase is address of supervisor procedure table.

if (register\_set\_available)  
    allocate\_new\_frame();  
else  
    { save\_register\_set( ); # Save a frame in memory at its FP.  
      allocate\_new\_frame( );  
      # Local register references now refer to new frame.  
    }

RIP = IP;  
IP[31:2] = effective\_address(temp[31:2]);  
IP[1:0] = 0;  
if ((temp.type == local) || (PC.em == supervisor))  
    { # Local call or supervisor call from supervisor mode.  
      tempa = (SP + (SALIGN\*16 - 1)) & ~(SALIGN\*16 - 1)  
      # Round stack pointer to next boundary.  
      # SALIGN=1 on i960 Jx processors.  
      temp.RRR = 000<sub>2</sub>;  
    }  
else # Supervisor call from user mode.

```

    {   tempa = SSP;                # Get Supervisor Stack pointer.
        temp.RRR = 0102 | PC.te;
        PC.em = supervisor;
        PC.te = temp.te;
    }
PFP = FP;
PFP.rrr = temp.RRR;
FP = tempa;
SP = tempa + 64;

```

Faults:           **STANDARD**                   Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).  
                   **PROTECTION.LENGTH**       Specifies a procedure number greater than  
   259.

Example:           **calls r12**                   # IP = value obtained from  
   # procedure table for procedure  
   # number given in r12.  
                   **calls 3**                       # Call procedure 3.

Opcode:           **calls**           660H           REG

See Also:         **bal, call, callx, ret**



**6.2.15 callx**

Mnemonic: **callx** Call Extended

Format: **callx** *targ*  
mem

Description: Calls new procedure. *targ* specifies IP of called procedure's first instruction.

In executing **callx**, the processor performs a local call as described in [section 7.1.3.1, "Call Operation" \(pg. 7-6\)](#). As part of this operation, the processor allocates a new set of local registers and a new stack frame for the called procedure. Processor then goes to the instruction specified with *targ* and begins execution of new procedure.

**callx** performs the same operation as call except the target instruction can be farther than  $-2^{23}$  to  $(2^{23} - 4)$  bytes from current IP.

The *targ* operand is a memory type, which allows the full range of addressing modes to be used to specify the IP of the target instruction. The "IP + displacement" addressing mode allows the instruction to be IP-relative. Indirect calls can be performed by placing the target address in a register and then using one of the register-indirect addressing modes.

Refer to [CHAPTER 2, DATA TYPES AND MEMORY ADDRESSING MODES](#) for more information.

Action: # Wait for any uncompleted instructions to finish;  
implicit\_synch();  
temp = (SP + (SALIGN\*16 - 1)) & ~(SALIGN\*16 - 1)  
# Round stack pointer to next boundary.  
# SALIGN=1 on i960 Jx processors.  
RIP = IP;  
if (register\_set\_available)  
allocate\_new\_frame( );  
else  
{ save\_register\_set( ); # Save register set in memory at its FP;  
allocate\_new\_frame( );  
}  
# Local register references now refer to new frame.  
IP[31:2] = effective\_address(targ[31:2]);  
IP[1:0] = 0;  
PFP = FP;  
FP = temp;  
SP = temp + 64;

Faults: STANDARD Refer to [section 6.1.6, "Faults" \(pg. 6-5\)](#).





## INSTRUCTION SET REFERENCE

### 6.2.17 **clrbt**

Mnemonic:	<b>clrbt</b>	Clear Bit		
Format:	<b>clrbt</b>	<i>bitpos</i> , reg/lit	<i>src</i> , reg/lit	<i>dst</i> reg
Description:	Copies <i>src</i> value to <i>dst</i> with one bit cleared. <i>bitpos</i> operand specifies bit to be cleared.			
Action:	$dst = src \& \sim(2^{*(bitpos\%32)});$			
Faults:	STANDARD	Refer to <a href="#">section 6.1.6, "Faults"</a> (pg. 6-5).		
Example:	<code>clrbt 23, g3, g6 # g6 = g3 with bit 23 cleared.</code>			
Opcode:	<b>clrbt</b>	58CH	REG	
See Also:	<b>alterbit, chkbit, notbit, setbit</b>			

**6.2.18 cmpdeci, cmpdeco**

Mnemonic: **cmpdeci** Compare and Decrement Integer  
**cmpdeco** Compare and Decrement Ordinal

Format: **cmpdec\*** *src1*, *src2*, *dst*  
reg/lit reg/lit reg

Description: Compares *src2* and *src1* values and sets the condition code according to comparison results. *src2* is then decremented by one and result is stored in *dst*. The following table shows condition code setting for the three possible results of the comparison.

**Table 6-6. Condition Code Settings**

Condition Code	Comparison
100 <sub>2</sub>	<i>src1</i> < <i>src2</i>
010 <sub>2</sub>	<i>src1</i> = <i>src2</i>
001 <sub>2</sub>	<i>src1</i> > <i>src2</i>



These instructions are intended for use in ending iterative loops. For **cmpdeci**, integer overflow is ignored to allow looping down through the minimum integer values.

Action: 

```
if(src1 < src2)
    AC.cc = 1002;
else if(src1 == src2)
    AC.cc = 0102;
else
    AC.cc = 0012;
dst = src2 - 1; # Overflow suppressed for cmpdeci.
```

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: 

```
cmpdeci 12, g7, g1 # Compares g7 with 12 and sets
                  # AC.cc to indicate the result
                  # g1 = g7 - 1.
```

Opcode: **cmpdeci** 5A7H REG  
**cmpdeco** 5A6H REG

See Also: **cmpinco, cmpo, cmpi, cmpinci, COMPARE AND BRANCH<cc>**

Side Effects: Sets the condition code in the arithmetic controls.



### 6.2.19 **cmpinci, cmpinco**

Mnemonic:     **cmpinci**     Compare and Increment Integer  
                   **cmpinco**     Compare and Increment Ordinal

Format:        **cmpinc\***     *src1*,            *src2*,            *dst*  
                                   reg/lit            reg/lit            reg

Description:    Compares *src2* and *src1* values and sets the condition code according to comparison results. *src2* is then incremented by one and result is stored in *dst*. The following table shows condition code settings for the three possible comparison results.

**Table 6-7. Condition Code Settings**

Condition Code	Comparison
100 <sub>2</sub>	<i>src1</i> < <i>src2</i>
010 <sub>2</sub>	<i>src1</i> = <i>src2</i>
001 <sub>2</sub>	<i>src1</i> > <i>src2</i>

These instructions are intended for use in ending iterative loops. For **cmpinci**, integer overflow is ignored to allow looping up through the maximum integer values.

Action:        if (*src1* < *src2*)  
                     AC.cc = 100<sub>2</sub>;  
                   else if (*src1* == *src2*)  
                     AC.cc = 010<sub>2</sub>;  
                   else  
                     AC.cc = 001<sub>2</sub>;

*dst* = *src2* + 1;    # Overflow suppressed for **cmpinci**.

Faults:        STANDARD                    Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example:        **cmpinco** *r8*, *g2*, *g9*    # Compares the values in *g2*  
   # and *r8* and sets AC.cc to  
   # indicate the result:  
   # *g9* = *g2* + 1

Opcode:        **cmpinci**     5A5H            REG  
                   **cmpinco**     5A4H            REG

See Also:       **cmpdeco, cmpo, cmpi, cmpdeci, COMPARE AND BRANCH<cc>**

Side Effects:   Sets the condition code in the arithmetic controls.





6.2.20 COMPARE

Mnemonic: **cmpi** Compare Integer  
**cmpib** Compare Integer Byte  
**cmpis** Compare Integer Short  
**cmpo** Compare Ordinal  
**cmpob** Compare Ordinal Byte  
**cmpos** Compare Ordinal Short

Format: **cmp\*** *src1*, *src2*  
reg/lit reg/lit

Description: Compares *src2* and *src1* values and sets condition code according to comparison results. The following table shows condition code settings for the three possible comparison results.



**Table 6-8. Condition Code Settings**

Condition Code	Comparison
100 <sub>2</sub>	<i>src1</i> < <i>src2</i>
010 <sub>2</sub>	<i>src1</i> = <i>src2</i>
001 <sub>2</sub>	<i>src1</i> > <i>src2</i>

**cmpi\*** followed by a branch-if instruction is equivalent to a compare-integer-and-branch instruction. The latter method of comparing and branching produces more compact code; however, the former method can execute byte and short compares without masking. The same is true for **cmpo\*** and the compare-ordinal-and-branch instructions.

Action: # For cmpo, cmpi, N = 31.  
# For cmpos, cmpis, N = 15.  
# For cmpob, cmpib, N = 7.

```

if (src1[N:0] < src2[N:0])
    AC.cc = 1002;
else if (src1[N:0] == src2[N:0])
    AC.cc = 0102;
else if (src1[N:0] > src2[N:0])
    AC.cc = 0012;

```

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).





6.2.21 COMPARE AND BRANCH<cc>

Mnemonic:	<b>cmpibe</b>	Compare Integer and Branch If Equal
	<b>cmpibne</b>	Compare Integer and Branch If Not Equal
	<b>cmpibl</b>	Compare Integer and Branch If Less
	<b>cmpible</b>	Compare Integer and Branch If Less Or Equal
	<b>cmpibg</b>	Compare Integer and Branch If Greater
	<b>cmpibge</b>	Compare Integer and Branch If Greater Or Equal
	<b>cmpibo</b>	Compare Integer and Branch If Ordered
	<b>cmpibno</b>	Compare Integer and Branch If Not Ordered

	<b>cmpobe</b>	Compare Ordinal and Branch If Equal
	<b>cmpobne</b>	Compare Ordinal and Branch If Not Equal
	<b>cmpobl</b>	Compare Ordinal and Branch If Less
	<b>cmpoble</b>	Compare Ordinal and Branch If Less Or Equal
	<b>cmpobg</b>	Compare Ordinal and Branch If Greater
	<b>cmpobge</b>	Compare Ordinal and Branch If Greater Or Equal



Format:	<b>cmpib*</b>	<i>src1</i> , reg/lit	<i>src2</i> , reg	<i>targ</i> disp
	<b>cmpob*</b>	<i>src1</i> , reg/lit	<i>src2</i> , reg	<i>targ</i> disp

Description: Compares *src2* and *src1* values and sets AC register condition code according to comparison results. When logical AND of condition code and mask part of opcode is not zero, the processor branches to instruction specified with *targ*; otherwise, the processor goes to next instruction.

*targ* can be no farther than  $-2^{12}$  to  $(2^{12} - 4)$  bytes from current IP. When using the Intel i960 processor assembler, *targ* must be a label which specifies target instruction's IP.

Functions these instructions perform can be duplicated with a **cmpi** or **cmpo** followed by a branch-if instruction, as described in [section 6.2.20](#), "COMPARE" (pg. 6-33).







Opcode:	<b>cmpibe</b>	3AH	COBR
	<b>cmpibne</b>	3DH	COBR
	<b>cmpibl</b>	3CH	COBR
	<b>cmpible</b>	3EH	COBR
	<b>cmpibg</b>	39H	COBR
	<b>cmpibge</b>	3BH	COBR
	<b>cmpibo</b>	3FH	COBR
	<b>cmpibno</b>	38H	COBR
	<b>cmpobe</b>	32H	COBR
	<b>cmpobne</b>	35H	COBR
	<b>cmpobl</b>	34H	COBR
	<b>cmpoble</b>	36H	COBR
	<b>cmpobg</b>	31H	COBR
	<b>cmpobge</b>	33H	COBR

See Also: **BRANCH<cc>, cmpi, cmpo, bal, balx**

Side Effects: Sets the condition code in the arithmetic controls.



### 6.2.22 **concmpi, concmpo**

Mnemonic:     **concmpi**   Conditional Compare Integer  
                  **concmpo**   Conditional Compare Ordinal

Format:       **concmp\***    *src1*,            *src2*  
                                   reg/lit            reg/lit

Description:   Compares *src2* and *src1* values when condition code bit 2 is not set. When comparison is performed, condition code is set according to comparison results. Otherwise, condition codes are not altered.

These instructions are provided to facilitate bounds checking by means of two-sided range comparisons (e.g., is A between B and C?). They are generally used after a compare instruction to test whether a value is inclusively between two other values.

The example below illustrates this application by testing whether *g3* value is between *g5* and *g6* values, where *g5* is assumed to be less than *g6*. First a comparison (**cmpo**) of *g3* and *g6* is performed. When *g3* is less than or equal to *g6* (i.e., condition code is either 010<sub>2</sub> or 001<sub>2</sub>), a conditional comparison (**concmpo**) of *g3* and *g5* is then performed. When *g3* is greater than or equal to *g5* (indicating that *g3* is within the bounds of *g5* and *g6*), condition code is set to 010<sub>2</sub>; otherwise, it is set to 001<sub>2</sub>.

Action:       if (AC.cc != 1XX<sub>2</sub>)  
                   {   if(src1 <= src2)  
                           AC.cc = 010<sub>2</sub>;  
                           else  
                               AC.cc = 001<sub>2</sub>;  
                   }

Faults:       STANDARD                   Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example:      cmpo g6, g3               # Compares g6 and g3  
   # and sets AC.cc.  
                   concmpo g5, g3        # If AC.cc < 100<sub>2</sub> (g6 ≥ g3)  
   # g5 is compared with g3.

At this point, depending on the register ordering, the condition code is one of those listed on [Table 6-10](#).



Table 6-10. `concmpo` example: register ordering and CC

Order	CC
$g5 < g6 < g3$	$100_2$
$g5 < g6 = g3$	$010_2$
$g5 < g3 < g6$	$010_2$
$g5 = g3 < g6$	$010_2$
$g3 < g5 < g6$	$001_2$

Opcode:            **concmpi**    5A3H            REG  
                       **concmpo**    5A2H            REG

See Also:           **cmpo, cmpi, cmpdeci, cmpdeco, cmpinci, cmpinco, COMPARE AND  
 BRANCH<cc>**

Side Effects:       Sets the condition code in the arithmetic controls.



## INSTRUCTION SET REFERENCE

### 6.2.23 **dcctl**

Mnemonic: **dcctl** Data-cache Control

Format: *src1*, *src2*, *src/dst*  
 reg/lit reg/lit reg

Description: Performs management and control of the data cache including disabling, enabling, invalidating, ensuring coherency, getting status, and storing cache contents to memory. Operations are indicated by the value of *src1*. *src2* and *src/dst* are also used by some operations. When needed by the operation, the processor orders the effects of the operation with previous and subsequent operations to ensure correct behavior.


**Table 6-11. dcctl Operand Fields**

Function	<i>src1</i>	<i>src2</i>	<i>src/dst</i>
Disable D-cache	0	NA	NA
Enable D-cache	1	NA	NA
Global invalidate D-cache	2	NA	NA
Ensure cache coherency <sup>1</sup>	3	NA	NA
Get D-cache status	4	NA	<i>src</i> : NA <i>dst</i> : Receives D-cache status (see <a href="#">Figure 6-1</a> ).
Reserved	5	NA	NA
Store D-cache to memory	6	Destination address for cache sets	<i>src</i> : D-cache set #'s to be stored (see <a href="#">Figure 6-1</a> ).
Reserved	7	NA	NA
Quick invalidate	8	1	NA
Reserved	9	NA	NA

1. Invalidates data cache on 80960Jx.







6

Figure 6-1. dcctl *src1* and *src/dst* Formats



Table 6-12. DCCTL Status Values and D-Cache Parameters

Value	Value on i960JA CPU	Value on i960JD/JF CPU	Value on i960JT CPU
bytes per atom	4	4	4
atoms per line	4	4	4
number of sets	64	128 (full)	256
number of ways	1 (Direct)	1 (Direct)	1 (Direct)
cache size	1-Kbytes	2-Kbytes(full)	4-Kbytes
Status[0] (enable / disable)	0 or 1	0 or 1	0 or 1
Status[1:3] (reserved)	0	0	0
Status[7:4] ( $\log_2(\text{bytes per atom})$ )	2	2	2
Status[11:8] ( $\log_2(\text{atoms per line})$ )	2	2	2
Status[15:12] ( $\log_2(\text{number of sets})$ )	6	7 (full)	8 (full)
Status[27:16] (number of ways - 1)	0	0	0





Figure 6-2. Store Data Cache to Memory Output Format





6

Figure 6-3. D-Cache Tag and Valid Bit Formats



## INSTRUCTION SET REFERENCE

```
Action:      if (PC.em != supervisor)
              generate_fault(TYPE.MISMATCH);
              order_wrt(previous_operations);
              switch (src1[7:0]) {

                case 0:      # Disable data cache.
                            disable_Dcache( );
                            break;

                case 1:      # Enable data cache.
                            enable_Dcache( );
                            break;

                case 2:      # Global invalidate data cache.
                            invalidate_Dcache( );
                            break;

                case 3:      # Ensure coherency of data cache with memory.
                            # Causes data cache to be invalidated on this processor.
                            ensure_Dcache_coherency( );
                            break;

                case 4:      # Get data cache status into src_dst.
                            if (Dcache_enabled) src_dst[0] = 1;
                            else src_dst[0] = 0;
                            # Atom is 4 bytes.
                            src_dst[7:4] = log2(bytes per atom);
                            # 4 atoms per line.
                            src_dst[11:8] = log2(atoms per line);
                            src_dst[15:12] = log2(number of sets);
                            src_dst[27:16] = number of ways-1; # in lines per set
                            # cache size = ([27:16]+1) << ([7:4] + [11:8] + [15:12]).
                            break;
              }
```





## INSTRUCTION SET REFERENCE

Example:

```

# g0 = 6, g1 = 0x10000000,
# g2 = 0x001F0001
dcctl g0,g1,g2 # Store the status of D-cache
# sets 1-0x1F to memory starting
# at 0x10000000.
```

Opcode:       **dcctl**       65CH       REG

See Also:     **sysctl**

Notes:       DCCTL function 6 stores data-cache sets to a target range in external memory. For any memory location that is cached and also within the target range for function 6, the corresponding word-valid bit is cleared after function 6 completes to ensure data-cache coherency. Thus, **dcctl** function 6 can alter the state of the cache after it completes, but only the word-valid bits. In all cases, even when the cache sets to store to external memory overlap the cache sets that map the target range in external memory, DCCTL function 6 always returns the state of the cache as it existed when the DCCTL was issued.

This instruction is implemented on the 80960Rx, 80960Hx and 80960Jx processor families only, and may or may not be implemented on future i960 processors.



**6.2.24 divi, divo**

Mnemonic: **divi** Divide Integer  
**divo** Divide Ordinal

Format: **div\*** *src1*, *src2*, *dst*  
reg/lit reg/lit reg

Description: Divides *src2* value by *src1* value and stores result in *dst*. Remainder is discarded.  
For **divi**, an integer-overflow fault can be signaled.

Action: **divo:**  
if (src1 == 0)  
{ dst = undefined\_value;  
generate\_fault (ARITHMETIC.ZERO\_DIVIDE);  
else  
dst = src2/src1;

**divi:**  
if (src1 == 0)  
{ dst = undefined\_value;  
generate\_fault (ARITHMETIC.ZERO\_DIVIDE);}  
else if ((src2 == -2\*\*31) && (src1 == -1))  
{ dst = -2\*\*31  
  
if (AC.om == 1)  
AC.of = 1;  
else  
generate\_fault (ARITHMETIC.OVERFLOW);  
}  
else  
dst = src2 / src1;

Faults: STANDARD Refer to [Section 6.1.6 on page 6-5](#).  
ARITHMETIC.ZERO\_DIVIDE The *src1* operand is 0.  
ARITHMETIC.OVERFLOW Result too large for destination register (**divi** only). When overflow occurs and AC.om=1, fault is suppressed and AC.of is set to 1. Result's least significant 32 bits are stored in *dst*.

Example: `divo r3, r8, r13 # r13 = r8/r3`

Opcode: **divi** 74BH REG  
**divo** 70BH REG

See Also: **ediv, mulo, muli, emul**



### 6.2.25 **ediv**

Mnemonic: **ediv** Extended Divide

Format: **ediv** *src1*, *src2*, *dst*  
 reg/lit reg/lit reg

Description: Divides *src2* by *src1* and stores result in *dst*. The *src2* value is a long ordinal (64 bits) contained in two adjacent registers. *src2* specifies the lower numbered register which contains operand's least significant bits. *src2* must be an even numbered register (i.e., g0, g2, ... or r4, r6, r8... ). *src1* value is a normal ordinal (i.e., 32 bits).

The result consists of a one-word remainder and a one-word quotient. Remainder is stored in the register designated by *dst*; quotient is stored in the next highest numbered register. *dst* must be an even numbered register (i.e., g0, g2, ... r4, r6, r8, ...).

This instruction performs ordinal arithmetic.

When this operation overflows (quotient or remainder do not fit in 32 bits), no fault is raised and the result is undefined.

Action:

```

if((reg_number(src2)%2 != 0) || (reg_number(dst)%2 != 0))
{
  dst[0] = undefined_value;
  dst[1] = undefined_value;
  generate_fault (OPERATION.INVALID_OPERAND);
}
else if(src1 == 0)
{
  dst[0] = undefined_value;
  dst[1] = undefined_value;
  generate_fault(ARITHMETIC.DIVIDE_ZERO);
}
else # Quotient
{
  dst[1] = ((src2 + reg_value(src2[1]) * 2**32) / src1)[31:0];
  #Remainder
  dst[0] = (src2 + reg_value(src2[1]) * 2**32
    - ((src2 + reg_value(src2[1]) * 2**32 / src1) * src1);
}

```

Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).  
 ARITHMETIC.ZERO\_DIVIDE The *src1* operand is 0.

Example: `ediv g3, g4, g10` # g10 = remainder of g4,g5/g3  
 # g11 = quotient of g4,g5/g3

Opcode: **ediv** 671H REG

See Also: **emul, divi, divo**





**6.2.26 emul**

Mnemonic: **emul** Extended Multiply

Format: **emul** *src1*, *src2*, *dst*  
 reg/lit reg/lit reg

Description: Multiplies *src2* by *src1* and stores the result in *dst*. Result is a long ordinal (64 bits) stored in two adjacent registers. *dst* specifies lower numbered register, which receives the result's least significant bits. *dst* must be an even numbered register (i.e., g0, g2, ... r4, r6, r8, ...).

This instruction performs ordinal arithmetic.

Action: 

```
if(reg_number(dst)%2 != 0)
{
  dst[0] = undefined_value;
  dst[1] = undefined_value;
  generate_fault(OPERATION.INVALID_OPERAND);
}
else
{
  dst[0] = (src1 * src2)[31:0];
  dst[1] = (src1 * src2)[63:32];
}
```



Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example: `emul r4, r5, g2 # g2,g3 = r4 * r5.`

Opcode: **emul** 670H REG

See Also: **ediv, muli, mulo**



**6.2.27 eshro**

Mnemonic: **eshro** Extended Shift Right Ordinal

Format: **eshro** *src1*, *src2*, *dst*  
 reg/lit reg/lit reg

Description: Shifts *src2* right by (*src1* **mod** 32) places and stores the result in *dst*. Bits shifted beyond the least-significant bit are discarded.

*src2* value is a long ordinal (i.e., 64 bits) contained in two adjacent registers. *src2* operand specifies the lower numbered register, which contains operand's least significant bits. *src2* operand must be an even numbered register (i.e., r4, r6, r8, ... or g0, g2).

*src1* operand is a single 32-bit register or literal where the lower 5 bits specify the number of places that the *src2* operand is to be shifted.

The least significant 32 bits of the shift operation result are stored in *dst*.

Action: 

```
if(reg_number(src2)%2 != 0)
{   dst[0] = undefined_value;
    dst[1] = undefined_value;
    generate_fault(OPERATION.INVALID_OPERAND);
}
else
    dst = shift_right((src2 + reg_value(src2[1]) * 2**32),(src1%32))[31:0];
```

Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example: `eshro g3, g4, g11 # g11 = g4,g5 shifted right by # (g3 MOD 32).`

Opcode: **eshro** 5D8H REG

See Also: **SHIFT, extract**

Notes: This core instruction is not implemented on the Kx and Sx 80960 processors.

**6.2.28 extract**

Mnemonic: **extract** Extract

Format: **extract** *bitpos* *len* *src/dst*  
reg/lit reg/lit reg

Description: Shifts a specified bit field in *src/dst* right and zero fills bits to left of shifted bit field. *bitpos* value specifies the least significant bit of the bit field to be shifted; *len* value specifies bit field length.

Action:  $src\_dst = (src\_dst \gg \min(bitpos, 32))$   
 $\& \sim (0xFFFFFFFF \ll len);$

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: `extract 5, 12, g4` # g4 = g4 with bits 5 through  
# 16 shifted right.

Opcode: **extract** 651H REG

See Also: **modify**



**6.2.29 FAULT<cc>**

Mnemonic: **faulte** Fault If Equal  
**faultne** Fault If Not Equal  
**faultl** Fault If Less  
**faultle** Fault If Less Or Equal  
**faultg** Fault If Greater  
**faultge** Fault If Greater Or Equal  
**faulto** Fault If Ordered  
**faultno** Fault If Not Ordered

Format: **fault\***

Description: Raises a constraint-range fault when the logical AND of the condition code and opcode’s mask part is not zero. For **faultno** (unordered), fault is raised when condition code is equal to 000<sub>2</sub>.

**faulto** and **faultno** are provided for use by implementations with a floating point coprocessor. They are used for compare and branch (or fault) operations involving real numbers.

The following table shows the condition code mask for each instruction. The mask is opcode bits 0-2.

**Table 6-13. Condition Code Mask Descriptions**

Instruction	Mask	Condition
<b>faultno</b>	000 <sub>2</sub>	Unordered
<b>faultg</b>	001 <sub>2</sub>	Greater
<b>faulte</b>	010 <sub>2</sub>	Equal
<b>faultge</b>	011 <sub>2</sub>	Greater or equal
<b>faultl</b>	100 <sub>2</sub>	Less
<b>faultne</b>	101 <sub>2</sub>	Not equal
<b>faultle</b>	110 <sub>2</sub>	Less or equal
<b>faulto</b>	111 <sub>2</sub>	Ordered

Action: **For all except faultno:**  
if(mask && AC.cc != 000<sub>2</sub>)  
generate\_fault(CONSTRAINT.RANGE);

**faultno:**  
if(AC.cc == 000<sub>2</sub>)  
generate\_fault(CONSTRAINT.RANGE);





Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).  
CONSTRAINT.RANGE When condition being tested is true.

Example: # Assume (AC.cc AND 110<sub>2</sub>) ≠ 000<sub>2</sub>  
faultle # Generate CONSTRAINT\_RANGE fault

Opcode:	<b>faulte</b>	1AH	CTRL
	<b>faultne</b>	1DH	CTRL
	<b>faultl</b>	1CH	CTRL
	<b>faultle</b>	1EH	CTRL
	<b>faultg</b>	19H	CTRL
	<b>faultge</b>	1BH	CTRL
	<b>faulto</b>	1FH	CTRL
	<b>faultno</b>	18H	CTRL

See Also: **BRANCH<cc>, TEST<cc>**



**6.2.30 flushreg**

Mnemonic: **flushreg** Flush Local Registers

Format: **flushreg**

Description: Copies the contents of every cached register set, except the current set, to its associated stack frame in memory. The entire register cache is then marked as purged (or invalid). On a return to a stack frame for which the local registers are not cached, the processor reloads one set of the locals from memory.

**flushreg** is provided to allow a debugger or application program to circumvent the processor's normal call/return mechanism. For example, a debugger may need to go back several frames in the stack on the next return, rather than using the normal return mechanism that returns one frame at a time. Since the local registers of an unknown number of previous stack frames may be cached, a **flushreg** must be executed prior to modifying the PFP to return to a frame other than the one directly below the current frame.

To reduce interrupt latency, **flushreg** is abortable. When an interrupt of higher priority than the current process is detected while **flushreg** is executing, **flushreg** flushes at least one frame and aborts. After executing the interrupt handler, the processor returns to the **flushreg** instruction and re-executes it. **flushreg** does not reflush any frames that were flushed before the interrupt occurred. **flushreg** is not aborted by high priority interrupts when tracing is enabled in the PC or when any faults are pending at the time of the interrupt.

Action: Each local cached register set except the current one is flushed to its associated stack frame in memory and marked as purged, meaning that they are reloaded from memory if and when they become the current local register set.

Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example: flushreg

Opcode: **flushreg** 66DH REG

**6.2.31 fmark**

Mnemonic: **fmark** Force Mark

Format: **fmark**

Description: Generates a mark trace event. Causes a mark trace event to be generated, regardless of mark trace mode flag setting, providing the trace enable bit, bit 0 in the Process Controls, is set.

For more information on trace fault generation, refer to [CHAPTER 9, TRACING AND DEBUGGING](#).

Action: A mark trace event is generated, independent of the setting of the mark-trace-mode flag.

Faults: STANDARD TRACE.MARK Refer to [section 6.1.6, "Faults"](#) (pg. 6-5). A TRACE.MARK fault is generated if PC.te=1.



Example: 

```
# Assume PC.te = 1
fmark
# Mark trace event is generated at this point in the
# instruction stream.
```

Opcode: **fmark** 66CH REG

See Also: **mark**



**6.2.32 halt**

Mnemonic: **halt** Halt CPU

Format: **halt** *src1*  
reg/lit

Description: Causes the processor to enter HALT mode, which is described in. Entry into Halt mode allows the interrupt enable state to be conditionally changed based on the value of *src1*.

**Table 6.14. Condition Changes**

<i>src1</i>	Operation
0	Disable interrupts and halt
1	Enable interrupts and halt
2	Use current interrupt enable state and halt

The processor exits Halt mode on a hardware reset or upon receipt of an interrupt that should be delivered based on the current process priority. After executing the interrupt that forced the processor out of Halt mode, execution resumes at the instruction immediately after the **halt** instruction. The processor must be in supervisor mode to use this instruction.

Action:

```

implicit_synof;
if (PC.em != supervisor)
    generate_fault(TYPE.MISMATCH);
switch(src1) {
    case 0:    # Disable interrupts. set ICON.gie.
               global_interrupt_enable = true;           break;
    case 1:    # Enable interrupts. clear ICON.gie.
               global_interrupt_enable = false;          break;
    case 2:    # Use the current interrupt enable state.
               break;
    default:
               generate_fault(OPERATION.INVALID_OPERAND);
               break;
}

ensure_bus_is_quiescent;
enter_HALT_mode;

```









**6.2.33 icctl**

Mnemonic: **icctl** Instruction-cache Control


Format: **icctl** *src1*, *src2*, *src/dst*  
 reg/lit reg/lit reg

Description: Performs management and control of the instruction cache including disabling, enabling, invalidating, loading and locking, getting status, and storing cache sets to memory. Operations are indicated by the value of *src1*. Some operations also use *src2* and *src/dst*. When needed by the operation, the processor orders the effects of the operation with previous and subsequent operations to ensure correct behavior. For specific function setup, see the following tables and diagrams:

**Table 6-15. icctl Operand Fields**

Function	<i>src1</i>	<i>src2</i>	<i>src/dst</i>
Disable I-cache	0	NA	NA
Enable I-cache	1	NA	NA
Invalidate I-cache	2	NA	NA
Load and lock I-cache	3	<i>src</i> : Starting address of code to lock.	Number of ways to lock.
Get I-cache status	4	NA	<i>dst</i> : Receives status (see <a href="#">Figure 6-4</a> ).
Get I-cache locking status	5	NA	<i>dst</i> : Receives status (see <a href="#">Figure 6-4</a> ).
Store I-cache sets to memory	6	Destination address for cache sets	<i>src</i> : I-cache set #'s to be stored (see <a href="#">Figure 6-4</a> ).





6

Figure 6-4. icctl *src1* and *src/dst* Formats



Table 6-16. ICCTL Status Values and Instruction Cache Parameters

Value	Value on i960JA CPU	Value on i960JD/JF CPU	Value on i960JTA CPU
bytes per atom	4	4	4
atoms per line	4	4	4
number of sets	64	128	512
number of ways	2	2	2
cache size	2-Kbytes	4-Kbytes	16-Kbytes
Status[0] (enable / disable)	0 or 1	0 or 1	0 or 1
Status[1:3] (reserved)	0	0	0
Status[7:4] (log2(bytes per atom))	2	2	2
Status[11:8] (log2(atoms per line))	2	2	2
Status[15:12] (log2(number of sets))	6	7	9
Status[27:16] (number of ways - 1)	1	1	1
Lock Status[7:0] (number of blocks that lock)	1	1	1
Lock Status[23:8] (block size in words)	256	512	2048
Lock Status[31:24] (number of blocks that are locked)	0 or 1	0 or 1	0 or 1



<b>Way 0</b>	Set_Data [Starting Set]	Destination Address (DA)
	Tag (Starting set)	DA + 4H
	Valid Bits (Starting set)	DA + 8H
	Word 0	DA + CH
	Word 1	DA + 10H
	Word 2	DA + 14H
	Word 3	DA + 18H
<b>Way 1</b>	Tag (Starting set)	DA + 1CH
	Valid Bits (Starting set)	DA + 20H
	Word 0	DA + 24H
	Word 1	DA + 28H
	Word 2	DA + 2CH
	Word 3	DA + 30H
	<b>Way 0</b>	Set_Data [Starting Set + 1]
Tag (Starting set + 1)		DA + 38H
Valid Bits (Starting set + 1)		DA + 3CH

6

Figure 6-5. Store Instruction Cache to Memory Output Format






Figure 6-6. I-Cache Set Data, Tag and Valid Bit Formats



Action:

```

if (PC.em != supervisor)
    generate_fault(TYPE.MISMATCH);
switch (src1[7:0]) {
    case 0:    # Disable instruction cache.
               disable_instruction_cache( );
               break;
    case 1:    # Enable instruction cache.
               enable_instruction_cache( );
               break;
    case 2:    # Globally invalidate instruction cache.
               # Includes locked lines also.
               invalidate_instruction_cache( );
               unlock_icache( );
               break;
    case 3:    # Load & Lock code into Instruction-Cache
               # src_dst has number of contiguous blocks to lock.
               # src2 has starting address of code to lock.
               # On the i960 Jx, src2 is aligned to a quad word boundary
               aligned_addr = src2 & 0xFFFFFFF0;
               invalidate(I-cache); unlock(I-cache);
               for (j = 0; j < src_dst; j++)
                   {
                       way = way_associated_with_block(j);
                       start = src2 + j*block_size;
                       end = start + block_size;
                       for (i = start; i < end; i=i+4)
                           {
                               set = set_associated_with(i);
                               word = word_associated_with(i);
                               Icache_line[set][way][word] =
                                   memory[i];
                               update_tag_n_valid_bits(set,way,word)
                               lock_icache(set,way,word);
                           } } break;
    case 4:    # Get instruction cache status into src_dst.
               if (Icache_enabled) src_dst[0] = 1;
               else src_dst[0] = 0;
               # Atom is 4 bytes.
               src_dst[7:4] = log2(bytes per atom);
               # 4 atoms per line.
               src_dst[11:8] = log2(atoms per line);
               src_dst[15:12] = log2(number of sets);
               src_dst[27:16] = number of ways-1; #in lines per set
               # cache size = ([27:16]+1) << ([7:4] + [11:8] + [15:12])
               break;

```

```

case 5:    # Get instruction cache locking status into dst.
           src_dst[7:0] = number_of_blocks_that_lock;
           src_dst[23:8] = block_size_in_words;
           src_dst[31:24] = number_of_blocks_that_are_locked;
           break;
case 6:    # Store instr cache sets to memory pointed to by src2.
           start = src_dst[15:0]    # Starting set number
           end   = src_dst[31:16]   # Ending set number
                                   # (zero-origin).
           if (end >= Icache_max_sets)
               end = Icache_max_sets - 1;
           if (start > end)
               generate_fault(OPERATION.INVALID_OPERAND);
           memadr = src2;           # Must be word-aligned.
           if(0x3 & memadr != 0)
               generate_fault(OPERATION.INVALID_OPERAND);
           for (set = start; set <= end; set++){
               # Set_Data is described at end of this code flow.
               memory[memadr] = Set_Data[set];
               memadr += 4;
               for (way = 0; way < numb_ways; way++){
                   {memory[memadr] = tags[set][way];
                     memadr += 4;
                     memory[memadr] = valid_bits[set][way];
                     memadr += 4;
                     for (word = 0; word < words_in_line;
                           word++){
                         {memory[memadr] =
                           Icache_line[set][way][word];
                           memadr += 4;
                         }
                     }
                   } } break;
           }
default:   # Reserved.
           generate_fault(OPERATION.INVALID_OPERAND);
           break;}

```

Faults:           STANDARD                           Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).  
                   TYPE.MISMATCH                 Attempt to execute instruction while not in  
   supervisor mode.







## INSTRUCTION SET REFERENCE

Example:

```
icctl g0,g1,g2      # g0 = 3, g1=0x10000000, g2=1
                   # Load and lock 1 block of cache
                   # (one way) with
                   # location of code at starting
                   # 0x10000000.
```

Opcode:           **icctl**           65BH           REG

See Also:         **sysctl**

Notes:            This instruction is implemented on the 80960Rx, 80960Hx and 80960Jx processor families only, and may or may not be implemented on future i960 processors.

### 6.2.34 intctl

Mnemonic: **intctl** Global Enable and Disable of Interrupts

Format: **intctl** *src1* *dst*  
reg/lit reg

Description: Globally enables, disables or returns the current status of interrupts depending on the value of *src1*. Returns the previous interrupt enable state (1 for enabled or 0 for disabled) in *dst*. When the state of the global interrupt enable is changed, the processor ensures that the new state is in full effect before the instruction completes. (This instruction is implemented by manipulating ICON.gie.)

<i>src1</i> Value	Operation
0	Disables interrupts
1	Enables interrupts
2	Returns current interrupt enable status

```

Action: if (PC.em != supervisor)
        generate_fault(TYPE.MISMATCH);
old_interrupt_enable = global_interrupt_enable;
switch(src1) {
    case 0: # Disable. Set ICON.gie to one.
            globally_disable_interrupts;
            global_interrupt_enable = false;
            order_wrt(subsequent_instructions);
            break;
    case 1: # Enable. Clear ICON.gie to zero.
            globally_enable_interrupts;
            global_interrupt_enable = true;
            order_wrt(subsequent_instructions);
            break;
    case 2: # Return status. Return ICON.gie
            break;
    default:
            generate_fault(OPERATION.INVALID_OPERAND);
            break;
}
if(old_interrupt_enable)
    dst = 1;
else
    dst = 0;

```





Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).  
TYPE.MISMATCH Attempt to execute instruction while not in supervisor mode.

Example: # ICON.gie = 0, interrupts enabled  
intctl 0, g4 # Disable interrupts (ICON.gie = 1)  
# g4 = 1

Opcode: **intctl** 658H REG

See Also: **intdis, inten**

Notes: This instruction is implemented on the 80960Rx, 80960Hx and 80960Jx processor families only, and may or may not be implemented on future i960 processors.



## INSTRUCTION SET REFERENCE

### 6.2.35 **intdis**

Mnemonic: **intdis** Global Interrupt Disable

Format: **intdis**

Description: Globally disables interrupts and ensures that the change takes effect before the instruction completes. This operation is implemented by setting ICON.gie to one.

Action: if (PC.em != supervisor)  
         generate\_fault(TYPE.MISMATCH);  
 # Implemented by setting ICON.gie to one.  
 globally\_disable\_interrupts;  
 global\_interrupt\_enable = false;  
 order\_wrt(subsequent\_instructions);

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).  
 TYPE.MISMATCH Attempt to execute instruction while not in supervisor mode.

Example: 

```
intdis      # ICON.gie = 0, interrupts enabled
           # Disable interrupts.
           # ICON.gie = 1
```

Opcode: **intdis** 5B4H REG

See Also: **intctl, inten**

Notes: This instruction is implemented on the 80960Rx, 80960Hx and 80960Jx processor families only, and may or may not be implemented on future i960 processors.





### 6.2.37 LOAD

Mnemonic:	<b>ld</b>	Load
	<b>ldob</b>	Load Ordinal Byte
	<b>ldos</b>	Load Ordinal Short
	<b>ldib</b>	Load Integer Byte
	<b>ldis</b>	Load Integer Short
	<b>ldl</b>	Load Long
	<b>ldt</b>	Load Triple
	<b>ldq</b>	Load Quad

Format:	<b>ld*</b>	<i>src</i> ,	<i>dst</i>
		mem	reg

Description: Copies byte or byte string from memory into a register or group of successive registers.

The *src* operand specifies the address of first byte to be loaded. The full range of addressing modes may be used in specifying *src*. Refer to [CHAPTER 2, DATA TYPES AND MEMORY ADDRESSING MODES](#) for more information.

*dst* specifies a register or the first (lowest numbered) register of successive registers.

**ldob** and **ldib** load a byte and **ldos** and **ldis** load a half word and convert it to a full 32-bit word. Data being loaded is sign-extended during integer loads and zero-extended during ordinal loads.

**ld**, **ldl**, **ldt** and **ldq** instructions copy 4, 8, 12 and 16 bytes, respectively, from memory into successive registers.

For **ldl**, *dst* must specify an even numbered register (i.e., g0, g2...). For **ldt** and **ldq**, *dst* must specify a register number that is a multiple of four (i.e., g0, g4, g8, g12, r4, r8, r12). Results are unpredictable when registers are not aligned on the required boundary or when data extends beyond register g15 or r15 for **ldl**, **ldt** or **ldq**.

Action: **ld**:  
`dst = read_memory(effective_address)[31:0];`  
`if((effective_address[1:0] != 002) && unaligned_fault_enabled)`  
`generate_fault(OPERATION.UNALIGNED);`

**ldob**:  
`dst[7:0] = read_memory(effective_address)[7:0];`  
`dst[31:8] = 0x000000;`



**Idib:**

```
dst[7:0] = read_memory(effective_address)[7:0];
if(dst[7] == 0)
    dst[31:8] = 0x000000;
else
    dst[31:8] = 0xFFFFFFFF;
```

**Idos:**

```
dst = read_memory(effective_address)[15:0];
# Order depends on endianness. See
# section 2.2.2, "Byte Ordering" (pg. 2-4)
dst[31:16] = 0x0000;
if((effective_address[0] != 02) && unaligned_fault_enabled)
    generate_fault(OPERATION.UNALIGNED);
```

6

**Idis:**

```
dst[15:0] = read_memory(effective_address)[15:0];
# Order depends on endianness. See
# section 2.2.2, "Byte Ordering" (pg. 2-4)
if(dst[15] == 02)
    dst[31:16] = 0x0000;
else
    dst[31:16] = 0xFFFF;
if((effective_address[0] != 02) && unaligned_fault_enabled)
    generate_fault(OPERATION.UNALIGNED);
```

**Idl:**

```
if((reg_number(dst) % 2) != 0)
    generate_fault(OPERATION.INVALID_OPERAND);
# dst not modified.
else
{
    dst = read_memory(effective_address)[31:0];
    dst+_1 = read_memory(effective_address+_4)[31:0];
    if((effective_address[2:0] != 0002) && unaligned_fault_enabled)
        generate_fault(OPERATION.UNALIGNED);
}
```

**Idt:**

```
if((reg_number(dst) % 4) != 0)
    generate_fault(OPERATION.INVALID_OPERAND);
# dst not modified.
else
{
    dst = read_memory(effective_address)[31:0];
    dst+_1 = read_memory(effective_address+_4)[31:0];
```





**6.2.38**    **Ida**

Mnemonic:    **Ida**            Load Address

Format:        **Ida**            *src*,            *dst*  
    mem            reg  
    *efa*

Description:    Computes the effective address specified with *src* and stores it in *dst*. The *src* address is not checked for validity. Any addressing mode may be used to calculate *efa*.

An important application of this instruction is to load a constant longer than 5 bits into a register. (To load a register with a constant of 5 bits or less, **mov** can be used with a literal as the *src* operand.)

Action:        *dst* = effective\_address;

Faults:        STANDARD                            Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example:        `lda 58 (g9), g1        # g1 = g9+58`  
    `lda 0x749, r8        # r8 = 0x749`

Opcode:        **Ida**            8CH            MEM



**6.2.39 mark**

Mnemonic: **mark** Mark

Format: **mark**

Description: Generates mark trace fault when mark trace mode is enabled. Mark trace mode is enabled when the PC register trace enable bit (bit 0) and the TC register mark trace mode bit (bit 7) are set.

When mark trace mode is not enabled, **mark** behaves like a no-op.

For more information on trace fault generation, refer to [CHAPTER 9, TRACING AND DEBUGGING](#).

Action: if(PC.te && TC.mk)  
generate\_fault(TRACE.MARK)

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).  
TRACE.MARK Trace fault is generated if PC.te=1 and TC.mk=1.

Example: # Assume that the mark trace  
# mode is enabled.  
  
ld xyz, r4  
addi r4, r5, r6  
mark  
  
# Mark trace event is generated  
# at this point in the  
# instruction stream.

Opcode: **mark** 66BH REG

See Also: **fmark, modpc, modtc**

**6.2.40 modac**

Mnemonic: **modac** Modify AC

Format: **modac** *mask*, *src*, *dst*  
 reg/lit reg/lit reg

Description: Reads and modifies the AC register. *src* contains the value to be placed in the AC register; *mask* specifies bits that may be changed. Only bits set in *mask* are modified. Once the AC register is changed, its initial state is copied into *dst*.

Action: temp = AC;  
 AC = (src & mask) | (AC & ~mask);  
 dst = temp;

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: modac g1, g9, g12 # AC = g9, masked by g1.  
 # g12 = initial value of AC.

Opcode: **modac** 645H REG

See Also: **modpc, modtc**

Side Effects: Sets the condition code in the arithmetic controls.



**6.2.41 modi**

Mnemonic:	<b>modi</b>	Modulo Integer
Format:	<b>modi</b>	<i>src1</i> , <i>src2</i> , <i>dst</i> reg/lit reg/lit reg
Description:	Divides <i>src2</i> by <i>src1</i> , where both are integers and stores the modulo remainder of the result in <i>dst</i> . When the result is nonzero, <i>dst</i> has the same sign as <i>src1</i> .	
Action:	<pre> if(src1 == 0)     {   dst = undefined_value;       generate_fault(ARITHMETIC.ZERO_DIVIDE);     } dst = src2 - (src2/src1) * src1; if((src2 * src1 &lt; 0) &amp;&amp; (dst != 0))     dst = dst + src1; </pre>	
Faults:	STANDARD	Refer to <a href="#">section 6.1.6, “Faults”</a> (pg. 6-5).
	ARITHMETIC.ZERO_DIVIDE	The <i>src1</i> operand is zero.
Example:	<code>modi r9, r2, r5 # r5 = modulo (r2/r9)</code>	
Opcode:	<b>modi</b>	749H REG
See Also:	<b>divi, divo, remi, remo</b>	
Notes:	<b>modi</b> generates the correct result (0) when computing $-2^{31} \bmod -1$ , although the corresponding 32-bit division does overflow, it does not generate a fault.	

**6.2.42 modify**

Mnemonic: **modify** Modify

Format: **modify** *mask*, *src*, *src/dst*  
reg/lit reg/lit reg

Description: Modifies selected bits in *src/dst* with bits from *src*. The *mask* operand selects the bits to be modified: only bits set in the *mask* operand are modified in *src/dst*.

Action:  $src\_dst = (src \& mask) | (src\_dst \& \sim mask);$

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: `modify g8, g10, r4` # r4 = g10 masked by g8.

Opcode: **modify** 650H REG

See Also: **alterbit, extract**



### 6.2.43 modpc

Mnemonic:	<b>modpc</b>	Modify Process Controls		
Format:	<b>modpc</b>	<i>src</i> , reg/lit	<i>mask</i> , reg/lit	<i>src/dst</i> reg
Description:	<p>Reads and modifies the PC register as specified with <i>mask</i> and <i>src/dst</i>. <i>src/dst</i> operand contains the value to be placed in the PC register; <i>mask</i> operand specifies bits that may be changed. Only bits set in the <i>mask</i> are modified. Once the PC register is changed, its initial value is copied into <i>src/dst</i>. The <i>src</i> operand is a dummy operand that should specify the same register as the <i>src/dst</i> operand.</p> <p>The processor must be in supervisor mode to use this instruction with a non-zero mask value. When <i>mask</i>=0, this instruction can be used to read the process controls, without the processor being in supervisor mode.</p> <p>When the action of this instruction lowers the processor priority, the processor checks the interrupt table for pending interrupts.</p> <p>When process controls are changed, the processor recognizes the changes immediately except in one situation: when <b>modpc</b> is used to change the trace enable bit, the processor may not recognize the change before the next four non-branch instructions are executed. For more information see <a href="#">section 3.7.3, “Process Controls (PC) Register”</a> (pg. 3-21).</p>			
Action:	<pre> if(mask != 0) {   if(PC.em != supervisor)     generate_fault(TYPE.MISMATCH);   temp = PC;   PC = (mask &amp; src_dst)   (PC &amp; ~mask);   src_dst = temp;   if(temp.priority &gt; PC.priority)     check_pending_interrupts; } else   src_dst = PC; </pre>			
Faults:	STANDARD TYPE.MISMATCH	Refer to <a href="#">section 6.1.6, “Faults”</a> (pg. 6-5).		
Example:	<pre> modpc g9, g9, g8    # process controls = g8                    # masked by g9. </pre>			
Opcode:	<b>modpc</b>	655H	REG	



See Also:

**modac, modtc**

Notes:

Since **modpc** does not switch stacks, it should not be used to switch the mode of execution from supervisor to user (the supervisor stack can get corrupted in this case). The call and return mechanism should be used instead.

### 6.2.44 modtc

Mnemonic: **modtc** Modify Trace Controls

Format: **modtc** *mask*, *src2*, *dst*  
 reg/lit reg/lit reg

Description: Reads and modifies TC register as specified with *mask* and *src2*. The *src2* operand contains the value to be placed in the TC register; *mask* operand specifies bits that may be changed. Only bits set in *mask* are modified. *mask* must not enable modification of reserved bits. Once the TC register is changed, its initial state is copied into *dst*.

The changed trace controls may take effect immediately or may be delayed. When delayed, the changed trace controls may not take effect until after the first non-branching instruction is fetched from memory or after four non-branching instructions are executed.

For more information on the trace controls, refer to [CHAPTER 8, FAULTS](#) and [CHAPTER 9, TRACING AND DEBUGGING](#).

Action: mode\_bits = 0x000000FE;  
 event\_flags = 0X0F000000  
 temp = TC;  
 tempa = (event\_flags & TC & mask) | (mode\_bits & mask);  
 TC = (tempa & src2) | (TC & ~tempa);  
 dst = temp;

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: modtc g12, g10, g2 # trace controls = g10 masked  
 # by g12; previous trace  
 # controls stored in g2.

Opcode: **modtc** 654H REG

See Also: **modac, modpc**





## 6.2.45 MOVE

Mnemonic:     **mov**            Move  
                  **movl**        Move Long  
                  **movt**        Move Triple  
                  **movq**        Move Quad

Format:         **mov\***        *src1*,            *dst*  
                                   reg/lit            reg

Description:    Copies the contents of one or more source registers (specified with *src*) to one or more destination registers (specified with *dst*).

For **movl**, **movt** and **movq**, *src1* and *dst* specify the first (lowest numbered) register of several successive registers. *src1* and *dst* registers must be even numbered (e.g., g0, g2, ... or r4, r6, ...) for **movl** and an integral multiple of four (e.g., g0, g4, ... or r4, r8, ...) for **movt** and **movq**.

The moved register values are unpredictable when: 1) the *src* and *dst* operands overlap; 2) registers are not properly aligned.

Action:         **mov:**  
                   if(is\_reg(src1))  
                       dst = src1;  
                   else  
                   {    dst[4:0] = src1;   #src1 is a 5-bit literal.  
                       dst[31:5] = 0;  
                   }  
                   **movl:**  
                   if((reg\_num(src1)%2 != 0) || (reg\_num(dst)%2 != 0))  
                   {    dst = undefined\_value;  
                       dst+\_1 = undefined\_value;  
                       generate\_fault(OPERATION.INVALID\_OPERAND);  
                   }  
                   else if(is\_reg(src1))  
                   {    dst = src1;  
                       dst+\_1 = src1+\_1;  
                   }  
                   else  
                   {    dst[4:0] = src1;   #src1 is a 5-bit literal.  
                       dst[31:5] = 0;  
                       dst+\_1[31:0] = 0;  
                   }

```

movt:
if((reg_num(src1)%4 != 0) || (reg_num(dst)%4 != 0))
{
    dst = undefined_value;
    dst+_1 = undefined_value;
    dst+_2 = undefined_value;
    generate_fault(OPERATION.INVALID_OPERAND);
}
else if(is_reg(src1))
{
    dst = src1;
    dst+_1 = src1+_1;
    dst+_2 = src1+_2;
}
else
{
    dst[4:0] = src1;    #src1 is a 5-bit literal.
    dst[31:5] = 0;
    dst+_1[31:0] = 0;
    dst+_2[31:0] = 0;
}
}

movq:
if((reg_num(src1)%4 != 0) || (reg_num(dst)%4 != 0))
{
    dst = undefined_value;
    dst+_1 = undefined_value;
    dst+_2 = undefined_value;
    dst+_3 = undefined_value;
    generate_fault(OPERATION.INVALID_OPERAND);
}
else if(is_reg(src1))
{
    dst = src1;
    dst+_1 = src1+_1;
    dst+_2 = src1+_2;
    dst+_3 = src1+_3;
}
else
{
    dst[4:0] = src1;    #src1 is a 5 bit literal.
    dst[31:5] = 0;
    dst+_1[31:0] = 0;
    dst+_2[31:0] = 0;
    dst+_3[31:0] = 0;
}
}

```

Faults:           STANDARD                           Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example:           movt g8, r4                       # r4, r5, r6 = g8, g9, g10





## INSTRUCTION SET REFERENCE

Opcode:	<b>mov</b>	5CCH	REG
	<b>movl</b>	5DCH	REG
	<b>movt</b>	5ECH	REG
	<b>movq</b>	5FCH	REG

See Also: **LOAD, STORE, lda**



## INSTRUCTION SET REFERENCE

### 6.2.46 **muli, mulo**

Mnemonic:	<b>muli</b> <b>mulo</b>	Multiply Integer Multiply Ordinal	
Format:	<b>mul*</b>	<i>src1</i> , reg/lit	<i>src2</i> , reg/lit
Description:	Multiplies the <i>src2</i> value by the <i>src1</i> value and stores the result in <i>dst</i> . The binary results from these two instructions are identical. The only difference is that <b>muli</b> can signal an integer overflow.		
Action:	<p><b>mulo:</b> dst = (src2 * src1)[31:0];</p> <p><b>muli:</b> true_result = (src1 * src2); dst = true_result[31:0]; if((true_result &gt; (2**31) - 1)    (true_result &lt; -2**31))# Check for overflow { if(AC.om == 1)     AC.of = 1;   else     generate_fault(ARITHMETIC.OVERFLOW); }</p>		
Faults:	STANDARD ARITHMETIC.OVERFLOW	Refer to <a href="#">section 6.1.6, “Faults”</a> (pg. 6-5). Result is too large for destination register ( <b>muli</b> only). When a condition of overflow occurs, the least significant 32 bits of the result are stored in the destination register.	
Example:	mul <sub>i</sub> r3, r4, r9      # r9 = r4 * r3		
Opcode:	<b>muli</b> <b>mulo</b>	741H 701H	REG REG
See Also:	<b>emul, ediv, divi, divo</b>		

**6.2.47 nand**

Mnemonic: **nand** Nand

Format: **nand** *src1*, *src2*, *dst*  
 reg/lit reg/lit reg

Description: Performs a bitwise NAND operation on *src2* and *src1* values and stores the result in *dst*.

Action:  $dst = \sim src2 | \sim src1;$

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: `nand g5, r3, r7 # r7 = r3 NAND g5`

Opcode: **nand** 58EH REG

See Also: **and, andnot, nor, not, notand, notor, or, ornot, xnor, xor**



## INSTRUCTION SET REFERENCE

**6.2.48 nor**

Mnemonic:	<b>nor</b>	Nor		
Format:	<b>nor</b>	<i>src1</i> , reg/lit	<i>src2</i> , reg/lit	<i>dst</i> reg
Description:	Performs a bitwise NOR operation on the <i>src2</i> and <i>src1</i> values and stores the result in <i>dst</i> .			
Action:	$dst = \sim src2 \& \sim src1;$			
Faults:	STANDARD	Refer to <a href="#">section 6.1.6, “Faults”</a> (pg. 6-5).		
Example:	<code>nor g8, 28, r5      # r5 = 28 NOR g8</code>			
Opcode:	<b>nor</b>	588H	REG	
See Also:	<b>and, andnot, nand, not, notand, notor, or, ornot, xnor, xor</b>			



**6.2.49 not, notand**

Mnemonic: **not** Not  
**notand** Not And

Format: **not** *src1*, *dst*  
reg/lit reg  
**notand** *src1*, *src2*, *dst*  
reg/lit reg/lit reg

Description: Performs a bitwise NOT (**not** instruction) or NOT AND (**notand** instruction) operation on the *src2* and *src1* values and stores the result in *dst*.

Action: **not:**  
 $dst = \sim src1;$

**notand:**  
 $dst = \sim src2 \& src1;$

Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example: `not g2, g4` #  $g4 = \text{NOT } g2$   
`notand r5, r6, r7` #  $r7 = \text{NOT } r6 \text{ AND } r5$

Opcode: **not** 58AH REG  
**notand** 584H REG

See Also: **and, andnot, nand, nor, notor, or, ornot, xnor, xor**



## INSTRUCTION SET REFERENCE

### 6.2.50 notbit

Mnemonic:	<b>notbit</b>	Not Bit		
Format:	<b>notbit</b>	<i>bitpos</i> , reg/lit	<i>src2</i> , reg/lit	<i>dst</i> reg
Description:	Copies the <i>src2</i> value to <i>dst</i> with one bit toggled. The <i>bitpos</i> operand specifies the bit to be toggled.			
Action:	$dst = src2 \wedge 2^{*(src1 \% 32)}$ ;			
Faults:	STANDARD	Refer to <a href="#">section 6.1.6, "Faults"</a> (pg. 6-5).		
Example:	notbit r3, r12, r7 # r7 = r12 with the bit # specified in r3 toggled.			
Opcode:	<b>notbit</b>	580H	REG	
See Also:	<b>alterbit, chkbit, clrbit, setbit</b>			





**6.2.51 notor**

Mnemonic: **notor** Not Or

Format: **notor** *src1*, *src2*, *dst*  
 reg/lit reg/lit reg

Description: Performs a bitwise NOTOR operation on *src2* and *src1* values and stores result in *dst*.

Action:  $dst = \sim src2 | src1;$

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: `notor g12, g3, g6 # g6 = NOT g3 OR g12`

Opcode: **notor** 58DH REG

See Also: **and, andnot, nand, nor, not, notand, or, ornot, xnor, xor**



## INSTRUCTION SET REFERENCE

### 6.2.52 or, ornot

Mnemonic:	<b>or</b>	Or		
	<b>ornot</b>	Or Not		
Format:	<b>or</b>	<i>src1</i> , reg/lit	<i>src2</i> , reg/lit	<i>dst</i> reg
	<b>ornot</b>	<i>src1</i> , reg/lit	<i>src2</i> , reg/lit	<i>dst</i> reg
Description:	Performs a bitwise OR ( <b>or</b> instruction) or ORNOT ( <b>ornot</b> instruction) operation on the <i>src2</i> and <i>src1</i> values and stores the result in <i>dst</i> .			
Action:	<b>or:</b> $dst = src2   src1;$  <b>ornot:</b> $dst = src2   \sim src1;$			
Faults:	STANDARD	Refer to <a href="#">section 6.1.6, "Faults"</a> (pg. 6-5).		
Example:	<code>or 14, g9, g3           # g3 = g9 OR 14</code> <code>ornot r3, r8, r11      # r11 = r8 OR NOT r3</code>			
Opcode:	<b>or</b>	587H	REG	
	<b>ornot</b>	58BH	REG	
See Also:	<b>and, andnot, nand, nor, not, notand, notor, xnor, xor</b>			



**6.2.53 remi, remo**

Mnemonic: **remi** Remainder Integer  
**remo** Remainder Ordinal

Format: **rem\*** *src1*, *src2*, *dst*  
reg/lit reg/lit reg

Description: Divides *src2* by *src1* and stores the remainder in *dst*. The sign of the result (when nonzero) is the same as the sign of *src2*.

Action: **remi, remo:**  
if(*src1* == 0)  
generate\_fault(ARITHMETIC.ZERO\_DIVIDE);  
*dst* = *src2* - (*src2*/*src1*)\**src1*;

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

ARITHMETIC.ZERO\_DIVIDE The *src1* operand is 0.

Example: `remo r4, r5, r6 # r6 = r5 rem r4`

Opcode: **remi** 748H REG  
**remo** 708H REG

See Also: **modi**

Notes: **remi** produces the correct result (0) even when computing  $-2^{31}$  **remi** -1, which would cause the corresponding division to overflow, although no fault is generated.



**6.2.54     ret**

Mnemonic:     **ret**           Return

Format:        **ret**

Description:   Returns program control to the calling procedure. The current stack frame (i.e., that of the called procedure) is deallocated and the FP is changed to point to the calling procedure's stack frame. Instruction execution is continued at the instruction pointed to by the RIP in the calling procedure's stack frame, which is the instruction immediately following the call instruction.

As shown in the action statement below, the return-status field and prereturn-trace flag determine the action that the processor takes on the return. These fields are contained in bits 0 through 3 of register r0 of the called procedure's local registers.

See [CHAPTER 7, PROCEDURE CALLS](#) for more on **ret**.

```

Action:        implicit_synchf();
               if(pfp.p && PC.te && TC.p)
               {   pfp.p = 0;
                   generate_fault(TRACE.PRERETURN);
               }
               switch(return_status_field)
               {
                 case 0002:        #local return
                   get_FP_and_IP();
                   break;
                 case 0012:        #fault return
                   tempa = memory(FP-16);
                   tempb = memory(FP-12);
                   get_FP_and_IP();
                   AC = tempb;
                   if(execution_mode == supervisor)
                     PC = tempa;
                   break;
                 case 0102:        #supervisor return, trace on return disabled
                   if(execution_mode != supervisor)
                     get_FP_and_IP();
                   else
                   {   PC.te = 0;
                       execution_mode = user;
                       get_FP_and_IP();
                   }
                   break;
               }

```

```

case 0112:      # supervisor return, trace on return enabled
    if(execution_mode != supervisor)
        get_FP_and_IP();
    else
    {   PC.te = 1;
        execution_mode = user;
        get_FP_and_IP();
    }
    break;
case 1002:      #reserved - unpredictable behavior
    break;
case 1012:      #reserved - unpredictable behavior
    break;
case 1102:      #reserved - unpredictable behavior
    break;
case 1112:      #interrupt return
    tempa = memory(FP-16);
    tempb = memory(FP-12);
    get_FP_and_IP();
    AC = tempb;
    if(execution_mode == supervisor)
        PC = tempa;
        check_pending_interrupts();
        break;
}

get_FP_and_IP()
{   FP = PFP;
    free(current_register_set);
    if(not_allocated(FP))
        retrieve_from_memory(FP);
    IP = RIP;
}

```

Faults:           STANDARD                   Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example:           ret                        # Program control returns to  
  # context of calling procedure.

Opcode:           **ret**            0AH           CTRL

See Also:         **call, calls, callx**

## INSTRUCTION SET REFERENCE

### 6.2.55 rotate

Mnemonic: **rotate** Rotate

Format: **rotate** *len*, *src2*, *dst*  
 reg/lit reg/lit reg

Description: Copies *src2* to *dst* and rotates the bits in the resulting *dst* operand to the left (toward higher significance). Bits shifted off left end of word are inserted at right end of word. The *len* operand specifies number of bits that the *dst* operand is rotated.

This instruction can also be used to rotate bits to the right. The number of bits the word is to be rotated right should be subtracted from 32 and the result used as the *len* operand.

Action: *src2* is rotated by *len* mod 32. This value is stored in *dst*.

Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example: rotate 13, r8, r12 # r12 = r8 with bits rotated  
 # 13 bits to left.

Opcode: **rotate** 59DH REG

See Also: **SHIFT, eshro**



**6.2.56 scanbit**

Mnemonic: **scanbit** Scan For Bit

Format: **scanbit** *src1*, *dst*  
                                   reg/lit            reg

Description: Searches *src1* for a set bit (1 bit). When a set bit is found, the bit number of the most significant set bit is stored in the *dst* and the condition code is set to 010<sub>2</sub>. When *src* value is zero, all 1's are stored in *dst* and condition code is set to 000<sub>2</sub>.

Action: `dst = 0xFFFFFFFF;`  
`AC.cc = 0002;`  
`for(i = 31; i >= 0; i--)`  
`{ if((src1 & 2**i) != 0)`  
`{ dst = i;`  
`AC.cc = 0102;`  
`break;`  
`}`  
`}`



Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example: `scanbit g8, g10` # assume g8 is nonzero  
                                   # g10 = bit number of most-  
                                   # significant set bit in g8;  
                                   # AC.cc = 010<sub>2</sub>.

Opcode: **scanbit** 641H REG

See Also: **spanbit, setbit**

Side Effects: Sets the condition code in the arithmetic controls.



**6.2.57 scanbyte**

Mnemonic: **scanbyte** Scan Byte Equal

Format: **scanbyte** *src1*, *src2*  
                                   reg/lit                    reg/lit

Description: Performs byte-by-byte comparison of *src1* and *src2* and sets condition code to 010<sub>2</sub> when any two corresponding bytes are equal. When no corresponding bytes are equal, condition code is set to 000<sub>2</sub>.

Action: `if((src1 & 0x000000FF) == (src2 & 0x000000FF)
          || (src1 & 0x0000FF00) == (src2 & 0x0000FF00)
          || (src1 & 0x00FF0000) == (src2 & 0x00FF0000)
          || (src1 & 0xFF000000) == (src2 & 0xFF000000))
          AC.cc = 0102;
          else
          AC.cc = 0002;`

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: `# Assume r9 = 0x11AB1100
scanbyte 0x00AB0011, r9# AC.cc = 0102`

Opcode: **scanbyte** 5ACH REG

See Also: **bswap**

Side Effects: Sets the condition code in the arithmetic controls.



**6.2.58 SEL<cc>**

Mnemonic:     **selno**     Select Based on Unordered  
                   **selg**        Select Based on Greater  
                   **sele**        Select Based on Equal  
                   **selge**     Select Based on Greater or Equal  
                   **sell**        Select Based on Less  
                   **selne**     Select Based on Not Equal  
                   **selle**     Select Based on Less or Equal  
                   **selo**        Select Based on Ordered

Format:         **sel\***        *src1*,            *src2*,            *dst*  
                                   reg/lit            reg/lit            reg

Description:    Selects either *src1* or *src2* to be stored in *dst* based on the condition code bits in the arithmetic controls. When for Unordered the condition code is 0, or when for the other cases the logical AND of the condition code and the mask part of the opcode is not zero, then the value of *src2* is stored in the destination. Else, the value of *src1* is stored in the destination.



**Table 6.17. Condition Code Mask Descriptions**

Instruction	Mask	Condition
<b>selno</b>	000 <sub>2</sub>	Unordered
<b>selg</b>	001 <sub>2</sub>	Greater
<b>sele</b>	010 <sub>2</sub>	Equal
<b>selge</b>	011 <sub>2</sub>	Greater or equal
<b>sell</b>	100 <sub>2</sub>	Less
<b>selne</b>	101 <sub>2</sub>	Not equal
<b>selle</b>	110 <sub>2</sub>	Less or equal
<b>selo</b>	111 <sub>2</sub>	Ordered

Action:         if ((mask & AC.cc) || (mask == AC.cc))  
                                   dst = src2;  
                   else  
                                   dst = src1;

Faults:         STANDARD                           Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).





**6.2.59 setbit**

Mnemonic: **setbit** Set Bit

Format: **setbit** *bitpos*, *src*, *dst*  
reg/lit reg/lit reg

Description: Copies *src* value to *dst* with one bit set. *bitpos* specifies bit to be set.

Action:  $dst = src | (2^{**}(\text{bitpos}\%32));$

Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example: `setbit 15, r9, r1 # r1 = r9 with bit 15 set.`

Opcode: **setbit** 583H REG

See Also: **alterbit, chkbit, clrbit, notbit**



**6.2.60 SHIFT**

Mnemonic:	<b>shlo</b>	Shift Left Ordinal
	<b>shro</b>	Shift Right Ordinal
	<b>shli</b>	Shift Left Integer
	<b>shri</b>	Shift Right Integer
	<b>shrdi</b>	Shift Right Dividing Integer

Format:	<b>sh*</b>	<i>len</i> ,	<i>src</i> ,	<i>dst</i>
		reg/lit	reg/lit	reg

Description: Shifts *src* left or right by the number of bits indicated with the *len* operand and stores the result in *dst*. Bits shifted beyond register boundary are discarded. For values of *len* > 32, the processor interprets the value as 32.

**shlo** shifts zeros in from the least significant bit; **shro** shifts zeros in from the most significant bit. These instructions are equivalent to **mulo** and **divo** by the power of 2, respectively.

**shli** shifts zeros in from the least significant bit. An overflow fault is generated when the bits shifted out are not the same as the most significant bit (bit 31). When overflow occurs, *dst* equals *src* shifted left as much as possible without overflowing.

**shri** performs a conventional arithmetic shift-right operation by shifting in the most significant bit (bit 31). When this instruction is used to divide a negative integer operand by the power of 2, it produces an incorrect quotient (discarding the bits shifted out has the effect of rounding the result toward negative).

**shrdi** is provided for dividing integers by the power of 2. With this instruction, 1 is added to the result when the bits shifted out are non-zero and the *src* operand was negative, which produces the correct result for negative operands.

**shli** and **shrdi** are equivalent to **muli** and **divi** by the power of 2.

Action:

```

shlo:
if(src1 < 32)
    dst = src * (2**len);
else
    dst = 0;
shro:
if(src1 < 32)
    dst = src / (2**len);
else
    dst = 0;

```



```

shli:
if(len > 32)
    count = 32;
else
    count = src1;
temp = src;
while((temp[31] == temp[30]) && (count > 0))
{
    temp = (temp * 2)[31:0];
    count = count - 1;
}
dst = temp;
if(count > 0)
{
    if(AC.om == 1)
        AC.of = 1;
    else
        generate_fault(ARITHMETIC.OVERFLOW);
}

```

```

shri:
if(len > 32)
    count = 32;
else
    count = src1;
temp = src;
while(count > 0)
{
    temp = (temp >> 1)[31:0];
    temp[31] = src[31];
    count = count - 1;
}
dst = temp;

```

```

shrdi:
dst = src / (2**len);

```

Faults:            STANDARD                            Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).  
                   ARITHMETIC.OVERFLOW        For **shli**.

Example:            `shli 13, g4, r6`        # g6 = g4 shifted left 13 bits.

Opcode:	<b>shlo</b>	59CH	REG
	<b>shro</b>	598H	REG
	<b>shli</b>	59EH	REG
	<b>shri</b>	59BH	REG
	<b>shrdi</b>	59AH	REG



## INSTRUCTION SET REFERENCE

See Also: **divi, muli, rotate, eshro**

Notes: **shli** and **shrdi** are identical to multiplications and divisions for all positive and negative values of *src2*. **shri** is the conventional arithmetic right shift that does not produce a correct quotient when *src2* is negative.

**6.2.61 spanbit**

Mnemonic: **spanbit** Span Over Bit

Format: **spanbit** *src*, *dst*  
reg/lit reg

Description: Searches *src* value for the most significant clear bit (0 bit). When a most significant 0 bit is found, its bit number is stored in *dst* and condition code is set to 010<sub>2</sub>. When *src* value is all 1's, all 1's are stored in *dst* and condition code is set to 000<sub>2</sub>.

Action:

```
dst = 0xFFFFFFFF;
AC.cc = 0002;
for(i = 31; i >= 0; i--)
{   if((src1 & 2**i) == 0)
    {   dst = i;
        AC.cc = 0102;
        break;
    }
}
```



Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example:

```
spanbit r2, r9      # Assume r2 is not 0xffffffff
                   # r9 = bit number of most-
                   # significant clear bit in r2;
                   # AC.cc = 0102
```

Opcode: **spanbit** 640H REG

See Also: **scanbit**

Side Effects: Sets the condition code in the arithmetic controls.



## 6.2.62 STORE

Mnemonic:	<b>st</b>	Store
	<b>stob</b>	Store Ordinal Byte
	<b>stos</b>	Store Ordinal Short
	<b>stib</b>	Store Integer Byte
	<b>stis</b>	Store Integer Short
	<b>stl</b>	Store Long
	<b>stt</b>	Store Triple
	<b>stq</b>	Store Quad

Format:	<b>st*</b>	<i>src1</i> , reg	<i>dst</i> mem
---------	------------	----------------------	-------------------

Description: Copies a byte or group of bytes from a register or group of registers to memory. *src* specifies a register or the first (lowest numbered) register of successive registers.

*dst* specifies the address of the memory location where the byte or first byte or a group of bytes is to be stored. The full range of addressing modes may be used in specifying *dst*. Refer to [section 2.3, “MEMORY ADDRESSING MODES”](#) (pg. 2-6) for a complete discussion.

**stob** and **stib** store a byte and **stos** and **stis** store a half word from the *src* register’s low order bytes. Data for ordinal stores is truncated to fit the destination width. When the data for integer stores cannot be represented correctly in the destination width, an Arithmetic Integer Overflow fault is signaled.

**st**, **stl**, **stt** and **stq** copy 4, 8, 12 and 16 bytes, respectively, from successive registers to memory.

For **stl**, *src* must specify an even numbered register (e.g., g0, g2, ... or r0, r2, ...). For **stt** and **stq**, *src* must specify a register number that is a multiple of four (e.g., g0, g4, g8, ... or r0, r4, r8, ...).

Action:

```

st:
if (illegal_write_to_on_chip_RAM)
    generate_fault(TYPE.MISMATCH);
else if ((effective_address[1:0] != 002) && unaligned_fault_enabled)
    {store_to_memory(effective_address)[31:0] = src1;
    generate_fault(OPERATION.UNALIGNED);}
else
    store_to_memory(effective_address)[31:0] = src1;

```





Action:

```

stob:
if (illegal_write_to_on_chip_RAM_or_MMR)
    generate_fault(TYPE.MISMATCH);
else
    store_to_memory(effective_address)[7:0] = src1[7:0];

stib:
if (illegal_write_to_on_chip_RAM_or_MMR)
    generate_fault(TYPE.MISMATCH);
else if ((src1[31:8] != 0) && (src1[31:8] != 0xFFFFFFFF))
    {
        store_to_memory(effective_address)[7:0] = src1[7:0];
        if (AC.om == 1)
            AC.of = 1;
        else
            generate_fault(ARITHMETIC.OVERFLOW);
    }
else
    store_to_memory(effective_address)[7:0] = src1[7:0];
end if;

stos:
if (illegal_write_to_on_chip_RAM_or_MMR)
    generate_fault(TYPE.MISMATCH);
else if ((effective_address[0] != 02) && unaligned_fault_enabled)
    {
        store_to_memory(effective_address)[15:0] = src1[15:0];
        generate_fault(OPERATION.UNALIGNED);
    }
else
    store_to_memory(effective_address)[15:0] = src1[15:0];

stis:
if (illegal_write_to_on_chip_RAM_or_MMR)
    generate_fault(TYPE.MISMATCH);
else if ((effective_address[0] != 02) && unaligned_fault_enabled)
    {
        store_to_memory(effective_address)[15:0] = src1[15:0];
        generate_fault(OPERATION.UNALIGNED);
    }
else if ((src1[31:16] != 0) && (src1[31:16] != 0xFFFF))
    {
        store_to_memory(effective_address)[15:0] = src1[15:0];
        if (AC.om == 1)
            AC.of = 1;
        else
            generate_fault(ARITHMETIC.OVERFLOW);
    }

```

```

else
    store_to_memory(effective_address)[15:0] = src1[15:0];

stl:
if (illegal_write_to_on_chip_RAM_or_MMR)
    generate_fault(TYPE.MISMATCH);
else if (reg_number(src1) % 2 != 0)
    generate_fault(OPERATION.INVALID_OPERAND);
else if ((effective_address[2:0] != 0002) && unaligned_fault_enabled)
    {
        store_to_memory(effective_address)[31:0] = src1;
        store_to_memory(effective_address + 4)[31:0] = src1+_1;
        generate_fault (OPERATION.UNALIGNED);
    }
else
    {
        store_to_memory(effective_address)[31:0] = src1;
        store_to_memory(effective_address + 4)[31:0] = src1+_1;
    }

stt:
if (illegal_write_to_on_chip_RAM_or_MMR)
    generate_fault(TYPE.MISMATCH);
else if (reg_number(src1) % 4 != 0)
    generate_fault(OPERATION.INVALID_OPERAND);
else if ((effective_address[3:0] != 00002) && unaligned_fault_enabled)
    {
        store_to_memory(effective_address)[31:0] = src1;
        store_to_memory(effective_address + 4)[31:0] = src1+_1;
        store_to_memory(effective_address + 8)[31:0] = src1+_2;
        generate_fault (OPERATION.UNALIGNED);
    }
else
    {
        store_to_memory(effective_address)[31:0] = src1;
        store_to_memory(effective_address + 4)[31:0] = src1+_1;
        store_to_memory(effective_address + 8)[31:0] = src1+_2;
    }

stq:
if (illegal_write_to_on_chip_RAM_or_MMR)
    generate_fault(TYPE.MISMATCH);
else if (reg_number(src1) % 4 != 0)
    generate_fault(OPERATION.INVALID_OPERAND);
else if ((effective_address[3:0] != 00002) && unaligned_fault_enabled)
    {
        store_to_memory(effective_address)[31:0] = src1;
        store_to_memory(effective_address + 4)[31:0] = src1+_1;
        store_to_memory(effective_address + 8)[31:0] = src1+_2;
    }

```







6.2.64 SUB<cc>

Mnemonic:     **subono**     Subtract Ordinal if Unordered  
                   **subog**        Subtract Ordinal if Greater  
                   **suboe**        Subtract Ordinal if Equal  
                   **suboge**     Subtract Ordinal if Greater or Equal  
                   **subol**        Subtract Ordinal if Less  
                   **subone**     Subtract Ordinal if Not Equal  
                   **subole**     Subtract Ordinal if Less or Equal  
                   **suboo**        Subtract Ordinal if Ordered  
                   **subino**     Subtract Integer if Unordered  
                   **subig**        Subtract Integer if Greater  
                   **subie**        Subtract Integer if Equal  
                   **subige**     Subtract Integer if Greater or Equal  
                   **subil**        Subtract Integer if Less  
                   **subine**     Subtract Integer if Not Equal  
                   **subile**     Subtract Integer if Less or Equal  
                   **subio**        Subtract Integer if Ordered

Format:         **sub\***        *src1*,            *src2*,            *dst*  
                                   reg/lit            reg/lit            reg

Description:    Subtracts *src1* from *src2* conditionally based on the condition code bits in the arithmetic controls.

When for Unordered the condition code is 0, or when for the other cases the logical AND of the condition code and the mask part of the opcode is not zero; then *src1* is subtracted from *src2* and the result stored in the destination.

Instruction	Mask	Condition
subono, subino	000 <sub>2</sub>	Unordered
subog, subig	001 <sub>2</sub>	Greater
suboe, subie	010 <sub>2</sub>	Equal
suboge, subige	011 <sub>2</sub>	Greater or equal
subol, subil	100 <sub>2</sub>	Less
subone, subine	101 <sub>2</sub>	Not equal
subole, subile	110 <sub>2</sub>	Less or equal
suboo, subio	111 <sub>2</sub>	Ordered







See Also:

**subc, subi, subo, SEL<cc>, TEST<cc>**

Notes:

These core instructions are not implemented on 80960Cx, Kx and Sx processors.



## INSTRUCTION SET REFERENCE

### 6.2.65 **subi, subo**

Mnemonic:	<b>subi</b> <b>subo</b>	Subtract Integer Subtract Ordinal		
Format:	<b>sub*</b>	<i>src1</i> , reg/lit	<i>src2</i> , reg/lit	<i>dst</i> reg
Description:	Subtracts <i>src1</i> from <i>src2</i> and stores the result in <i>dst</i> . The binary results from these two instructions are identical. The only difference is that <b>subi</b> can signal an integer overflow.			
Action:	<p><b>subo:</b> dst = (src2 - src1)[31:0];</p> <p><b>subi:</b> true_result = (src2 - src1); dst = true_result[31:0]; if((true_result &gt; (2**31) - 1)    (true_result &lt; -2**31))# Check for overflow {   if(AC.om == 1)     AC.of = 1;   else     generate_fault(ARITHMETIC.OVERFLOW); }</p>			
Faults:	STANDARD ARITHMETIC.OVERFLOW	Refer to <a href="#">section 6.1.6, “Faults”</a> (pg. 6-5). For <b>subi</b> .		
Example:	subi g6, g9, g12   # g12 = g9 - g6			
Opcode:	<b>subi</b> <b>subo</b>	593H 592H	REG REG	
See Also:	<b>addi, addo, subc, addc</b>			



**6.2.66 syncf**

Mnemonic: **syncf** Synchronize Faults

Format: **syncf**

Description: Waits for all faults to be generated that are associated with any prior uncompleted instructions.

Action: `if(AC.nif == 1)`  
           `break;`  
           `else`  
             `wait_until_all_previous_instructions_in_flow_have_completed();`  
             `# This also means that all of the faults on these instructions have`  
             `# been reported.`

Faults: STANDARD Refer to [section 6.1.6, “Faults”](#) (pg. 6-5).

Example: `ld xyz, g6`  
           `addi r6, r8, r8`  
           `syncf`  
           `and g6, 0x1f, g8`  
           `# The syncf instruction ensures that any faults`  
           `# that may occur during the execution of the`  
           `# ld and addi instructions occur before the`  
           `# and instruction is executed.`

Opcode: **syncf** 66FH REG

See Also: **mark, fmark**


**6.2.67 sysctl**

Mnemonic: **sysctl** System Control

Format: **sysctl** *src1*, *src2*, *src/dst*  
 reg/lit reg/lit reg

Description: Performs system management and control operations including requesting software interrupts, invalidating the instruction cache, configuring the instruction cache, processor reinitialization, modifying memory-mapped registers, and acquiring breakpoint resource information.

Processor control function specified by the message field of *src1* is executed. The type field of *src1* is interpreted depending upon the command. Remaining *src1* bits are reserved. The *src2* and *src3* operands are also interpreted depending upon the command.



**Figure 6-7. Src1 Operand Interpretation**

**Table 6-18. sysctl Field Definitions**


Message	src1			src2	src/dst
	Type	Field 1	Field 2	Field 3	Field 4
Request Interrupt	0x0	Vector Number	N/U	N/U	N/U
Invalidate Cache	0x1	N/U	N/U	N/U	N/U
Configure Instruction Cache	0x2	Cache Mode Configuration (See Table 6-19)	N/U	Cache load address	N/U
Reinitialize	0x3	N/U	N/U	Starting IP	PRCB Pointer
Load Control Register	0x4	Register Group Number	N/U	N/U	N/U
Modify Memory-Mapped Control Register (MMR)	0x5	N/U	Lower 2 bytes of MMR address	Value to write	Mask
Breakpoint Resource Request	0x6	N/U	N/U	N/U	Breakpoint info (See Figure 6-8)

**NOTE:** Sources and fields that are not used (designated N/U) are ignored.



**Table 6-19. Cache Mode Configuration**

Mode Field	Mode Description	80960JA	80960JF/JD	80960JT
000 <sub>2</sub>	Normal cache enabled	2 Kbyte	4 Kbyte	16 Kbyte
XX1 <sub>2</sub>	Full cache disabled	2 Kbyte	4 Kbyte	16 Kbyte
100 <sub>2</sub> or 110 <sub>2</sub>	Load and lock one way of the cache	1 Kbyte	2 Kbyte	8 Kbyte



**6**

**Figure 6-8. src/dst Interpretation for Breakpoint Resource Request**

```

Action:      if (PC.em != supervisor)
              generate_fault(TYPE.MISMATCH);
              order_wrt(previous_operations);
              OPtr = (src1 & 0xff00) >> 8;
              switch (OPtr) {
                case 0: # Signal Software Interrupt
                      vector_to_post = 0xff & src1;
                      priority_to_post = vector_to_post >> 3;
                      pend_ints_addr = interrupt_table_base + 4 + priority_to_post;
                      pend_priority = memory_read(interrupt_table_base,atomic_lock);
                      # Priority zero just rescans Interrupt Table
                      if (priority_to_post != 0)
                          { pend_ints = memory_read(pend_ints_addr, non-cacheable)
                            pend_ints[7 & vector] = 1;
                              pend_priority[priority_to_post] = 1;
                                memory_write(pend_ints_addr, pend_ints); }
                      memory_write(interrupt_table_base,pend_priority,atomic_unlock);
                      # Update internal software priority with highest priority interrupt
                      # from newly adjusted Pending Priorities word. The current internal
                      # software priority is always replaced by the new, computed one. (If
                      # there is no bit set in pending_priorities word for the current
                      # internal one, then it is discarded by this action.)
                      if (pend_priority == 0)
                          SW_Int_Priority = 0;
                      else { msb_set = scan_bit(pend_priority);
                            SW_Int_Priority = msb_set; }
                      # Make sure change to internal software priority takes full effect
  
```



```

# before next instruction.
order_wrt(subsequent_operations);
    break;
case 1:    # Global Invalidate Instruction Cache
    invalidate_instruction_cache( );
    unlock_instruction_cache( );
    break;
case 2:    # Configure Instruction-Cache
    mode = src1 & 0xff;
    if (mode & 1) disable_instruction_cache;
    else switch (mode) {
        case 0:    enable_instruction_cache; break;
        case 4,6:  # Load & Lock code into I-Cache
            # All contiguous blocks are locked.
            # Note:  block = way on i960 Jx processor.
            # src2 has starting address of code to lock.
            # src2 is aligned to a quad word
            # boundary.
            aligned_addr = src2 & 0xfffff0;
            invalidate(I-cache); unlock(I-cache);
            for (j = 0; j < number_of_blocks_that_lock; j++)
            { way = block_associated_with_block(j);
              start = src2 + j*block_size;
              end = start + block_size;
              for (i = start; i < end; i=i+4)
                { set = set_associated_with(i);
                  word = word_associated_with(i);
                  Icache_line[set][way][word] =
                                memory[i];
                  update_tag_n_valid_bits(set,way,word)
                  lock_icache(set,way,word);
                } } break;
        default:
            generate_operation_invalid_operand_fault;
    } break;
case 3:    # Software Re-init
    disable(I_cache); invalidate(I_cache);
    disable(D_cache); invalidate(D_cache);
    Process_PRCB(dst); # dst has ptr to new PRCB
    IP = src2;
    break;
case 4:    /* Load One Group of Control Registers From Control Table*/
    grpoff = (src1 & 0xff) * 16;
    for (i = 0; i < 4; i=i+4)

```



```
memory[control_reg_addr(i,grpoff)] = memory[i+grpoff];
}
break;
```

```
Action: case 5: # Modify One Memory-Mapped Control Register (MMR)
           # src1[31:16] has lower 2 bytes of MMR address
           # src2 has value to write; dst has mask.
           # After operation, dst has old value of MMR
           addr = (0xff00 << 16) | (src1 >> 16);
           temp = memory[addr];
           memory[addr] = (src2 & dst) | (temp & ~dst);
           dst = temp;
           break;
        case 6: # Breakpoint Resource Request
           acquire_available_instr_breakpoints( );
           dst[3:0] = number_of_available_instr_breakpoints;
           acquire_available_data_breakpoints( );
           dst[7:4] = number_of_available_data_breakpoints;
           dst[31:8] = 0;
           break;
        default: # Reserved, fault occurs
           generate_fault(OPERATION.INVALID_OPERAND);
           break;
    }
order_wrt(subsequent_operations);
```



Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

```
Example: ldconst 0x100,r6 # Set up message.
          sysctl r6,r7,r8 # Invalidate I-cache.
          # r7, r8 are not used.
          ldconst 0x204, g0 # Set up message type and
          # cache configuration mode.
          # Lock half cache.
          ldconst 0x20000000,g2 # Starting address of code.
          sysctl g0,g2,g2 # Execute Load and Lock.
```

Opcode: **sysctl** 659H REG

See Also: **dcctl, icctl**

Notes: This instruction is implemented on 80960Rx, Hx, Jx and Cx processors, and may or may not be implemented on future i960 processors.



## INSTRUCTION SET REFERENCE

### 6.2.68 TEST<cc>

Mnemonic:	<b>teste</b>	Test For Equal
	<b>testne</b>	Test For Not Equal
	<b>testl</b>	Test For Less
	<b>testle</b>	Test For Less Or Equal
	<b>testg</b>	Test For Greater
	<b>testge</b>	Test For Greater Or Equal
	<b>testo</b>	Test For Ordered
	<b>testno</b>	Test For Not Ordered

Format: **test\*** *dst:src1*  
reg

Description: Stores a true (01H) in *dst* when the logical AND of the condition code and opcode mask part is not zero. Otherwise, the instruction stores a false (00H) in *dst*. For **testno** (Unordered), a true is stored when the condition code is 000<sub>2</sub>, otherwise a false is stored.

The following table shows the condition code mask for each instruction. The mask is in bits 0-2 of the opcode.

**Table 6-20. Condition Code Mask Descriptions**

Instruction	Mask	Condition
<b>testno</b>	000 <sub>2</sub>	Unordered
<b>testg</b>	001 <sub>2</sub>	Greater
<b>teste</b>	010 <sub>2</sub>	Equal
<b>testge</b>	011 <sub>2</sub>	Greater or equal
<b>testl</b>	100 <sub>2</sub>	Less
<b>testne</b>	101 <sub>2</sub>	Not equal
<b>testle</b>	110 <sub>2</sub>	Less or equal
<b>testo</b>	111 <sub>2</sub>	Ordered



Action: For all **TEST<cc>** except **testno**:  
 if((mask & AC.cc) != 000<sub>2</sub>)  
     src1 = 1;     #true value  
 else  
     src1 = 0;     #false value

**testno**:  
 if(AC.cc == 000<sub>2</sub>)  
     src1 = 1;     #true value  
 else  
     src1 = 0;     #false value

Faults: STANDARD Refer to [section 6.1.6, "Faults"](#) (pg. 6-5).

Example: # Assume AC.cc = 100<sub>2</sub>  
 testl g9                   # g9 = 0x00000001



Opcode:

<b>teste</b>	22H	COBR
<b>testne</b>	25H	COBR
<b>testl</b>	24H	COBR
<b>testle</b>	26H	COBR
<b>testg</b>	21H	COBR
<b>testge</b>	23H	COBR
<b>testo</b>	27H	COBR
<b>testno</b>	20H	COBR

See Also: **cmpi, cmpdeci, cmpinci**



## INSTRUCTION SET REFERENCE

### 6.2.69 **xnor, xor**

Mnemonic:	<b>xnor</b>	Exclusive Nor		
	<b>xor</b>	Exclusive Or		
Format:	<b>xnor</b>	<i>src1</i> ,	<i>src2</i> ,	<i>dst</i>
		reg/lit	reg/lit	reg
	<b>xor</b>	<i>src1</i> ,	<i>src2</i> ,	<i>dst</i>
		reg/lit	reg/lit	reg
Description:	Performs a bitwise XNOR ( <b>xnor</b> instruction) or XOR ( <b>xor</b> instruction) operation on the <i>src2</i> and <i>src1</i> values and stores the result in <i>dst</i> .			
Action:	<b>xnor:</b> $dst = \sim(src2   src1)   (src2 \& src1);$			
	<b>xor:</b> $dst = (src2   src1) \& \sim(src2 \& src1);$			
Faults:	STANDARD	Refer to <a href="#">section 6.1.6, "Faults"</a> (pg. 6-5).		
Example:	<pre>xnor r3, r9, r12    # r12 = r9 XNOR r3 xor g1, g7, g4     # g4 = g7 XOR g1</pre>			
Opcode:	<b>xnor</b>	589H	REG	
	<b>xor</b>	586H	REG	
See Also:	<b>and, andnot, nand, nor, not, notand, notor, or, ornot</b>			





# PROCEDURE CALLS





## CHAPTER 7 PROCEDURE CALLS

This chapter describes mechanisms for making procedure calls, which include branch-and-link instructions, built-in call and return mechanism, call instructions (**call**, **callx**, **calls**), return instruction (**ret**) and call actions caused by interrupts and faults.

The i960<sup>®</sup> processor architecture supports two methods for making procedure calls:

- A RISC-style branch-and-link: a fast call best suited for calling procedures that do not call other procedures.
- An integrated call and return mechanism: a more versatile method for making procedure calls, providing a highly efficient means for managing a large number of registers and the program stack.

On a branch-and-link (**bal**, **balx**), the processor branches and saves a return IP in a register. The called procedure uses the same set of registers and the same stack as the calling procedure. On a call (**call**, **callx**, **calls**) or when an interrupt or fault occurs, the processor also branches to a target instruction and saves a return IP. Additionally, the processor saves the local registers and allocates a new set of local registers and a new stack for the called procedure. The saved context is restored when the return instruction (**ret**) executes.

In many RISC architectures, a branch-and-link instruction is used as the base instruction for coding a procedure call. The user program then handles register and stack management for the call. Since the i960 architecture provides a fully integrated call and return mechanism, coding calls with branch-and-link are not necessary. Additionally, the integrated call is much faster than typical RISC-coded calls.

The branch-and-link instruction in the i960 processor family, therefore, is used primarily for calling leaf procedures. Leaf procedures call no other procedures; they reside at the “leaves” of the call tree.

In the i960 architecture the integrated call and return mechanism is used in two ways:

- explicit calls to procedures in a user’s program
- implicit calls to interrupt and fault handlers

The remainder of this chapter explains the generalized call mechanism used for explicit and implicit calls and call and return instructions.

## PROCEDURE CALLS

The processor performs two call actions:

- |                   |  |
|-------------------|--|
| <i>local</i>      | When a local call is made, execution mode remains unchanged and the stack frame for the called procedure is placed on the <i>local stack</i> . The local stack refers to the stack of the calling procedure. |
| <i>supervisor</i> | When a supervisor call is made from user mode, execution mode is switched to supervisor and the stack frame for the called procedure is placed on the <i>supervisor stack</i> .                              |
- When a supervisor call is issued from supervisor mode, the call degenerates into a local call (i.e., no mode nor stack switch).

Explicit procedure calls can be made using several instructions. Local call instructions **call** and **callx** perform a local call action. With **call** and **callx**, the called procedure's IP is included as an operand in the instruction.

A system call is made with **calls**. This instruction is similar to **call** and **callx**, except that the processor obtains the called procedure's IP from the *system procedure table*. A system call, when executed, is directed to perform either the local or supervisor call action. These calls are referred to as *system-local* and *system-supervisor* calls, respectively. A system-supervisor call is also referred to as a *supervisor call*.

### 7.1 CALL AND RETURN MECHANISM

At any point in a program, the i960 processor has access to the global registers, a local register set and the procedure stack. A subset of the stack allocated to the procedure is called the stack frame.

- When a call executes, a new stack frame is allocated for the called procedure. The processor also saves the current local register set, freeing these registers for use by the newly called procedure. In this way, every procedure has a unique stack and a unique set of local registers.
- When a return executes, the current local register set and current stack frame are deallocated. The previous local register set and previous stack frame are restored.

#### 7.1.1 Local Registers and the Procedure Stack

The processor automatically allocates a set of 16 local registers for each procedure. Since local registers are on-chip, they provide fast access storage for local variables. Of the 16 local registers, 13 are available for general use; r0, r1 and r2 are reserved for linkage information to tie procedures together.

The processor does not always clear or initialize the set of local registers assigned to a new procedure. Therefore, initial register contents are unpredictable. Also, because the processor does not initialize the local register save area in the newly created stack frame for the procedure, its contents are equally unpredictable.



The procedure stack can be located anywhere in the address space and grows from low addresses to high addresses. It consists of contiguous frames, one frame for each active procedure. Local registers for a procedure are assigned a save area in each stack frame (Figure 7-1). The procedure stack, available to the user, begins after this save area.

To increase procedure call speed, the architecture allows an implementation to cache the saved local register sets on-chip. Thus, when a procedure call is made, the contents of the current set of local registers often do not have to be written out to the save area in the stack frame in memory. Refer to section 7.1.4, “Caching Local Register Sets” (pg. 7-7) and section 7.1.4.1, “Reserving Local Register Sets for High Priority Interrupts” (pg. 7-8) for more about local registers and procedure stack interrelations.




Figure 7-1. Procedure Stack Structure and Local Registers

## PROCEDURE CALLS

### 7.1.2 Local Register and Stack Management

Global register g15 (FP) and local registers r0 (PFP), r1 (SP) and r2 (RIP) contain information to link procedures together and link local registers to the procedure stack (Figure 7-1). The following subsections describe this linkage information.

#### 7.1.2.1 Frame Pointer

The frame pointer is the current stack frame's first byte address. It is stored in global register g15, the frame pointer (FP) register. The FP register is always reserved for the frame pointer; do not use g15 for general storage.

Stack frame alignment is defined for each implementation of the i960 processor family, according to an SALIGN parameter (see section A.3, "Data and Data Structure Alignment" (pg. A-3)). In the i960 Jx processor, stacks are aligned on 16-byte boundaries (see Figure 7-1). When the processor needs to create a new frame on a procedure call, it adds a padding area to the stack so that the new frame starts on a 16-byte boundary.

#### 7.1.2.2 Stack Pointer

The stack pointer is the byte-aligned address of the stack frame's next unused byte. The stack pointer value is stored in local register r1, the stack pointer (SP) register. The procedure stack grows upward (i.e., toward higher addresses). When a stack frame is created, the processor automatically adds 64 to the frame pointer value and stores the result in the SP register. This action creates the register save area in the stack frame for the local registers.

The program must modify the SP register value when data is stored or removed from the stack. The i960 architecture does not provide an explicit push or pop instruction to perform this action. This is typically done by adding the size of all pushes to the stack in one operation.

#### 7.1.2.3 Considerations When Pushing Data onto the Stack

Care should be taken in writing to the stack in the presence of unforeseen faults and interrupts. In the general case, to ensure that the data written to the stack is not corrupted by a fault or interrupt record, the SP should be incremented first to allocate the space, and then the data should be written to the allocated space:

```
mov    sp,r4
addo   24,sp,sp
st     data,(r4)
...
st     data,20(r4)
```



#### 7.1.2.4 Considerations When Popping Data off the Stack

Care should be taken in reading the stack in the presence of unforeseen faults and interrupts. In the general case, to ensure that data about to be popped off the stack is not corrupted by a fault or interrupt record, the data should be read first and then the sp should be decremented:

```
subo 24,sp,r4
ld   20(r4),rn
...
ld   (r4),rn
mov  r4,sp
```

#### 7.1.2.5 Previous Frame Pointer

The previous frame pointer is the previous stack frame's first byte address. This address's upper 28 bits are stored in local register r0, the previous frame pointer (PFP) register. The four least-significant bits of the PFP are used to store the return type field. See [Figure 7-5](#) and [Table 7-2](#) for more information on the PFP and the return-type field.

7

#### 7.1.2.6 Return Type Field

PFP register bits 0 through 3 contain return type information for the calling procedure. When a procedure call is made — either explicit or implicit — the processor records the call type in the return type field. The processor then uses this information to select the proper return mechanism when returning to the calling procedure. The use of this information is described in [section 7.8, “RETURNS”](#) (pg. 7-20).

#### 7.1.2.7 Return Instruction Pointer

The actual RIP register (r2) is reserved by the processor to support the call and return mechanism and must not be used by software; the actual value of RIP is unpredictable at all times. For example, an implicit procedure call (fault or interrupt) can occur at any time and modify the RIP. An OPERATION.INVALID\_OPERAND fault is generated when attempting to write to the RIP.

The image of the RIP register in the stack frame is used by the processor to determine that frame's return instruction address. When a call is made, the processor saves the address of the instruction after the call in the image of the RIP register in the calling frame.

### 7.1.3 Call and Return Action

To clarify how procedures are linked and how the local registers and stack are managed, the following sections describe a general call and return operation and the operations performed with the FP, SP, PFP and RIP registers.

## PROCEDURE CALLS

The events for call and return operations are given in a logical order of operation. The i960 Jx processor can execute independent operations in parallel; therefore, many of these events execute simultaneously. For example, to improve performance, the processor often begins prefetching of the target instruction for the call or return before the operation is complete.

### 7.1.3.1 Call Operation

When a **call**, **calls** or **callx** instruction is executed or an implicit call is triggered:

1. The processor stores the instruction pointer for the instruction following the call in the current stack's RIP register (r2).
2. The current local registers — including the PFP, SP and RIP registers — are saved, freeing these for use by the called procedure. The local registers are saved in the on-chip local register cache when space is available.
3. The frame pointer (g15) for the calling procedure is stored in the current stack's PFP register (r0). The return type field in the PFP register is set according to the call type which is performed. See [section 7.8, "RETURNS"](#) (pg. 7-20).
4. For a local or system-local call, a new stack frame is allocated by using the old stack pointer value saved in step 2. This value is first rounded to the next 16-byte boundary to create a new frame pointer, then stored in the FP register. Next, 64 bytes are added to create the new frame's register save area. This value is stored in the SP register.

For an interrupt call from user mode in a non-interrupted state, the current interrupt stack pointer value is used instead of the SP value saved in step 2.

For a system-supervisor call from user mode, the current Supervisor Stack Pointer (SSP) value is used instead of the SP value saved in step 2.

5. The instruction pointer is loaded with the address of the first instruction in the called procedure. The processor gets the new instruction pointer from the **call**, the system procedure table, the interrupt table or the fault table, depending on the type of call executed.

Upon completion of these steps, the processor begins executing the called procedure. Sometime before a return or nested call, the local register set is bound to the allocated stack frame.





### 7.1.3.2 Return Operation

A return from any call type — explicit or implicit — is always initiated with a return (**ret**) instruction. On a return, the processor performs these operations:

1. The current stack frame and local registers are deallocated by loading the FP register with the value of the PFP register.
2. The local registers for the return target procedure are retrieved. The registers are usually read from the local register cache; however, in some cases, these registers have been flushed from register cache to memory and must be read directly from the save area in the stack frame.
3. The processor sets the instruction pointer to the value of the RIP register.

Upon completion of these steps, the processor executes the instruction to which it returns. The frames created before the **ret** instruction was executed are overwritten by later implicit or explicit call operations.

7

### 7.1.4 Caching Local Register Sets

Actual implementations of the i960 architecture may cache some number of local register sets within the processor to improve performance. Local registers are typically saved and restored from the local register cache when calls and returns are executed. Other overhead associated with a call or return is performed in parallel with this data movement.

When the number of nested procedures exceeds local register cache size, local register sets must at times be saved to (and restored from) their associated save areas in the procedure stack. Because these operations require access to external memory, this local cache miss affects call and return performance.

When a call is made and no frames are available in the register cache, a register set in the cache must be saved to external memory to make room for the current set of local registers in the cache (see [section 4.2, “LOCAL REGISTER CACHE”](#) (pg. 4-2)). This action is referred to as a frame spill. The oldest set of local registers stored in the cache is spilled to the associated local register save area in the procedure stack. [Figure 7-2](#) illustrates a call operation with and without a frame spill.

Similarly, when a return is made and the local register set for the target procedure is not available in the cache, these local registers must be retrieved from the procedure stack in memory. This operation is referred to as a frame fill. [Figure 7-3](#) illustrates return operations with and without frame fills.

The **flushreg** instruction (described in [section 6.2.30, “flushreg”](#) (pg. 6-54)) writes all local register sets (except the current one) to their associated stack frames in memory. The register cache is then invalidated, meaning that all flushed register sets must be restored from their save areas in memory.

## PROCEDURE CALLS

For most programs, the existence of the multiple local register sets and their saving/restoring in the stack frames should be transparent. However, there are some special cases:

- A store to the register save area in memory does not necessarily update a local register set, unless user software executes **flushreg** first.
- Reading from the register save area in memory does not necessarily return the current value of a local register set, unless user software executes **flushreg** first.
- There is no mechanism, including **flushreg**, to access the current local register set with a read or write to memory.
- **flushreg** must be executed sometime before returning from the current frame when the current procedure modifies the PFP in register r0, or else the behavior of the **ret** instruction is not predictable.
- The values of the local registers r2 to r15 in a new frame are undefined.


**flushreg** is commonly used in debuggers or fault handlers to gain access to all saved local registers. In this way, call history may be traced back through nested procedures.

### 7.1.4.1 Reserving Local Register Sets for High Priority Interrupts

To decrease interrupt latency for high priority interrupts, software can limit the number of frames available to all remaining code. This includes code that is either in the executing state (non-interrupted) or code that is in the interrupted state but has a process priority less than 28. For the purposes of discussion here, this remaining code is referred to as *non-critical code*. Specifying a limit for non-critical code ensures that some number of free frames are available to high-priority interrupt service routines. Software can specify the limit for non-critical code by writing bits 10 through 8 of the register cache configuration word in the PRCB (see [Figure 12-6 on page 12-17](#)). The value indicates how many frames within the register cache may be used by non-critical code before a frame needs to be flushed to external memory. The programmed limit is used only when a frame is pushed, which occurs only for an implicit or explicit call.

Allowed values of the programmed limit range from 0 to 7. Setting the value to 0 reserves no frames for high-priority interrupts. Setting the value to 7 causes the register cache to become disabled for non-critical code. See [section 12.3.1.2, “Process Control Block \(PRCB\)” \(pg. 12-16\)](#).





7

Figure 7-2. Frame Spill




Figure 7-3. Frame Fill



### 7.1.5 Mapping Local Registers to the Procedure Stack

Each local register set is mapped to a register save area of its respective frame in the procedure stack (Figure 7-1). Saved local register sets are frequently cached on-chip rather than saved to memory. The caching mechanism is not write-through. Local register set contents are not saved automatically to the save area in memory when the register set is cached. This would cause a significant performance loss for call operations.

Also, no automatic update policy is implemented for the register cache. When the register save area in memory for a cached register set is modified, there is no guarantee that the modification is reflected when the register set is restored. For a frame spill, the set must be flushed to memory prior to the modification for the modification to be valid.

The **flushreg** instruction causes the contents of all cached local register sets to be written (flushed) to their associated stack frames in memory. The register cache is then invalidated, meaning that all flushed register sets are restored from their save areas in memory. The current set of local registers is not written to memory. **flushreg** is commonly used in debuggers or fault handlers to gain access to all saved local registers. In this way, call history may be traced back through nested procedures. **flushreg** is also used when implementing task switches in multitasking kernels. The procedure stack is changed as part of the task switch. To change the procedure stack, **flushreg** is executed to update the current procedure stack and invalidate all entries in the local register cache. Next, the procedure stack is changed by directly modifying the FP and SP registers and executing a call operation. After **flushreg** executes, the procedure stack may also be changed by modifying the previous frame in memory and executing a return operation.

When a set of local registers is assigned to a new procedure, the processor may or may not clear or initialize these registers. Therefore, initial register contents are unpredictable. Also, the processor does not initialize the local register save area in the newly created stack frame for the procedure; its contents are equally unpredictable.

## 7.2 MODIFYING THE PFP REGISTER

The FP must not be directly modified by user software or risk corrupting the local registers. Instead, implement context switches by modifying the PFP.

Modification of the PFP is typically for context switches; as part of the switch, the active procedure changes the pointer to the frame that it returns to (previous frame pointer — PFP). Great care should be taken in modifying the PFP. In the general case, a **flushreg** must be issued before and after modifying the PFP when the local register cache is enabled (see Example 7-1). This requirement ensures the correct operation of a context switch on all i960 processors in all situations.

### Example 7-1. flushreg

```
# Do a context switch.
# Assume PFP = 0x5000.
flushreg                # Flush Frames to correct address.
lda 0x8000,pfp
flushreg                # Ensure that "ret" gets updated PFP.
ret
```

The **flushreg** before the modification is necessary to ensure that the frame of the previous context (mapped to 0x5000 in the example) is “spilled” to the proper external memory address and removed from the local register cache. When the **flushreg** before the modification was omitted, a **flushreg** (or implicit frame spill due to an interrupt) after the modification of PFP would cause the frame of the previous context to be written to the wrong location in external memory.

The **flushreg** after the modification ensures that outstanding results are completely written to the PFP before a subsequent **ret** instruction can be executed. Recall that the **ret** instruction uses the low-order 4 bits of the PFP to select which **ret** function to perform. Requiring the **flushreg** after the PFP modification allows an i960 implementation to implement a simple mechanism that quickly selects the **ret** function at the time the **ret** instruction is issued and provides a faster return operation.

Note the **flushreg** after the modification executes very quickly because the local register cache has already been flushed by the **flushreg** before; only synchronization of the PFP is performed. i960 processor implementations may provide other mechanisms to ensure PFP synchronization in addition to **flushreg**, but a **flushreg** after a PFP modification is ensured to work on all i960 processors.

## 7.3 PARAMETER PASSING

Parameters are passed between procedures in two ways:

- value*            Parameters are passed directly to the calling procedure as part of the call and return mechanism. This is the fastest method of passing parameters.
- reference*        Parameters are stored in an argument list in memory and a pointer to the argument list is passed in a global register.

When passing parameters by value, the calling procedure stores the parameters to be passed in global registers. Since the calling procedure and the called procedure share the global registers, the called procedure has direct access to the parameters after the call.

When a procedure needs to pass more parameters than fits in the global registers, they can be passed by reference. Here, parameters are placed in an argument list and a pointer to the argument list is placed in a global register.



The argument list can be stored anywhere in memory; however, a convenient place to store an argument list is in the stack for a calling procedure. Space for the argument list is created by incrementing the SP register value. When the argument list is stored in the current stack, the argument list is automatically deallocated when no longer needed.

A procedure receives parameters from — and returns values to — other calling procedures. To do this successfully and consistently, all procedures must agree on the use of the global registers.

Parameter registers pass values into a function. Up to 12 parameters can be passed by value using the global registers. When the number of parameters exceeds 12, additional parameters are passed using the calling procedure's stack; a pointer to the argument list is passed in a pre-designated register. Similarly, several registers are set aside for return arguments and a return argument block pointer is defined to point to additional parameters. When the number of return arguments exceeds the available number of return argument registers, the calling procedure passes a pointer to an argument list on its stack where the remaining return values are placed. [Example 7-2](#) illustrates parameter passing by value and by reference.

7

Local registers are automatically saved when a call is made. Because of the local register cache, they are saved quickly and with no external bus traffic. The efficiency of the local register mechanism plays an important role in two cases when calls are made:

1. When a procedure is called which contains other calls, global parameter registers should be moved to working local registers at the beginning of the procedure. In this way, parameter registers are freed and nested calls are easily managed. The register move instruction necessary to perform this action is very fast; the working parameters — now in local registers — are saved efficiently when nested calls are made.
2. When other procedures are nested within an interrupt or fault procedure, the procedure must preserve all normally non-preserved parameter registers, such as the global registers. This is necessary because the interrupt or fault occurs at any point in the user's program and a return from an interrupt or fault must restore the exact processor state. The interrupt or fault procedure can move non-preserved global registers to local registers before the nested call.

### Example 7-2. Parameter Passing Code Example

```

# Example of parameter passing . . .
# C-source:int a,b[10];
#     a = procl(a,1,'x',&b[0]);
#     assembles to ...
    mov     r3,g0           # value of a
    ldconst 1,g1           # value of 1
    ldconst 120,g2         # value of "x"
    lda     0x40(fp),g3    # reference to b[10]
    call    _procl
    mov     g0,r3          #save return value in "a"
    .
    .
_procl:
    movq    g0,r4          # save parameters
    .
    .                       # other instructions in procedure
    .                       # and nested calls
    mov     r3,g0          # load return parameter
    ret

```

## 7.4 LOCAL CALLS

A local call does not cause a stack switch. A local call can be made two ways:

- with the **call** and **callx** instructions; or
- with a system-local call as described in [section 7.5, “SYSTEM CALLS”](#) (pg. 7-15).

**call** specifies the address of the called procedures as the IP plus a signed, 24-bit displacement (i.e.,  $-2^{23}$  to  $2^{23} - 4$ ). **callx** allows any of the addressing modes to be used to specify the procedure address. The IP-with-displacement addressing mode allows full 32-bit IP-relative addressing.

When a local call is made with a **call** or **callx**, the processor performs the same operation as described in [section 7.1.3.1, “Call Operation”](#) (pg. 7-6). The target IP for the call is derived from the instruction’s operands and the new stack frame is allocated on the current stack.





## 7.5 SYSTEM CALLS

A system call is a call made via the system procedure table. It can be used to make a system-local call — similar to a local call made with **call** and **callx** in the sense that there is no stack nor mode switch — or a system supervisor call. A system call is initiated with **calls**, which requires a procedure number operand. The procedure number provides an index into the system procedure table, where the processor finds IPs for specific procedures.

Using an i960 processor language assembler, a system procedure is directly declared using the `.sysproc` directive. At link time, the optimized call directive, `callj`, is replaced with a **calls** when a system procedure target is specified. (Refer to current i960 processor assembler documentation for a description of the `.sysproc` and `callj` directives.)

The system call mechanism offers two benefits. First, it supports application software portability. System calls are commonly used to call kernel services. By calling these services with a procedure number rather than a specific IP, applications software does not need to be changed each time the implementation of the kernel services is modified. Only the entries in the system procedure table must be changed. Second, the ability to switch to a different execution mode and stack with a system supervisor call allows kernel procedures and data to be insulated from applications code. This benefit is further described in [section 3.8, “USER-SUPERVISOR PROTECTION MODEL”](#) (pg. 3-23).

7

### 7.5.1 System Procedure Table

The system procedure table is a data structure for storing IPs to system procedures. These can be procedures which software can access through (1) a system call or (2) the fault handling mechanism. Using the system procedure table to store IPs for fault handling is described in [section 8.1, “FAULT HANDLING OVERVIEW”](#) (pg. 8-1).

[Figure 7-4](#) shows the system procedure table structure. It is 1088 bytes in length and can have up to 260 procedure entries. At initialization, the processor caches a pointer to the system procedure table. This pointer is located in the PRCB. The following subsections describe this table’s fields.




Figure 7-4. System Procedure Table



**7.5.1.1 Procedure Entries**

A procedure entry in the system procedure table specifies a procedure’s location and type. Each entry is one word in length and consists of an address (IP) field and a type field. The address field gives the address of the first instruction of the target procedure. Since all instructions are word aligned, only the entry’s 30 most significant bits are used for the address. The entry’s two least-significant bits specify entry type. The procedure entry type field indicates call type: system-local call or system-supervisor call (Table 7-1). On a system call, the processor performs different actions depending on the type of call selected.

**Table 7-1. Encodings of Entry Type Field in System Procedure Table**

Encoding	Call Type
00	System-Local Call
01	Reserved <sup>1</sup>
10	System-Supervisor Call
11	Reserved <sup>1</sup>



1. Calls with reserved entry types have unpredictable behavior.

**7.5.1.2 Supervisor Stack Pointer**

When a system-supervisor call is made, the processor switches to a new stack called the *supervisor stack*, when not already in supervisor mode. The processor gets a pointer to this stack from the supervisor stack pointer field in the system procedure table (Figure 7-4) during the reset initialization sequence and caches the pointer internally. Only the 30 most significant bits of the supervisor stack pointer are given. The processor aligns this value to the next 16-byte boundary to determine the first byte of the new stack frame.

**7.5.1.3 Trace Control Bit**

The trace control bit (byte 12, bit 0) specifies the new value of the trace enable bit in the PC register (PC.te) when a system-supervisor call causes a switch from user mode to supervisor mode. Setting this bit to 1 enables tracing in the supervisor mode; setting it to 0 disables tracing. The use of this bit is described in section 9.1.2, “PC Trace Enable Bit and Trace-Fault-Pending Flag” (pg. 9-3).



## PROCEDURE CALLS

### 7.5.2 System Call to a Local Procedure

When a **calls** instruction references an entry in the system procedure table with an entry type of 00, the processor executes a system-local call to the selected procedure. The action that the processor performs is the same as described in [section 7.1.3.1, “Call Operation”](#) (pg. 7-6). The call’s target IP is taken from the system procedure table and the new stack frame is allocated on the current stack, and the processor does not switch to supervisor mode. The **calls** algorithm is described in [section 6.2.14, “calls”](#) (pg. 6-25).

### 7.5.3 System Call to a Supervisor Procedure

When a **calls** instruction references an entry in the system procedure table with an entry type of 10<sub>2</sub>, the processor executes a system-supervisor call to the selected procedure. The call’s target IP is taken from the system procedure table.

The processor performs the same action as described in [section 7.1.3.1, “Call Operation”](#) (pg. 7-6), with the following exceptions:

- When the processor is in user mode, it switches to supervisor mode.
- When a mode switch occurs, SP is read from the Supervisor Stack Pointer (SSP) base. A new frame for the called procedure is placed at the location pointed to after alignment of SP.
- When no mode switch occurs, the new frame is allocated on the current stack.
- When a mode switch occurs, the state of the trace enable bit in the PC register is saved in the return type field in the PFP register. The trace enable bit is then loaded from the trace control bit in the system procedure table.
- When no mode switch occurs, the value 000<sub>2</sub> (**calls** instruction) or 001<sub>2</sub> (fault call) is saved in the return type field of the pfp register.

When the processor switches to supervisor mode, it remains in that mode and creates new frames on the supervisor stack until a return is performed from the procedure that caused the original switch to supervisor mode. While in supervisor mode, either the local call instructions (**call** and **callx**) or **calls** can be used to call procedures.

The user-supervisor protection model and its relationship to the supervisor call are described in [section 3.8, “USER-SUPERVISOR PROTECTION MODEL”](#) (pg. 3-23).



## 7.6 USER AND SUPERVISOR STACKS

When using the user-supervisor protection mechanism, the processor maintains separate stacks in the address space. One of these stacks — the user stack — is for procedures executed in user mode; the other stack — the supervisor stack — is for procedures executed in supervisor mode.

The user and supervisor stacks are identical in structure (Figure 7-1). The base stack pointer for the supervisor stack is automatically read from the system procedure table and cached internally during initialization. Each time a user-to-supervisor mode switch occurs, the cached supervisor stack pointer base is used for the starting point of the new supervisor stack. The base stack pointer for the user stack is usually created in the initialization code. See section 12.2, “INITIALIZATION” (pg. 12-2). The base stack pointers must be aligned to a 16-byte boundary; otherwise, the first frame pointer on the interrupt stack is rounded up to the previous 16-byte boundary.

## 7.7 INTERRUPT AND FAULT CALLS

7

The architecture defines two types of implicit calls that make use of the call and return mechanism: interrupt-handling procedure calls and fault-handling procedure calls. A call to an interrupt procedure is similar to a system-supervisor call. Here, the processor obtains pointers to the interrupt procedures through the interrupt table. The processor always switches to supervisor mode on an interrupt procedure call.


A call to a fault procedure is similar to a system call. Fault procedure calls can be local calls or supervisor calls. The processor obtains pointers to fault procedures through the fault table and (optionally) through the system procedure table.

When a fault call or interrupt call is made, a fault record or interrupt record is placed in the newly generated stack frame for the call. These records hold the machine state and information to identify the fault or interrupt. When a return from an interrupt or fault is executed, machine state is restored from these records. See CHAPTER 8, FAULTS and CHAPTER 11, INTERRUPTS for more information on the structure of the fault and interrupt records.

## PROCEDURE CALLS

### 7.8 RETURNS

The return (**ret**) instruction provides a generalized return mechanism that can be used to return from any procedure that was entered by **call**, **calls**, **callx**, an interrupt call or a fault call. When **ret** executes, the processor uses the information from the return-type field in the PFP register (Figure 7-5) to determine the type of return action to take.



**Figure 7-5. Previous Frame Pointer Register (PFP) (r0)**

*return-type field* indicates the type of call which was made. Table 7-2 shows the return-type field encoding for the various calls: local, supervisor, interrupt and fault.

*trace-on-return flag* (PFP.rt0 or bit 0 of the return-type field) stores the trace enable bit value when an explicit system-supervisor call is made from user mode. When the call is made, the PC register trace enable bit is saved as the trace-on-return flag and then replaced by the trace controls bit in the system procedure table. On a return, the trace enable bit's original value is restored. This mechanism allows instruction tracing to be turned on or off when a supervisor mode switch occurs. See section 9.5.2.1, "Tracing on Explicit Call" (pg. 9-13).

*prereturn-trace flag* (PFP.p) is used in conjunction with call-trace and prereturn-trace modes. When call-trace mode is enabled when a call is made, the processor sets the prereturn-trace flag; otherwise it clears the flag. Then, when this flag is set and prereturn-trace mode is enabled, a prereturn trace event is generated on a return, before any actions associated with the return operation are performed. See section 9.2, "TRACE MODES" (pg. 9-3) for a discussion of interaction between call-trace and prereturn-trace modes with the prereturn-trace flag.



Table 7-2. Encoding of Return Status Field

Return Status Field	Call Type	Return Action
000	Local call (system-local call or system-supervisor call made from supervisor mode)	Local return (return to local stack; no mode switch)
001	Fault call	Fault return
01t	System-supervisor from user mode	Supervisor return (return to user stack, mode switch to user mode, trace enable bit is replaced with the t <sup>1</sup> bit stored in the PFP register on the call)
100	reserved <sup>2</sup>	
101	reserved <sup>2</sup>	
110	reserved <sup>2</sup>	
111	Interrupt call	Interrupt return



**NOTES:**

1. “t” denotes the trace-on-return flag; used only for system supervisor calls which cause a user-to-supervisor mode switch.
2. This return type results in unpredictable behavior.

### 7.9 BRANCH-AND-LINK

A branch-and-link is executed using either the branch-and-link instruction (**bal**) or branch-and-link-extended instruction (**balx**). When either instruction executes, the processor branches to the first instruction of the called procedure (the target instruction), while saving a return IP for the calling procedure in a register. The called procedure uses the same set of local registers and stack frame as the calling procedure:

- For **bal**, the return IP is automatically saved in global register g14
- For **balx**, the return IP instruction is saved in a register specified by one of the instruction’s operands

A return from a branch-and-link is generally carried out with a **bx** (branch extended) instruction, where the branch target is the address saved with the branch-and-link instruction. The branch-and-link method of making procedure calls is recommended for calls to leaf procedures. Leaf procedures typically call no other procedures. Branch-and-link is the fastest way to make a call, providing the calling procedure does not require its own registers or stack frame.







FAULTS





This chapter describes the i960<sup>®</sup> Jx processor's fault handling facilities. Subjects covered include the fault handling data structures and fault handling mechanisms. See [section 8.10, "FAULT REFERENCE"](#) (pg. 8-21) for detailed information on each fault type.

## 8.1 FAULT HANDLING OVERVIEW

The i960 processor architecture defines various conditions in code and/or the processor's internal state that could cause the processor to deliver incorrect or inappropriate results or that could cause it to choose an undesirable control path. These are called *fault conditions*. For example, the architecture defines faults for divide-by-zero and overflow conditions on integer calculations with an inappropriate operand value.

As shown in [Figure 8-1](#), the architecture defines a fault table, a system procedure table, a set of fault handling procedures and stacks (user stack, supervisor stack and interrupt stack) to handle processor-generated faults.

8




Figure 8-1. Fault-Handling Data Structures



## FAULTS

The fault table contains pointers to fault handling procedures. The system procedure table optionally provides an interface to any fault handling procedure and allows faults to be handled in supervisor mode. Stack frames for fault handling procedures are created on either the user or supervisor stack, depending on the mode in which the fault is handled. If the processor is in the interrupted state, the processor uses the interrupt stack.

Once these data structures and the code for the fault procedures are established in memory, the processor handles faults automatically and independently from application software.

The processor can detect a fault at any time while executing instructions, whether from a program, interrupt handling procedure or fault handling procedure. When a fault occurs, the processor determines the fault type and selects a corresponding fault handling procedure from the fault table. It then invokes the fault handling procedure by means of an implicit call. As described later in this chapter, the fault handler call can be:

- A local call (call-extended operation)
- A system-local call (local call through the system procedure table)
- A system-supervisor call (supervisor call through the system procedure table)

A normal fault condition is handled by the processor in the following manner:

- The current local registers are saved and cached on-chip.
- PFP = FP and the value 001 is written to the Return Type Field (Fault Call). Refer to [section 7.8, “RETURNS” \(pg. 7-20\)](#) for more information.
- If the fault call is a system-supervisor call from user mode, the processor switches to the supervisor stack; otherwise, SP is re-aligned on the current stack.
- The processor writes the fault record on the new stack. This record includes information on the fault and the processor’s state when the fault was generated.
- The Instruction Pointer (IP) of the first instruction of the fault handler is accessed through the fault table or through the system procedure table (for system fault calls).

After the fault record is created, the processor executes the selected fault handling procedure. If a fault is recoverable (i.e., the program can be resumed after handling the fault) the Return Instruction Pointer (RIP) is defined for the fault being serviced (see [section 8.10, “FAULT REFERENCE” \(pg. 8-21\)](#)), and the processor will resume execution at the RIP upon return from the fault handler. If the RIP is undefined, the fault handling procedure can create one by using the **flushreg** instruction followed by a modification of the RIP in the previous frame (see [Section 8.7.5 on page 8-15](#)). The fault handler can also call a debug monitor or reset the processor instead of resuming prior execution.

This procedure call mechanism also handles faults that occur:

- While the processor is servicing an interrupt
- While the processor is servicing another fault



8.2 FAULT TYPES

The i960 architecture defines a basic set of faults that are categorized by type and subtype. Each fault has a unique type and subtype number. When the processor detects a fault, it records the fault type and subtype numbers in the fault record. It then uses the type number to select the fault handling procedure.

The fault handling procedure can optionally use the subtype number to select a specific fault handling action. The i960 Jx processor recognizes i960 architecture-defined faults and a new fault subtype for detecting unaligned memory accesses. Table 8-1 lists all faults that the i960 Jx processor detects, arranged by type and subtype. Text that follows the table gives column definitions.

Table 8-1. i960® Jx Processor Fault Types and Subtypes

Fault Type		Fault Subtype		Fault Record
Number	Name	Number or Bit Position	Name	
0H	OVERRIDE	NA	NA	See section 8.10.4, "OVERRIDE Faults" (pg. 8-26)
0H	PARALLEL	NA	NA	see section 8.6.4, "Parallel Faults" (pg. 8-9)
1H	TRACE	Bit 1 Bit 2 Bit 3 Bit 4 Bit 5 Bit 6 Bit 7	INSTRUCTION BRANCH CALL RETURN PREReturn SUPERVISOR MARK/BREAKPOINT	0001 0002H 0001 0004H 0001 0008H 0001 0010H 0001 0020H 0001 0040H 0001 0080H
2H	OPERATION	1H 2H 3H 4H	INVALID_OPCODE UNIMPLEMENTED UNALIGNED INVALID_OPERAND	0002 0001H 0002 0002H 0002 0003H 0002 0004H
3H	ARITHMETIC	1H 2H	INTEGER_OVERFLOW ZERO-DIVIDE	0003 0001H 0003 0002H
4H	Reserved			
5H	CONSTRAINT	1H	RANGE	0005 0001H
6H	Reserved			
7H	PROTECTION	Bit 1	LENGTH	0007 0002H
8H - 9H	Reserved			
AH	TYPE	1H	MISMATCH	000A 0001H
BH - FH	Reserved			

8



## FAULTS

In [Table 8-1](#):

- The first (left-most) column contains the fault type numbers in hexadecimal.
- The second column shows the fault type name.
- The third column gives the fault subtype number as either: (1) a hexadecimal number or (2) as a bit position in the fault record's 8-bit fault subtype field. The bit position method of indicating a fault subtype is used for certain faults (such as trace faults) in which two or more fault subtypes may occur simultaneously.
- The fourth column gives the fault subtype name. For convenience, individual faults are referenced by their fault-subtype names. Thus an OPERATION.INVALID\_OPERAND fault is referred to as an INVALID\_OPERAND fault; an ARITHMETIC.INTEGER\_OVERFLOW fault is referred to as an INTEGER\_OVERFLOW fault.
- The fifth column shows the encoding of the word in the fault record that contains the fault type and fault subtype numbers.


Other i960 processor family members may provide extensions that recognize additional fault conditions. Fault type and subtype encoding allows all faults to be included in the fault table: those that are common to all i960 processors and those that are specific to one or more family members. The fault types are used consistently for all family members. For example, Fault Type 4H is reserved for floating point faults. Any i960 processor with floating point operations uses Entry 4H to store the pointer to the floating point fault handling procedure.

### 8.3 FAULT TABLE

The fault table ([Figure 8-2](#)) is the processor's pathway to the fault handling procedures. It can be located anywhere in the address space. From the process control block, the processor obtains a pointer to the fault table during initialization.

The fault table contains one entry for each fault type. When a fault occurs, the processor uses the fault type to select an entry in the fault table. From this entry, the processor obtains a pointer to the fault handling procedure for the type of fault that occurred. Once called, a fault handling procedure has the option of reading the fault subtype or subtypes from the fault record when determining the appropriate fault recovery action.





8

Figure 8-2. Fault Table and Fault Table Entries



## FAULTS

As indicated in [Figure 8-2](#), two fault table entry types are allowed: local-call entry and system-call entry. Each is two words in length. The entry type field (bits 0 and 1 of the entry's first word) and the value in the entry's second word determine the entry type.

<i>local-call entry</i> (type $00_2$ )	Provides an instruction pointer for the fault handling procedure. The processor uses this entry to invoke the specified procedure by means of an implicit local-call operation. The second word of a local procedure entry is reserved. It must be set to zero when the fault table is created and not accessed after that.
<i>system-call entry</i> (type $10_2$ )	Provides a procedure number in the system procedure table. This entry must have an entry type of $10_2$ and a value in the second word of $0000\ 027FH$ . The processor computes the system procedure number by shifting right the first word of the fault entry by two bit positions. Using this system procedure number, the processor invokes the specified fault handling procedure by means of an implicit call-system operation similar to that performed for the <b>calls</b> instruction.

Other entry types ( $01_2$  and  $11_2$ ) are reserved and have unpredictable behavior.

To summarize, a fault handling procedure can be invoked through the fault table in any of three ways: a local call, a system-local call or a system-supervisor call.

### 8.4 STACK USED IN FAULT HANDLING

The i960 architecture does not define a dedicated fault handling stack. Instead, to handle a fault, the processor uses either the user, interrupt or supervisor stack, whichever is active when the fault is generated. There is, however, one exception: if the user stack is active when a fault is generated and the fault handling procedure is called with an implicit system supervisor call, the processor switches to the supervisor stack to handle the fault.

### 8.5 FAULT RECORD

When a fault occurs, the processor records information about the fault in a fault record in memory. The fault handling procedure uses the information in the fault record to correct or recover from the fault condition and, if possible, resume program execution. The fault record is stored on the same stack that the fault handling procedure will use to handle the fault.






### 8.5.1 Fault Record Description

Figure 8-3 shows the fault record's structure. In this record, the fault's type number and subtype number (or bit positions for multiple subtypes) are stored in the fault type and subtype fields, respectively. The Address of Faulting Instruction Field contains the IP of the instruction that caused the processor to fault.

When a fault is generated, the existing PC and AC register contents are stored in their respective fault record fields. The processor uses this information to resume program execution after the fault is handled.



8

Figure 8-3. Fault Record




## FAULTS

The Resumption Information Field is used to store information about a pending trace fault. If a trace fault and a non-trace fault occur simultaneously, the non-trace fault is serviced first and the pending trace may be lost depending on the non-trace fault encountered. The Trace Reporting paragraph for each fault specifies whether the pending trace is kept or lost.

### 8.5.2 Fault Record Location

The fault record is stored on the stack that the processor uses to execute the fault handling procedure. As shown in Figure 8-4, this stack can be the user stack, supervisor stack or interrupt stack. The fault record begins at byte address  $NFP-1$ .  $NFP$  refers to the new frame pointer that is computed by adding the memory size allocated for padding and the fault record to the previous stack pointer ( $SP$ ). The processor calculates the new stackpointer ( $NSP$ ) by adding 80 bytes to the  $NFP$ .



**Figure 8-4. Storage of the Fault Record on the Stack**



## 8.6 MULTIPLE AND PARALLEL FAULTS

Multiple fault conditions can occur during a single instruction execution and during multiple instruction execution when the instructions are executed by different units within the processor. The following sections describe how faults are handled under these conditions.

### 8.6.1 Multiple Non-Trace Faults on the Same Instruction

Multiple fault conditions can occur during a single instruction execution. For example, an instruction can have an invalid operand and unaligned address. When this situation occurs, the processor is required to recognize and generate at least one of the fault conditions. The processor may not detect all fault conditions and will report only one detected non-trace fault on a single instruction.

In a multiple fault situation, the reported fault condition is left to the implementation.

### 8.6.2 Multiple Trace Fault Conditions on the Same Instruction

Trace faults on different instructions cannot happen concurrently, because trace faults are precise (see [section 8.9, “PRECISE AND IMPRECISE FAULTS”](#) (pg. 8-19)). Multiple trace fault conditions on the same instruction are reported in a single trace fault record (with the exception of prereturn trace, which always happens alone). To support multiple fault reporting, the trace fault uses bit positions in the fault-subtype field to indicate occurrences of multiple faults of the same type (see [Table 8-1](#)).

8

### 8.6.3 Multiple Trace and Non-Trace Fault Conditions on the Same Instruction

The execution of a single instruction can create one or more trace fault conditions in addition to multiple non-trace fault conditions. When this occurs:

- The pending trace is dismissed if any of the non trace faults dismisses it, as mentioned in the “Trace Reporting” paragraph for that fault in [section 8.10, “FAULT REFERENCE”](#) (pg. 8-21).
- The processor services one of the non trace faults.
- Finally, the trace is serviced upon return from the non-trace fault handler if it was not dismissed in step 1.

### 8.6.4 Parallel Faults

The i960 Jx processor exploits the architecture’s tolerance of out-of-order instruction execution by issuing instructions to independent execution units on the chip. The following subsections describe how the processor handles faults in this environment.

## FAULTS

### 8.6.4.1 Faults on Multiple Instructions Executed in Parallel

If AC.nif=0, imprecise faults relative to different instructions executing in parallel may be reported in a single parallel fault record. For these conditions, the processor calls a unique fault handler, the PARALLEL fault handler (see [section 8.9.4, “No Imprecise Faults \(AC.nif\) Bit”](#) (pg. 8-20)). This mechanism allows instructions that can fault to be executed in parallel with other instructions or out of order.

In parallel fault situations, the processor saves the fault type and subtype of the second and subsequent faults detected in the optional section of the fault record. The optional section is the area below NFP-64 where the fault records for each of the parallel faults that occurred are stored. The fault handling procedure for parallel faults can then analyze the fault record and handle the faults. The fault record for parallel faults is described in the next section.

If the RIP is undefined for at least one of the faults found in the parallel fault record, then the RIP of the parallel fault handler is undefined. In this case, the parallel fault handling procedure can either create a RIP and return or call a debug monitor to analyze the faults.

If the RIP is defined for all faults found in the fault record, then it will point to the next instruction not yet executed. The parallel fault handler can simply return to the next instruction not yet executed with a **ret** instruction.

Consider the following code example, where the **mul** and the **add** instructions both have overflow conditions. AC.om=0, AC.nif = 0, and both instructions are in the instruction cache at the time of their execution. The **add** and **mul** are allowed to execute in parallel when AC.nif = 0, because they are executed in different units. The faults that these instructions can generate (ARITHMETIC) are imprecise.

```
mul  g2, g4, g6;           # results in integer overflow
add  g8, g9, g10;          # results in integer overflow
```

The fault on the **add** is detected before the fault on the **mul** because the **mul** takes longer to execute. The fault call synchronizes faults on the way to the overflow fault handler for the **add** instruction (see [section 8.9.5, “Controlling Fault Precision”](#) (pg. 8-20)), which is when the **mul** fault is detected. The processor builds a parallel fault record with information relative to both faults and calls the parallel fault handler. In the fault handler, ARITHMETIC faults may be recovered by storing the desired result of the instruction in the proper destination register and setting the AC.of flag (optional) to indicate that an overflow occurred. A **ret** at the end of the parallel fault handler routine will then return to the next instruction not yet executed in the program flow.

On the i960 Jx processor, the **mul** overflow fault is the only fault that can happen with a delay. Therefore, parallel fault records can report a maximum of 2 faults, one of which must be a **mul** ARITHMETIC.INTEGER\_OVERFLOW fault.



A parallel fault handler must be accessed through a system-supervisor call. Local and system-local parallel fault handlers are not supported by the architecture and have unpredictable behavior. Tracing is disabled upon entry into the parallel fault handler (PC.te is cleared). It is restored upon return from the handler. To prevent infinite internal loops, the parallel fault handler should not set PC.te.

#### 8.6.4.2 Fault Record for Parallel Faults

When parallel faults occur, the processor selects one of the faults and records it in the first 16 bytes of the fault record as described in [section 8.5.1, “Fault Record Description”](#) (pg. 8-7). The remaining parallel faults are written to the fault record’s optional section, and the fault handling procedure for parallel faults is invoked. [Figure 8-3](#) shows the structure of the fault record for parallel faults.

The OType/OSubtype word at NFP - 20 contains the number of parallel faults. The optional section also contains a 32-byte parallel fault record for each additional parallel fault. These parallel fault records are stored incrementally in the fault record starting at byte offset NFP-65. The fault record for each additional fault contains only the fault type, fault subtype, address-of-faulting-instruction and the optional fault section. (For example, if two parallel faults occur, the fault record for the second fault is located from NFP-96 to NFP-65.)

To calculate byte offsets, “n” indicates the fault number. Thus, for the second fault recorded (n=2), the relationship (NFP-4-(n \* 32)) reduces to NFP-72. For the i960 Jx processor, a maximum of two faults are reported in the parallel fault record, and one of them must be the ARITHMETIC.INTEGER\_OVERFLOW fault on a **multi** instruction.

8

#### 8.6.5 Override Faults

The i960 Jx processor can detect a fault condition while the processor is preparing to service a previously detected fault. When this occurs, it is called an *override condition*. This section describes this condition and how the processor handles it.

A normal fault condition is handled by the processor in the following manner:

- The current local registers are saved and cached on-chip.
- PFP = FP and the value 001 is written to the Return Type Field (Fault Call). Refer to [section 7.8, “RETURNS”](#) (pg. 7-20) for more information.
- If the fault call is a system-supervisor call from user mode, the processor switches to the supervisor stack; otherwise, SP is re-aligned on the current stack.
- The processor writes the fault record on the new stack.
- The IP of the first instruction of the fault handler is accessed through the fault table or through the system procedure table (for system fault calls).

## FAULTS

A fault that occurs during any of the above actions is called an override fault. In response to this condition, the processor does the following:

- Switches the execution mode to supervisor.
- Selects the override condition that shows that the writing of the fault record was unsuccessful. If no such fault exists, the processor selects one of the other fault conditions. This method ensures that the fault handler has information regarding the fault record write.
- Saves information pertaining to the override condition selected. The fault record describes the first fault as described previously. Field OType contains the fault type of the second fault, field OSubtype contains the fault subtype of the second fault and field override-fault-data contains what would normally be the fault data field for the second fault type.
- Attempts to access the IP of the first instruction in the override fault handler through the system procedure table.

It should be noted that a fault that occurs while the processor is actually executing a fault handling procedure is not an override fault.

The override fault entry is entry 0. If the override fault entry in the fault table points to a location beyond the system procedure table, the processor enters system error mode. Override fault conditions include: PROTECTION and OPERATION.UNIMPLEMENTED faults.

An override fault handler must be accessed through a system-supervisor call. Local and system-local override fault handlers are not supported by the architecture and have an unpredictable behavior. Tracing is disabled upon entry into the override fault handler (PC.te is cleared). It is restored upon return from the handler. To prevent infinite internal loops, the override fault handler should not set PC.te.

### 8.6.6 System Error

If a fault is detected while the processor is in the process of servicing an override or parallel fault, the processor enters the system error state. Note that “servicing” indicates that the processor has detected the override or parallel fault, but has not begun executing the fault handling procedure. This type of error causes the processor to enter a system error state. In this state, the processor uses only one read bus transaction to signal the fail code message; the address of the bus transaction is the fail code itself.

## 8.7 FAULT HANDLING PROCEDURES

The fault handling procedures can be located anywhere in the address space except within the on-chip data RAM or MMR space. Each procedure must begin on a word boundary. The processor can execute the procedure in user or supervisor mode, depending on the fault table entry type.



### 8.7.1 Possible Fault Handling Procedure Actions

The processor allows easy recovery from many faults that occur. When fault recovery is possible, the processor's fault handling mechanism allows the processor to automatically resume work on the program or pending interrupt when the fault occurred. Resumption is initiated with a **ret** instruction in the fault handling procedure.

If recovery from the fault is not possible or not desirable, the fault handling procedure can take one of the following actions, depending on the nature and severity of the fault condition (or conditions, in the case of multiple faults):

- Return to a point in the program or interrupt code other than the point of the fault.
- Call a debug monitor.
- Perform processor or system shutdown with or without explicitly saving the processor state and fault information.

When working with the processor at the development level, a common fault handling strategy is to save the fault and processor state information and call a debugging tool such as a monitor.

**8**

### 8.7.2 Program Resumption Following a Fault

Because of the wide variety of faults, they can occur at different times with respect to the faulting instruction:

- Before execution of the faulting instruction (e.g., fetch from on-chip RAM)
- During instruction execution (e.g., integer overflow)
- Immediately following execution (e.g., trace)

#### 8.7.2.1 Faults Happening Before Instruction Execution

The following fault types occur before instruction execution:

- ARITHMETIC.ZERO\_DIVIDE
- TYPE.MISMATCH
- PROTECTION.LENGTH
- All OPERATION subtypes except UNALIGNED

For these faults, the contents of a destination register are lost, and memory is not updated. The RIP is defined for the ARITHMETIC.ZERO\_DIVIDE fault only. In some cases the fault occurs before the faulting instruction is executed, the faulting instruction may be fixed and re-executed upon return from the fault handling procedure.

## FAULTS

### 8.7.2.2 Faults Happening During Instruction Execution

The following fault types occur during instruction execution:

- CONSTRAINT.RANGE
- OPERATION.UNALIGNED
- ARITHMETIC.INTEGER\_OVERFLOW

For these faults, the fault handler must explicitly modify the RIP to return to the faulting application (except for ARITHMETIC.INTEGER\_OVERFLOW).

When a fault occurs during or after execution of the faulting instruction, the fault may be accompanied by a program state change such that program execution cannot be resumed after the fault is handled. For example, when an integer overflow fault occurs, the overflow value is stored in the destination. If the destination register is the same as one of the source registers, the source value is lost, making it impossible to re-execute the faulting instruction.

### 8.7.2.3 Faults Happening After Instruction Execution

For these faults, the Return Instruction Pointer (RIP) is defined and the fault handler can return to the next instruction in the flow:

- TRACE
- ARITHMETIC.INTEGER\_OVERFLOW

In general, resumption of program execution with no changes in the program's control flow is possible with the following fault types or subtypes:

- All TRACE Subtypes

The effect of specific fault types on a program is defined in [section 8.10, "FAULT REFERENCE"](#) (pg. 8-21) under the heading *Program State Changes*.

### 8.7.3 Return Instruction Pointer (RIP)

When a fault handling procedure is called, a Return Instruction Pointer (RIP) is saved in the image of the RIP in the faulting frame. The RIP can be accessed at address PFP+8 while executing the fault handler after a **flushreg**. The RIP in the previous frame points to an instruction where program execution can be resumed with no break in the program's control flow. It generally points to the faulting instruction or to the next instruction to be executed. In some instances, however, the RIP is undefined. RIP content for each fault is described in [section 8.10, "FAULT REFERENCE"](#) (pg. 8-21).





#### 8.7.4 Returning to the Point in the Program Where the Fault Occurred

As described in [section 8.7.2, “Program Resumption Following a Fault”](#) (pg. 8-13), most faults can be handled such that program control flow is not affected. In this case, the processor allows a program to be resumed at the point where the fault occurred, following a return from a fault handling procedure (initiated with a **ret** instruction). The resumption mechanism used here is similar to that provided for returning from an interrupt handler.

Also, to restore the PC register from the fault record upon return from the fault handler, the fault handling procedure must be executed in supervisor mode either by using a supervisor call or by running the program in supervisor mode. See the pseudocode in [section 6.2.54, “ret”](#) (pg. 6-92).

#### 8.7.5 Returning to a Point in the Program Other Than Where the Fault Occurred

A fault handling procedure can also return to a point in the program other than where the fault occurred. To do this, the fault procedure must alter the RIP. To do this reliably, the fault handling procedure should perform the following steps:

1. Flush the local register sets to the stack with a **flushreg** instruction.
2. Modify the RIP in the previous frame.
3. Clear trace-fault-pending flag in fault record’s process controls field before the return (optional).
4. Execute a return with the **ret** instruction.

Use this technique carefully and only in situations where the fault handling procedure is closely coupled with the application program.

#### 8.7.6 Fault Controls

For certain fault types and subtypes, the processor employs register mask bits or flags that determine whether or not a fault is generated when a fault condition occurs. [Table 8-2](#) summarizes these flags and masks, the data structures in which they are located, and the fault subtypes they affect.

The integer overflow mask bit inhibits the generation of integer overflow faults. The use of this mask is discussed in [section 8.10, “FAULT REFERENCE”](#) (pg. 8-21).

The Arithmetic Controls no imprecise faults (AC.nif) bit controls the synchronizing of faults for a category of faults called imprecise faults. The function of this bit is described in [section 8.9, “PRECISE AND IMPRECISE FAULTS”](#) (pg. 8-19).

## FAULTS

TC register trace mode bits and the PC register trace enable bit support trace faults. Trace mode bits enable trace modes; the trace enable bit (PC.te) enables trace fault generation. The use of these bits is described in the trace faults description in [section 8.10, “FAULT REFERENCE”](#) (pg. 8-21). Further discussion of these flags is provided in [CHAPTER 9, TRACING AND DEBUGGING](#).

**Table 8-2. Fault Control Bits and Masks**

Flag or Mask Name	Location	Faults Affected
Integer Overflow Mask Bit	Arithmetic Controls (AC) Register	INTEGER_OVERFLOW
No Imprecise Faults Bit	Arithmetic Controls (AC) Register	All Imprecise Faults
Trace Enable Bit	Process Controls (PC) Register	All TRACE Faults
Trace Mode	Trace Controls (TC) Register	All TRACE Faults except hardware breakpoint traces and <b>fmark</b>
Unaligned Fault Mask	Process Control Block (PRCB)	UNALIGNED Fault

The unaligned fault mask bit is located in the process control block (PRCB), which is read from the fault configuration word (located at address PRCB pointer + 0CH) during initialization. It controls whether unaligned memory accesses generate a fault. See [section 13.5.2, “Bus Transactions Across Region Boundaries”](#) (pg. 13-7).

### 8.8 FAULT HANDLING ACTION

Once a fault occurs, the processor saves the program state, calls the fault handling procedure and, if possible, restores the program state when the fault recovery action completes. No software other than the fault handling procedures is required to support this activity.

Three types of implicit procedure calls can be used to invoke the fault handling procedure: a local call, a system-local call and a system-supervisor call.

The following subsections describe actions the processor takes while handling faults. It is not necessary to read these sections to use the fault handling mechanism or to write a fault handling procedure. These sections are provided for those readers who wish to know the details of the fault handling mechanism.



### 8.8.1 Local Fault Call

When the selected fault handler entry in the fault table is an entry type  $000_2$  (a local procedure), the processor operates as described in [section 7.1.3.1, “Call Operation”](#) (pg. 7-6), with the following exceptions:

- A new frame is created on the stack that the processor is currently using. The stack can be the user stack, supervisor stack or interrupt stack.
- The fault record is copied into the area allocated for it in the stack ([Figure 8-4](#)), beginning at NFP-1.
- The processor gets the IP for the first instruction in the called fault handling procedure from the fault table.
- The processor stores the fault return code ( $001_2$ ) in the PFP return type field.

If the fault handling procedure is not able to perform a recovery action, it performs one of the actions described in [section 8.7.2, “Program Resumption Following a Fault”](#) (pg. 8-13).

If the handler action results in recovery from the fault, a **ret** instruction in the fault handling procedure allows processor control to return to the program that was executing when the fault occurred. Upon return, the processor performs the action described in [section 7.1.3.2, “Return Operation”](#) (pg. 7-7), except that the arithmetic controls field from the fault record is copied into the AC register. If the processor is in user mode before execution of the return, the process controls field from the fault record is not copied back to the PC register.

8

### 8.8.2 System-Local Fault Call

When the fault handler selects an entry for a local procedure in the system procedure table (entry type  $10_2$ ), the processor performs the same action as is described in the previous section for a local fault call or return. The only difference is that the processor gets the fault handling procedure's address from the system procedure table rather than from the fault table.

### 8.8.3 System-Supervisor Fault Call

When the fault handler selects an entry for a supervisor procedure in the system procedure table, the processor performs the same action described in [section 7.1.3.1, “Call Operation”](#) (pg. 7-6), with the following exceptions:

- If the fault occurs while in user mode, the processor switches to supervisor mode, reads the supervisor stack pointer from the system procedure table and switches to the supervisor stack. A new frame is then created on the supervisor stack.
- If the fault occurs while in supervisor mode, the processor creates a new frame on the current stack. If the processor is executing a supervisor procedure when the fault occurred, the current stack is the supervisor stack; if it is executing an interrupt handler procedure, the current stack is the interrupt stack. (The processor switches to supervisor mode when handling interrupts.)

## FAULTS

- The fault record is copied into the area allocated for it in the new stack frame, beginning at NFP-1. (See [Figure 8-4](#).)
- The processor gets the IP for the first instruction of the fault handling procedure from the system procedure table (using the index provided in the fault table entry).
- The processor stores the fault return code (001<sub>2</sub>) in the PFP register return type field. If the fault is not a trace, parallel or override fault, it copies the state of the system procedure table trace control flag (byte 12, bit 0) into the PC register trace enable bit. If the fault is a trace, parallel or override fault, the trace enable bit is cleared.

On a return from the fault handling procedure, the processor performs the action described in [section 7.1.3.2, “Return Operation”](#) (pg. 7-7) with the addition of the following:

- The fault record arithmetic controls field is copied into the AC register.
- If the processor is in supervisor mode prior to the return from the fault handling procedure (which it should be), the fault record process controls field is copied into the PC register. The mode is then switched back to user, if it was in user mode before the call.
- The processor switches back to the stack it was using when the fault occurred. (If the processor was in user mode when the fault occurred, this operation causes a switch from the supervisor stack to the user stack.)
- If the trace-fault-pending flag and trace enable bits are set in the PC field of the fault record, the trace fault on the instruction at the origin of the supervisor fault call is handled at this time.

The user should note that PC register restoration causes any changes to the process controls done by the fault handling procedure to be lost.

### 8.8.4 Faults and Interrupts

If an interrupt occurs during an instruction that will fault, an instruction that has already faulted, or fault handling procedure selection, the processor handles the interrupt in the following way:

1. Completes the selection of the fault handling procedure.
2. Creates the fault record.
3. Services the interrupt just prior to executing the first instruction of the fault handling procedure.
4. Handles the fault upon return from the interrupt.

Handling the interrupt before the fault reduces interrupt latency.



## 8.9 PRECISE AND IMPRECISE FAULTS

As described in [section 8.10.5, “PARALLEL Faults”](#) (pg. 8-27), the i960 architecture — to support parallel and out-of-order instruction execution — allows some faults to be generated together.

The processor provides two mechanisms for controlling the circumstances under which faults are generated: the AC register no-imprecise-faults bit (AC.nif) and the instructions that synchronize faults. See [section 8.9.5, “Controlling Fault Precision”](#) (pg. 8-20) for more information. Faults are categorized as precise, imprecise and asynchronous. The following subsections describe each.

### 8.9.1 Precise Faults

A fault is precise if it meets all of the following conditions:

- The faulting instruction is the earliest instruction in the instruction issue order to generate a fault.
- All instructions after the faulting instruction, in instruction issue order, are guaranteed not to have executed.

TRACE and PROTECTION.LENGTH faults are always precise. Precise faults cannot be found in parallel records with other precise or imprecise faults.

**8**

### 8.9.2 Imprecise Faults

Faults that do not meet all of the requirements for precise faults are considered imprecise. For imprecise faults, the state of execution of instructions surrounding the faulting instruction may be unpredictable. When instructions are executed out of order and an imprecise fault occurs, it may not be possible to access the source operands of the instruction. This is because they may have been modified by subsequent instructions executed out of order. However, the RIP of some imprecise faults (e.g., ARITHMETIC) points to the next instruction that has not yet executed and guarantees the return from the fault handler to the original flow of execution. Faults that the architecture allows to be imprecise are OPERATION, CONSTRAINT, ARITHMETIC and TYPE.

### 8.9.3 Asynchronous Faults

Asynchronous faults are those whose occurrence has no direct relationship to the instruction pointer. This group includes MACHINE faults, which are not implemented on the 80960Jx.

### 8.9.4 No Imprecise Faults (AC.nif) Bit

The Arithmetic Controls no imprecise faults (AC.nif) bit controls imprecise fault generation. If AC.nif is set, out of order instruction execution is disabled and all faults generated are precise. Therefore, setting this bit will reduce processor performance. If AC.nif is clear, several imprecise faults may be reported together in a parallel fault record. Precise faults can never be found in parallel fault records, thus only more than one imprecise fault occurring concurrently with AC.nif = 0 can produce a parallel fault.

Compiled code should execute with the AC.nif bit clear, using **syncf** where necessary to ensure that faults occur in order. In this mode, imprecise faults are considered to be catastrophic errors from which recovery is not needed. This also allows the processor to take advantage of internal pipelining, which can speed up processing time. When only precise faults are allowed, the processor must restrict the use of pipelining to prevent imprecise faults.

The AC.nif bit should be set if recovery from one or more imprecise faults is required. For example, the AC.nif bit should be set if a program needs to handle and recover from unmasked integer-overflow faults. The fault handling procedure cannot be closely coupled with the application to perform imprecise fault recovery.

### 8.9.5 Controlling Fault Precision

The **syncf** instruction forces the processor to complete execution of all instructions that occur prior to **syncf** and to generate all faults before it begins work on instructions that occur after **syncf**. This instruction has two uses:

- It forces faults to be precise when the AC.nif bit is clear.
- It ensures that all instructions are complete and all faults are generated in one block of code before executing another block of code.

The implicit fault call operation synchronizes all faults. In addition, the following instructions or operations perform synchronization of all faults:

- Call and return operations including **call**, **callx**, **calls** and **ret** instructions, plus the implicit interrupt and fault call operations.
- Atomic operations including **atadd** and **atmod**.



## 8.10 FAULT REFERENCE

This section describes each fault type and subtype and gives detailed information about what is stored in the various fields of the fault record. The section is organized alphabetically by fault type. The following paragraphs describe the information that is provided for each fault type.

Fault Type:	Gives the number that appears in the fault record fault-type field when the fault is generated.
Fault Subtype:	Lists the fault subtypes and the number associated with each fault subtype.
Function:	Describes the purpose and handling of the fault type and each subtype.
RIP:	Describes the value saved in the image of the RIP register in the stack frame that the processor was using when the fault occurred. In the RIP definitions, “next instruction” refers to the instruction directly after the faulting instruction or to an instruction to which the processor can logically return when resuming program execution.  Note that the discussions of many fault types specify that the RIP contains the address of the instruction that would have executed next had the fault not occurred.
Fault IP:	Describes the contents of the fault record’s fault instruction pointer field, typically the faulting instruction’s IP.
Fault Data:	Describes any values stored in the fault record’s fault data field.
Class:	Indicates if a fault is precise or imprecise.
Program State Changes:	Describes the process state changes that would prevent re-executing the faulting instruction if applicable.
Trace Reporting:	Relates whether a trace fault (other than PRERET) can be detected on the faulting instruction, also if and when the fault is serviced.
Notes:	Additional information specific to particular implementations of the i960 architecture.

## FAULTS

### 8.10.1 ARITHMETIC Faults

Fault Type: 3H

Fault Subtype:	<b>Number</b>	<b>Name</b>
	0H	Reserved
	1H	INTEGER_OVERFLOW
	2H	ZERO_DIVIDE
	3H-FH	Reserved

Function: Indicates a problem with an operand or the result of an arithmetic instruction. An INTEGER\_OVERFLOW fault is generated when the result of an integer instruction overflows its destination and the AC register integer overflow mask is cleared. Here, the result's *n* least significant bits are stored in the destination, where *n* is destination size. Instructions that generate this fault are:

<b>addi</b>	<b>subi</b>	<b>stis</b>
<b>stib</b>	<b>shli</b>	<b>ADDI&lt;cc&gt;</b>
<b>muli</b>	<b>divi</b>	<b>SUBI&lt;cc&gt;</b>

An ARITHMETIC.ZERO\_DIVIDE fault is generated when the divisor operand of an ordinal- or integer-divide instruction is zero. Instructions that generate this fault are:

<b>divo</b>	<b>divi</b>
<b>ediv</b>	<b>remi</b>
<b>remo</b>	<b>modi</b>

RIP: IP of the instruction that would have executed next if the fault had not occurred.

Fault IP: IP of the faulting instruction.

Class: Imprecise.

Program State Changes: Faults may be imprecise when executing with the AC.nif bit cleared. INTEGER\_OVERFLOW and ZERO\_DIVIDE faults may not be recoverable because the result is stored in the destination before the fault is generated (e.g., the faulting instruction cannot be re-executed if the destination register was also a source register for the instruction).

Trace Reporting: The trace is reported upon return from the arithmetic fault handler.





**8.10.2 CONSTRAINT Faults**

Fault Type:	5H	
Fault Subtype:	<b>Number</b>	<b>Name</b>
	0H	Reserved
	1H	RANGE
	2H-FH	Reserved
Function:	Indicates the program or procedure violated an architectural constraint.  A CONSTRAINT.RANGE fault is generated when a <b>FAULT&lt;cc&gt;</b> instruction is executed and the AC register condition code field matches the condition required by the instruction.	
RIP:	No defined value.	
Fault IP:	Faulting instruction.	
Class:	Imprecise.	
Program State Changes:	These faults may be imprecise when executing with the AC.nif bit cleared. No changes in the program's control flow accompany these faults. A CONSTRAINT.RANGE fault is generated after the <b>FAULT&lt;cc&gt;</b> instruction executes. The program state is not affected.	
Trace Reporting:	Serviced upon return from the Constraint fault handler.	

**8**

## FAULTS

### 8.10.3 OPERATION Faults

Fault Type: 2H

Fault Subtype:	<b>Number</b>	<b>Name</b>
	0H	Reserved
	1H	INVALID_OPCODE
	2H	UNIMPLEMENTED
	3H	UNALIGNED
	4H	INVALID_OPERAND
	5H - FH	Reserved

Function: Indicates the processor cannot execute the current instruction because of invalid instruction syntax or operand semantics.

An INVALID\_OPCODE fault is generated when the processor attempts to execute an instruction containing an undefined opcode or addressing mode.

An UNIMPLEMENTED fault is generated when the processor attempts to execute an instruction fetched from on-chip data RAM, or when a non-word or unaligned access to a memory-mapped region is performed, or when attempting to write memory-mapped region 0xFF0084XX when rights have not been granted.

An UNALIGNED fault is generated when the following conditions are present: (1) the processor attempts to access an unaligned word or group of words in non-MMR memory; and (2) the fault is enabled by the unaligned-fault mask bit in the PRCB fault configuration word.

An INVALID\_OPERAND fault is generated when the processor attempts to execute an instruction that has one or more operands having special requirements that are not satisfied. This fault is generated when specifying a non-defined **sysctl**, **icctl**, **dcctl** or **intctl** command, or referencing an unaligned long-, triple- or quad-register group, or by referencing an undefined register, or by writing to the RIP register (r2).

RIP: No defined value.

Fault IP: Address of the faulting instruction.

Fault Data: When an UNALIGNED fault is signaled, the effective address of the unaligned access is placed in the fault record's optional data section, beginning at address NFP-24. This address is useful to debug a program that is making unintentional unaligned accesses.

Class: Imprecise.

Program State Changes: For the INVALID\_OPCODE and UNIMPLEMENTED faults (case: store to MMR), the destination of the faulting instruction is not modified. (For the UNALIGNED fault, the memory operation completes correctly before the fault is reported.) In all other cases, the destination is undefined.

Trace Reporting: OPERATION.UNALIGNED fault: the trace is reported upon return from the OPERATION fault handler.  
All other subtypes: the trace event is lost.

Note: OPERATION.UNALIGNED fault is not implemented on i960 Kx and Sx CPUs.



## FAULTS

### 8.10.4 OVERRIDE Faults

Fault Type:	Fault table entry = 0H  The fault type in the fault record on the stack equals the fault type of the initial fault.
Fault Subtype:	The fault subtype in the fault record on the stack equals the fault subtype of the initial fault.
Fault OType:	The fault type of the additional fault detected while attempting to deliver the program fault.
Fault OSubtype:	The fault subtype of the additional fault detected while attempting to deliver the program fault.
Function:	The override fault handler must be accessed through a system-supervisor call. Local and system-local override fault handlers are not supported and have an unpredictable behavior. Tracing is disabled upon entry into the override fault handler (PC.te is cleared). It is restored upon return from the handler. To prevent infinite internal loops, the override fault handler should not set PC.te.
Trace Reporting:	Same behavior as if the override condition had not existed. Refer to the description of the original program fault.

**8.10.5 PARALLEL Faults**

Fault Type:	Fault table entry = 0H Fault type in fault record = fault type of one of the parallel faults.
Fault Subtype:	Fault subtype of one of the parallel faults.
Fault OType:	0H
Fault OSubtype:	Number of parallel faults.
Function:	See <a href="#">section 8.6.4, “Parallel Faults”</a> (pg. 8-9) for a complete description of parallel faults. When the AC.nif=0, the architecture permits the processor to execute instructions in parallel and out-of-order by different execution units. When an imprecise fault occurs in any of these units, it is not possible to stop the execution of those instructions after the faulting instruction. It is also possible that more than one fault is detected from different instructions almost at the same time.
	<p>When there is more than one outstanding fault at the point when all execution units terminate, a parallel fault situation arises. The fault record of parallel faults contains the fault information of all faults that occurred in parallel. The number of parallel faults is indicated in the OSubtype Field (NFP-20). See <a href="#">Figure 8-3</a>. The maximum size of the fault record is implementation dependent and depends on the number of parallel and pipeline execution units in the specific implementation.</p> <p>The parallel fault handler must be accessed through a system-supervisor call. Local and system-local parallel fault handlers are not supported by the i960 processor and have an unpredictable behavior. Tracing is disabled upon entry into the parallel fault handler (PC.te is cleared). It is restored upon return from the handler. To prevent infinite internal loops, the parallel fault handler should not set PC.te.</p>
RIP:	If all parallel fault types allow a RIP to be defined, the RIP is the next instruction in the flow of execution, otherwise it is undefined.
Fault IP:	IP of one of the faulting instructions.
Class:	Imprecise.
Program State Changes:	State changes associated with all the parallel faults.
Trace Reporting:	If all parallel fault types allow for a resumption trace, then a trace is reported upon return from the parallel fault handler, or else it is lost.

## FAULTS

### 8.10.6 PROTECTION Faults

Fault Type: 7H

Fault Subtype:	<b>Number</b>	<b>Name</b>
	Bit 0	Reserved
	Bit 1	LENGTH
	Bits 2-7	Reserved

Function: Indicates that a program or procedure is attempting to perform an illegal operation that the architecture protects against.

A PROTECTION.LENGTH fault is generated when the index operand used in a **calls** instruction points to an entry beyond the extent of the system procedure table.

RIP: IP of the faulting instruction.

Fault IP: PROTECTION.LENGTH: IP of the faulting instruction.

Class: PROTECTION.LENGTH: Is precise.

Program State Changes: LENGTH: The instruction does not execute.

Trace Reporting: PROTECTION.LENGTH: The trace event is lost.



**8.10.7 TRACE Faults**

Fault Type: 1H

Fault Subtype:	<b>Number</b>	<b>Name</b>
	Bit 0	Reserved
	Bit 1	INSTRUCTION
	Bit 2	BRANCH
	Bit 3	CALL
	Bit 4	RETURN
	Bit 5	PRERETURN
	Bit 6	SUPERVISOR
	Bit 7	MARK/BREAKPOINT

Function: Indicates the processor detected one or more trace events. The event tracing mechanism is described in [CHAPTER 9, TRACING AND DEBUGGING](#).

A trace event is the occurrence of a particular instruction or instruction type in the instruction stream. The processor recognizes seven different trace events: instruction, branch, call, return, prereturn, supervisor, mark. It detects these events only if the TC register mode bit is set for the event. If the PC register trace enable bit is also set, the processor generates a fault when a trace event is detected.



A TRACE fault is generated following the instruction that causes a trace event (or prior to the instruction for the prereturn trace event). The following trace modes are available:

INSTRUCTION	Generates a trace event following every instruction.
BRANCH	Generates a trace event following any branch instruction when the branch is taken (a branch trace event does not occur on branch-and-link or call instructions).
CALL	Generates a trace event following any call or branch-and-link instruction or an implicit fault call.
RETURN	Generates a trace event following a <b>ret</b> .



PRERETURN	Generates a trace event prior to any <b>ret</b> instruction, provided the PFP register prereturn trace flag is set (the processor sets the flag automatically when a call trace is serviced). A prereturn trace fault is always generated alone.
SUPERVISOR	Generates a trace event following any <b>calls</b> instruction that references a supervisor procedure entry in the system procedure table and on a return from a supervisor procedure where the return status type in the PFP register is 010 <sub>2</sub> or 011 <sub>2</sub> .
MARK/BREAKPOINT	Generates a trace event following the <b>mark</b> instruction. The MARK fault subtype bit indicates a match of the instruction-address breakpoint register, the data-address breakpoint register as well as the <b>fmark</b> and <b>mark</b> instructions.

A TRACE fault subtype bit is associated with each mode. Multiple fault subtypes can occur simultaneously; all trace fault conditions detected on one instruction (except prereturn) are reported in one single trace fault, with the fault subtype bit set for each subtype that occurs. The prereturn trace is always reported alone.

When a fault type other than a TRACE fault is generated during execution of an instruction that causes a trace event, the non-trace fault is handled before the trace fault. An exception is the prereturn-trace fault, which occurs before the processor detects a non-trace fault and is handled first.

Similarly, if an interrupt occurs during an instruction that causes a trace event, the interrupt is serviced before the TRACE fault is handled. Again, the TRACE.PRERETURN fault is different. Since it is generated before the instruction, it is handled before any interrupt that occurs during instruction execution.

A trace fault handler must be accessed through a system-supervisor call (it must be a supervisor procedure in the system procedure table). Local and system-local trace fault handlers are not supported by the architecture and may have unpredictable behavior. Tracing is automatically disabled when entering the trace fault handler and is restored upon return from the trace fault handler. The trace fault handler should not modify PC.te.





RIP: Instruction immediately following the instruction traced, in instruction issue order, except for PRERETURN. For PRERETURN, the RIP is the return instruction traced.

Fault IP: IP of the faulting instruction for all except prereturn trace and call trace (on implicit fault calls), for which the fault IP field is undefined.

Class: Precise.

Program State Changes: All trace faults except PRERETURN are serviced after the execution of the faulting instruction. The processor returns to the instruction immediately following the instruction traced, in instruction issue order. For PRERETURN, the return is traced before it executes. The processor re-executes the return instruction after completion of the PRERETURN trace fault handler.



## FAULTS

### 8.10.8 TYPE Faults

Fault Type: AH

Fault Subtype:	<b>Number</b>	<b>Name</b>
	0H	Reserved
	1H	MISMATCH
	2H-FH	Reserved

Function: Indicates a program or procedure attempted to perform an illegal operation on an architecture-defined data type or a typed data structure.

A TYPE.MISMATCH fault is generated when attempts are made to:

- Execute a privileged (supervisor-mode only) instruction while the processor is in user mode. Privileged instructions on the i960 Jx processor are:

<b>modpc</b>	<b>dcctl</b>
<b>halt</b>	<b>intctl</b>
<b>sysctl</b>	<b>inten</b>
<b>icctl</b>	<b>intdis</b>

- Write to on-chip data RAM while the processor is in supervisor-only write mode and BCON.irq is set. See [Figure 13-3](#).
- Write to the first 64 bytes of on-chip data RAM while the processor is in either user or supervisor mode and BCON.sirp is set. See [Figure 13-3](#).
- Write to memory-mapped registers in supervisor space from user mode.
- Write to timer registers while in user mode, when timer registers are protected against user-mode writes.

RIP: No defined value.

Fault IP: IP of the faulting instruction.

Class: Imprecise.

Program State Changes: The fault happens before execution of the instruction. The machine state is not changed.

Trace Reporting: The trace event is lost.

Note: **modpc** can be used in user mode, to read the PC. In supervisor mode, **modpc** is used to modify the PC.





# 9

## TRACING AND DEBUGGING





## CHAPTER 9

# TRACING AND DEBUGGING

This chapter describes the i960<sup>®</sup> Jx processor's facilities for runtime activity monitoring. The i960 architecture provides facilities for monitoring processor activity through trace event generation. A trace event indicates a condition where the processor has just completed executing a particular instruction or a type of instruction or where the processor is about to execute a particular instruction. When the processor detects a trace event, it generates a trace fault and makes an implicit call to the fault handling procedure for trace faults. This procedure can, in turn, call debugging software to display or analyze the processor state when the trace event occurred. This analysis can be used to locate software or hardware bugs or for general system monitoring during program development.

Tracing is enabled by the process controls (PC) register trace enable bit and a set of trace mode bits in the trace controls (TC) register. Alternatively, the **mark** and **fmark** instructions can be used to generate trace events explicitly in the instruction stream.

The i960 Jx processor also provides four hardware breakpoint registers that generate trace events and trace faults. Two registers are dedicated to trapping on instruction execution addresses (IPB0,1), while the remaining two registers can trap on the addresses of various types of data accesses (DAB0,1).

9

### 9.1 TRACE CONTROLS

To use the architecture's tracing facilities, software must provide trace fault handling procedures, perhaps interfaced with a debugging monitor. Software must also manipulate the following registers and control bits to enable the various tracing modes and enable or disable tracing in general.

- TC register mode bits
- DAB0-DAB1 registers' address field and enable bit (in the control table)
- System procedure table supervisor-stack-pointer field trace control bit
- IPB0-IPB1 registers' address field (in the control table)
- PC register trace enable bit
- Previous Frame Pointer (PFP) register return status field prereturn trace flag (bit 3)
- Breakpoint Control (BPCON) register breakpoint mode bits and enable bits (in the control table)

These controls are described in the following subsections.

### 9.1.1 Trace Controls (TC) Register

The TC register (Figure 9-1) allows software to define conditions that generate trace events.




Figure 9-1. 80960Jx Trace Controls (TC) Register

The TC register contains mode bits and event flags. Mode bits define a set of tracing conditions that the processor can detect. For example, when the call-trace mode bit is set, the processor generates a trace event when a call or branch-and-link operation executes. See section 9.2 (pg. 9-3). The processor uses event flags to monitor which breakpoint trace events are generated.

A special instruction, modify-trace-controls (**modtc**), allows software to modify the TC register. On initialization, the TC register is read from the Control Table. **modtc** can then be used to set or clear trace mode bits as required. Updating TC mode bits may take up to four non-branching instructions to take effect. Software can access the breakpoint event flags using **modtc**. The processor automatically sets and clears these flags as part of its trace handling mechanism: the breakpoint event flag corresponding to the trace being serviced is set in the TC while servicing a breakpoint trace fault; the TC event flags are cleared upon return from the trace fault handler. When the program is not in a trace fault handler, or when the trace is not for breakpoints, the TC event bits are clear. On the i960 Jx processor, TC register bits 0, 8 through 23 and 28 through 31 are reserved. Software must initialize these bits to zero and cannot modify them afterwards.



### 9.1.2 PC Trace Enable Bit and Trace-Fault-Pending Flag

The Process Controls (PC) register trace enable bit and the trace-fault-pending flag in the PC field of the fault record control tracing (see [section 3.7.3, “Process Controls \(PC\) Register”](#) (pg. 3-21)). The trace enable bit enables the processor’s tracing facilities; when set, the processor generates trace faults on all trace events.

Typically, software selects the trace modes to be used through the TC register. It then sets the trace enable bit to begin tracing. This bit is also altered as part of some call and return operations that the processor performs as described in [section 9.5.2, “Tracing on Calls and Returns”](#) (pg. 9-12).

The update of PC.te through **modpc** may take up to four non-branching instructions to take effect. The update of PC.te through call and return operations is immediate.

The trace-fault-pending flag, in the PC field of the fault record, allows the processor to remember to service a trace fault when a trace event is detected at the same time as another event (e.g., non-trace fault, interrupt). The non-trace fault event is serviced before the trace fault, and depending on the event type and execution mode, the trace-fault-pending flag in the PC field of the fault record may be used to generate a fault upon return from the non-trace fault event (see [section 9.5.2.4, “Tracing on Return from Implicit Call: Fault Case”](#) (pg. 9-15)).

## 9.2 TRACE MODES

This section defines trace modes enabled through the TC register. These modes can be enabled individually or several modes can be enabled at once. Some modes overlap, such as call-trace mode and supervisor-trace mode.

- Instruction trace
- Branch trace
- Mark trace
- Prereturn trace
- Call trace
- Return trace
- Supervisor trace

See [section 9.4, “HANDLING MULTIPLE TRACE EVENTS”](#) (pg. 9-11) for a description of processor function when multiple trace events occur.

### 9.2.1 Instruction Trace

When the instruction-trace mode is enabled in TC (TC.i = 1) and tracing is enabled in PC (PC.te = 1), the processor generates an instruction-trace fault immediately after an instruction is executed. A debug monitor can use this mode (TC.i = 1, PC.te = 1) to single-step the processor.

### 9.2.2 Branch Trace

When the branch-trace mode is enabled in TC (TC.b = 1) and PC.te is set, the processor generates a branch-trace fault immediately after a branch instruction executes, if the branch is taken. A branch-trace event is not generated for conditional-branch instructions that do not branch, branch-and-link instructions, and call-and-return instructions.

### 9.2.3 Call Trace

When the call-trace mode is enabled in TC (TC.c = 1) and PC.te is set. The processor generates a call-trace fault when a call instruction (**call**, **callx** or **calls**) or a branch-and-link instruction (**bal** or **balx**) executes. See [section 9.5.2.1, “Tracing on Explicit Call” \(pg. 9-13\)](#) for a detailed description of call tracing on explicit instructions. Interrupt calls are never traced.

An implicit call to a non trace fault handler also generates a call trace if TC.c and PC.te are set after the call. Refer to [section 9.5.2.2, “Tracing on Implicit Call” \(pg. 9-14\)](#) for a complete description of this case.

When the processor services an explicit call trace fault, it sets the prereturn-trace flag (PFP register bit 3) in the new frame created by the call operation or in the current frame if a branch-and-link operation was performed. The processor uses this flag to determine whether or not to signal a prereturn-trace event on a **ret** instruction.

### 9.2.4 Return Trace

When the return-trace mode is enabled in TC and PC.te is set. The processor generates a return-trace fault for a return from an explicit call (PFP.rrr = 000 or PFP.rrr = 01x). See [section 9.5.2.3, “Tracing on Return from Explicit Call” \(pg. 9-15\)](#).

A return from fault may be traced and a return from interrupt cannot be traced. See [section 9.5.2.4, “Tracing on Return from Implicit Call: Fault Case” \(pg. 9-15\)](#) and [section 9.5.2.5, “Tracing on Return from Implicit Call: Interrupt Case” \(pg. 9-16\)](#) for details.

### 9.2.5 Prereturn Trace

When the TC prereturn-trace mode, the PC.te, and the PFP prereturn-trace flag (PFP.p) are set, the processor generates a prereturn-trace fault prior to executing a **ret** execution. The dependence on PFP.p implies that prereturn tracing cannot be used without enabling call tracing. The processor sets PFP.p whenever it services a call-trace fault (as described above) for call-trace mode.





If another trace event occurs at the same time as the prereturn-trace event, the processor generates a fault on the non-prereturn-trace event first. Then, on a return from that fault handler, it generates a fault on the prereturn-trace event. The prereturn trace is the only trace event that can cause two successive trace faults to be generated between instruction boundaries.

### 9.2.6 Supervisor Trace

When supervisor-trace mode is enabled in TC and PC.te is set, the processor generates a supervisor-trace fault after either of the following:

- A **call**-system instruction (**calls**) executes from user mode and the procedure table entry is for a system-supervisor call.
- A **ret** instruction executes from supervisor mode and the return-type field is set to 010<sub>2</sub> or 011<sub>2</sub> (i.e., return from **calls**).

This trace mode allows a debugging program to determine kernel-procedure call boundaries within the instruction stream.

### 9.2.7 Mark Trace

Mark trace mode allows trace faults to be generated at places other than those specified with the other trace modes, using the **mark** instruction. It should be noted that the MARK fault subtype bit in the fault record is used to indicate a match of the instruction-address breakpoint registers or the data-address breakpoint registers as well as the **fmark** and **mark** instructions.

9

#### 9.2.7.1 Software Breakpoints

**mark** and **fmark** allow breakpoint trace faults to be generated at specific points in the instruction stream. When mark trace mode is enabled and PC.te is set, the processor generates a mark trace fault any time it encounters a **mark** instruction. **fmark** causes the processor to generate a mark trace fault regardless of whether or not mark trace mode is enabled, provided PC.te is set. If PC.te is clear, **mark** and **fmark** behave like no-ops.

#### 9.2.7.2 Hardware Breakpoints

The hardware breakpoint registers are provided to enable generation of trace faults on instruction execution and data access.

The i960 Jx processor implements two instruction and two data address breakpoint registers, denoted IPB0, IPB1, DAB0 and DAB1. The instruction and data address breakpoint registers are 32-bit registers. The instruction breakpoint registers cause a break *after* execution of the target instruction. The DABx registers cause a break *after* the memory access has been issued to the bus controller, or the data cache.

Hardware breakpoint registers may be armed or disarmed. When the registers are armed, hardware breakpoints can generate an architectural trace fault. When the registers are disarmed, no action occurs, and execution continues normally. Since instructions are always word aligned, the two low-order bits of the IPBx registers act as control bits. Control bits for the DABx registers reside in the Breakpoint Control (BPCON) registers. BPCON enables the data address breakpoint registers, and sets the specific modes of these registers. Hardware breakpoints are globally enabled by the process controls trace enable bit (PC.te).

The IPBx, DABx, and BPCON registers may be accessed using normal load and store instructions (except for loads from IPBx register). The application must be in supervisor mode for a legal access to occur. See [Section 3.3, MEMORY-MAPPED CONTROL REGISTERS \(pg. 3-6\)](#) for more information on the address for each register.

Applications must request modification rights to the hardware breakpoint resources, before attempting to modify these resources. Rights are requested by executing the **sysctl** instruction, as described in the following section.

### 9.2.7.3 Requesting Modification Rights to Hardware Breakpoint Resources

Application code must always first request and acquire modification rights to the hardware breakpoint resources before any attempt is made to modify them. This mechanism is employed to eliminate simultaneous usage of breakpoint resources by emulation tools and application code. An emulation tool exercises supervisor control over breakpoint resource allocation. If the emulator retains control of breakpoint resources, none are available for application code. If an emulation tool is not being used in conjunction with the device, modification rights to breakpoint resources will be granted to the application. The emulation tool may relinquish control of breakpoint resources to the application.

If the application attempts to modify the breakpoint or breakpoint control (BPCON) registers without first obtaining rights, an OPERATION.UNIMPLEMENTED fault will be generated. In this case, the breakpoint resource will not be modified, whether accessed through a **sysctl** instruction or as a memory-mapped register.



Application code requests modification rights by executing the **sysctl** instruction and issuing the Breakpoint Resource Request message (*src1.Message\_Type* = 06H). In response, the current available breakpoint resources will be returned as the *src/dst* parameter (*src/dst* must be a register). The *src2* parameter is not used. Results returned in the *src/dst* parameter must be interpreted as shown in [Table 9-1](#).

**Table 9-1. *src/dst* Encoding**

<i>src/dst</i> 7:4	<i>src/dst</i> 3:0
Number of Available Data Address Breakpoints	Number of Available Instruction Breakpoints

**NOTE:** *src/dst* 31:8 are reserved and will always return zeroes.

The following code sample illustrates the execution of the breakpoint resource request.

```
ldconst 0x600, r4           # Load the Breakpoint Resource
                             # Request message type into r4.
sysctl r4, r4, r4          # Issue the request.
```

Assume in this example that after execution of the **sysctl** instruction, the value of r4 is 0000 0022H. This indicates that the application has gained modification rights to both instruction and both data address breakpoint registers. If the value returned is zero, the application has not gained the rights to the breakpoint resources.



Because the i960 Jx processor does not initialize the breakpoint registers from the control table during initialization (as i960 Cx processors do), the application must explicitly initialize the breakpoint registers in order to use them once modification rights have been granted by the **sysctl** instruction.

**9.2.7.4 Breakpoint Control Register**

The format of the BPCON registers are shown in [Figure 9-2](#) and [Figure 9-3](#). Each breakpoint has four control bits associated with it: two mode and two enable bits. The enable bits (DABx.e0, DABx.e1) in BPCON act to enable or disable the data address breakpoints, while the mode bits (DABx.m0, DABx.m1) dictate which type of access will generate a break event.






Figure 9-2. Breakpoint Control Register (BPCON)

Programming the BPCON register is summarized in Table 9-2 and Table 9-3.

Table 9-2. Configuring the Data Address Breakpoint (DAB) Registers

PC.te	DABx.e1	DABx.e0	Description
0	X	X	No action. With PC.te clear, breakpoints are globally disabled.
X	0	0	No action. DABx is disabled.
1	0	1	Reserved.
1	1	0	Reserved.
1	1	1	Generate a Trace Fault.

NOTE: "X" = don't care. Reserved combinations must not be used.

The mode bits of BPCON control what type of access generates a fault, trace message, or break event, as summarized in Table 9-3.

Table 9-3. Programming the Data Address Breakpoint (DAB) Modes

DABx.m1	DABx.m0	Mode
0	0	Break on Data Write Access Only.
0	1	Break on Data Read or Data Write Access.
1	0	Break on Data Read Access.
1	1	Reserved.



### 9.2.7.5 Data Address Breakpoint (DAB) Registers

The format for the Data Address Breakpoint (DAB) registers is shown in [Figure 9-3](#). Each breakpoint register contains a 32-bit address of a byte to match on.

A breakpoint is triggered when both a data access's type and address matches that specified by BPCON and the appropriate DAB register. The mode bits for each DAB register, which are contained in BPCON (see [section 9.2.7.4](#)), qualify the access types that DAB will match. An access-type match selects that DAB register to perform address checking. An address match occurs when the byte address of any of the bytes referenced by the data access matches the byte address contained within a selected DAB.

Consider the following example. DAB0 is enabled to break on any data read access and has a value of 100FH. Any of the following instructions will cause the DAB0 breakpoint to be triggered:

```
ldob      0x100f,r8
ldos      0x100e,r8
ld        0x100c,r8
ld        0x100d,r8    /* even unaligned accesses */
ldl       0x1008,r8
ldt       0x1004,r8
ldq       0x1000,r8
```

Note that the instruction:

```
ldt 0x1000,r8
```

does not cause the breakpoint to be triggered because byte 100FH is not referenced by the triple word access.

Data address breakpoints can be set to break on any data read, any data write, or any data read or data write access. All accesses qualify for checking. These include explicit load and store instructions, and implicit data accesses performed by other instructions and normal processor operations.

For data accesses to the memory-mapped control register space, it is unpredictable whether breakpoint traces are generated when the access matches the breakpoints and also results in an OPERATION fault or TYPE.MISMATCH fault. The OPERATION or TYPE.MISMATCH fault will always be reported in this case.




Figure 9-3. Data Address Breakpoint (DAB) Register Format

### 9.2.7.6 Instruction Breakpoint (IPB) Registers

The format for the instruction breakpoint registers is given in [Figure 9-4. Instruction Breakpoint \(IPB\) Register Format](#). The upper thirty bits of the IPB<sub>x</sub> register contain the word-aligned instruction address on which to break. The two low-order bits indicate the action to take upon an address match.




Figure 9-4. Instruction Breakpoint (IPB) Register Format

Programming the instruction breakpoint register modes is shown in [Table 9-4](#)

On the i960 Jx processor, the instruction breakpoint memory-mapped registers can be read by using the **sysctl** instruction only. They can be modified by **sysctl** or by a word-length store instruction.



**Table 9-4. Instruction Breakpoint Modes**

PC.te	IPBx.m1	IPBx.m0	Action
0	X	X	No action. Globally disabled.
X	0	0	No action. IPBx disabled.
1	0	1	Reserved.
1	1	0	Reserved.
1	1	1	Generate a Trace Fault.

**NOTE:** "X" = don't care. Reserved combinations must not be used.

### 9.3 GENERATING A TRACE FAULT

To summarize the information presented in the previous sections, the processor services a trace fault when PC.te is set and the processor detects any of the following conditions:

- An instruction included in a trace mode group executes or is about to execute (in the case of a prereturn trace event) and the trace mode for that instruction is enabled.
- A fault call operation executes and the call-trace mode is enabled.
- A **mark** instruction executes and the mark-trace mode is enabled.
- An **fmark** instruction executes.
- The processor executes an instruction at an IP matching an enabled instruction address breakpoint (IPB) register.
- The processor issues a memory access matching the conditions of an enabled data address breakpoint (DAB) register.



### 9.4 HANDLING MULTIPLE TRACE EVENTS

With the exception of a prereturn trace event, which is always reported alone, it is possible for a combination of trace events to be reported in the same fault record. The processor may not report all events; however, it will always report a supervisor event and it will always signal at least one event.

If the processor reports prereturn trace and other trace types at the same time, it reports the other trace types in a single trace fault record first, and then services the prereturn trace fault upon return from the other trace fault.



## 9.5 TRACE FAULT HANDLING PROCEDURE

The processor calls the trace fault handling procedure when it detects a trace event. See [section 8.7, “FAULT HANDLING PROCEDURES”](#) (pg. 8-12) for general requirements for fault handling procedures.

The trace fault handling procedure is involved in a specific way and is handled differently than other faults. A trace fault handler must be invoked with an implicit system-supervisor call. When the call is made, the PC register trace enable bit is cleared. This disables trace faults in the trace fault handler. Recall that for all other implicit or explicit system-supervisor calls the trace enable bit is replaced with the supervisor stack pointer trace enable bit (SSP.te) located at byte 12, bit 0 of the system procedure table. The exception handling of trace enable for trace faults ensures that tracing is turned off when a trace fault handling procedure is being executed. This is necessary to prevent an endless loop of trace fault handling calls.

### 9.5.1 Tracing and Interrupt Procedures

When the processor invokes an interrupt handling procedure to service an interrupt, it disables tracing. It does this by saving the PC register’s current state in the interrupt record, then clearing the PC register trace enable bit.

On returning from the interrupt handling procedure, the processor restores the PC register to the state it was in prior to handling the interrupt, which restores the trace enable bit. See [section 9.5.2.2, “Tracing on Implicit Call”](#) (pg. 9-14) and [section 9.5.2.5, “Tracing on Return from Implicit Call: Interrupt Case”](#) (pg. 9-16) for detailed descriptions of tracing on calls and returns from interrupts.

### 9.5.2 Tracing on Calls and Returns

During call and return operations, the trace enable flag (PC.te) may be altered. This section discusses how tracing is handled on explicit and implicit calls and returns.

Since all trace faults (except prereturn) are serviced after execution of the traced instruction, tracing on calls and returns is controlled by the PC.te in effect after the call or the return.





9.5.2.1 Tracing on Explicit Call

Tracing an explicit call happens before execution of the first instruction of the procedure called.

Tracing is not modified by using a **call** or **callx** instruction. Further, tracing is not modified by using a **calls** instruction from supervisor mode. When **calls** is issued from user mode, PC.te is read from the supervisor stack pointer trace enable bit (SSP.te) of the system procedure table, which is cached on chip during initialization. The trace enable bit in effect before the **calls** is stored in the new PFP[0] bit and is restored upon return from the routine (see [section 9.5.2.3, “Tracing on Return from Explicit Call”](#) (pg. 9-15)). The **calls** instruction and all instructions of the procedure called are traced according to the new PC.te.

Table 9-5 summarizes all cases.

Table 9-5. Tracing on Explicit Call

Call Type	Calling Procedure Trace Enable	Calling Procedure Mode	Saved PFP.rt[2:0]	Called Procedure Trace Enable Bit
call, callx	PC.te	user or supervisor	000 <sub>2</sub>	PC.te
calls	PC.te	supervisor	000 <sub>2</sub>	PC.te
calls	PC.te	user	01a <sub>2</sub> Stores PC.te into bit 0 of PFP.rt2:0	SSP.te

Refer to [Table 7-2, “Encoding of Return Status Field,”](#) pg. 7-21).



9.5.2.2 Tracing on Implicit Call

Tracing on an implicit call happens before execution of the first instruction of the non-trace fault handler called. Table 9-6 summarizes all cases of tracing on implicit call. In the table, a is a bit variable that symbolizes the trace enable bit in PC.

Table 9-6. Tracing on Implicit Call

Call Type	System Procedure Table Entry	Previous Frame Pointer Return Status (PFP.rt[2:0])	Source PC.te	Target PC.te	PC.te Value Used for Traces on Implicit Call
00-Fault <sup>1</sup>	N.A.	001 <sub>2</sub>	a <sup>2</sup>	a <sup>2</sup>	a <sup>2</sup>
10-Fault <sup>1</sup>	00 <sub>2</sub>	001 <sub>2</sub>	a <sup>2</sup>	a <sup>2</sup>	a <sup>2</sup>
10-Fault <sup>1</sup>	10 <sub>2</sub>	001 <sub>2</sub>	a <sup>2</sup>	SSP.te	SSP.te
00-Parallel/Override Fault 00-Trace Fault	x <sup>2</sup>	Type of trace fault not supported			
10-Parallel/Override Fault 10-Trace Fault	00 <sub>2</sub>	Type of trace fault not supported			
10-Parallel/Override Fault 10-Trace Fault	10 <sub>2</sub>	001 <sub>2</sub>	a <sup>2</sup>	0	0
Interrupt	N.A.	111 <sub>2</sub>	a <sup>2</sup>	0	0

1. On i960 Jx processor, all faults except parallel/override and trace faults.
2. "x" and "a" are bit variables.

Tracing is not altered on the way to a local or a system-local fault handler, so the call is traced if PC.te and TC.c are set before the call. For an implicit system-supervisor call, PC.te is read from the Supervisor Stack Pointer enable bit (SSP.te). The trace on the call is serviced before execution of the first instruction of the non-trace fault handler (tracing is disabled on the way to a trace fault handler).

On the i960 Jx processor, the parallel/override fault handler must be accessed through a system-supervisor call. Tracing is disabled on the way to the parallel/override fault handler.

The only type of trace fault handler supported is the system-supervisor type. Tracing is disabled on the way to the trace fault handler.

Tracing is disabled by the processor on the way to an interrupt handler, so an interrupt call is never traced.

Note that the Fault IP field of the fault record is not defined when tracing a fault call, because there is no instruction pointer associated with an implicit call.



9.5.2.3 Tracing on Return from Explicit Call

Table 9-7 shows all cases.

Table 9-7. Tracing on Return from Explicit Call

PFP.rt2:0	Execution Mode PC.em	Trace Enable Used for Trace on Return
000 <sub>2</sub>	user or supervisor	PC.te
01a <sub>2</sub>	user	PC.te
01a <sub>2</sub>	super	t <sub>2</sub> (from PFP.r[2:0])

Refer to Table 7-2, “Encoding of Return Status Field,” pg. 7-21).

For a return from local call (return type 000<sub>2</sub>), tracing is not modified. For a return from system call (return type 01a, with PC.te equal to “a” before the call), tracing of the return and subsequent instructions is controlled by “a”, which is restored in the PC.te during execution of the return.

9.5.2.4 Tracing on Return from Implicit Call: Fault Case

When the processor detects several fault conditions on the same instruction (referred to as the “target”), the non-trace fault is serviced first. Upon return from the non-trace fault handler, the processor services a trace fault on the target if in supervisor mode before the return and if the trace enable and trace-fault-pending flags are set in the PC field of the non-trace fault record (at FP-16).



If the processor is in user mode before the return, tracing is not altered. The pending trace on the target instruction is lost, and the return is traced according to the current PC.te.

Table 9-8. Tracing on Return from Fault

PFP.rrr	PC.em Before Return	PC.te Before Return	Target PC.te After Return	Pending Trace on Target When	Trace on Return When
001	user	w	w	Pending Trace is Lost	w & TC.event
001	super	w	(FP-16).te	(FP-16).te & (FP-16).tfp	Not Traced



**9.5.2.5 Tracing on Return from Implicit Call: Interrupt Case**

When an interrupt and a trace fault are reported on the same instruction, the instruction completes and then the interrupt is serviced. Upon return from the interrupt, the trace fault is serviced if the interrupt handler did not switch to user mode. On the i960 Jx processor, the interrupt handler returns directly to the trace fault handler.

If the interrupt return is executed from user mode, the PC register is not restored and tracing of the return occurs according to the PC.te and TC.modes bit fields.

**Table 9-9. Tracing on Return from Interrupt**

rrr	PC.em	PC.te	Tgt PC.te	Pending Trace on Target When	Trace on Return When
111	user	w	w	Pending Trace is Lost	w & TC.ev
111	super	w	(FP-16).TE	RIP points to trace handler	Not Traced*

\* Assume the interrupt handler does not turn tracing on. If it does, it is unpredictable whether the return is traced or not.





10

TIMERS





# CHAPTER 10 TIMERS

This chapter describes the i960<sup>®</sup> Jx processor's dual, independent 32-bit timers. Topics include timer registers (TMRx, TCRx and TRRx), timer operation, timer interrupts, and timer register values at initialization.

Each timer is programmed by the timer registers. These registers are memory-mapped within the processor, addressable on 32-bit boundaries. When enabled, a timer decrements the user-defined count value with each Timer Clock (TCLOCK) cycle. The countdown rate is also user-configurable to be equal to the bus clock frequency, or the bus clock rate divided by 2, 4 or 8. The timers can be programmed to either stop when the count value reaches zero (single-shot mode) or run continuously (auto-reload mode). When a timer's count reaches zero, the timer's interrupt unit signals the processor's interrupt controller. [Figure 10-1](#) shows a diagram of the timer functions. See also [Figure 10-5](#) for the Timer Unit state diagram.




Figure 10-1. Timer Functional Diagram



**Table 10-1. Timer Performance Ranges**

Bus Frequency (MHz)	Max Resolution (ns)	Max Range (mins)
40	25	14.3
33	30.3	17.4
25	40	22.9
20	50	28.6
16	62.5	35.8

**10.1 TIMER REGISTERS**

As shown in [Table 10-2](#), each timer has three memory-mapped registers:

- Timer Mode Register - programs the specific mode of operation or indicates the current programmed status of the timer. This register is described in [section 10.1.1, “Timer Mode Registers \(TMR0, TMR1\)”](#) (pg. 10-3).
- Timer Count Register - contains the timer’s current count. See [section 10.1.2, “Timer Count Register \(TCR0, TCR1\)”](#) (pg. 10-6).
- Timer Reload Register - contains the timer’s reload count. See [section 10.1.3, “Timer Reload Register \(TRR0, TRR1\)”](#) (pg. 10-7).

**Table 10-2. Timer Registers**

Timer Unit	Register Acronym	Register Name
Timer 0	TMR0	Timer Mode Register 0
	TCR0	Timer Count Register 0
	TRR0	Timer Reload Register 0
Timer 1	TMR1	Timer Mode Register 1
	TCR1	Timer Count Register 1
	TRR1	Timer Reload Register 1

For register memory locations, see [Table 3-5, \(pg. 3-11\)](#).





### 10.1.1 Timer Mode Registers (TMR0, TMR1)

The Timer Mode Register (TMRx) lets the user program the mode of operation and determine the current status of the timer. TMRx bits are described in the subsections following [Figure 10-2](#) and are summarized in [Table 10-4](#).




Figure 10-2. Timer Mode Register (TMR0, TMR1)



## TIMERS

### 10.1.1.1 Bit 0 - Terminal Count Status Bit (TMRx.tc)

The TMRx.tc bit is set when the Timer Count Register (TCRx) decrements to 0 and bit 2 (TMRx.reload) is not set for a timer. The TMRx.tc bit allows applications to monitor timer status through software instead of interrupts. TMRx.tc remains set until software accesses (reads or writes) the TMRx. The access clears TMRx.tc. The timer ignores any value specified for TMRx.tc in a write request.

When auto-reload is selected for a timer and the timer is enabled, the TMRx.tc bit status is unpredictable. Software should not rely on the value of the TMRx.tc bit when auto-reload is enabled.

The processor also clears the TMRx.tc bit upon hardware or software reset. Refer to [section 12.2, “INITIALIZATION”](#) (pg. 12-2).

### 10.1.1.2 Bit 1 - Timer Enable (TMRx.enable)

The TMRx.enable bit allows user software to control the timer’s RUN/STOP status. When:

TMRx.enable = 1     The Timer Count Register (TCRx) value decrements every Timer Clock (TCLOCK) cycle. TCLOCK is determined by the Timer Input Clock Select (TMRx.csel bits 0-1). See [section 10.1.1.5](#). When TMRx.reload=0, the timer automatically clears TMRx.enable when the count reaches zero. When TMRx.reload=1, the bit remains set. See [section 10.1.1.3](#).

TMRx.enable = 0     The timer is disabled and ignores all input transitions.

User software sets this bit. Once started, the timer continues to run, regardless of other processor activity. For example, the timer runs while the processor is in Halt mode. Three events can stop the timer:

- User software explicitly clearing this bit (i.e., TMRx.enable = 0).
- TCRx value decrements to 0, and the Timer Auto Reload Enable (TMRx.reload) bit = 0.
- Hardware or software reset. Refer to [section 12.2, “INITIALIZATION”](#) (pg. 12-2).



### 10.1.1.3 Bit 2 - Timer Auto Reload Enable (TMRx.reload)

The TMRx.reload bit determines whether the timer runs continuously or in single-shot mode. When TCRx = 0 and TMRx.enable = 1 and:

TMRx.reload = 1      The timer runs continuously. The processor:

1. Automatically loads TCRx with the value in the Timer Reload Register (TRRx), when TCRx value decrements to 0.
2. Decrements TCRx until it equals 0 again.

Steps 1 and 2 repeat until software clears TMRx bits 1 or 2.

TMRx.reload = 0      The timer runs until the Timer Count Register = 0. TRRx has no effect on the timer.

User software sets this bit. When TMRx.enable and TMRx.reload are set and TRRx does not equal 0, the timer continues to run in auto-reload mode, regardless of other processor activity. For example, the timer runs while the processor is in Halt mode. Two events can stop the timer:

- User software explicitly clearing either TMRx.enable or TMRx.reload.
- Hardware or software reset. Refer to [section 12.2, “INITIALIZATION”](#) (pg. 12-2).

The processor clears this bit upon hardware or software reset. Refer to [section 12.2, “INITIALIZATION”](#) (pg. 12-2).

10

### 10.1.1.4 Bit 3 - Timer Register Supervisor Read/Write Control (TMRx.sup)

The TMRx.sup bit enables or disables user mode writes to the timer registers (TMRx, TCRx, TRRx). Supervisor mode writes are allowed regardless of this bit's condition. Software can read these registers from either mode.

When:

TMRx.sup = 1      The timer generates a TYPE.MISMATCH fault when a user mode task attempts a write to any of the timer registers; however, supervisor mode writes are allowed.

TMRx.sup = 0      The timer registers can be written from either user or supervisor mode.

The processor clears TMRx.sup upon hardware or software reset. Refer to [section 12.2, “INITIALIZATION”](#) (pg. 12-2).

## TIMERS

### 10.1.1.5 Bits 4, 5 - Timer Input Clock Select (TMRx.csel1:0)

User software programs the TMRx.csel bits to select the Timer Clock (TCLOCK) frequency. See [Table 10-3](#). As shown in [Figure 10-1](#), the bus clock is an input to the timer clock unit. These bits allow the application to specify whether TCLOCK runs at or slower than the bus clock frequency.


**Table 10-3. Timer Input Clock (TCLOCK) Frequency Selection**

Bit 5 TMRx.csel1	Bit 4 TMRx.csel0	Timer Clock (TCLOCK)
0	0	Timer Clock = Bus Clock
0	1	Timer Clock = Bus Clock / 2
1	0	Timer Clock = Bus Clock / 4
1	1	Timer Clock = Bus Clock / 8

The processor clears these bits upon hardware or software reset (TCLOCK = Bus Clock).

### 10.1.2 Timer Count Register (TCR0, TCR1)

The Timer Count Register (TCRx) is a 32-bit register that contains the timer's current count. The register value decrements with each timer clock tick. When this register value decrements to zero (terminal count), a timer interrupt is generated. When TMRx.reload is not set for the timer, the status bit in the timer mode register (TMRx.tc) is set and remains set until the TMRx register is accessed. [Figure 10-3](#) shows the timer count register.



**Figure 10-3. Timer Count Register (TCR0, TCR1)**

The valid programmable range is from 1H to FFFF FFFFH. (Avoid programming TCRx to 0 as it has varying results as described in [section 10.5, “UNCOMMON TCRX AND TRRX CONDITIONS”](#) (pg. 10-12).)

User software can read or write TCRx whether the timer is running or stopped. Bit 3 of TMRx determines user read/write control (see [section 10.1.1.4](#)). The TCRx value is undefined after hardware or software reset.



### 10.1.3 Timer Reload Register (TRR0, TRR1)

The Timer Reload Register (TRRx; [Figure 10-4](#)) is a 32-bit register that contains the timer’s reload count. The timer loads the reload count value into TCRx when TMRx.reload is set (1), TMRx.enable is set (1) and TCRx equals zero.

As with TCRx, the valid programmable range is from 1H to FFFF FFFFH. Avoid programming a value of 0, as it may prevent TINTx from asserting continuously. (See [section 10.5, “UNCOMMON TCRX AND TRRX CONDITIONS”](#) (pg. 10-12) for more information.)

User software can access TRRx whether the timer is running or stopped. Bit 3 of TMRx determines read/write control (see [section 10.1.1.4](#)). TRRx value is undefined after hardware or software reset.




Figure 10-4. Timer Reload Register (TRR0, TRR1)

## 10.2 TIMER OPERATION

This section summarizes timer operation and describes load/store access latency for the timer registers.

### 10.2.1 Basic Timer Operation

Each timer has a programmable enable bit in its control register (TMRx.enable) to start and stop counting. The supervisor (TMRx.sup) bit controls write access to the enable bit. This allows the programmer to prevent user mode tasks from enabling or disabling the timer. Once the timer is enabled, the value stored in the Timer Count Register (TCRx) decrements every Timer Clock (TCLOCK) cycle. TCLOCK is determined by the Timer Input Clock Select (TMRx.csel) bit setting. The countdown rate can be set to equal the bus clock frequency, or the bus clock rate divided by 2, 4 or 8. Setting TCLOCK to a slower rate lets the user specify a longer count period with the same 32-bit TCRx value.



## TIMERS

Software can read or write the TCRx value whether the timer is running or stopped. This lets the user monitor the count without using hardware interrupts. The TMRx.sup bit lets the programmer allow or prevent user mode writes to TCRx, TMRx and TRRx.

When the TCRx value decrements to zero, the unit's interrupt request signals the processor's interrupt controller. See [section 10.3, "TIMER INTERRUPTS" \(pg. 10-11\)](#) for more information. The timer checks the value of the timer reload bit (TMRx.reload) setting. When TMRx.reload. = 1, the processor:

- Automatically reloads TCRx with the value in the Timer Reload Register (TRRx).
- Decrements TCRx until it equals 0 again.

This process repeats until software clears TMRx.reload or TMR.enable.

When TMRx.reload = 0, the timer stops running and sets the terminal count bit (TMRx.tc). This bit remains set until user software reads or writes the TMRx register. Either access type clears the bit. The timer ignores any value specified for TMRx.tc in a write request.

**Table 10-4. Timer Mode Register Control Bit Summary**

Bit 3 (TMRx.sup)	TRRx	TCRx	Bit 2 (TMRx.reload)	Bit 1 (TMRx.enable)	Action
X	X	X	X	0	Timer disabled.
X	X	N	0	1	Timer enabled, TMRx.enable is cleared when TCRx decrements to zero.
X	N	N	1	1	Timer and auto reload enabled, TMRx.enable remains set when TCRx=0. When TCRx=0, TCRx equals the TRRx value.
0	X	X	X	X	No faults for user mode writes are generated.
1	X	X	X	X	TYPE.MISMATCH fault generated on user mode write.

**Notes:**

X = don't care

N = a number between 1H and FFFF FFFFH



### 10.2.2 Load/Store Access Latency for Timer Registers

As with all other load accesses from internal memory-mapped registers, a load instruction that accesses a timer register has a latency of one internal processor cycle. With one exception, a store access to a timer register completes and all state changes take effect before the next instruction begins execution. The exception to this is when disabling a timer. Latency associated with the disabling action is such that a timer interrupt may be posted immediately after the disabling instruction completes. This can occur when the timer is near zero as the store to TMRx occurs. In this case, the timer interrupt is posted immediately after the store to TMRx completes and before the next instruction can execute. [Table 10-5](#) summarizes the timer access and response timings. Refer also to the individual register descriptions for details.

Note that the processor may delay the actual issuing of the load or store operation due to previous instruction activity and resource availability of processor functional units.

The processor ensures that the TMRx.tc bit is cleared within one bus clock after a load or store instruction accesses TMRx.

**Table 10-5. Timer Responses to Register Bit Settings (Sheet 1 of 2)**

Name	Status	Action
(TMRx.tc) Terminal Count Bit 0	READ	Timer clears this bit when user software accesses TMRx. This bit can be set 1 bus clock later. The timer sets this bit within 1 bus clock of TCRx reaching zero when TMRx.reload=0.
	WRITE	Timer clears this bit within 1 bus clock after the software accesses TMRx. The timer ignores any value specified for TMRx.tc in a write request.
(TMRx.enable) Timer Enable Bit 1	READ	Bit is available 1 bus clock after executing a read instruction from TMRx.
	WRITE	Writing a '1' enables the bus clock to decrement TCRx within 1 bus clock after executing a store instruction to TMRx.
(TMRx.reload) Timer Auto Reload Enable Bit 2	READ	Bit is available 1 bus clock after executing a read instruction from TMRx.
	WRITE	Writing a '1' enables the reload capability within 1 bus clock after the store instruction to TMRx has executed. The timer loads TRRx data into TCRx and decrements this value during the next bus clock cycle.



Table 10-5. Timer Responses to Register Bit Settings (Sheet 2 of 2)

Name	Status	Action
(TMRx.sup) Timer Register Supervisor Write Control Bit 3	READ	Bit is available 1 bus clock after executing a read instruction from TMRx.
	WRITE	Writing a '1' locks out user mode writes within 1 bus clock after the store instruction executes to TMRx. Upon detecting a user mode write the timer generates a TYPE.MISMATCH fault.
(TMRx.csel1:0) Timer Input Clock Select Bits 4-5	READ	Bits are available 1 bus clock after executing a read instruction from TMRx.csel1:0 bit(s).
	WRITE	The timer re-synchronizes the clock cycle used to decrement TCRx within one bus clock cycle after executing a store instruction to TMRx.csel1:0 bit(s).
(TCRx.d31:0) Timer Count Register	READ	The current TCRx count value is available within 1 bus clock cycle after executing a read instruction from TCRx. When the timer is running, the pre-decremented value is returned as the current value.
	WRITE	The value written to TCRx becomes the active value within 1 bus clock cycle. When the timer is running, the value written is decremented in the current clock cycle.
(TRRx.d31:0) Timer Reload Register	READ	The current TRRx count value is available within 1 bus clock after executing a read instruction from TRRx. When the timer is transferring the TRRx count into TCRx in the current count cycle, the timer returns the new TCRx count value to the executing read instruction.
	WRITE	The value written to TRRx becomes the active value stored in TRRx within 1 bus clock cycle. When the timer is transferring the TRRx value into the TCRx, data written to TRRx is also transferred into TCRx.





### 10.3 TIMER INTERRUPTS

Each timer is the source for one interrupt. When a timer detects a zero count in its TCRx, the timer generates an internal edge-detected Timer Interrupt signal (TINTx) to the interrupt controller, and the interrupt-pending (IPND.tipx) bit is set in the interrupt controller. Each timer interrupt can be selectively masked in the Interrupt Mask (IMSK) register or handled as a dedicated hardware-requested interrupt. Refer to [CHAPTER 11, INTERRUPTS](#) for a description of hardware-requested interrupts.

When the interrupt is disabled after a request is generated, but before a pending interrupt is serviced, the interrupt request is still active (the Interrupt Controller latches the request). When a timer generates a second interrupt request before the CPU services the first interrupt request, the second request may be lost.

When auto-reload is enabled for a timer, the timer continues to decrement the value in TCRx even after entry into the timer interrupt handler.

### 10.4 POWERUP/RESET INITIALIZATION

Upon power up, external hardware reset or software reset (**sysctl**), the timer registers are initialized to the values shown in [Table 10-6](#).

**Table 10-6. Timer Powerup Mode Settings**

Mode/Control Bit	Notes
TMRx.tc = 0	No terminal count
TMRx.enable = 0	Prevents counting and assertion of TINTx
TMRx.reload = 0	Single terminal count mode
TMRx.sup = 0	Supervisor or user mode access
TMRx.csel1:0 = 0	Timer Clock = Bus Clock
TCRx.d31:0 = 0	Undefined
TRRx.d31:0 = 0	Undefined
TINTx output	Deasserted



## TIMERS

### 10.5 UNCOMMON TCRX AND TRRX CONDITIONS

Table 10-4 summarizes the most common settings for programming the timer registers. Under certain conditions, however, it may be useful to set the Timer Count Register or the Timer Reload Register to zero before enabling the timer. Table 10-7 details the conditions and results when these conditions are set.

**Table 10-7. Uncommon TMRx Control Bit Settings**

TRRx	TCRx	Bit 2 (TMRx.reload)	Bit 1 (TMRx.enable)	Action
X	0	0	1	TMRx.tc and TINTx set, TMR.enable cleared
0	0	1	1	Timer and auto reload enabled, TINTx not generated and timer enable remains set.
0	N	1	1	Timer and auto reload enabled. TINT.x set when TCRx=0. The timer remains enabled but further TINTx's are not generated.
N	0	1	1	Timer and auto reload enabled, TINTx not set initially, TCRx = TRRx, TINTx set when TCRx has completely decremented the value it loaded from TRRx. TMR.enable remains set.

**NOTE:**

X = don't care

N = a number between 1H and FFFF FFFFH



10.6 TIMER STATE DIAGRAM

Figure 10-5 shows the common states of the Timer Unit. For uncommon conditions see section 10.5, “UNCOMMON TCRX AND TRRX CONDITIONS” (pg. 10-12).




Figure 10-5. Timer Unit State Diagram



INTERRUPTS





This chapter describes the i960<sup>®</sup> processor core architecture interrupt mechanism and the i960 Jx processor interrupt controller. Key topics include the i960 Jx processor's facilities for requesting and posting interrupts, the programmer's interface to the on-chip interrupt controller, latency and how to optimize interrupt performance.

## 11.1 OVERVIEW

An interrupt is an event that causes a temporary break in program execution so the processor can handle another task. Interrupts commonly request I/O services or synchronize the processor with some external hardware activity. For interrupt handler portability across the i960 processor family, the architecture defines a consistent interrupt state and interrupt-priority-handling mechanism. To manage and prioritize interrupt requests in parallel with processor execution, the i960 Jx processor provides an on-chip programmable interrupt controller.

Requests for interrupt service come from many sources. These requests are prioritized so that instruction execution is redirected only if an interrupt request is of higher priority than that of the executing task. On the i960 Jx processor, interrupt requests may originate from external hardware sources, internal timer unit sources or from software. External interrupts are detected with the chip's 8-bit interrupt port and with a dedicated Non-Maskable Interrupt ( $\overline{\text{NMI}}$ ) input. Interrupt requests originate from software by the **sysctl** instruction. To manage and prioritize all possible interrupts, the processor integrates an on-chip programmable interrupt controller. Integrated interrupt controller configuration and operation is described in [section 11.7, "EXTERNAL INTERFACE DESCRIPTION"](#) (pg. 11-18).


When the processor is redirected to service an interrupt, it uses a vector number that accompanies the interrupt request to locate the vector entry in the interrupt table. From that entry, it gets an address to the first instruction of the selected interrupt procedure. The processor then makes an implicit call to that procedure.

When the interrupt call is made, the processor uses a dedicated interrupt stack. The processor creates a new frame for the interrupt on this stack and a new set of local registers is allocated to the interrupt procedure. The interrupted program's current state is also saved.

Upon return from the interrupt procedure, the processor restores the interrupted program's state, switches back to the stack that the processor was using prior to the interrupt and resumes program execution.

Since interrupts are handled based on priority, requested interrupts are often saved for later service rather than being handled immediately. The mechanism for saving the interrupt is referred to as interrupt posting. Interrupt posting is described in [section 11.6.5, “Posting Interrupts”](#) (pg. 11-9).

The i960 core architecture defines two data structures to support interrupt processing: the interrupt table (see [Figure 11-1](#)) and interrupt stack. The interrupt table contains 248 vectors for interrupt handling procedures (eight of which are reserved) and an area for posting software-requested interrupts. The interrupt stack prevents interrupt handling procedures from using the stack in use by the application program. It also allows the interrupt stack to be located in a different area of memory than the user and supervisor stack (e.g., fast SRAM).



**Figure 11-1. Interrupt Handling Data Structures**

**11.1.1 The i960<sup>®</sup> Jx Processor Interrupt Controller**

The i960 Jx processor Interrupt Controller Unit (ICU) provides a flexible, low-latency means for requesting and posting interrupts and minimizing the core’s interrupt handling burden. Acting independently from the core, the interrupt controller posts interrupts requested by hardware and software sources and compares the priorities of posted interrupts with the current process priority.

The interrupt controller provides the following features for managing hardware-requested interrupts:

- Low latency, high throughput handling
- Support of up to 240 external sources
- Eight external interrupt pins, one non-maskable interrupt pin, two internal timers sources for detection of hardware-requested interrupts
- Edge or level detection on external interrupt pins
- Debounce option on external interrupt pins

The user program interfaces to the interrupt controller with six memory-mapped control registers. The interrupt control register (ICON) and interrupt map control registers (IMAP0-IMAP2) provide configuration information. The interrupt pending (IPND) register posts hardware-requested interrupts. The interrupt mask (IMSK) register selectively masks hardware-requested interrupts.





## 11.2 SOFTWARE REQUIREMENTS FOR INTERRUPT HANDLING

To use the processor's interrupt handling facilities, user software must provide the following items in memory:

- Interrupt Table
- Interrupt Handler Routines
- Interrupt Stack

These items are established in memory as part of the initialization procedure. Once these items are present in memory and pointers to them have been entered in the appropriate system data structures, the processor handles interrupts automatically and independently from software.

## 11.3 INTERRUPT PRIORITY

Each interrupt vector number is eight bits in length, allowing up to 256 unique vector numbers to be defined in principle. Each vector number priority is defined by dividing the vector number by eight. Thus, at each priority level, there are eight possible vector numbers (e.g., vector numbers 8-15 have a priority of 1 and vector numbers 246-255 have a priority of 31). Vector numbers 0-7 cannot be used because a priority-0 interrupt would never successfully stop execution of a program of any priority. In addition, vector numbers 244-247 and 249-251 are reserved; therefore, 240 external interrupt sources and the non-maskable interrupt ( $\overline{\text{NMI}}$ ) are available to the user.

The processor compares its current priority with the interrupt request priority to determine whether to service the interrupt immediately or to delay service. The interrupt is serviced immediately if its priority is higher than the priority of the program or interrupt the processor is executing currently. If the interrupt priority is less than or equal to the processor's current priority, the processor does not service the request but rather posts it as a pending interrupt. See [section 11.4.2, "Pending Interrupts"](#) (pg. 11-5). When multiple interrupt requests are pending at the same priority level, the request with the highest vector number is serviced first.

Priority-31 interrupts are handled as a special case. Even when the processor is executing at priority level 31, a priority-31 interrupt interrupts the processor. On the i960 Jx processor, the non-maskable interrupt ( $\overline{\text{NMI}}$ ) interrupts priority-31 execution; no interrupt can interrupt an  $\overline{\text{NMI}}$  handler.

11.4 INTERRUPT TABLE

The interrupt table (see Figure 11-2) is 1028 bytes in length and can be located anywhere in the non-reserved address space. It must be aligned on a word boundary. The processor reads a pointer to the interrupt table byte 0 during initialization. The interrupt table must be located in RAM since the processor must be able to read and write the table's pending interrupt section.

The interrupt table is divided into two sections: vector entries and pending interrupts. Each are described in the subsections that follow.




Figure 11-2. Interrupt Table



### 11.4.1 Vector Entries

A vector entry contains a specific interrupt handler's address. When an interrupt is serviced, the processor branches to the address specified by the vector entry.

Each interrupt is associated with an 8-bit vector number that points to a vector entry in the interrupt table. The vector entry section contains 248 word-length entries. Vector numbers 8-243 and 252-255 and their associated vector entries are used for conventional interrupts. Vector numbers 244-247 and 249-251 are reserved. Vector number 248 and its associated vector entry is used for the non-maskable interrupt ( $\overline{\text{NMI}}$ ). Vector numbers 0-7 cannot be used.

Vector entry 248 contains the  $\overline{\text{NMI}}$  handler address. When the processor is initialized, the  $\overline{\text{NMI}}$  vector located in the interrupt table is automatically read and stored in location 0H of internal data RAM. The NMI vector is subsequently fetched from internal data RAM to improve this interrupt's performance.

The vector entry structure is given at the bottom of [Figure 11-2](#). Each interrupt procedure must begin on a word boundary, so the processor assumes that the vector's two least significant bits are 0. Bits 0 and 1 of an entry indicate entry type: on the i960 Jx processor, only type 00 is valid. The other possible entry types are reserved and must not be used.

### 11.4.2 Pending Interrupts

The pending interrupts section comprises the interrupt table's first 36 bytes, divided into two fields: pending priorities (byte offset 0 through 3) and pending interrupts (4 through 35).

Each of the 32 bits in the pending priorities field indicate an interrupt priority. When the processor posts a pending interrupt in the interrupt table, the bit corresponding to the interrupt's priority is set. For example, if an interrupt with a priority of 10 is posted in the interrupt table, bit 10 is set.

11

Each of the pending interrupts field's 256 bits represents an interrupt vector number. Byte offset 5 is for vectors 8 through 15, byte offset 6 is for vectors 16 through 23, and so on. Byte offset 4, the first byte of the pending interrupts field, is reserved. When an interrupt is posted, its corresponding bit in the pending interrupt field is set.

This encoding of the pending priority and pending interrupt fields permits the processor to first check if there are any pending interrupts with a priority greater than the current program and then determine the vector number of the interrupt with the highest priority.

**11.4.3 Caching Portions of the Interrupt Table**

The architecture allows all or part of the interrupt table to be cached internally to the processor. The purpose of caching these fields is to reduce interrupt latency by allowing the processor to access certain interrupt vector numbers and the pending interrupt information without having to make external memory accesses. The i960 Jx processor caches the following:

- The value of the highest priority posted in the pending priorities field.
- A predefined subset of interrupt vector numbers (entries from the interrupt table).
- Pending interrupts received from external interrupt pins.


This caching mechanism is non-transparent; the processor may modify fields in a cached interrupt table without modifying the same fields in the interrupt table itself. Vector caching is described in [section 11.9.2.1, “Vector Caching Option” \(pg. 11-35\)](#).



### 11.5 INTERRUPT STACK AND INTERRUPT RECORD

The interrupt stack can be located anywhere in the non-reserved address space. The processor obtains a pointer to the base of the stack during initialization. The interrupt stack has the same structure as the local procedure stack described in [section 7.1.1, “Local Registers and the Procedure Stack”](#) (pg. 7-2). As with the local stack, the interrupt stack grows from lower addresses to higher addresses.

The processor saves the state of an interrupted program, or an interrupted interrupt procedure, in a record on the interrupt stack. [Figure 11-3](#) shows the structure of this interrupt record.



11

**Figure 11-3. Storage of an Interrupt Record on the Interrupt Stack**

The interrupt record is always stored on the interrupt stack adjacent to the new frame that is created for the interrupt handling procedure. It includes the state of the AC and PC registers at the time the interrupt was serviced and the interrupt vector number used. Relative to the new frame pointer (NFP), the saved AC register is located at address NFP-12, the saved PC register is located at address NFP-16.

In the i960 Jx processor, the stack is aligned to a 16-byte boundary. When the processor needs to create a new frame on an interrupt call, it adds a padding area to the stack so that the new frame starts on a 16-byte boundary.



## INTERRUPTS

### 11.6 MANAGING INTERRUPT REQUESTS

The i960 processor architecture provides a consistent interrupt model, as required for interrupt handler compatibility between various implementations of the i960 processor family. The architecture, however, leaves the interrupt request management strategy to the specific i960 processor family implementations. In the i960 Jx processor, a programmable on-chip interrupt controller manages all interrupt requests (Figure 11-12). These requests originate from:

- Eight-bit external interrupt pins  $\overline{XINT}[7:0]$
- Two internal timer unit interrupts (TINT[1:0])
- Non-maskable interrupt pin ( $\overline{NMI}$ )
- **sysctl** instruction execution (software-initiated interrupts)

#### 11.6.1 External Interrupts

External interrupt pins can be programmed to operate in three modes:

1. Dedicated mode: the pins may be individually mapped to interrupt vectors.
2. Expanded mode: the pins may be interpreted as a bit field which can request any of the 240 possible external interrupts that the i960 processor family supports.
3. Mixed mode: five pins operate in expanded mode and can request 32 different interrupts, and three pins operate in dedicated mode.

Dedicated-mode requests are posted in the Interrupt Pending Register (IPND). The processor's ICU does not post expanded-mode requests.

#### 11.6.2 Non-Maskable Interrupt ( $\overline{NMI}$ )

The  $\overline{NMI}$  pin generates an interrupt for implementation of critical interrupt routines.  $\overline{NMI}$  provides an interrupt that cannot be masked and that has a priority of 31. The interrupt vector for  $\overline{NMI}$  resides in the interrupt table as vector number 248. During initialization, the core caches the vector for  $\overline{NMI}$  on-chip, to reduce  $\overline{NMI}$  latency. The  $\overline{NMI}$  vector is cached in location 0H of internal data RAM.

The core immediately services  $\overline{NMI}$  requests. While servicing an  $\overline{NMI}$ , the core does not respond to any other interrupt requests — even another  $\overline{NMI}$  request. The processor remains in this non-interruptible state until any return-from-interrupt (in supervisor mode) occurs. Note that a return-from-interrupt in user mode does not unblock  $\overline{NMI}$  events and should be avoided by software. An interrupt request on the  $\overline{NMI}$  pin is always falling-edge detected.



### 11.6.3 Timer Interrupts

Each of the two timer units has an associated interrupt to allow the application to accept or post the interrupt request. Timer unit interrupt requests are always handled as dedicated-mode interrupt requests.

### 11.6.4 Software Interrupts

The application program may use the **sysctl** instruction to request interrupt service. The vector that **sysctl** requests is serviced immediately or posted in the interrupt table's pending interrupts section, depending upon the current processor priority and the request's priority. The interrupt controller caches the priority of the highest priority interrupt posted in the interrupt table. The processor can request vector 248 (NMI) as a software interrupt; however, the interrupt vector will be read from the interrupt table, not from the internal vector cache.

### 11.6.5 Posting Interrupts

Interrupts are posted to the processor by a number of different mechanisms; these are described in the following sections.

- Software interrupts: interrupts posted through the interrupt table, by software running on the i960 Jx processor.
- External Interrupts: interrupts posted through the interrupt table, by an external agent to the i960 Jx processor.
- Hardware interrupts: interrupts posted directly to the i960 Jx processor through an implementation-dependent mechanism that may avoid using the interrupt table.

#### 11.6.5.1 Posting Software Interrupts via **sysctl**

In the i960 Jx processor, **sysctl** is typically used to request an interrupt in a program (see [Example 11-1](#)). The request interrupt message type (00H) is selected and the interrupt vector number is specified in the least significant byte of the instruction operand. See [section 6.2.67](#), “**sysctl**” (pg. 6-114) for a complete discussion of **sysctl**.

**Example 11-1. Using sysctl to Request an Interrupt**

```
ldconst 0x53,g5    # Vector number 53H is loaded
                  # into byte 0 of register g5 and
                  # the value is zero extended into
                  # byte 1 of the register
sysctl g5, g5, g5  # Vector number 53H is posted
```

A literal can be used to post an interrupt with a vector number from 8 to 31. Here, the required value of 00H in the second byte of a register operand is implied.

The action of the processor when it executes the **sysctl** instruction is as follows:

1. The processor performs an atomic write to the interrupt table and sets the bits in the pending-interrupts and pending-priorities fields that correspond to the requested interrupt.
2. The processor updates the internal software priority register with the value of the highest pending priority from the interrupt table. This may be the priority of the interrupt that was just posted.

The interrupt controller continuously compares the following three values: software priority register, current process priority, priority of the highest pending hardware-generated interrupt. When the software priority register value is the highest of the three, the following actions occur:

1. The interrupt controller signals the core that a software-generated interrupt is to be serviced.
2. The core checks the interrupt table in memory, determines the vector number of the highest priority pending interrupt and clears the pending-interrupts and pending-priorities bits in the table that correspond to that interrupt.
3. The core detects the interrupt with the next highest priority that is posted in the interrupt table (if any) and writes that value into the software priority register.
4. The core services the highest priority interrupt.

If more than one pending interrupt is posted in the interrupt table at the same interrupt priority, the core handles the interrupt with the highest vector number first. The software priority register is an internal register and, as such, is not visible to the user. The core updates this register's value only when **sysctl** requests an interrupt or when a software-generated interrupt is serviced.





### 11.6.5.2 Posting Software Interrupts Directly in the Interrupt Table

Software can post interrupts by setting the desired pending-interrupt and pending-priorities bits directly. Direct posting requires that software ensure that no external I/O agents post a pending interrupt simultaneously, and that an interrupt cannot occur after one bit is set but before the other is set. Note, however, that this method is not recommended and is not reliable.

### 11.6.5.3 Posting External Interrupts

An external agent posts (sets) a pending interrupt with vector “v” to the i960 processor through the interrupt table by executing the following algorithm:

#### Example 11-2. External Agent Posting

```
External_Agent_Posting:
x = atomic_read(pending_priorities); # synchronize;
z = read(pending_interrupts[v/8]);
x[v/8] = 1;
z[v mod 8] = 1;
write(pending_interrupts[v/8]) = z;
atomic_write(pending_priorities) = x;
```

Generally, software cannot use this algorithm to post interrupts because there is no way for software to have an atomic (locking) read/write operation span multiple instructions.

**11**

### 11.6.5.4 Posting Hardware Interrupts

Certain interrupts are posted directly to the processor by an implementation-dependent mechanism that can bypass the interrupt table. This is often done for performance reasons.

### 11.6.6 Resolving Interrupt Priority

The interrupt controller continuously compares the processor’s priority to the priorities of the highest-posted software interrupt and the highest-pending hardware interrupt. The core is interrupted when a pending interrupt request is higher than the processor priority or has a priority of 31. (Note that a priority-31 interrupt handler can be interrupted by another priority-31 interrupt.) There are no priority-0 interrupts, since such an interrupt would never have a priority higher than the current process, and would therefore never be serviced.

## INTERRUPTS

In the event that both hardware and software requested interrupts are posted at the same level, the hardware interrupt is delivered first while the software interrupt is left pending. As a result, if both priority-31 hardware- and software-requested interrupts are pending, control is first transferred to the interrupt handler for the hardware-requested interrupt. However, before the first instruction of that handler can be executed, the pending software-requested interrupt is delivered, which causes control to be transferred to the corresponding interrupt handler.

### Example 11-3. Interrupt Resolution

```

/* Model used to resolve interrupts between execution of all instructions */
if (NMI_pending && !block_NMI)
  { block_NMI = true; /* Reset on return from NMI INTR handler */
    vecnum = 248; vector_addr = 0;
    PC.priority = 31;
    push_local_register_set();
    goto common_interrupt_process; }
if (ICON.gie == enabled) {
  expand_HW_int();
  temp = max(HW_Int_Priority, SW_Int_Priority);
  if (temp == 31 || temp > PC.priority)
    { PC.priority = temp;
      if (SW_Int_Priority > HW_Int_Priority) goto Deliver_SW_Int;
      else{ vecnum = HW_vecnum; goto Deliver_HW_Int;}
    }
}

```

### 11.6.7 Sampling Pending Interrupts in the Interrupt Table

At specific points, the processor checks the interrupt table for pending interrupts. If one is found, it is handled as if the interrupt occurred at that time. In the i960 Jx processor, a check for pending interrupts in the interrupt table is made when requesting a software interrupt with **sysctl**, or when servicing a software interrupt.

When a check of the interrupt table is made, the algorithm shown in [Example 11-4](#) is used. Since the pending interrupts may be cached, the check for pending interrupt operation may not involve any memory operations. The algorithm uses synchronization because there may be multiple agents posting and unposting interrupts. In the algorithm, w, x, y, and z are temporary registers within the processor.



## Example 11-4. Sampling Pending Interrupts

```

Check_For_Pending_Interrupts:
x = read(pending_priorities);
if(x == 0) return(); #nothing to do
y = most_significant_bit(x);
if(y != 31 && y <= current_priority) return();
x = atomic_read(pending_priorities); #synchronize
if(x == 0)
    {atomic_write(pending_priorities) = x;
    return();} #interrupts disappeared
    # (e.g., handled by another processor)
y = most_significant_bit(x); #must be repeated
if(y != 31 && y <= current_priority)
    {atomic_write(pending_priorities) = x;
    return();} #interrupt disappeared
z = read(pending_interrupts[y]); #z is a byte
if(z == 0)
    {x[y] = 0; #false alarm, should not happen
    atomic_write(pending_priorities) = x;
    return();}
else
    {w = most_significant_bit[z];
    z[w] = 0;
    write(pending_interrupts[y]) = z;
    if(z == 0) x[y] = 0; #no others at this level
    atomic_write(pending_priorities) = x;
    take_interrupt();}

```

The algorithm shows that the pending interrupts are marked by a bit in the pending interrupts field, and that the pending priorities field is an optimization; the processor examines pending interrupts only if the corresponding bit in Pending Priorities is set.

The steps prior to the `atomic_read` are another optimization. Note that these steps must be repeated within the synchronized critical section, since another processor could have detected and accepted the same pending interrupt(s).

Use `sysctl` with a vector in the range 0 to 7 to force the core to check the interrupt table for pending interrupts. When an external agent is posting interrupts to a shared interrupt table, use `sysctl` periodically to guarantee recognition of pending interrupts posted in the table by the external agent.

# INTERRUPTS

## 11.6.8 Interrupt Controller Modes

The eight external interrupt pins can be configured for one of three modes: dedicated, expanded or mixed. Each mode is described in the subsections that follow.

### 11.6.8.1 Dedicated Mode

In dedicated mode, each external interrupt pin is assigned a vector number. Vector numbers that may be assigned to a pin are those with the encoding  $PPPP\ 0010_2$  (Figure 11-4), where bits marked P are programmed with bits in the interrupt map (IMAP) registers. This encoding of programmable bits and preset bits can designate 15 unique vector numbers, each with a unique, even-numbered priority. (Vector  $0000\ 0010_2$  is undefined; it has a priority of 0.)

Dedicated-mode interrupts are posted in the interrupt pending (IPND) register. Single bits in the IPND register correspond to each of the eight dedicated external interrupt inputs, or the two timer inputs to the interrupt controller. The interrupt mask (IMSK) register selectively masks each of the dedicated-mode interrupts. Optionally, the IMSK register can be saved and cleared when a dedicated-mode interrupt is serviced. This allows other hardware-generated interrupts to be locked out until the mask is restored. See section 11.7.3, “Memory-Mapped Control Registers” (pg. 11-21) for a further description of the IMSK, IPND and IMAP registers.

Interrupt vectors are assigned to timer inputs in the same way external pins are assigned dedicated-mode vectors. The timer interrupts are always dedicated-mode interrupts.




Figure 11-4. Dedicated Mode



11.6.8.2 Expanded Mode

In expanded mode, up to 240 interrupts can be requested from external sources. Multiple external sources are externally encoded into the 8-bit interrupt vector number. This vector number is then applied to the external interrupt pins (Figure 11-5), with the  $\overline{XINT0}$  pin representing the least-significant bit and  $\overline{XINT7}$  the most significant bit of the number. Note that external interrupt pins are active low; therefore, the inverse of the vector number is actually applied to the pins.

In expanded mode, external logic is responsible for posting and prioritizing external sources. Typically, this scheme is implemented with a simple configuration of external priority encoders. The interrupt source must remain asserted until the processor services the interrupt and explicitly clears the source. As shown in Figure 11-6, simple, combinational logic can handle prioritization of the external sources when more than one expanded mode interrupt is pending.

An expanded mode interrupt source must remain asserted until the processor services the interrupt and explicitly clears the source. External-interrupt pins in expanded mode are always active low and level-detect. The interrupt controller ignores vector numbers 0 through 7. The output of the external priority encoders in Figure 11-6 can use the 0 vector to indicate that no external interrupts are pending.

The low-order four bits of IMAPO buffer the expanded-mode interrupt internally.  $\overline{XINT}[7:4]$  are placed in IMAPO[3:0];  $\overline{XINT}[3:0]$  are latched in a special register for use in further arbitrating the interrupt and in selecting the interrupt handler.

IMSK register bit 0 provides a global mask for all expanded interrupts. The remaining bits (1-7) must be set to 0 in expanded mode. Optionally, the mask bit can be saved and cleared when an expanded mode interrupt is serviced. This allows other hardware-requested interrupts to be locked out until the mask is restored. IPND register bits 0-7 have no function in expanded mode, since external logic is responsible for posting interrupts.




Figure 11-5. Expanded Mode






Figure 11-6. Implementation of Expanded Mode Sources



### 11.6.8.3 Mixed Mode

In mixed mode, pins  $\overline{\text{XINT0}}$  through  $\overline{\text{XINT4}}$  are configured for expanded mode. These pins are encoded for the five most-significant bits of an expanded-mode vector number; the three least-significant bits of the vector number are set internally to  $010_2$ . Pins  $\overline{\text{XINT5}}$  through  $\overline{\text{XINT7}}$  are configured for dedicated mode.

Do not write to the low-order four bits of  $\text{IMAP0}$  as these bits are used to buffer the expanded-mode interrupt internally.  $\overline{\text{XINT}}[4:1]$  are placed in  $\text{IMAP0}[3:0]$ ;  $\overline{\text{XINT0}}$  is latched in a special register for use in further arbitrating the interrupt and in selecting the interrupt handler.

$\text{IMSK}$  register bit 0 is a global mask for the expanded-mode interrupts; bits 5 through 7 mask the dedicated interrupts from pins  $\overline{\text{XINT5}}$  through  $\overline{\text{XINT7}}$ , respectively.  $\text{IMSK}$  register bits 1-4 must be set to 0 in mixed mode. The  $\text{IPND}$  register posts interrupts from the dedicated-mode pins  $\overline{\text{XINT}}[7:5]$ .  $\text{IPND}$  register bits that correspond to expanded-mode inputs are not used.

### 11.6.9 Saving the Interrupt Mask

Whenever an interrupt requested by  $\overline{\text{XINT}}[7:0]$  or by the internal timers is serviced, the  $\text{IMSK}$  register is automatically saved in register r3 of the new local register set allocated for the interrupt handler. After the mask is saved, the  $\text{IMSK}$  register is optionally cleared. This allows all interrupts except  $\overline{\text{NMI}}$ s to be masked while an interrupt is being serviced. Since the  $\text{IMSK}$  register value is saved, the interrupt procedure can restore the value before returning. The option of clearing the mask is selected by programming the  $\text{ICON}$  register as described in [section 11.7.4, “Interrupt Control Register \(ICON\)”](#) (pg. 11-22). Several options are provided for interrupt mask handling:

- Mask unchanged
- Cleared for dedicated-mode sources only
- Cleared for expanded-mode sources only
- Cleared for all hardware-requested interrupts (dedicated and expanded mode)

The second and third options are used in mixed mode, where both dedicated-mode and expanded-mode inputs are allowed. Timer unit interrupts are always dedicated-mode interrupts.

Note that when the same interrupt is requested simultaneously by a dedicated- and an expanded-mode source, the interrupt is considered an expanded-mode interrupt and the  $\text{IMSK}$  register is handled accordingly.

## INTERRUPTS

The IMSK register must be saved and cleared when expanded mode inputs request a priority-31 interrupt. Priority-31 interrupts are interrupted by other priority-31 interrupts. In expanded mode, the interrupt pins are level-activated. For level-activated interrupt inputs, instructions within the interrupt handler are typically responsible for causing the source to deactivate. When these priority-31 interrupts are not masked, another priority-31 interrupt is signaled and serviced before the handler can deactivate the source. The first instruction of the interrupt handling procedure is never reached, unless the option is selected to clear the IMSK register on entry to the interrupt.

Another use of the mask is to lock out other interrupts when executing time-critical portions of an interrupt handling procedure. All hardware-generated interrupts are masked until software explicitly replaces the mask.

The processor does not restore r3 to the IMSK register when the interrupt return is executed. When the IMSK register is cleared, the interrupt handler must restore the IMSK register to enable interrupts after return from the handler.

### 11.7 EXTERNAL INTERFACE DESCRIPTION

This section describes the physical characteristics of the interrupt inputs. The i960 Jx processor provides eight external interrupt pins and one non-maskable interrupt pin for detecting external interrupt requests. The eight external pins can be configured as dedicated inputs, where each pin is capable of requesting a single interrupt. The external pins can also be configured in an expanded mode, where the value asserted on the external pins represents an interrupt vector number. In this mode, up to 240 values can be directly requested with the interrupt pins. The external interrupt pins can be configured in mixed mode. In this mode, some pins are dedicated inputs and the remaining pins are used in expanded mode.

#### 11.7.1 Pin Descriptions

The interrupt controller provides nine interrupt pins:

$\overline{XINT}[7:0]$	External Interrupt (input) - These eight pins cause interrupts to be requested. Pins are software configurable for three modes: dedicated, expanded, mixed. Each pin can be programmed as an edge- or level-detect input. Also, a debounce sampling mode for these pins can be selected under program control.
$\overline{NMI}$	Non-Maskable Interrupt (input) - This edge-activated pin causes a non-maskable interrupt event to occur. $\overline{NMI}$ is the highest priority interrupt recognized. A debounce sampling mode for $\overline{NMI}$ can be selected under program control. This pin is internally synchronized.

External interrupt pin functions  $\overline{XINT}[7:0]$  depend on the operation mode (expanded, dedicated or mixed) and on several other options selected by setting ICON register bits.





### 11.7.2 Interrupt Detection Options

The  $\overline{\text{XINT}}[7:0]$  pins can be programmed for level-low or falling-edge detection when used as dedicated inputs. All dedicated inputs plus the  $\overline{\text{NMI}}$  pin are programmed (globally) for fast sampling or debounce sampling. Expanded-mode inputs are always sampled in debounce mode. Pin detection and sampling options are selected by programming the ICON register.

When falling-edge detection is enabled and a high-to-low transition is detected, the processor sets the corresponding pending bit in the IPND register. The processor clears the IPND bit upon entry into the interrupt handler.

When a pin is programmed for low-level detection, the pin's bit in the IPND register remains set as long as the pin is asserted (low). The processor attempts to clear the IPND bit on entry into the interrupt handler; however, if the active level on the pin is not removed at this time, the bit in the IPND register remains set until the source of the interrupt is deactivated and the IPND bit is explicitly cleared by software. Software may attempt to clear an interrupt pending bit before the active level on the corresponding pin is removed. In this case, the active level on the interrupt pin causes the pending bit to remain asserted.

After the interrupt signal is deasserted, the handler then clears the interrupt pending bit for that source before return from handler is executed. If the pending bit is not cleared, the interrupt is re-entered after the return is executed.

[Example 11-5](#) demonstrates how a level detect interrupt is typically handled. The example assumes that the `ld` from address “INTR\_SRC,” deactivates the interrupt input.

**Example 11-5. Return from a Level-detect Interrupt**

```
# Clear level-detect interrupts before return from handler
ld    INTR_SRC, g0 # Dismiss the extern. interrupt
lda   IPND_MMR, g1 # g1 = IPND MMR address
lda   0x80, g2    # g2 = mask to clear XINT7 IPND bit

# Loop until IPND bit 7 clears
wait:
mov   0, g3
# Try to clear the XINT7 IPND bit
atmod g1, g2, g3
bbs   0x7, g3, wait # Branch until IPND bit 7 clears

# Optionally restore IMSK
mov   r3, IMSK
ret                                     # Return from handler
```

11

The debounce sampling mode provides a built-in filter for noisy or slow-falling inputs. The debounce sampling mode requires that a low level is stable for three consecutive cycles before the expanded mode vector is resolved internally. Expanded mode interrupts are always sampled using the debounce sampling mode. This allows for skew time between changing outputs of external priority encoders.

Figure 11-7 shows how a signal is sampled in each mode. The debounce-sampling option adds several clock cycles to an interrupt's latency due to the multiple clocks of sampling. Inputs are sampled once every CLKIN cycle (external bus clock).

Interrupt pins are asynchronous inputs. Setup or hold times relative to CLKIN are not needed to ensure proper pin detection. Note in Figure 11-7 that interrupt inputs are sampled once every two CLKIN cycles. For practical purposes, this means that asynchronous interrupting devices must generate an interrupt signal that is asserted for at least three CLKIN cycles for the fast sampling mode or seven CLKIN cycles for the debounce sampling mode. See section 1.4, "Related Documents" (pg. 1-10). These documents have setup and hold specifications that guarantee detection of the interrupt on particular edges of CLKIN. These specification are useful in designs that use synchronous logic to generate interrupt signals to the processor. These specification must also be used to calculate the minimum signal width, as shown in Figure 11-7.




Figure 11-7. Interrupt Sampling



### 11.7.3 Memory-Mapped Control Registers

The programmer’s interface to the interrupt controller is through six memory-mapped control registers: ICON control register, IMAPO-IMAP2 control registers, IMSK register and IPND control register. [Table 11-1](#) describes the ICU registers.

**Table 11-1. Interrupt Control Registers Memory-Mapped Addresses**


Register Name	Description	Address
IPND	Interrupt Pending Register	FF00 8500H
IMSK	Interrupt Mask Register	FF00 8504H
ICON	Interrupt Control Register	FF00 8510H
IMAP0	Interrupt Map Register 0	FF00 8520H
IMAP1	Interrupt Map Register 1	FF00 8524H
IMAP2	Interrupt Map Register 2	FF00 8528H



# INTERRUPTS

## 11.7.4 Interrupt Control Register (ICON)

The ICON register (see [Figure 11-8](#)) is a 32-bit memory-mapped control register that sets up the interrupt controller. Software can manipulate this register using the load/store type instructions. The ICON register is also automatically loaded at initialization from the control table in external memory.



**Figure 11-8. Interrupt Control (ICON) Register**

The *interrupt mode field* (bits 0 and 1) determines the operation mode for the external interrupt pins (XINT[7:0]), dedicated, expanded or mixed.

The *signal detection mode bits* (bits 2 - 9) determine whether the signals on the individual external interrupt pins (XINT[7:0]) are level-low activated or falling-edge activated. Expanded-mode inputs are always level-detected; the NMI input is always edge-detected, regardless of the bit's value.



The *global interrupts enable bit* (bit 10) globally enables or disables the external interrupt pins and timer unit inputs. It does not affect the  $\overline{\text{NMI}}$  pin. This bit performs the same function as clearing the mask register. The global interrupts enable bit is also changed indirectly by the use of the following instructions: **intn**, **intdis**, **intctl**.

The *mask-operation field* (bits 11, 12) determines the operation the core performs on the mask register when a hardware-generated interrupt is serviced. On an interrupt, the IMASK register is either unchanged; cleared for dedicated-mode interrupts; cleared for expanded-mode interrupts; or cleared for both dedicated- and expanded-mode interrupts. IMASK is never cleared for NMI or software interrupts.

The *vector cache enable bit* (bit 13) determines whether interrupt table vector entries are fetched from the interrupt table or from internal data RAM. Only vectors with the four least-significant bits equal to  $0010_2$  may be cached in internal data RAM.

The *sampling-mode bit* (bit 14) determines whether dedicated inputs and  $\overline{\text{NMI}}$  pin are sampled using debounce sampling or fast sampling. Expanded-mode inputs are always detected using debounce mode.

Bits 15 through 31 are reserved and must be set to 0 at initialization.

### 11.7.5 Interrupt Mapping Registers (IMAP0-IMAP2)

The IMAP registers (Figure 11-9) are three 32-bit registers (IMAP0 through IMAP2). These registers are used to program the vector number associated with the interrupt source when the source is connected to a dedicated-mode input. IMAP0 and IMAP1 contain mapping information for the external interrupt pins (four bits per pin). IMAP2 contains mapping information for the timer-interrupt inputs (four bits per interrupt).

Each set of four bits contains a vector number's four most-significant bits; the four least-significant bits are always  $0010_2$ . In other words, each source can be programmed for a vector number of PPPP  $0010_2$ , where "P" indicates a programmable bit. For example, IMAP0 bits 4 through 7 contain mapping information for the  $\overline{\text{XINTI}}$  pin. If these bits are set to  $0110_2$ , the pin is mapped to vector number  $0110\ 0010_2$  (or vector number 98).

Software can access the mapping registers using load/store type instructions. The mapping registers are also automatically loaded at initialization from the control table in external memory. Note that bits 16 through 31 of IMAP0 and IMAP1 are reserved and should be set to 0 at initialization. Bits 0-15 and 24-31 of IMAP2 are also reserved and should be set to 0.




Figure 11-9. Interrupt Mapping (IMAP0-IMAP2) Registers



### 11.7.5.1 Interrupt Mask (IMSK) and Interrupt Pending (IPND) Registers

The IMSK and IPND registers (see [Figure 11-10](#) and [Figure 11-11](#)) are both memory-mapped registers. Bits 0 through 7 of these registers are associated with the external interrupt pins ( $\overline{XINT0}$  through  $\overline{XINT7}$ ) and bits 12 and 13 are associated with the timer-interrupt inputs (TMR0 and TMR1). All other bits are reserved and should be set to 0 at initialization.




Figure 11-10. Interrupt Pending (IPND) Register




Figure 11-11. Interrupt Mask (IMSK) Registers





The IPND register posts dedicated-mode interrupts originating from the eight external dedicated sources (when configured in dedicated mode) and the two timer sources. Asserting one of these inputs causes a 1 to be latched into its associated bit in the IPND register. In expanded mode, bits 0 through 7 of this register are not used and should not be modified; in mixed mode, bits 0 through 4 are not used and should not be modified.

The mask register provides a mechanism for masking individual bits in the IPND register. An interrupt source is disabled if its associated mask bit is set to 0.

Mask register bit 0 has two functions: it masks interrupt pin  $\overline{XINT0}$  in dedicated mode and it masks all expanded-mode interrupts globally in expanded and mixed modes. In expanded mode, bits 1 through 7 are not used and should contain zeros only; in mixed mode, bits 1 through 4 are not used and should contain zeros only.

When delivering a hardware interrupt, the interrupt controller conditionally clears IMSK based on the value of the ICON.mo bit. Note that IMSK is never cleared for NMI or software interrupt.

Although software can read and write IPND and IMSK using any memory-format instruction, a read-modify-write operation on these registers must be performed using the atomic-modify instruction (ATMOD). Executing an ATMOD on one of these registers causes the interrupt controller to perform regular interrupt processing (including using or automatically updating IPND and IMSK) either before or after, but not during the read-modify-write operation on that register. This requirement ensures that modifications to IPND and IMSK take effect cleanly, completely, and at a well-defined point. Note that the processor does not assert the LOCK pin externally when executing an atomic instruction to IPND and IMSK.

When the processor core handles a pending interrupt, it attempts to clear the bit that is latched for that interrupt in the IPND register before it begins servicing the interrupt. If that bit is associated with an interrupt source that is programmed for level detection and the true level is still present, the bit remains set. Because of this, the interrupt routine for a level-detected interrupt should clear the external interrupt source and explicitly clear the IPND bit before return from the handler is executed.

An alternative method of posting interrupts in the IPND register, other than through the external interrupt pins, is to set bits in the register directly using an ATMOD instruction. This operation has the same effect as requesting an interrupt through the external interrupt pins. The bit set in the IPND register must be associated with an interrupt source that is programmed for dedicated-mode operation.

### 11.7.5.2 Interrupt Controller Register Access Requirements

Like all other load accesses from internal memory-mapped registers, once issued, a load instruction that accesses an interrupt register has a latency of one internal processor cycle.

A store access to an interrupt register is synchronous with respect to the next instruction; that is, the operation completes fully and all state changes take effect before the next instruction begins execution.

## INTERRUPTS

Interrupts can be enabled and disabled quickly by the new **intdis** and **inten** instructions, which take four cycles each to execute. **intctl** takes a few cycles longer because it returns the previous interrupt enable value. See [CHAPTER 6, INSTRUCTION SET REFERENCE](#) for more information on these instructions.

### 11.7.5.3 Default and Reset Register Values

The ICON and IMAP2:0 control registers are loaded from the control table in external memory when the processor is initialized or reinitialized. The control table is described in [section 12.3.3, “Control Table”](#) (pg. 12-20). The IMSK register is set to 0 when the processor is initialized (**RESET** is deasserted). The IPND register value is undefined after a power-up initialization (cold reset). The application is responsible for clearing this register before any mask register bits are set; otherwise, unwanted interrupts may be triggered. The pending register value is retained for a reset while power is on (warm reset).

## 11.8 INTERRUPT OPERATION SEQUENCE

The interrupt controller, microcode and core resources handle all stages of interrupt service. Interrupt service is handled in the following stages:

**Requesting Interrupt** — In the i960 Jx processor, the programmable on-chip interrupt controller transparently manages all interrupt requests. Interrupts are generated by hardware (external events) or software (the application program). Hardware requests are signaled on the 8-bit external interrupt port ( $\overline{XINT}[7:0]$ ), the non-maskable interrupt pin ( $\overline{NMI}$ ) or the two timer channels. Software interrupts are signaled with the **sysctl** instruction with post-interrupt message type.

**Posting Interrupts** — When an interrupt is requested, the interrupt is either serviced immediately or saved for later service, depending on the interrupt’s priority. Saving the interrupt for later service is referred to as posting. Once posted, an interrupt becomes a pending interrupt. Hardware and software interrupts are posted differently:

- Hardware interrupts are posted by setting the interrupt’s assigned bit in the interrupt pending (IPND) memory mapped register
- Software interrupts are posted by setting the interrupt’s assigned bit in the interrupt table’s pending priorities and pending interrupts fields



Checking Pending Interrupts — The interrupt controller compares each pending interrupt's priority with the current process priority. If process priority changes, posted interrupts of higher priority are then serviced. Comparing the process priority to posted interrupt priority is handled differently for hardware and software interrupts. Each hardware interrupt is assigned a specific priority when the processor is configured. The priority of all posted hardware interrupts is continually compared to the current process priority. Software interrupts are posted in the interrupt table in external memory. The highest priority posted in this table is also saved in an on-chip software priority register; this register is continually compared to the current process priority.

Servicing Interrupts — If the process priority falls below that of any posted interrupt, the interrupt is serviced. The comparator signals the core to begin a microcode sequence to perform the interrupt context switch and branch to the first instruction of the interrupt routine.

Figure 11-12 illustrates interrupt controller function. For best performance, the interrupt flow for hardware interrupt sources is implemented entirely in hardware.

The comparator signals the core only when a posted interrupt is a higher priority than the process priority. Because the comparator function is implemented in hardware, microcode cycles are never consumed unless an interrupt is serviced.




Figure 11-12. Interrupt Controller



### 11.8.1 Setting Up the Interrupt Controller

This section provides an example of setting up the interrupt controller. The following example describes how the interrupt controller can be dynamically configured after initialization.

[Example 11-6](#) sets up the interrupt controller for expanded-mode operation. Initially the IMSK register is masked to allow for setup. A value that selects expanded-mode operation is loaded into the ICON register and the IMSK is unmasked.

#### Example 11-6. Programming the Interrupt Controller for Expanded Mode

```
# Example expanded mode setup . . .
mov    0, g0
mov    1, g1
st     g0, IMSK           # mask, IMSK MMR at 0XFF008504
st     g1, ICON
st     g1, IMSK           # unmask expanded interrupts
```

### 11.8.2 Interrupt Service Routines

An interrupt handling procedure performs a specific action that is associated with a particular interrupt vector number. For example, one interrupt handler task might initiate a timer unit request. The interrupt handler procedures can be located anywhere in the non-reserved address space. Since instructions in the i960 processor architecture must be word-aligned, each procedure must begin on a word boundary.

When an interrupt handling procedure is called, the processor allocates a new frame on the interrupt stack and a set of local registers for the procedure. If not already in supervisor mode, the processor always switches to supervisor mode while an interrupt is being handled. It also saves the states of the AC and PC registers for the interrupted program.

The interrupt procedure shares the remainder of the execution environment resources (namely the global registers and the address space) with the interrupted program. Thus, interrupt procedures must preserve and restore the state of any resources shared with a non-cooperating program. For example, an interrupt procedure that uses a global register that is not permanently allocated to it should save the register's contents before using the register and restore the contents before returning from the interrupt handler.

To reduce interrupt latency to critical interrupt routines, interrupt handlers may be locked into the instruction cache. See [section 11.9.2.2, “Caching Interrupt Routines and Reserving Register Frames”](#) (pg. 11-36) for a complete description.

## INTERRUPTS

### 11.8.3 Interrupt Context Switch

When the processor services an interrupt, it automatically saves the interrupted program state or interrupt procedure and calls the interrupt handling procedure associated with the new interrupt request. When the interrupt handler completes, the processor automatically restores the interrupted program state.

The method that the processor uses to service an interrupt depends on the processor state when the interrupt is received. If the processor is executing a background task when an interrupt request is posted, the interrupt context switch must change stacks to the interrupt stack. This is called an executing-state interrupt. If the processor is already executing an interrupt handler, no stack switch is required since the interrupt stack is already in use. This is called an interrupted-state interrupt.

The following subsections describe interrupt handling actions for executing-state and interrupted-state interrupts. In both cases, it is assumed that the interrupt priority is higher than that of the processor and thus is serviced immediately when the processor receives it.

#### 11.8.3.1 Servicing an Interrupt from Executing State

When the processor receives an interrupt while in the executing state (i.e., executing a program,  $PC.s = 0$ ), it performs the following actions to service the interrupt. This procedure is the same regardless of whether the processor is in user or supervisor mode when the interrupt occurs. The processor:

1. Switches to the interrupt stack (as shown in [Figure 11-3](#)). The interrupt stack pointer becomes the new stack pointer for the processor.
2. Saves the current PC and AC in an interrupt record on the interrupt stack. The processor also saves the interrupt vector number.
3. Allocates a new frame on the interrupt stack and loads the new frame pointer (NFP) in global register g15.
4. Sets the state flag in PC to interrupted ( $PC.s = 1$ ), its execution mode to supervisor and its priority to the priority of the interrupt. Setting the processor's priority to that of the interrupt ensures that lower priority interrupts cannot interrupt the servicing of the current interrupt.
5. Clears the trace enable bit in PC. Clearing this bit allows the interrupt to be handled without trace faults being raised.
6. Sets the frame return status field  $pf\bar{p}[2:0]$  to  $111_2$ .
7. Performs a call operation as described in [CHAPTER 7, PROCEDURE CALLS](#). The address for the called procedure is specified in the interrupt table for the specified interrupt vector number.



After completing the interrupt procedure, the processor:

1. Copies the arithmetic controls field and the process controls field from the interrupt record into the AC and PC, respectively. It then switches to the executing state and restores the trace-enable bit to its value before the interrupt occurred.
2. Deallocates the current stack frame and interrupt record from the interrupt stack and switches to the stack it was using before servicing the interrupt.
3. Performs a return operation as described in [CHAPTER 7, PROCEDURE CALLS](#).
4. Resumes work on the program, if there are no pending interrupts to be serviced or trace faults to be handled.

### 11.8.3.2 Servicing an Interrupt from Interrupted State

If the processor receives an interrupt while it is servicing another interrupt, and the new interrupt has a higher priority than the interrupt currently being serviced, the current interrupt-handler routine is interrupted. Here, the processor performs the same interrupt-servicing action as is described in [Section 11.8.3.1](#) to save the state of the interrupted interrupt-handler routine. The interrupt record is saved on the top of the interrupt stack prior to the new frame that is created for use in servicing the new interrupt. See [Figure 11-3](#).

On the return from the current interrupt handler to the previous interrupt handler, the processor de-allocates the current stack frame and interrupt record, and stays on the interrupt stack.

## 11.9 OPTIMIZING INTERRUPT PERFORMANCE

[Figure 11-13](#) depicts the path from interrupt source to interrupt service routine. This section discusses interrupt performance in general and suggests techniques the application can use to get the best interrupt performance.




Figure 11-13. Interrupt Service Flowchart





### 11.9.1 Interrupt Service Latency

The established measure of interrupt performance is the time required to perform an interrupt task switch, which is known as *interrupt service latency*. Latency is the time measured between activation of an interrupt source and execution of the first instruction for the accompanying interrupt-handling procedure.

Interrupt latency depends on interrupt controller configuration and the instruction being executed at the time of the interrupt. The processor also has a number of cache options that reduce interrupt latency. In the discussion that follows, interrupt latency is expressed as a number of bus clock cycles, and reflects differences between the 80960JA/JF, the 80960JD due to the 80960JD processor's clock-doubled core, and the 80960JT due to the processor's clock-tripled core.

### 11.9.2 Features to Improve Interrupt Performance

The i960 Jx processor implementation employs four methods to reduce interrupt latency:

- Caching interrupt vectors on-chip
- Caching of interrupt handling procedure code
- Reserving register frames in the local register cache
- Caching the interrupt stack in the data cache

#### 11.9.2.1 Vector Caching Option

To reduce interrupt latency, the i960 Jx processors allow some interrupt table vector entries to be cached in internal data RAM. When the vector cache option is enabled and an interrupt request has a cached vector to be serviced, the controller fetches the associated vector from internal RAM rather than from the interrupt table in memory.

Interrupts with a vector number with the four least-significant bits equal to  $0010_2$  can be cached. The vectors that can be cached coincide with the vector numbers that are selected with the mapping registers and assigned to dedicated-mode inputs. The vector caching option is selected when programming the ICON register; software must explicitly store the vector entries in internal RAM.

Since the internal RAM is mapped to the address space directly, this operation can be performed using the core's store instructions. [Table 11-2](#) shows the required vector mapping to specific locations in internal RAM. For example, the vector entry for vector number 18 must be stored at RAM location 04H, and so on.

The  $\overline{\text{NMI}}$  vector is also shown in [Table 11-2](#). This vector is always cached in internal data RAM at location 0000H. The processor automatically loads this location at initialization with the value of vector number 248 in the interrupt table.

**Table 11-2. Location of Cached Vectors in Internal RAM**

Vector Number (Binary)	Vector Number (Decimal)	Internal RAM Address
NMI	248	0000H
0001 0010 <sub>2</sub>	18	0004H
0010 0010 <sub>2</sub>	34	0008H
0011 0010 <sub>2</sub>	50	000CH
0100 0010 <sub>2</sub>	66	0010H
0101 0010 <sub>2</sub>	82	0014H
0110 0010 <sub>2</sub>	98	0018H
0111 0010 <sub>2</sub>	114	001CH
1000 0010 <sub>2</sub>	130	0020H
1001 0010 <sub>2</sub>	146	0024H
1010 0010 <sub>2</sub>	162	0028H
1011 0010 <sub>2</sub>	178	002CH
1100 0010 <sub>2</sub>	194	0030H
1101 0010 <sub>2</sub>	210	0034H
1110 0010 <sub>2</sub>	226	0038H
1111 0010 <sub>2</sub>	242	003CH

**11.9.2.2 Caching Interrupt Routines and Reserving Register Frames**

The time required to fetch the first instructions of an interrupt-handling procedure affects interrupt response time and throughput. The user can reduce this fetch time by caching interrupt procedures or portions of procedures in the i960 Jx processor’s instruction cache. The **icctl** instruction can load and lock these procedures into the instruction cache. See [section 4.4, “INSTRUCTION CACHE”](#) (pg. 4-4) for information on the instruction cache.

To decrease interrupt latency for high priority interrupts (priority 28 and above), software can limit the number of frames in the local register cache available to code running at a lower priority (priority 27 and below). This ensures that some number of free frames are available to high-priority interrupt service routines. See [section 4.2, “LOCAL REGISTER CACHE”](#) (pg. 4-2), for more details.

**11.9.2.3 Caching the Interrupt Stack**

By locating the interrupt stack in cacheable memory, the performance of interrupt returns can be improved. This is because accesses to the interrupt record by the interrupt return can be satisfied by the data cache. See [section 13.6, “Programming the Logical Memory Attributes”](#) (pg. 13-8) for details on how to enable data caching for portions of memory.



### 11.9.3 Base Interrupt Latency

In many applications, the processor’s instruction mix and cache configuration are known sufficiently well to use typical interrupt latency in calculations of overall system performance. For example, a timer interrupt may frequently trigger a task switch in a multi-tasking kernel. Base interrupt latency assumes the following:

- Single-cycle RISC instruction is interrupted.
- Frame flush does not occur.
- Bus queue is empty.
- Cached interrupt handler.
- No interaction of faults and interrupts (i.e., a stable system).

Table 11-3 shows the base latencies for all interrupt types, with varying pin sampling and vector caching options. Note that the 80960JD interrupt latency is approximately 50% less than the 80960JA/JF interrupt latency due to its core clock operating at twice the speed of CLKIN.

The 80960JT is approximately 70% less than the 80960JA/JF and approximately 30% less than the 80960JD, due to its core clock operating at three times the speed of CLKIN.

**Table 11-3. Base Interrupt Latency**

Interrupt Type	Detection Option	Vector Caching Enabled	Typical 80960JA/JF Latency (Bus Clocks)	Typical 80960JD Latency (Bus Clocks)	Typical 80960JT (3x) Latency (Bus Clocks)
NMI	Fast	Yes	29	14.5	9.7
	Debounced	Yes	32	15.5	13.7
Dedicated Mode XINT[7:0], TINT[1:0]	Fast	Yes	34	17.5	12
		No	40+a	21+b	14+c
	Debounced	Yes	37	21.5	16.3
		No	45+a	26+b	18.3+c
Expanded Mode XINT[7:0], TINT[1:0]	Debounced	Yes	37	22	16
		No	45+a	26+b	18.7+c
Software	NA	Yes	68	35	20+c+d
		No	69+a	36.5+b	20+2c+d
Notes: a = MAX (0, N - 7) b = MAX (0, N - 3.5) c = MAX (0, N - 2.3) d = N where "N" is the number of bus cycles needed to perform a word load.					



## INTERRUPTS

### 11.9.4 Maximum Interrupt Latency

In real-time applications, worst-case interrupt latency must be considered for critical handling of external events. For example, an interrupt from a mechanical subsystem may need service to calculate servo loop parameters to maintain directional control. Determining worst-case latency depends on knowledge of the processor's instruction mix and operating environment as well as the interrupt controller configuration. Excluding certain very long, uninterruptable instructions from critical sections of code reduces worst-case interrupt latency to levels approaching the base latency.

The following tables present worst-case interrupt latencies based on possible execution of **divo** (r15 destination), **divo** (r3 destination), **calls** or **flushreg** instructions or software interrupt detection. The assumptions for these tables are the same as for [Table 11-8](#), except for instruction execution. It is also assumed that the instructions are already in the cache and that tracing is disabled.

**Table 11-4. Worst-Case Interrupt Latency Controlled by divo to Destination r15**

Interrupt Type	Detection Option	Vector Caching Enabled	Worst 80960JA/JF Latency (Bus Clocks)	Worst 80960JD Latency (Bus Clocks)	Worst 80960JT (3x) Latency (Bus Clocks)
NMI	Fast	Yes	42	23.5	16.7
	Debounced	Yes	46	26	20.3
Dedicated Mode XINT[7:0], TINT[1:0]	Fast	Yes	45	23.5	17
		No	45+a	23.5+b	17+c
	Debounced	Yes	49	27.5	22.3
		No	51+a	27.5+b	22.3+c
Expanded Mode XINT[7:0], TINT[1:0]	Debounced	Yes	50	27.5	21
		No	51+a	27.5+b	21+c

**NOTES:**

a = MAX (0, N - 11)

b = MAX (0, N - 5)

c = MAX (0, N-4.7)

where "N" is the number of bus cycles needed to perform a word load.



**Table 11-5. Worst-Case Interrupt Latency Controlled by divo to Destination r3**

Interrupt Type	Detection Option	Vector Caching Enabled	Worst 80960JA/JF Latency (Bus Clocks)	Worst 80960JD Latency (Bus Clocks)	Worst 80960JT (3x) Latency (Bus Clocks)
NMI	Fast	Yes	59	30.5	21
	Debounced	Yes	64	34.5	24
Dedicated Mode XINT[7:0], TINT[1:0]	Fast	Yes	65	33.5	23.3
		No	72+a	37.5+b	24+c
	Debounced	Yes	69	37	28
		No	76+a	42+b	29+c
Expanded Mode XINT[7:0], TINT[1:0]	Debounced	Yes	70	37.5	27.7
		No	76+a	42+b	29.7+c

**NOTES:**

a = MAX (0,N - 7)

b = MAX (0,N - 3.5)

c = MAX (0,N-2.3)

where "N" is the number of bus cycles needed to perform a word load.

**Table 11-6. Worst-Case Interrupt Latency Controlled by calls**

Interrupt Type	Detection Option	Vector Caching Enabled	Worst 80960JA/JF Latency (Bus Clocks)	Worst 80960JD Latency (Bus Clocks)	Worst 80960JT (3x) Latency (Bus Clocks)
NMI	Fast	Yes	53+a	27+c	22.6+f
	Debounced	Yes	56+a	32+c	26.7+f
Dedicated Mode XINT[7:0], TINT[1:0]	Fast	Yes	58+a	29.5+c	25.3+f
		No	66+a+b	33.5+c+d	27.3+e+f
	Debounced	Yes	62+a	33+c	29.3+f
		No	69+a+b	38+b+c	30.6+e+f
Expanded Mode XINT[7:0], TINT[1:0]	Debounced	Yes	63+a	32.5+c	29.7+f
		No	70+a+b	38+c+d	31+e+f

**NOTES:**

a = MAX (0,N - 4)

b = MAX (0,N - 7)

c = MAX (0,N - 2.5)

d = MAX (0,N - 3.5)

e = MAX (0, N-2.7)

f = MAX (0, N-1.3)

where "N" is the number of bus cycles needed to perform a word load.

**Table 11-7. Worst-Case Interrupt Latency When Delivering a Software Interrupt**

Interrupt Type	Detection Option	Vector Caching Enabled	Worst 80960JA/JF Latency (Bus Clocks)	Worst 80960JD Latency (Bus Clocks)	Worst 80960JT (1x) Latency (Bus Clocks)
NMI	Fast	Yes	96	47	31.7+2c+d
	Debounced	Yes	97	47	35.7+2c+d
Dedicated Mode $\overline{XINT}[7:0]$ , TINT[1:0]	Fast	Yes	99	48	34+2c+d
		No	107+a	53+b	34.7+3c+d
	Debounced	Yes	100	48	38+2c+d
		No	107+a	53+b	38.7+3c+d
Expanded Mode $\overline{XINT}[7:0]$ , TINT[1:0]	Debounced	Yes	96	48	38.3+2c+d
		No	105+a	53+b	39.3+2c+d

**NOTES:**

a = MAX (0,N - 7)

b = MAX (0,N - 3.5)

c = MAX (0, N-2.3)

d = N

where "N" is the number of bus cycles needed to perform a word load.



**Table 11-8. Worst-Case Interrupt Latency Controlled by flushreg of One Stack Frame**

Interrupt Type	Detection Option	Vector Caching Enabled	Worst 80960JA/JF Latency (Bus Clocks)	Worst 80960JD Latency (Bus Clocks)	Worst 80960JT (1x) Latency (Bus Clocks)
NMI	Fast	Yes	77+a+b	41+d+e	28.3+A
	Debounced	Yes	81+a+b	43+d+e	32.3+A
Dedicated Mode XINT[7:0], TINT[1:0]	Fast	Yes	82+a+b	43+d+e	30+A
		No	89+a+b+c	47.5+d+e+f	32+A+k
	Debounced	Yes	86+a+b	47+d+e	34+A
		No	93+a+b+c	51+d+e+f	35.3+A+k
Expanded Mode XINT[7:0], TINT[1:0]	Debounced	Yes	88+a+b	47.5+d+e	34+A
		No	93+a+b+c	52+d+e+f	37+A+k

Notes:  
a = MAX (0, M - 15)  
b = MAX (0, M - 28)  
c = MAX (0, N - 7)  
d = MAX (0, M - 7.5)  
e = MAX (0, M - 15)  
f = MAX (0, n - 3.5)  
A = g+h+i  
g = MAX (0, M - 4.7)  
h = MAX (0, 2M - [7.3+g])  
i = MAX (0, 3M - [13.7+g+h])  
j = MAX (0, 4M+h - 53)  
k = MAX (0, N - [7-j])

stq\_cycles = number of cycles to execute stq instruction.  
g, h, i account for scoreboarding due to the possibility of long memory access latencies.  
j and k account for long STQ time affecting the loading of the interrupt vector from the Interrupt Table.  
where "M" is the number of bus cycles needed to perform a quad word store and "N" is the number of bus cycles needed to perform a word load. Interrupt latency increases rapidly as the number of flushed stack frames increases.

## INTERRUPTS

### 11.9.4.1 Avoiding Certain Destinations for MDU Operations

Typically, when delivering an interrupt, the processor attempts to push the first four local registers (pfp, sp, rip, and r3) onto the local register cache as early as possible. Because of register-interlock, this operation is stalled until previous instructions return their results to these registers. In most cases, this is not a problem; however, in the case of instructions performed by the Multiply/Divide Unit (**divo**, **divi**, **ediv**, **modi**, **remo**, and **remi**), the processor could be stalled for many cycles waiting for the result and unable to proceed to the next step of interrupt delivery.

Interrupt latency can be improved by avoiding the first four local registers as the destination for a Multiply/Divide Unit operation. (Registers pfp, sp, and rip should be avoided for general operations as these are used for procedure linking.)

### 11.9.4.2 Masking Integer Overflow Faults for **syncf**

The i960 core architecture requires an implicit **syncf** before delivering an interrupt so that a fault handler can be dispatched first, if necessary. The **syncf** can require a number of cycles to complete if a multi-cycle multiply or divide instruction was issued previously and integer-overflow faults are unmasked (allowed to occur). Interrupt latency can be improved by masking integer-overflow faults, which allows the implicit **syncf** to complete in much shorter time.







# 12

## INITIALIZATION AND SYSTEM REQUIREMENTS







## CHAPTER 12

# INITIALIZATION AND SYSTEM REQUIREMENTS

This chapter describes the steps that the i960<sup>®</sup> Jx processor performs during initialization. Discussed are the  $\overline{\text{RESET}}$  pin, the reset state and built-in self test (BIST) features. This chapter also describes the processor's basic system requirements — including power, ground and clock — and concludes with some general guidelines for high-speed circuit board design.

### 12.1 OVERVIEW

During the time that the  $\overline{\text{RESET}}$  pin is held asserted, the processor is in a quiescent reset state. All external pins are inactive and the internal processor state is forced to a known condition. The processor begins initialization when the  $\overline{\text{RESET}}$  pin is deasserted.

When initialization begins, the processor uses an Initial Memory Image (IMI) to establish its state. The IMI includes:

- Initialization Boot Record (IBR) – contains the addresses of the first instruction of the user's code and the PRCB.
- Process Control Block (PRCB) – contains pointers to system data structures; also contains information used to configure the processor at initialization.
- System data structures – the processor caches several data structure pointers internally at initialization.

Software can reinitialize the processor. When a reinitialization takes place, a new PRCB and reinitialization instruction pointer are specified. Reinitialization is useful for relocating data structures from ROM to RAM after initialization.

The i960 Jx processor supports several facilities to assist in system testing and start-up diagnostics. ONCE mode electrically removes the processor from a system. This feature is useful for system-level testing where a remote tester exercises the processor system. The i960 Jx processor also supports JTAG boundary scan (see [CHAPTER 15, TEST FEATURES](#)). During initialization, the processor performs an internal functional self test and external bus self test. These features are useful for system diagnostics to ensure basic CPU and system bus functionality.

The processor is designed to minimize the requirements of its external system. It requires an input clock (CLKIN) and clean power and ground connections ( $V_{SS}$  and  $V_{CC}$ ). Since the processor can operate at a high frequency, the external system must be designed with considerations to reduce induced noise on signals, power and ground.

12.2 INITIALIZATION

Initialization describes the mechanism that the processor uses to establish its initial state and begin instruction execution. Initialization begins when the RESET pin is deasserted. At this time, the processor automatically configures itself with information specified in the IMI and performs its built-in self test based on the sampling of the STEST pin. The processor then branches to the first instruction of user code. See Figure 12-1 for a flow chart of i960 Jx processor initialization.




Figure 12-1. Processor Initialization Flow



The objective of the initialization sequence is to provide a complete, working initial state when the first user instruction executes. The user's startup code needs only to perform several basic functions to place the processor in a configuration for executing application code.

### 12.2.1 Reset State Operation


The  $\overline{\text{RESET}}$  pin, when asserted (active low), causes the processor to enter the reset state. All external signals go to a defined state (Table 12-2), internal logic is initialized, and certain registers are set to defined values (Table 12-2). When the  $\overline{\text{RESET}}$  pin is deasserted, the processor initializes as described in section 12.5, “Startup Code Example” (pg. 12-23).  $\overline{\text{RESET}}$  is a level-sensitive, asynchronous input. If HOLD is asserted while the processor is in reset, the processor will acknowledge the request. All external pins will assume their usual  $T_H$  (hold state) states while the bus is in the hold state.

The  $\overline{\text{RESET}}$  pin must be asserted when power is applied to the processor. The processor then stabilizes in the reset state. This power-up reset is referred to as *cold reset*. To ensure that all internal logic has stabilized in the reset state, a valid input clock (CLKIN) and  $V_{CC}$  must be present and stable for a specified time before  $\overline{\text{RESET}}$  can be deasserted.

The processor may also be cycled through the reset state after execution has started. This is referred to as *warm reset*. For a warm reset, the  $\overline{\text{RESET}}$  pin must be asserted for a minimum number of clock cycles. If a warm reset is asserted during a bus hold, the processor continues to drive HOLDA until HOLD is deasserted. However, the processor will begin the internal initialization process. Refer to section 1.4, “Related Documents” (pg. 1-10). Specifications for a cold and warm reset can be found in these documents.

While the processor's  $\overline{\text{RESET}}$  pin is asserted, output pins are driven to the states as indicated in Table 12-2. The reset state cannot be entered under direct control from user code. No reset instruction — or other condition that forces a reset — exists on the i960 Jx processors. The  $\overline{\text{RESET}}$  pin must be asserted to enter the reset state. The processor does, however, provide a means to re-enter the initialization process. See section 12.4.1, “Reinitializing and Relocating Data Structures” (pg. 12-22).

Figure 12-2. Cold Reset Waveform



- Notes:**
1. The processor asserts **FAIL** during built-in self-test. If self-test passes, the **FAIL** pin is deasserted. The processor also asserts **FAIL** during the bus confidence test. If the bus confidence test passes, **FAIL** is deasserted and the processor begins user program execution.
  2. If the processor fails built-in self-test, it will initiate one dummy load bus access. The load address will indicate the point of self-test failure.
  3. Since the bus is idle, hold requests will be honored during reset and built-in self-test.

F\_XL028A

Table 12-1. Reset States

Pins	Reset State	Pins	Reset State
AD31:0	Floating	W/R	Low (read)
ALE	Low (inactive)	DT/R	Low (receive)
ALE	High (inactive)	DN	High (inactive)
ADS	High (inactive)	BLAST	High (inactive)
A3:2	Floating	LOCK/ ONCE	High (inactive)
BE3:0	High (inactive)	HOLDA	Valid Output
WIDTH/HLTD1:0	Floating	FAIL	Low (Active)
D/C	Floating	TDO	Valid Output

Table 12-2. Register Values After Reset (Sheet 1 of 2)

Register	Value After Cold Reset	Value After Software Re-Init
AC	AC initial image in PRCB	AC initial image in PRCB
PC	001F2002H	001F2002H
TC	initial image in Control Table, offset 68H	initial image in Control Table, offset 68H
FP (g15)	interrupt stack base & (~0xF)	interrupt stack base & (~0xF)
PFP (r0)	undefined	undefined
SP (r1)	FP+64	FP+64
RIP (r2)	undefined	undefined
IPND	undefined	value before software re-init
IMSK	00H	value before software re-init
LMAR0-1	undefined	value before software re-init
LMMR0-1	bit 0 = 0; bits 1 -31 = undefined	bit 0 = 0, bits 1-31 = undefined
DLMCON	bit 0 = bit 7 of byte at FEFF FF3CH bit 1 = 0; bits 2 -31 = undefined	bit 0 = value before software re-init, bit 1 = 0, bits 2-31 = undefined
TRR0-1	undefined	value before software re-init
TCR0-1	undefined	value before software re-init
TMR0-1	bits 1-5 = 0; bits 0, 6-31 = undefined	bits 1-5 = 0; bits 0, 6-31 = undefined
IPB0	0000.0000H	0000.0000H
IPB1	0000.0000H	0000.0000H
DAB0	0000.0000H	0000.0000H
DAB1	0000.0000H	0000.0000H

Table 12-2. Register Values After Reset (Sheet 2 of 2)

Register	Value After Cold Reset	Value After Software Re-Init
IMAP0	initial image in Control Table, offset 10H	initial image in Control Table, offset 10H
IMAP1	initial image in Control Table, offset 14H	initial image in Control Table, offset 14H
IMAP2	initial image in Control Table, offset 18H	initial image in Control Table, offset 18H
ICON	initial image in Control Table, offset 1CH	initial image in Control Table, offset 1CH
PMCON0_1	initial image in Control Table, offset 20H	initial image in Control Table, offset 20H
PMCON2_3	initial image in Control Table, offset 28H	initial image in Control Table, offset 28H
PMCON4_5	initial image in Control Table, offset 30H	initial image in Control Table, offset 30H
PMCON6_7	initial image in Control Table, offset 38H	initial image in Control Table, offset 38H
PMCON8_9	initial image in Control Table, offset 40H	initial image in Control Table, offset 40H
PMCON10_11	initial image in Control Table, offset 48H	initial image in Control Table, offset 48H
PMCON12_13	initial image in Control Table, offset 50H	initial image in Control Table, offset 50H
PMCON14_15	initial image in Control Table, offset 58H	initial image in Control Table, offset 58H
BPCON	0000 0000H	set to 0
BCON	initial image in Control Table, offset 6CH	initial image in Control Table, offset 6CH
DEVICEID	initialized by reset process	initialized by reset process

### 12.2.2 Self Test Function (STEST, $\overline{\text{FAIL}}$ )

As part of initialization, the i960 Jx processor executes a bus confidence self test, an alignment check for data structures within the initial memory image (IMI), and optionally, an built-in self test program. The self test (STEST) pin enables or disables built-in self test. The  $\overline{\text{FAIL}}$  pin indicates that the self tests passed or failed by asserting  $\overline{\text{FAIL}}$ . During normal operations the  $\overline{\text{FAIL}}$  pin can be asserted if a System Error is detected. The following subsections further describe these pin functions.

Internal self test checks basic functionality of internal data paths, registers and memory arrays on-chip. Internal self test is not intended to be a full validation of processor functionality; it is intended to detect catastrophic internal failures and complement a user's system diagnostics by ensuring a confidence level in the processor before any system diagnostics are executed.





### 12.2.2.1 The STEST Pin

The STEST pin enables and disables Built-In Self Test (BIST). BIST can be disabled if the initialization time needs to be minimized or if diagnostics are simply not necessary. The STEST pin is sampled on the rising edge of the  $\overline{\text{RESET}}$  input:

- If STEST is asserted (high), the processor executes the built-in self test.
- If STEST is deasserted, the processor bypasses built-in self test.

### 12.2.2.2 External Bus Confidence Test

The external bus confidence test is always performed regardless of STEST pin value.

The external bus confidence test checks external bus functionality; it reads eight words from the Initialization Boot Record (IBR) and performs a checksum on the words and the constant FFFF FFFFH. The test passes only when the processor calculates a sum of zero (0). The external bus confidence test can detect catastrophic bus failures such as external address, data or control lines that are stuck, shorted or open.

### 12.2.2.3 The Fail Pin ( $\overline{\text{FAIL}}$ )

The  $\overline{\text{FAIL}}$  pin signals errors in either the built-in self test or bus confidence self test.  $\overline{\text{FAIL}}$  is asserted (low) for each self test (Figure 12-3):

- When any test fails, the  $\overline{\text{FAIL}}$  pin remains asserted, a fail code message is driven onto the address bus, and the processor stops execution at the point of failure.
- When a system error occurs,  $\overline{\text{FAIL}}$  is also asserted. See section 12.2.2.4, “IMI Alignment Check and System Error” (pg. 12-8) for details.
- When the test passes,  $\overline{\text{FAIL}}$  is deasserted.

If  $\overline{\text{FAIL}}$  stays asserted, the only way to resume normal operation is to perform a reset operation. When the STEST pin is used to disable the built-in self test, the test does not execute; however,  $\overline{\text{FAIL}}$  still asserts at the point where the built-in self test would occur.  $\overline{\text{FAIL}}$  is deasserted after the bus confidence test passes. In Figure 12-3, all transitions on the  $\overline{\text{FAIL}}$  pin are relative to CLKIN. Refer to section 1.4, “Related Documents” (pg. 1-10). Further timing information can be found in these documents.




Figure 12-3. FAIL Sequence

12.2.2.4 IMI Alignment Check and System Error

The alignment check during initialization for data structures within the IMI ensures that the PRCB, control table, interrupt table, system-procedure table, and fault table are aligned to word boundaries. Normal processor operation is not possible without the alignment of these key data structures. The alignment check is one case where a System Error could occur.

The other case of System Error can occur during regular operation when generation of an override fault incurs a fault. The sequence of events leading up to this case is quite uncommon.

When a System Error is detected, the FAIL pin is asserted, a fail code message is driven onto the address bus, and the processor stops execution at the point of failure. The only way to resume normal operation of the processor is to perform a reset operation. Because System Error generation can occur sometime after the BUS confidence test and even after initialization during normal processor operation, the FAIL pin will be at a logic one before the detection of a System Error.

12.2.2.5 FAIL Code

The processor uses only one read bus transaction to signal the fail code message; the address of the bus transaction is the fail code itself. The fail code is of the form: **0xfeffffnn**; bits 6 to 0 contain a mask recording the possible failures. Bit 7, when one, indicates the mask contains failures from Built-In Self-Test (BIST); when zero, the mask indicates other failures. The fail codes are shown in [Table 12-3](#) and [Table 12-4](#).



**Table 12-3. Fail Codes For BIST (bit 7 = 1)**

Bit	When set:
6	On-chip Data-RAM failure detected by BIST
5	Internal Microcode ROM failure detected by BIST
4	I-cache failure detected by BIST
3	D-cache failure detected by BIST
2	Local-register cache or processor core (RF, EU, MDU, PSQ) failure detected by BIST
1	Always Zero.
0	Always Zero.

**Table 12-4. Remaining Fail Codes (bit 7 = 0)**

Bit	When set:
6	Always One; this bit does not indicate a failure.
5	Always One; this bit does not indicate a failure.
4	A data structure within the IMI is not aligned to a word boundary.
3	A System Error during normal operation has occurred.
2	The Bus Confidence test has failed.
1	Always Zero.
0	Always Zero.

### 12.3 Architecturally Reserved Memory Space

The i960 Jx microprocessor contains  $2^{32}$  bytes of address space. Portions of this address space are architecturally reserved and must not be used. [Section 3.5, "MEMORY ADDRESS SPACE" \(pg. 3-13\)](#) shows the reserved address space. The i960 Jx suppresses all external bus cycles from 0 to 3FFH and from FF00 0000H to FFFF FFFFH.

Addresses FEFF FF60H through FFFF FFFFH are reserved for implementation-specific functions. This address range is termed "reserved" since i960 architecture implementations may use these addresses for functions such as memory-mapped registers or data structures. Therefore, to ensure complete object level compatibility, portable code must not access or depend on values in this region.



## INITIALIZATION AND SYSTEM REQUIREMENTS

The i960 Jx microprocessor uses the reserved address range 0000 0000H through 0000 03FFH for internal data RAM. This internal data RAM is used for storage of interrupt vectors plus general purpose storage available for application software variable allocation or data structures. Loads and stores directed to these addresses access internal memory; instruction fetches from these addresses are not allowed for the i960 Jx microprocessor. See [CHAPTER 4, CACHE AND ON-CHIP DATA RAM](#), for more details.

### 12.3.1 Initial Memory Image (IMI)

The IMI comprises the minimum set of data structures that the processor needs to initialize its system. As shown in [Figure 12-4](#), these structures are: the initialization boot record (IBR), process control block (PRCB) and system data structures. The IBR is located at a fixed address in memory. The other components are referenced directly or indirectly by pointers in the IBR and the PRCB.

The IMI performs three functions for the processor:

- Provides initial configuration information for the core and integrated peripherals.
- Provides pointers to the system data structures and the first instruction to be executed after processor initialization.
- Provides checksum words that the processor uses in its self test routine at startup.

Several data structures are typically included as part of the IMI because values in these data structures are accessed by the processor during initialization. These data structures are usually programmed in the systems's boot ROM, located in memory region 14\_15 of the address space. The required data structures are:

- PRCB
- IBR
- System procedure table
- Control table
- Interrupt table
- Fault table

To ensure proper processor operation, the PRCB, system procedure table, control table, interrupt table, and fault table must not be located in architecturally reserved memory -- addresses reserved for on-chip Data RAM and addresses at and above FEFB FF60H. In addition, each of these structures must start at a word-aligned address; a System Error occurs if any of these structures are not word-aligned (see [section 12.2.2.3](#)).





At initialization, the processor loads the Supervisor Stack Pointer (SSP) from the system procedure table, aligns it to a 16-byte boundary, and caches the pointer in the SSP memory-mapped control register (see [section 3.3, “MEMORY-MAPPED CONTROL REGISTERS”](#) (pg. 3-6)). The supervisor stack pointer is located in the preamble of the system procedure table at byte offset 12 from the base address. The system procedure table base address is programmed in the PRCB. See [section 7.5.1, “System Procedure Table”](#) (pg. 7-15) for the format of the system procedure table.

At initialization, the NMI vector is loaded from the interrupt table and saved at location 0000 0000H of the internal data RAM. The interrupt table is typically programmed in the boot ROM and then relocated to internal RAM by reinitializing the processor.

The fault table is typically located in boot ROM. If it is necessary to locate the fault table in RAM, the processor must be reinitialized.

The remaining data structures that an application may need are the user stack, supervisor stack and interrupt stack. These stacks must be located in a system’s RAM.

At initialization, the processor loads the interrupt stack pointer in the ISP memory-mapped register. It then zeroes-out the low order four bits of the ISP, to align it to a 16 byte boundary, and places it in the FP. To ensure correct operation, the value needed for ISP from the PRCB must be quad-word aligned.




Figure 12-4. Initial Memory Image (IMI) and Process Control Block (PRCB)



12.3.1.1 Initialization Boot Record (IBR)

The initialization boot record (IBR) is the primary data structure required to initialize the i960 Jx processor. The IBR is a 12-word structure which must be located at address FEFF FF30H (see [Table 12-5](#)). The IBR is made up of four components: the initial bus configuration data, the first instruction pointer, the PRCB pointer and the bus confidence test checksum data.

Table 12-5. Initialization Boot Record

Byte Physical Address	Description
FEFF FF30H	PMCON14_15, byte 0
FEFF FF31 to FEFF FF33	<i>Reserved</i>
FEFF FF34H	PMCON14_15, byte 1
FEFF FF35 to FEFF FF37	<i>Reserved</i>
FEFF FF38H	PMCON14_15, byte 2
FEFF FF39 to FEFF FF3B	<i>Reserved</i>
FEFF FF3CH	PMCON14_15, byte 3
FEFF FF3D to FEFF FF3F	<i>Reserved</i>
FEFF FF40 to FEFF FF43	First Instruction Pointer
FEFF FF44 to FEFF FF47	PRCB Pointer
FEFF FF48 to FEFF FF4B	Bus Confidence Self-Test Check Word 0
FEFF FF4C to FEFF FF4F	Bus Confidence Self-Test Check Word 1
FEFF FF50 to FEFF FF53	Bus Confidence Self-Test Check Word 2
FEFF FF54 to FEFF FF57	Bus Confidence Self-Test Check Word 3
FEFF FF58 to FEFF FF5B	Bus Confidence Self-Test Check Word 4
FEFF FF5C to FEFF FF5F	Bus Confidence Self-Test Check Word 5

When the processor reads the IMI during initialization, it must know the bus characteristics of external memory where the IMI is located. Specifically, it must know the bus width and endianness for the remainder of the IMI. At initialization, the processor sets the PMCON register to an 8-bit bus width. The processor then needs to form the initial DLMCON and PMCON14\_15 registers so that the memory containing the IBR can be accessed correctly. The lowest-order byte of each of the IBR's first 4 words are used to form the register values. On the i960 Jx processor, the bytes at FEFF FF30 and FEFF FF34 are not needed, so the processor starts fetching at address FEFF FF38. The loading of these registers is shown in the pseudo-code flow in [Example 12-1](#).



### Example 12-1. Processor Initialization Flow

```

Processor_Initialization_flow()
{
    FAIL_pin = true;
    restore_full_cache_mode; disable(I_cache); invalidate(I_cache);
    disable(D_cache); invalidate(D_cache);
    BCON.ctv = 0; /* Selects PMCON14_15 to control all accesses */
    PMCON14_15 = 0; /* Selects 8-bit bus width */

/** Exit Reset State & Start_Init **/
    if (STEST_ON_RISING_EDGE_OF_RESET)
        status = BIST(); /* BIST does not return if it fails */
    FAIL_pin = false;
    PC = 0x001f2002; /* PC.Priority = 31, PC.em = Supervisor, */
                  /* PC.te = 0; PC.State = Interrupted */
    ibr_ptr = 0xfeffff30; /* ibr_ptr used to fetch IBR words */

/** Read PMCON14_15 image in IBR **/
    FAIL_pin = true;      IMSK      = 0;
    DLMCON.dcen = 0;      LMMR0.lmte = 0;  LMMR1.lmte = 0;
    PMCON14_15[byte2] = 0xc0 & memory[ibr_ptr + 8];
    DLMCON.be = (memory[ibr_ptr + 0xc] >> 7);

/** Compute CheckSum on Boot Record **/
    carry = 0; CheckSum = 0xffffffff;
    for (i=0; i<8; i++) /* carry is carry out from previous add*/
        CheckSum = memory[ibr_ptr + 16 + i*4] + CheckSum + carry;
    if (CheckSum != 0)
        { fail_msg = 0xfeffff64; /* Fail BUS Confidence Test */
          dummy = memory[fail_msg]; /* Do load with address = fail_msg */
          for (;;) ;
        }
    else FAIL_pin = false; /* loop forever with FAIL pin true */

/** Process PRCB **/
    prcb_ptr = memory[ibr_ptr+0x14];
    Process_PRCB(prcb_ptr); /* See Process PRCB Section for Details */
    IP = memory[ibr_ptr+0x10];
    g0 = DEVICE_ID;
    return; /* Execute First Instruction */
}

```

Bit 31 of the assembled PMCON word loaded from the IBR is written to DLMCON.be to establish the initial endianness of memory; the processor initializes the DLMCON.dcen bit to 0 to disable data caching. The remainder of the assembled word is used to initialize PMCON14\_15. In conjunction with this step, the processor clears the bus control table valid bit (BCON.ctv), to ensure for the remainder of initialization that every bus request issued takes configuration information from the PMCON14\_15 register, regardless of the memory region associated with the request. At a later point in initialization, the processor loads the remainder of the memory region





configuration table from the external control table. The Bus Configuration (BCON) register is also loaded at this time. The control table valid (BCON.ctv) bit is then set in the control table to validate the PMCON registers after they are loaded. In this way, the bus controller is completely configured during initialization. (See [CHAPTER 14, EXTERNAL BUS](#) for a complete discussion of memory regions and configuring the bus controller.)

After the bus configuration data is loaded and the new bus configuration is in place, the processor loads the remainder of the IBR which consists of the first instruction pointer, the PRCB pointer and six checksum words. The PRCB pointer and the first instruction pointer are internally cached. The six checksum words — along with the PRCB pointer and the first instruction pointer — are used in a checksum calculation which implements a confidence test of the external bus. The checksum calculation is shown in the pseudo-code flow in [Example 12-1](#). If the checksum calculation equals zero, then the confidence test of the external bus passes.

[Figure 12-4](#) further describe the IBR organization.




Figure 12-5. PMCON14\_15 Register Bit Description in IBR



## INITIALIZATION AND SYSTEM REQUIREMENTS

### 12.3.1.2 Process Control Block (PRCB)

The PRCB contains base addresses for system data structures and initial configuration information for the core and integrated peripherals. The base addresses are accessed from these internal registers. The registers are accessible to the users through the memory mapped interface. Upon reset or reinitialization, the registers are initialized. The PRCB format is shown in [Table 12-6](#).

**Table 12-6. PRCB Configuration**

Physical Address	Description
PRCB POINTER + 00H	Fault Table Base Address
PRCB POINTER + 04H	Control Table Base Address
PRCB POINTER + 08H	AC Register Initial Image
PRCB POINTER + 0CH	Fault Configuration Word
PRCB POINTER + 10H	Interrupt Table Base Address
PRCB POINTER + 14H	System Procedure Table Base Address
PRCB POINTER + 18H	Reserved
PRCB POINTER + 1CH	Interrupt Stack Pointer
PRCB POINTER + 20H	Instruction Cache Configuration Word
PRCB POINTER + 24H	Register Cache Configuration Word

The initial configuration information is programmed in the arithmetic controls (AC) initial image, the fault configuration word, the instruction cache configuration word, and the register cache configuration word. [Figure 12-6](#) shows these configuration words.






Figure 12-6. Process Control Block Configuration Words

**12.3.2 Process PRCB Flow**

The following pseudo-code flow illustrates the processing of the PRCB. Note that this flow is used for both initialization and reinitialization (through **sysctl**).

**Example 12-2. Process PRCB Flow**

```

Process_PRCB(prcb_ptr)
{
  PRCB_mmr = prcb_ptr;
  reset_state(data_ram); /* It is unpredictable whether the      */
                        /* Data RAM keeps its prior contents */
  fault_table = memory[PRCB_mmr];
  ctrl_table = memory[PRCB_mmr+0x4];
  AC = memory[PRCB_mmr+0x8];
  fault_config = memory[PRCB_mmr+0xc];
  if (1 & (fault_config >> 30)) generate_fault_on_unaligned_access = false;
  else generate_fault_on_unaligned_access = true;

  /** Load Interrupt Table and Cache NMI Vector Entry in Data RAM**/
  Reset_block_NMI;
  interrupt_table = memory[PRCB_mmr+0x10];
  memory[0] = memory[interrupt_table + (248*4) + 4];

  /** Process System Procedure Table **/
  sysproc = memory[PRCB_mmr+0x14];
  temp = memory[sysproc+0xc];
  SSP_mmr = (~0x3) & temp;
  SSP.te = 1 & temp;

  /** Initialize ISP, FP, SP, and PFP **/
  ISP_mmr = memory[PRCB_mmr+0x1c];
  FP = (~0xF) & ISP_mmr;
  SP = FP + 64;
  PFP = FP;

  /** Initialize Instruction Cache **/
  ICCW = memory[PRCB_mmr+0x20];
  if (1 & (ICCW >> 16) ) disable(I_cache);

  /** Configure Local Register Cache **/
  programmed_limit = (7 & (memory[PRCB_mmr+0x24] >> 8) );
  config_reg_cache( programmed_limit );

  /** Load_control_table. **/
  load_control_table(ctrl_table+0x10 , ctrl_table+0x58);
  load_control_table(ctrl_table+0x68 , ctrl_table+0x6c);
  IBP0 = 0x0; IBP1 = 0x0; DAB0 = 0x0; DAB1 = 0x0; BPCON = 0x0

  /** Initialize Timers **/
  TMR0.tc = 0; TMR1.tc = 0; TMR0.enable = 0; TMR1.enable = 0;
  TMR0.sup = 0; TMR1.sup = 0; TMR0.reload = 0; TMR1.reload = 0;
  TMR0.csel = 0; TMR1.csel = 0;
  DLMCON.dcen = 0
  LMMR00.lmte = 0
  LMMR1.lmte = 0
  return;
}

```

### 12.3.2.1 AC Initial Image

The AC initial image is loaded into the on-chip AC register during initialization. The AC initial image allows the initial value of the overflow mask, no imprecise faults bit and condition code bits to be selected at initialization.

The AC initial image condition code bits can be used to specify the source of an initialization or reinitialization when a single instruction entry point to the user startup code is desirable. This is accomplished by programming the condition code in the AC initial image to a different value for each different entry point. The user startup code can detect the condition code values — and thus the source of the reinitialization — by using the compare or compare-and-branch instructions.

### 12.3.2.2 Fault Configuration Word

The fault configuration word allows the operation-unaligned fault to be masked when an unaligned memory request is issued. (See [section 14.2.5, “Data Alignment” \(pg. 14-22\)](#) for a description of unaligned memory requests.) Whenever an unaligned access is encountered, the processor *always* performs the access. After performing the access, the processor determines whether it should generate a fault. If bit 30 in the fault configuration word is set, a fault is not generated after an unaligned memory request is issued. If bit 30 is clear, a fault is generated after an unaligned memory request is performed. An application may elect to generate a fault to detect unwanted unaligned access. Note that unaligned accesses to MMR space are not affected by bit 30, are never performed and always causes an operation.unimplemented fault.

### 12.3.2.3 Instruction Cache Configuration Word

The instruction cache configuration word allows the instruction cache to be enabled or disabled at initialization. If bit 16 in the instruction cache configuration word is set, the instruction cache is disabled and all instruction fetches are directed to external memory. Disabling the instruction cache is useful for tracing execution in a software debug environment. The instruction cache remains disabled until one of three operations is performed:

- The processor is reinitialized with a new value in the instruction cache configuration word
- **icctl** is issued with the enable instruction cache operation
- **sysctl** is issued with the configure instruction cache message type and a cache configuration mode other than disable cache

### 12.3.2.4 Register Cache Configuration Word

The register cache configuration word specifies the number of free frames in the local register cache that can be used by non-critical code — code that is either in the executing state (non-interrupted) or code which is in the interrupted state, but, has a process priority less than 28 — must reserve for critical code (interrupted state and process priority greater than or equal to 28).

The register cache and the configuration word are explained further in [section 4.2, “LOCAL REGISTER CACHE”](#) (pg. 4-2).

### 12.3.3 Control Table

The control table is the data structure that contains the on-chip control registers values. It is automatically loaded during initialization and must be completely constructed in the IMI. [Figure 12-7](#) shows the Control Table format.

For register bit definitions of the on-chip control table registers, see the following:

- IMAP — [Section 11.7.5, “Interrupt Mapping Registers \(IMAP0-IMAP2\)”](#) (pg. 11-23)
- ICON — [Section 11.7.4, “Interrupt Control Register \(ICON\)”](#) (pg. 11-22)
- PMCON — [Section 13.5.3, “Modifying the PMCON Registers”](#) (pg. 13-7)
- TC — [Section 9.1.1, “Trace Controls \(TC\) Register”](#) (pg. 9-2)
- BCON — [Section 13.4.1, “Bus Control \(BCON\) Register”](#) (pg. 13-6)

31		0
	Reserved (Initialize to 0)	00H
	Reserved (Initialize to 0)	04H
	Reserved (Initialize to 0)	08H
	Reserved (Initialize to 0)	0CH
	Interrupt Map 0 (IMAP0)	10H
	Interrupt Map 1 (IMAP1)	14H
	Interrupt Map 2 (IMAP2)	18H
	Interrupt Configuration (ICON)	1CH
	Physical Memory Region 0:1 Configuration (PMCON0_1)	20H
	Reserved (Initialize to 0)	24H
	Physical Memory Region 2:3 Configuration (PMCON2_3)	28H
	Reserved (Initialize to 0)	2CH
	Physical Memory Region 4:5 Configuration (PMCON4_5)	30H
	Reserved (Initialize to 0)	34H
	Physical Memory Region 6:7 Configuration (PMCON6_7)	38H
	Reserved (Initialize to 0)	3CH
	Physical Memory Region 8:9 Configuration (PMCON8_9)	40H
	Reserved (Initialize to 0)	44H
	Physical Memory Region 10:11 Configuration (PMCON10_11)	48H
	Reserved (Initialize to 0)	4CH
	Physical Memory Region 12:13 Configuration (PMCON12_13)	50H
	Reserved (Initialize to 0)	54H
	Physical Memory Region 14:15 Configuration (PMCON14_15)	58H
	Reserved (Initialize to 0)	5CH
	Reserved (Initialize to 0)	60H
	Reserved (Initialize to 0)	64H
	Trace Controls (TC)	68H
	Bus Configuration Control (BCON)	6CH

Figure 12-7. Control Table

12.4 DEVICE IDENTIFICATION ON RESET

A number characterizing the microprocessor type and stepping is programmed during manufacture into the DEVICEID memory-mapped register. During initialization, the value is also placed in g0.




Figure 12-8. IEEE 1149.1 Device Identification Register

The value for device identification is compliant with the IEEE 1149.1 specification and Intel standards. For specific DEVICEID, refer to the appropriate data sheet. Refer to [section 1.4, “Related Documents”](#) (pg. 1-10). Specific information on DEVICEIDs can be found in these documents.

12.4.1 Reinitializing and Relocating Data Structures

Reinitialization can reconfigure the processor and change pointers to data structures. The processor is reinitialized by issuing the **sysctl** instruction with the reinitialize processor message type. (See [section 6.2.67, “sysctl”](#) (pg. 6-114) for a description of **sysctl**.) The reinitialization instruction pointer and a new PRCB pointer are specified as operands to the **sysctl** instruction. When the processor is reinitialized, the fields in the newly specified PRCB are loaded as described in [section 12.3.1.2, “Process Control Block \(PRCB\)”](#) (pg. 12-16).

Reinitialization is useful for relocating data structures to RAM after initialization. The interrupt table must be located in RAM: to post software-generated interrupts, the processor writes to the pending priorities and pending interrupts fields in this table. It may also be necessary to relocate the control table to RAM: it must be in RAM if the control register values are to be changed by user code. In some systems, it is necessary to relocate other data structures (fault table and system procedure table) to RAM because of unsatisfactory load performance from ROM.





After initialization, the software is responsible for copying data structures from ROM into RAM. The processor is then reinitialized with a new PRCB which contains the base addresses of the new data structures in RAM.

Reinitialization is required to relocate any of the data structures listed below, since the processor caches the pointers to the structures.

The processor caches the following pointers during its initialization. To modify these data structures, a software re-initialization is needed.

- Interrupt Table Address
- Fault Table Address
- System Procedure Table Address
- Control Table Address

### 12.5 Startup Code Example

After initialization is complete, user start-up code typically copies initialized data structures from ROM to RAM, reinitializes the processor, sets up the first stack frame, changes the execution state to non-interrupted and calls the `_main` routine. This section presents an example start-up routine and associated header file. This simplified start-up file can be used as a basis for more complete initialization routines.

The examples in this section are useful for creating and evaluating startup code. The following lists the example's number, name and page.

- [Example 12-3. Initialization Header File \(init.h\) \(pg. 12-24\)](#)
- [Example 12-4., Startup Routine \(init.s\) \(pg. 12-25\)](#)
- [Example 12-5., High-Level Startup Code \(initmain.c\) \(pg. 12-28\)](#)
- [Example 12-6., Control Table \(ctltbl.c\) \(pg. 12-29\)](#)
- [Example 12-7., Initialization Boot Record File \(rom\\_ibr.c\) \(pg. 12-30\)](#)
- [Example 12-8., Linker Directive File \(init.ld\) \(pg. 12-31\)](#)
- [Example 12-9., Makefile \(pg. 12-33\)](#)

Example 12-3. Initialization Header File (init.h)

```
/*-----*/
/*  init.h                                     */
/*-----*/

#define BYTE_N(n,data)  (((unsigned)(data) >> (n*8)) & 0xFF)

typedef struct
{
    unsigned char bus_byte_0;
    unsigned char reserved_0[3];
    unsigned char bus_byte_1;
    unsigned char reserved_1[3];
    unsigned char bus_byte_2;
    unsigned char reserved_2[3];
    unsigned char bus_byte_3;
    unsigned char reserved_3[3];
    void      (*first_inst)();
    unsigned *prcb_ptr;
    int      check_sum[6];
}IBR;

/* PMCON Bus Width can be 8,16 or 32, default to 8
 * PMCON14_15 BOOT_BIG_ENDIAN  0=little endian, 1=big endian
 */
#define BUS_WIDTH(bw)  ((bw==16)?(1<<22):(0)) | ((bw==32)?(2<<22):(0))
#define BOOT_BIG_ENDIAN (on)  ((on)?(1<<31:0))

/* Bus configuration */
#define DEFAULT  (BUS_WIDTH(8) | BOOT_BIG_ENDIAN(0))
#define I_O      (BUS_WIDTH(8) | BOOT_BIG_ENDIAN(0))
#define DRAM     (BUS_WIDTH(32) | BOOT_BIG_ENDIAN(0))
#define ROM      (BUS_WIDTH(8) | BOOT_BIG_ENDIAN(0))
```



Example 12-4. Startup Routine (init.s) (Sheet 1 of 4)

```

/*-----*/
/*  init.s                                     */
/*-----*/

/* initial PRCB */

    .globl  _rom_prcb
    .align 4 /* or .align 2 */
_rom_prcb:
    .word  boot_flt_table      # 0 - Fault Table
    .word  _boot_control_table # 4 - Control Table
    .word  0x00001000          # 8 - AC reg mask overflow fault
    .word  0x40000000          # 12 - Flt CFG
    .word  boot_intr_table     # 16 - Interrupt Table
    .word  rom_sys_proc_table  # 20 - System Procedure Table
    .word  0                    # 24 - Reserved
    .word  _intr_stack         # 28 - Interrupt Stack Pointer
    .word  0x00000000          # 32 - Inst. Cache - enable cache
    .word  0x00001200          # 36 - Register Cache Configuration

/* ROM system procedure table */

    .equ   supervisor_proc, 2
    .text
    .align 6 /* or .align 2 or .align 4 */
rom_sys_proc_table:
    .space 12                # Reserved
    .word  _supervisor_stack  # Supervisor stack pointer
    .space 32                # Preserved
    .word  _default_sysproc   # sysproc 0
    .word  _default_sysproc   # sysproc 1
    .word  _default_sysproc   # sysproc 2
    .word  _default_sysproc   # sysproc 3
    .word  _default_sysproc   # sysproc 4
    .word  _default_sysproc   # sysproc 5
    .word  _default_sysproc   # sysproc 6
    .word  _fault_handler + supervisor_proc # sysproc 7
    .word  _default_sysproc   # sysproc 8
    .space 251*4             # sysproc 9-259

/* Fault Table */

    .equ   syscall, 2
    .equ   fault_proc, 7
    .text
    .align 4
boot_flt_table:
    .word  (fault_proc<<2) + syscall # 0-Parallel Fault
    .word  0x27f
    .word  (fault_proc<<2) + syscall # 1-Trace Fault
    .word  0x27f
    .word  (fault_proc<<2) + syscall # 2-Operation Fault
    .word  0x27f

```

**Example 12-4. Startup Routine (init.s) (Sheet 2 of 4)**

```

.word    (fault_proc<<2) + syscall    # 3-Arithmetic Fault
.word    0x27f
.word    0                             # 4-Reserved
.word    0
.word    (fault_proc<<2) + syscall    # 5-Constraint Fault
.word    0x27f
.word    0                             # 6-Reserved
.word    0
.word    (fault_proc<<2) + syscall    # 7-Protection Fault
.word    0x27f
.word    0                             # 8-Reserved
.word    0
.word    0                             # 9-Reserved
.word    0
.word    (fault_proc<<2) + syscall    # 0xa-Type Fault
.word    0x27f
.space   21*8                          # reserved
/* Boot Interrupt Table */

.text
boot_intr_table:
.word    0                             # Pending Priorities
.word    0, 0, 0, 0, 0, 0, 0, 0, 0    # Pending Interrupts          Vectors
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 8
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 10
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 18
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 20
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 28
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 30
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 38
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 40
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 48
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 50
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 58
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 60
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 68
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 70
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 78
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 80
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 88
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 90
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # 98
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # a0
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # a8
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # b0
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # b8
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # c0
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # c8
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # d0
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # d8
.word    _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # e0

```



Example 12-4. Startup Routine (init.s) (Sheet 3 of 4)

```

.word   _intx, _intx, _intx, _intx, _intx, _intx, _intx, _intx # e8
.word   _intx, _intx, _intx, _intx,    0,    0,    0,    0 # f0
.word   _nmi,   0,    0,    0, _intx, _intx, _intx, _intx # f8

/* START */
/* Processor starts execution here after reset. */
.text
.globl  _start_ip
.globl  _reinit
_start_ip:
    mov     0, g14          /* g14 must be 0 for ic960 C compiler */
/* MON960 requires copying the .data area into RAM. If a user application
* does not require this it is not necessary.
* Copy the .data into RAM. The .data has been packed in the ROM after the
* code area. If the copy is not needed (RAM-based monitor), the symbol
* rom_data can be defined as 0 in the linker directives file.
*/
    lda     rom_data, g1          # load source of copy
    cmpobe  0, g1, 1f
    lda     __Bdata, g2          # load destination
    lda     __Edata, g3
init_data:
    ldq     (g1), r4
    addo   16, g1, g1
    stq    r4, (g2)
    addo   16, g2, g2
    cmpobl g2, g3, init_data
1:
/* Initialize the BSS area of RAM. */
    lda     __Bbss, g2          # start of bss
    lda     __Ebss, g3          # end of bss
    movq   0, r4
bss_fill:
    stq    r4, (g2)
    addo   16, g2, g2
    cmpobl g2, g3, bss_fill

_reinit:
    ldconst 0x300, r4          # reinitialize sys control
    lda     1f, r5
    lda     _ram_prpcb, r6
    sysctl  r4, r5, r6
1:
    lda     _user_stack, pfp
    lda     64(pfp), sp
    mov    pfpf, fp          /* new pfp */
    flushreg

    ldconst 0x001f2403, r3      /* PC mask */
    ldconst 0x000f0003, r4      /* PC value */
    modpc  r3, r3, r4          /* Lower interrupt priority */

```



**Example 12-4. Startup Routine (init.s) (Sheet 4 of 4)**

```
/* Clear the IPND register */
    lda    0xff008500, g0
    mov    0, g1
    st     g1, (g0)
    callx  _main                #to main routine

    .globl _intr_stack
    .globl _user_stack
    .globl _supervisor_stack
    .bss   _user_stack, 0x0200, 6      # default application stack
    .bss   _intr_stack, 0x0200, 6     # interrupt stack
    .bss   _supervisor_stack, 0x0600, 6 # fault (supervisor) stack

    .text
_fault_handler:
    ldconst 'F', g0
    call   _co
    ret

_default_sysproc:
    ret

_intx:
    ldconst 'I', g0
    call   _co
    ret
```

**Example 12-5. High-Level Startup Code (initmain.c)**

```
unsigned componentid = 0;

main()
{
    /* system- or board-specific code goes here */
}
/* this code is called by init.s */

co()
{
    /* system or board-specific output routine goes here */
}
```



Example 12-6. Control Table (ctltbl.c)

```

/*-----*/
/*  ctbl.c                                     */
/*-----*/
#include "init.h"

typedef struct
{
    unsigned control_reg[28];
}CONTROL_TABLE;
const CONTROL_TABLE boot_control_table = {
    /* Reserved */
    0, 0, 0, 0,
    /* Interrupt Map Registers */
    0, 0, 0, /* Interrupt Map Regs (set by code as needed) */
    0x43bc, /* ICON
            *
            * - dedicated mode,
            * - enabled
            * system_init 0 - falling edge activated,
            * system_init 1 - falling edge activated,
            * system_init 2 - falling edge activated,
            * system_init 3 - falling edge activated,
            * system_init 4 - level-low activated,
            * system_init 5 - falling edge activated,
            * system_init 6 - falling edge activated,
            * system_init 7 - falling edge activated,
            *
            * - mask unchanged,
            * - not cached,
            *
            * - fast,
            */

    /* Physical Memory Configuration Registers */

    DEFAULT, 0, /* Region 0_1 */
    DEFAULT, 0, /* Region 2_3 */
    DEFAULT, 0, /* Region 4_5 */
    I_O, 0, /* Region 6_7 */
    DEFAULT, 0, /* Region 8_9 */
    DEFAULT, 0, /* Region 10_11 */
    DRAM, 0, /* Region 12_13 */
    ROM, 0, /* Region 14_15 */

    /* Bus Control Register */
    0, /* Reserved */
    0, /* Reserved */
    1 /* BCON Register (Region config. valid)
    */
};

```

**Example 12-7. Initialization Boot Record File (rom\_ibr.c) (Sheet 1 of 2)**

```
#include "init.h"

/*
 * NOTE: The ibr must be located at 0xFEFFFF30. Use the linker to
 * locate this structure.
 *
 * The boot configuration is always region 14_15, since the IBR
 * must be located there
 */

extern void start_ip();
extern unsigned rom_prCB;
extern unsigned checksum;

#define CS_6 (int) &checksum /* value calculated in linker */
#define BOOT_CONFIG ROM

const IBR init_boot_record =
{
    BYTE_N(0,BOOT_CONFIG), /* PMCON14_15 byte 1 */
    0,0,0, /* reserved set to 0 */
    BYTE_N(1,BOOT_CONFIG), /* PMCON14_15 byte 2 */
    0,0,0, /* reserved set to 0 */
    BYTE_N(2,BOOT_CONFIG), /* PMCON14_15 byte 3 */
    0,0,0, /* reserved set to 0 */
}
```





**Example 12-7. Initialization Boot Record File (rom\_ibr.c) (Sheet 2 of 2)**

```
BYTE_N(3,BOOT_CONFIG),      /* PMCON14_15 byte 4 */
    0,0,0,                  /* reserved set to 0 */
    start_ip,
    &rom_prcb,
    -2,
    0,
    0,
    0,
    0,
    0,
    CS_6
};
```

**Example 12-8. Linker Directive File (init.ld) (Sheet 1 of 2)**

```
/*-----*/
/*  init.ld                                */
/*-----*/

MEMORY
{
    /*
     * Enough space must be reserved in ROM after the text
     * section to hold the initial values of the data section.
     */
    rom:      o=0xfefe0000,l=0x1fc00
    rom_dat:  o=0xfeffc00,l=0x0300    /* placeholder for .data image */

    ibr:      o=0xfefff30,l=0x0030
    data:     o=0xa0000000,l=0x0300
    bss:      o=0xa0000300,l=0x7d00
}
```

## Example 12-8. Linker Directive File (init.ld) (Sheet 2 of 2)

```
SECTIONS
{
    .ibr :
    {
        rom_ibr.o
    } > ibr

    .text :
    {
    } > rom

    .data :
    {
    } > data

    .bss :
    {
    } > data
}

rom_data = __Etext;          /* used in init.s as source of .data
                             section initial values. ROM960
                             "move" command places the .data
                             section right after the .text section */

_checksum = -(_rom_prcb + _start_ip);

HLL()

/*Rommer script embedded here: the following creates a ROM image
**move $0 .text 0
**move $0
**move $0 .ibr 0x1ff30
**mkimage $0 $0.ima
**ihex $0.ima $0.hex mode16
**map $0
**quit
**/
```



## Example 12-9. Makefile

```
/*-----*/
/*  makefile                                */
/*-----*/

LDFILE = init
FINALOBJ = init
OBJS = init.o ctltbl.o initmain.o
IBR = rom_ibr.o
LDFLAGS = -AJF -Fcoff -T$(LDFILE) -m
ASFLAGS = -AJF -V
CCFLAGS = -AJF -Fcoff -V -c

init.ima: $(FINALOBJ)
    rom960 $(LDFILE) $(FINALOBJ)

init: $(OBJS) $(IBR)
    gld960 $(LDFLAGS) -o $< $(OBJS)

.s.o:
    gas960c $(ASFLAGS) $<

.c.o:
    gcc960 $(CCFLAGS) $<
```

## 12.6 SYSTEM REQUIREMENTS

The following sections discuss generic hardware requirements for a system built around the i960 Jx processor. This section describes electrical characteristics of the processor's interface to the external circuit. The CLKIN, RESET, STEST, FAIL, ONCE, V<sub>SS</sub> and V<sub>CC</sub> pins are described in detail. Specific signal functions for the external bus signals and interrupt inputs are discussed in their respective sections in this manual.

### 12.6.1 Input Clock (CLKIN)

The clock input (CLKIN) determines processor execution rate and timing. It is designed to be driven by most common TTL crystal clock oscillators. The clock input must be free of noise and conform with the specifications listed in the data sheet. CLKIN input capacitance is minimal; for this reason, it may be necessary to terminate the CLKIN circuit board trace at the processor to reduce overshoot and undershoot.

### 12.6.2 Power and Ground Requirements (V<sub>CC</sub>, V<sub>SS</sub>)

The large number of V<sub>SS</sub> and V<sub>CC</sub> pins effectively reduces the impedance of power and ground connections to the chip and reduces transient noise induced by current surges. The i960 Jx processor is implemented in CHMOS IV technology. Unlike NMOS processes, power dissipation in the CHMOS process is due to capacitive charging and discharging on-chip and in the processor's output buffers; there is almost no DC power component. The nature of this power consumption results in current surges when capacitors charge and discharge. The processor's power consumption depends mostly on frequency. It also depends on voltage and capacitive bus load (see appropriate data sheet listed below).

To reduce clock skew on the i960 Jx processor, the V<sub>CCPLL</sub> pin for the Phase Lock Loop (PLL) circuit is isolated on the pinout. A lowpass filter reduces noise induced clock jitter and its effects on timing relationships in system designs. Refer to [section 1.4, "Related Documents"](#) (pg. 1-10). These documents contain specific circuit examples for the V<sub>CCPLL</sub> pin.




### 12.6.3 V<sub>CC5</sub> Pin Requirements

In 3.3 V-only systems and systems that drive the i960 Jx processor pins from 3.3 V logic, connect the V<sub>CC5</sub> pin directly to the 3.3 V V<sub>CC</sub> plane.

In mixed voltage systems that drive the i960 Jx Processor inputs in excess of 3.3 V, the V<sub>CC5</sub> pin must be connected to the system’s 5 V supply. To limit current flow into the V<sub>CC5</sub> pin, there is a limit to the voltage differential between the V<sub>CC5</sub> pin and other V<sub>CC</sub> pins. The voltage differential (V<sub>DIFF</sub>) between the 80960Jx V<sub>CC5</sub> pin and its 3.3 V V<sub>CC</sub> pins should never exceed 2.25 V. This limit applies to power up, power down and steady-state operation. Refer to [section 1.4, “Related Documents”](#) (pg. 1-10). Further information can be found for the V<sub>CC5</sub> pin requirements in these documents.

If the voltage difference requirements cannot be meet due to system design limitations, an alternate solution may be employed. As shown in Figure, a minimum of a 100Ω series resistor may be used to limit the current into the V<sub>CC5</sub> pin. This resistor ensures that current drawn by the V<sub>CC5</sub> pin does not exceed the maximum rating for this pin.



**Figure 12-9. V<sub>CC5</sub> Current-Limiting Resistor**

This resistor is not necessary in systems that can guarantee the V<sub>DIFF</sub> specification.

### 12.6.4 Power and Ground Planes

Power and ground planes are recommended to be used in i960 Jx processor systems to minimize noise. Justification for these power and ground planes is the same as for multiple V<sub>SS</sub> and V<sub>CC</sub> pins. Power and ground lines have inherent inductance and capacitance; therefore, an impedance  $Z=(L/C)^{1/2}$ .

Total characteristic impedance for the power supply can be reduced by adding more lines. This effect is illustrated in [Figure 12-10](#), which shows that two lines in parallel have half the impedance of one. Ideally, a plane — an infinite number of parallel lines — results in the lowest impedance. Fabricate power and ground planes with a 1 oz. copper for outer layers and 0.5 oz. copper for inner layers.

All power and ground pins must be connected to the planes. Ideally, the i960 Jx processor should be located at the center of the board to take full advantage of these planes, simplify layout and reduce noise.






Figure 12-10. Reducing Characteristic Impedance

**12.6.5 Decoupling Capacitors**

Decoupling capacitors placed across the processor between  $V_{CC}$  and  $V_{SS}$  reduce voltage spikes by supplying the extra current needed during switching. Place these capacitors close to the device because connection line inductance negates their effect. Also, for this reason, the capacitors should be low inductance. Chip capacitors (surface mount) exhibit lower inductance.

**12.6.6 I/O Pin Characteristics**

The i960 Jx processor interfaces to its system through its pins. This section describes the general characteristics of the input and output pins.



**12.6.6.1 Output Pins**

All output pins on the i960 Jx processor are three-state outputs. Each output can drive a logic 1 (low impedance to  $V_{CC}$ ); a logic 0 (low impedance to  $V_{SS}$ ); or float (present a high impedance to  $V_{CC}$  and  $V_{SS}$ ). Each pin can drive an appreciable external load. Refer to [section 1.4, “Related Documents”](#) (pg. 1-10). Specific information on drive capability, timing and derating information, to calculate output delays based on pin loading, can be found in these documents.

**12.6.6.2 Input Pins**

All i960 Jx processor inputs are designed to detect TTL thresholds, providing compatibility with the vast amount of available random logic and peripheral devices that use TTL outputs.

Most i960 Jx processor inputs are synchronous inputs ([Table 12-7](#)). A synchronous input pin must have a valid level (TTL logic 0 or 1) when the value is used by internal logic. If the value is not valid, it is possible for a metastable condition to be produced internally resulting in undetermined behavior. Refer to [section 1.4, “Related Documents”](#) (pg. 1-10). Specific information on input valid setup and hold times relatives to CLKIN can be found in the documents.

**Table 12-7. Input Pins**

Synchronous Inputs (sampled by CLKIN)	Asynchronous Inputs (sampled by CLKIN)	Asynchronous Inputs (sampled by RESET)
AD31:0 RDYRCV HOLD TDI TMS	$\overline{\text{RESET}}$ XINT7:0 $\overline{\text{NMI}}$	STEST $\overline{\text{LOCKONCE}}$

i960 Jx processor inputs which are considered asynchronous are internally synchronized to the rising edge of CLKIN. Since they are internally synchronized, the pins only need to be held long enough for proper internal detection. In some cases, it is useful to know if an asynchronous input will be recognized on a particular CLKIN cycle or held off until a following cycle. The i960 Jx microprocessor data sheet provides setup and hold requirements relative to CLKIN which ensure recognition of an asynchronous input. The data sheets also supply hold times required for detection of asynchronous inputs.

The  $\overline{\text{ONCE}}$  and STEST inputs are asynchronous inputs. These signals are sampled and latched on the rising edge of the  $\overline{\text{RESET}}$  input instead of CLKIN.



### 12.6.7 High Frequency Design Considerations

At high signal frequencies and/or with fast edge rates, the transmission line properties of signal paths in a circuit must be considered. Transmission line effects and crosstalk become significant in comparison to the signals. These errors can be transient and therefore difficult to debug. In this section, some high-frequency design issues are discussed; for more information, consult a reference on high-frequency design.

### 12.6.8 Line Termination

Input voltage level violations are usually due to voltage spikes that raise input voltage levels above the maximum limit (overshoot) and below the minimum limit (undershoot). These voltage levels can cause excess current on input gates, resulting in permanent damage to the device. Even if no damage occurs, many devices are not guaranteed to function as specified if input voltage levels are exceeded.

Signal lines are terminated to minimize signal reflections and prevent overshoot and undershoot. Terminate the line if the round-trip signal path delay is greater than signal rise or fall time. If the line is not terminated, the signal reaches its high or low level before reflections have time to dissipate and overshoot or undershoot occurs.

For the i960 Jx processor, two termination methods are attractive: AC and series. An AC termination matches the impedance of the trace, thereby eliminating reflections due to the impedance mismatch.

Series termination decreases current flow in the signal path by adding a series resistor as shown in [Figure 12-11](#). The resistor increases signal rise and fall times so that the change in current occurs over a longer period of time. Because the amount of voltage overshoot and undershoot depends on the change in current over time ( $V = L di/dt$ ), the increased time reduces overshoot and undershoot. Place the series resistor as close as possible to the signal source. AC termination is effective in reducing signal reflection (ringing). This termination is accomplished by adding an RC combination at the signal's farthest destination ([Figure 12-12](#)). While the termination provides no DC load, the RC combination damps signal transients.

Selection of termination methods and values is dependent upon many variables, such as output buffer impedance, board trace impedance and input impedance.








Figure 12-11. Series Termination




Figure 12-12. AC Termination

**12.6.9 Latchup**

Latchup is a condition in a CMOS circuit in which  $V_{CC}$  becomes shorted to  $V_{SS}$ . Intel's CMOS IV processes are immune to latchup under normal operation conditions. Latchup can be triggered when the voltage limits on I/O pins are exceeded, causing internal PN junctions to become forward biased. The following guidelines help prevent latchup:

- Observe the maximum rating for input voltage on I/O pins.



## INITIALIZATION AND SYSTEM REQUIREMENTS

- Never apply power to an i960 Jx processor pin or a device connected to an i960 Jx processor pin before applying power to the i960 Jx processor itself.
- Prevent overshoot and undershoot on I/O pins by adding line termination and by designing to reduce noise and reflection on signal lines.

### 12.6.10 Interference


Interference is the result of electrical activity in one conductor that causes transient voltages to appear in another conductor. Interference increases with the following factors:

- Frequency Interference is the result of changing currents and voltages. The more frequent the changes, the greater the interference.
- Closeness-of-conductors Interference is due to electromagnetic and electrostatic fields whose effects are weaker further from the source.

Two types of interference must be considered in high frequency circuits: electromagnetic interference (EMI) and electrostatic interference (ESI).

EMI is caused by the magnetic field that exists around any current-carrying conductor. The magnetic flux from one conductor can induce current in another conductor, resulting in transient voltage. Several precautions can minimize EMI:

- Run ground lines between two adjacent lines wherever they traverse a long section of the circuit board. The ground line should be grounded at both ends.
- Run ground lines between the lines of an address bus or a data bus if either of the following conditions exist:
  - The bus is on an external layer of the board.
  - The bus is on an internal layer but not sandwiched between power and ground planes that are at most 10 mils away.



**Figure 12-13. Avoid Closed-Loop Signal Paths**

ESI is caused by the capacitive coupling of two adjacent conductors. The conductors act as the plates of a capacitor; a charge built up on one induces the opposite charge on the other.

The following steps reduce ESI:

- Separate signal lines so that capacitive coupling becomes negligible.
- Run a ground line between two lines to cancel the electrostatic fields.<sup>1</sup>





# 13

## MEMORY CONFIGURATION





## CHAPTER 13

# MEMORY CONFIGURATION

The Bus Control Unit (BCU) includes logic to control many common types of memory subsystems directly. Every bus access is “formatted” according to the BCU programming. The i960 Jx processor’s BCU programming model differs from schemes used in other i960 processors.

### 13.1 Memory Attributes

Every location in memory has associated physical and logical attributes. For example, a specific location may have the following attributes:

- **Physical:** Memory is an 8-bit wide ROM
- **Logical:** Memory is ordered big-endian and data is non-cacheable

In the example above, physical attributes correspond to those parameters that indicate *how to physically access the data*. The BCU uses physical attributes to determine the bus protocol and signal pins to use when controlling the memory subsystem. The logical attributes tell the BCU how to interpret, format and control interaction of on-chip data caches. The physical and logical attributes for an individual location are independently programmable.

#### 13.1.1 Physical Memory Attributes

The only programmable physical memory attribute for the i960 Jx microprocessor is the bus width, which can be 8-, 16- or 32-bits wide.

For the purposes of assigning memory attributes, the physical address space is partitioned into 8, fixed 512 Mbyte regions determined by the upper three address bits. The regions are numbered as 8 paired sections for consistency with other i960 processor implementations. Region 0\_1 maps to addresses 0000 0000H to 1FFF FFFFH and region 14\_15 maps to addresses E000 0000H to FFFF FFFFH. The physical memory attributes for each region are programmable through the PMCON registers. The PMCON registers are loaded from the Control Table. The i960 Jx microprocessor provides one PMCON register for each region. The descriptions of the PMCON registers and instructions on programming them are found in [Section 13.3](#).

13.1.2 Logical Memory Attributes

The i960 Jx provides a mechanism for defining two *logical memory templates* (LMTs). An LMT may be used to specify the logical memory attributes for a section (or subset) of a physical memory subsystem connected to the BCU (e.g., DRAM, SRAM). The logical memory attributes defined by the i960 Jx are byte ordering and whether the information is cacheable or non-cacheable in the on-chip data cache.

There are typically several different LMTs defined within a single memory subsystem. For example, data within one area of DRAM may be non-cacheable while data in another area is cacheable. [Figure 13-1](#) shows the use of the Control Table (PMCON registers) with logical memory templates for a single DRAM region in a typical application.




Figure 13-1. PMCON and LMCON Example





Each logical memory template is defined by programming Logical Memory Configuration (LMCON) registers. An LMCON Register pair defines a data template for areas of memory that have common logical attributes. The Jx microprocessor has two pairs of LMCON registers — defining two separate templates. The extent of each data template is described by an address (on 4 Kbyte boundaries) and an address mask. The address is programmed in the Logical Memory Address register (LMADR). The mask is programmed in the Logical Memory Mask register (LMMSK). These two registers constitute the LMCON register pair.

The *Default Logical Memory Configuration* register is used to provide configuration data for areas of memory that do not fall within one of the two logical data templates. The DLMCON also specifies byte-ordering (little endian/big endian) for all data accesses in memory, including on-chip data RAM.

The LMCON registers and their programming are described in [Section 13.6, Programming the Logical Memory Attributes](#).

## 13.2 Differences With Previous i960 Processors

The mechanism described in this chapter is not implemented on the i960 Kx or Sx processors. Although the i960 Cx processor has a memory configuration mechanism, it is different from the 80960Jx's in the following ways:

- For the purposes of assigning physical and logical memory attributes, the i960 Cx processor evenly divides physical memory into 16 contiguous regions. When assigning physical memory attributes, the Jx divides memory into 8 contiguous, 512 Mbyte regions starting on 512 Mbyte boundaries. The logical memory templates of the i960 Jx processor provide a programmable association of logical memory addresses, whereas the i960 Cx processor assigns these attributes to the physical memory regions.
- The i960 Cx processor provides per-region programming of wait states, address pipelining and bursting. No such mechanisms exist on the 80960Jx. Bus wait states must be generated using external logic.

**13.3 Programming the Physical Memory Attributes (PMCON Registers)**

The layout of the Physical Memory Configuration registers, PMCON0\_1 through PMCON14\_15, is shown in [Figure 13-2](#), which gives the descriptions of the individual bits. The PMCON registers reside within memory-mapped control register space. Each PMCON register controls one 512-Mbyte region of memory according to the mapping shown in [Table 13-1](#)

**Table 13-1. PMCON Address Mapping**

<b>Register (Control Table Entry)</b>	<b>Region Controlled</b>
PMCON0_1	0000.0000H to 0FFF.FFFFH and 1000.0000H to 1FFF.FFFFH
PMCON2_3	2000.0000H to 2FFF.FFFFH and 3000.0000H to 3FFF.FFFFH
PMCON4_5	4000.0000H to 4FFF.FFFFH and 5000.0000H to 5FFF.FFFFH
PMCON6_7	6000.0000H to 6FFF.FFFFH and 7000.0000H to 7FFF.FFFFH
PMCON8_9	8000.0000H to 8FFF.FFFFH and 9000.0000H to 9FFF.FFFFH
PMCON10_11	A000.0000H to AFFF.FFFFH and B000.0000H to BFFF.FFFFH
PMCON12_13	C000.0000H to CFFF.FFFFH and D000.0000H to DFFF.FFFFH
PMCON14_15	E000.0000H to EFFF.FFFFH and F000.0000H to FFFF.FFFFH



13.3.1 Bus Width

The bus width for a region is controlled by the BW1:0 bits in the PMCON register. The operation of the i960 Jx processor with different bus width programming options is described in section 14.2.3.1, “Bus Width” (pg. 14-7).

The bit combination “11” is reserved for the BW1:0 field and can result in unpredictable operation.




Figure 13-2. PMCON Register Bit Description

13.4 Physical Memory Attributes at Initialization

All eight PMCON registers are loaded automatically during system initialization. The initial values are stored in the Control Table in the Initialization Boot Record (see section 12.3.1, “Initial Memory Image (IMI)” (pg. 12-10)).

### 13.4.1 Bus Control (BCON) Register

Immediately after a hardware reset, the PMCON register contents are marked invalid in the Bus Control (BCON) register. Figure 13-3 shows the BCON register and Control Table Valid (CTV) bit. Whenever the PMCON entries are marked invalid in BCON, the BCU uses the parameters in PMCON14\_15 for *all* regions. On a hardware reset, PMCON14\_15 is automatically cleared. This operation configures all regions to an 8-bit bus width. Subsequently, the processor loads all PMCON registers from the Control Table. The processor then loads BCON from the Control Table. If BCON.ctv is clear, then PMCON14\_15 will remain in use for all bus accesses. If BCON.ctv is set, the region table is valid and the BCU uses the programmed PMCON values for each region.




Figure 13-3. Bus Control Register (BCON)



## 13.5 Boundary Conditions for Physical Memory Regions

The following sections describe the operation of the PMCON registers during conditions other than “normal” accesses.

### 13.5.1 Internal Memory Locations

The PMCON registers are ignored during accesses to internal memory or memory-mapped registers. The processor performs those accesses over 32-bit buses, except for local register cache accesses. The register bus is 128 bits wide.

### 13.5.2 Bus Transactions Across Region Boundaries

An unaligned bus request that spans region boundaries uses the PMCON settings of both regions. Accesses that lie in the first region use that region’s PMCON parameters, and the remaining accesses use the second region’s PMCON parameters.

For example, an unaligned quad word load/store beginning at address 1FFF FFFE<sub>H</sub> would cross boundaries from region 0\_1 to 2\_3. The physical parameters for region 0\_1 would be used for the first 2-byte access and the physical parameters for region 2\_3 would be used for the remaining access.

### 13.5.3 Modifying the PMCON Registers

An application can modify the value of a PMCON register by using the **st** or **sysctl** instruction. If a **st** or **sysctl** instruction is issued when an access is in progress, the current access is completed before the modification takes effect.

### 13.6 Programming the Logical Memory Attributes

The bit/bit field definitions for the LMADR1:0 and LMMR1:0 registers are shown in [Figure 13-4](#) and [Figure 13-5](#). LMCON registers reside within the memory-mapped control register space.




Figure 13-4. Logical Memory Template Starting Address Registers (LMADR0-1)







Figure 13-5. Logical Memory Template Mask Registers (LMMR0-1)

## MEMORY CONFIGURATION

The Default Logical Memory Configuration (DLMCON) register is shown in [Figure 13-6](#). The BCU uses the parameters in the DLMCON register when the current access does not fall within one of the two logical memory templates (LMTs). Notice the byte ordering is controlled for the entire address space by programming the DLMCON register.



**Figure 13-6. Default Logical Memory Configuration Register (DLMCON)**





### 13.6.1 Defining the Effective Range of a Logical Data Template

For each logical data template, an LMADR register sets the base address using the A31:12 field. The LMMR register sets the address mask using the MA31:12 field. The effective address range for a logical data template is defined using the A31:12 field in an LMADR<sub>x</sub> register and the MA31:12 field in an LMMR<sub>x</sub> register. For each access, the upper 20 address bits (A31:12) are compared against A31:12 in the LMADR<sub>x</sub> register. Only address bits with corresponding MA bits set are compared. Address bits with corresponding MA bits cleared (0) are automatically considered a “match”. The processor will only use the logical data template when all compared address bits match. Two examples help clarify the operation of the address comparators.

- Create a template 64 Kbytes in length beginning at address 0010 0000H and ending at address 0010 FFFFH. Determine the form of the candidate address to match and then program the LMADR and LMMR registers:

```
Candidate Address is of form: 0010 XXXX
LMADR <31:12> should be:   0010 0...
LMMR <31:12> should be:   FFFF 0...
```

- Multiple data templates can be created from a single LMADR/LMMR register pair by aliasing effective addresses. For example, to create sixteen 64 Kbyte templates, each beginning on modulo 1 Mbyte boundaries starting at 0000 0000H and ending with 00F0 0000H, the registers are programmed as follows:

```
Candidate Address is of form: 00X0 XXXX
LMADR <31:12> should be:   0000 0...
LMMR <31:12> should be:   FF0F 0...
```

### 13.6.2 Selecting the Byte Order

The BCU can automatically convert aligned big endian data in memory into little endian data for the processor core. The conversion is done transparently in hardware, with no performance penalty. The BE bit in the DLMCON register controls the default byte ordering for address regions of the system including internal data RAM but excluding memory-mapped registers. Instruction fetches and data accesses are automatically converted to little endian format when they are fetched from external memory and the programmed default byte-order (DLMCON.be) is big-endian.

The recommended, portable way to determine the byte-ordering associated with a logical memory template is to read the appropriate LMADR. The i960 Jx microprocessor supports this method by always ensuring that the DLMCON.be bit is reflected in bit zero of LMADR0 and LMADR1 (also labelled as LMADR.be) when they are read. Any attempts to write bit zero of an LMADR are ignored.

Great care should be exercised when dynamically changing the processor's homogenous byte order. See [section 13.6.8, "Dynamic Byte Order Changing"](#) (pg. 13-14) for an instruction code example.

Byte-ordering is not applicable to memory-mapped registers since they are always accessed as words.

### 13.6.3 Data Caching Enable

Enabling and disabling data caching for an LMT is controlled via the DCEN bit in the LMADR register. Likewise, the DCEN bit in DLMCON enables and disables data-caching for regions of memory that are not covered by the LMCON registers. The DCEN bit has no effect on the instruction cache.

### 13.6.4 Enabling the Logical Memory Template

The LMTE bit activates the logical data template in the LMMR register for the programmed range.



**13.6.5 Initialization**

Immediately following a hardware reset, all LMTs are disabled. The LMTE bit in each of the LMMR registers is cleared (0) and all other bits are undefined. Immediately after a hardware reset the Default Logical Memory Control register (DLMCON) has the values shown in [Table 13-2](#).

**Table 13-2. DLMCON Values at Reset**

DLMCON Bit	Value Upon Hardware Reset	Value Upon Software Re-initialization
DCEN (Data Caching Enable)	0 (Data Caching Disabled)	0 (Data Caching Disabled)
BE (Big-Endian)	Initialized from PMCON14_15 image in IBR bit 31	Value before software re-initialization

Application software may initialize and enable the logical memory template after hardware reset. After a software re-initialization, the DLMCON.be retains its value and DLMCON.dcen is cleared.

**13.6.6 Boundary Conditions for Logical Memory Templates**

The following sections describe the operation of the LMT registers during conditions other than “normal” accesses. See [CHAPTER 4, CACHE AND ON-CHIP DATA RAM](#) for a treatment of data cache coherency when modifying an LMT.

**13.6.6.1 Internal Memory Locations**

The LMT registers are not used during accesses to memory-mapped registers. Internal data RAM locations are never cached; LMT bits controlling caching are ignored for data RAM accesses. However, the byte-ordering of the internal data RAM is controlled by DLMCON.be.

**13.6.6.2 Overlapping Logical Data Template Ranges**

Logical data templates that specify overlapping ranges are not allowed. When an access is attempted that matches more than one enabled LMT range, the operation of the access becomes undefined.

To establish different logical memory attributes for the same address range, program non-overlapping logical ranges, then use partial physical address decoding.



## MEMORY CONFIGURATION

### 13.6.6.3 Accesses Across LMT Boundaries

Accesses that cross LMT boundaries should be avoided. These accesses are unaligned and broken into a number of smaller aligned accesses, which reside in one or the other LMT, but not both. Each smaller access is completed using the parameters of the LMT in which it resides.

### 13.6.7 Modifying the LMT Registers

An LMT register can be modified using **st** or **sysctl** instructions. Both instructions ensure data cache coherency and order the modification with previous and subsequent data accesses.

### 13.6.8 Dynamic Byte Order Changing

Programmed byte order changes take effect immediately. The next instruction fetch will use the new byte order setting. This byte-swapping usually results in errors because the current instruction stream uses the previous byte order setting.

Dynamically changing the byte order to perform limited operations is possible if the code sequence is locked in the instruction cache. The application must ensure that code executes from within the locked region (including faults and interrupts) while the opposite byte order is in effect. The following example illustrates this method:

```
safe_addr:  lda      safe_addr,r4
           mov      1,r5
           icctl   0x3,r4,r5      # Lock code in cache.
           ld      DLMCON_MM,r6
           notbit  0,r6,r7
           st      r7,DLMCON_MM  # Toggle byte order.
           . . .
           <Short code sequence>
           . . .
           st      r6,DLMCON_MM  # Restore byte order.
           icctl   2,0,r6        # Invalidate cache
                                   # to unlock code.
```

In most cases, it is safer to retain the original byte order and use the **bswap** instruction to convert data between little-endian and big-endian byte order.



EXTERNAL BUS





## CHAPTER 14 EXTERNAL BUS

This chapter describes the bus interface of the i960<sup>®</sup> Jx processor. It explains the following:

- Bus states and their relationship to each other
- Bus signals, which consist of address/data, control/status
- Read, write, burst and atomic bus transactions
- Related bus functions such as arbitration

This chapter also serves as a starting point for the hardware designer when interfacing typical memory and peripheral devices to the i960 Jx processor's address/data bus.

For information on programmable bus configuration, refer to CHAPTER 12, MEMORY CONFIGURATION.

### 14.1 OVERVIEW

The bus is the data communication path between the various components of an i960 Jx microprocessor hardware system, allowing the processor to fetch instructions, manipulate data and interact with its I/O environment. To perform these tasks at high bandwidth, the processor features a burst transfer capability, allowing up to four successive 32-bit data transfers at a maximum rate of one word every clock cycle.

The address/data path is multiplexed for economy and bus width is programmable to 8-, 16- and 32-bit widths. The processor has dedicated control signals for external address latches, buffers and data transceivers. In addition, the processor uses other signals to communicate with alternate bus masters. All bus transactions are synchronized with the processor's clock input (CLKIN); therefore, the memory system control logic can be implemented as state machines.

### 14.2 BUS OPERATION

Knowing definitions of the terms *request*, *access* and *transfer* is essential to understand descriptions of bus operations.

The processor's bus control unit is designed to decouple bus activity from instruction execution in the core as much as possible. When a load or store instruction or instruction prefetch is issued, a bus *request* is generated in the bus control unit. The bus control unit independently processes the request and retrieves data from memory for load instructions and instruction prefetches. The bus control unit delivers data to memory for store instructions.

The i960 architecture defines byte, short word, word, double word, triple word and quad word data lengths for load and store instructions. When a load or store instruction is encountered, the processor issues a bus request of the appropriate data length: for example, **ldq** requests that four words of data be retrieved from memory; **stob** requests that a single byte be delivered to memory. The processor always fetches instructions using double or quad word bus requests.

A bus *access* is defined as a bus transaction bounded by the assertion of  $\overline{ADS}$  (address/data status) and de-assertion of  $\overline{BLAST}$  (burst last) signals, which are outputs from the processor. A bus access consists of one to four data *transfers*. During each transfer, the processor either reads data or drives data on the bus. The number of transfers per access and the number of accesses per request is governed by the requested data length, the programmed width of the bus and the alignment of the address.

#### 14.2.1 Basic Bus States

The bus has five basic bus states: idle (Ti), address (Ta), wait/data (Tw/Td), recovery (Tr), and hold (Th). During system operation, the processor continuously enters and exits different bus states.

The bus occupies the idle (Ti) state when no address/data transactions are in progress and when **RESET** is asserted. When the processor needs to initiate a bus access, it enters the Ta state to transmit the address.

Following a Ta state, the bus enters the Tw/Td state to transmit or receive data on the address/data lines. Assertion of the  $\overline{RDYRCV}$  input signal indicates completion of each transfer. When data is not ready, the processor can wait as long as necessary for the memory or I/O device to respond.

After the data transfer, the bus exits the Tw/Td state and enters the recovery (Tr) state. In the case of a burst transaction, the bus exits the Td state and re-enters the Td/Tw state to transfer the next data word. The processor asserts the  $\overline{BLAST}$  signal during the last Tw/Td states of an access. Once all data words transfer in a burst access (up to four), the bus enters the Tr state to allow devices on the bus to recover.

The processor remains in the Tr state until  $\overline{RDYRCV}$  is deasserted. When the recovery state completes, the bus enters the Ti state if no new accesses are required. If an access is pending, the bus enters the Ta state to transmit the new address.








Figure 14.1. Bus States with Arbitration

## EXTERNAL BUS

### 14.2.2 Bus Signal Types

Bus signals consist of three groups: address/data, control/status and bus arbitration. They are listed in [Table 14.1](#). Refer to [Section 1.4, “Related Documents”](#) (pg. 1-10). A detailed description of all signals can be found in these documents.

#### 14.2.2.1 Clock Signal

The CLKIN input signal is the reference for all i960 Jx microprocessor signal timing relationships. Note that this is true even for the i960 JD processor, even though the CPU core runs at twice the CLKIN rate. Transitions on the AD31:2, AD1:0, A3:2,  $\overline{ADS}$ , BE3:0, WIDTH/HLTD1:0, D/ $\overline{C}$ , W/ $\overline{R}$ ,  $\overline{DEN}$ ,  $\overline{BLAST}$ ,  $\overline{RDYRCV}$ ,  $\overline{LOCK/ONCE}$ , HOLD/HOLDA and BSTAT bus signal pins are always measured directly from the rising edge of CLKIN. The processor asserts ALE and  $\overline{ALE}$  directly from the rising CLKIN edge at the beginning of a Ta state but deasserts them approximately half way through the state instead of the next rising CLKIN edge. All transitions on DT/ $\overline{R}$  are also referenced to a point halfway through the Ta state instead of rising CLKIN edges.

#### 14.2.2.2 Address/Data Signal Definitions

The address/data signal group consists of 34 lines. 32 of these signals multiplex within the processor to serve a dual purpose. During Ta, the processor drives AD31:2 with the address of the bus access. At all other times, these lines are defined to contain data. A3:2 are demultiplexed address pins providing incrementing word addresses during burst cycles. AD1:0 denote burst size during Ta and data during other states.

The processor routinely performs data transfers less than 32 bits wide. If the programmed bus width is 32 bits and transfers are 16- or 8-bit, then during write cycles the processor will replicate the data that is being driven on the unused address/data pins. If the programmed bus width is 16 or 8 bits, then during write cycles the processor continues driving the previous address on any unused address/data pins.

Whenever the programmed bus width is less than 32 bits, additional demultiplexed address bits are available on unused byte enable pins (See [section 14.2.3.1, “Bus Width”](#) (pg. 14-7)). These signals increment during burst accesses in similar fashion to the A3:2 pins.

#### 14.2.2.3 Control/Status Signal Definitions

The control/status signal group consists of 15 signals. These signals control data buffers and address latches or furnish information useful to external chip-select generation logic. All output control/status signals are three-state.



Table 14-1. Summary of i960 Jx Processor Bus Signals

Signal Symbol	Name (Direction)	Signal Function
AD31:2	Address/Data 31:2 (I/O)	Word address, driven during Ta. Read or write data, driven or sampled during Tw/Td.
AD1:0	Address/Data 1:0 and Size 1:0 (I/O)	Number of transfers, driven during Ta. Read or write data, driven or sampled during Tw/Td.
A3:2	Address 3:2 (O)	Incrementing burst address bits, driven during Ta and Tw/Td.
ALE	Address Latch Enable (O)	Driven during Ta for demultiplexing AD bus.
$\overline{ALE}$	Address Latch Enable (Inverted) (O)	Driven during Ta for demultiplexing AD bus.
$\overline{ADS}$	Address/Data Status (O)	Valid address indicator, driven during Ta.
$\overline{BE3:0}$	Byte Enables 3:0 and Byte High Enable/Byte Low Enable and A1:0 (O)	Enable selected data bytes on bus. (16-bit bus) $\overline{BE3}$ and $\overline{BE0}$ enable high and low bytes. (8-bit bus) $\overline{BE1:0}$ are incrementing burst address bits. Driven during Ta and Tw/Td.
WIDTH/HLT D1:0	Width and Processor Halted (O)	Physical bus size, driven during Ta and Tw/Td. Can denote Halt Mode.
D/ $\overline{C}$	Data/Code (O)	Data access or instruction access, driven during Ta and Tw/Td.
W/ $\overline{R}$	Write/Read (O)	Indication of data direction, driven during Ta and Tw/Td.
DT/ $\overline{R}$	Data Transmit/Receive (O)	Delayed indication of data direction, driven during Ta and Tw/Td.
$\overline{DEN}$	Data Enable (O)	Enables data on bus, driven during Tw/Td.
$\overline{BLAST}$	Burst Last (O)	Last transfer of a bus access, driven during Tw/Td.
$\overline{RDYRCV}$	Ready/Recover (I)	Data transfer edge when sampled low during Tw/Td. Bus recovered when sampled high during Tr.
$\overline{LOCK}/\overline{ONCE}$	Lock/On-Circuit Emulation (I/O)	Atomic operation, driven during Ta and Tw/Td. ONCE floats all pins when sampled at reset.
HOLD	Hold (I)	Acquisition request from external bus master, sampled any clock.
HOLDA	Hold Acknowledge (O)	Bus control granted to external bus master, driven during Th.
BSTAT	Bus Status (O)	Processor may stall unless it can acquire bus, driven any clock.

Bus accesses begin with the assertion of  $\overline{ADS}$  (address/data status) during a  $T_a$  state. External decoding logic typically uses  $\overline{ADS}$  to qualify a valid address at the rising clock edge at the end of  $T_a$ . The processor pulses ALE (address latch enable) active high for one half clock during  $T_a$  to latch the multiplexed address on AD31:2 in external address latches. An inverted signal,  $\overline{ALE}$ , is also present for compatibility with i960 Kx processor-based companion devices.

The byte enable ( $\overline{BE3:0}$ ) signals denote which bytes on the 32-bit data bus will transfer data during an access. The processor asserts byte enables during  $T_a$  and deasserts them during  $T_r$ . When the data bus is configured for 16 bits, two byte enables become byte high enable and byte low enable and an additional address bit A1 is provided. When the bus is configured for 8 bits, there are no byte enables, but additional address bits A1:0 are provided. Note that the processor always drives byte enable pins to logical 1's during the  $T_r$  state, even when they are used as addresses.

The WIDTH1:0,  $D/\overline{C}$  and  $W/\overline{R}$  signals yield useful bus access information for external memory and I/O controllers. The WIDTH1:0 signals denote programmed physical memory attributes. The data/code pin indicates whether an access is a data transaction (1) or an instruction transaction (0). The write/read pin indicates the direction of data flow relative to the i960 Jx processor. WIDTH1:0,  $D/\overline{C}$  and  $W/\overline{R}$  change state as needed during the  $T_a$  state.

$DT/\overline{R}$  and  $\overline{DEN}$  pins are used to control data transceivers. Data transceivers may be used in a system to isolate a memory subsystem or control loading on data lines.  $DT/\overline{R}$  (data transmit/receive) is used to control transceiver direction. In the second half of the  $T_a$  state, it transitions high for write cycles or low for read cycles.  $\overline{DEN}$  (data enable) is used to enable the transceivers.  $\overline{DEN}$  is asserted during the first  $T_w/T_d$  state of a bus access and deasserted during  $T_r$ .  $DT/\overline{R}$  and  $\overline{DEN}$  timings ensure that  $DT/\overline{R}$  does not change state when  $\overline{DEN}$  is asserted.

A bus access may be either non-burst or burst. A non-burst access ends after one data transfer to a single location. A burst access involves two to four data cycles to consecutive memory locations. The processor asserts BLAST (burst last) to indicate the last data cycle of an access in both burst and non-burst situations.

All i960 Jx processor wait states are controlled by the  $\overline{RDYRCV}$  (ready/recover) input signal.

### 14.2.3 Bus Accesses

The i960 Jx microprocessor uses the bus signals to transfer data between the processor and another component. The maximum transfer rate is achieved when performing burst accesses at the rate of four 32-bit data words per six clocks.



14.2.3.1 Bus Width

Each region's data bus width is programmed in a Physical Memory Region Configuration (PMCON) register. The processor allows an 8-, 16- or 32-bit data bus width for each region. The processor places 8- and 16-bit data on low-order data pins, simplifying the interface to narrow bus external devices. As shown in Figure 14-2, 8-bit data is placed on lines AD7:0; 16-bit data is placed on lines AD15:0; 32-bit data is placed on lines AD31:0. The processor encodes bus width on the WIDTH1:0 pins so that external logic may enable the bus correctly.




Figure 14-2. Data Width and Byte Encodings

Depending on the programmed bus width, the byte enable signals provide either data enables or low-order address lines:

- 8-bit region:  $\overline{BE0:1}$  provide the byte address (A0, A1) (see Table 14-2).
- 16-bit region:  $\overline{BE1}$  provides the short-word address (A1);  $\overline{BE3}$  is the byte high enable signal (BHE);  $\overline{BE0}$  is the byte low enable signal (BLE) (see Table 14-3).
- 32-bit region: byte enables are not encoded as address pins. Byte enables  $\overline{BE3:0}$  select bytes 0 through 3 of the 32-bit words addressed by AD31:2 (see Table 14-4).

When the byte enables function as address lines, they increment with each transfer during burst accesses. Otherwise, byte enables never toggle between transfers of a burst, due to microcode breakup of unaligned requests.



Table 14-2. 8-Bit Bus Width Byte Enable Encodings

Byte	BE3 (Not Used)	BE2 (Not Used)	BE1 (Used as A1)	BE0 (Used as A0)
0	1	1	0	0
1	1	1	0	1
2	1	1	1	0
3	1	1	1	1

Table 14-3. 16-Bit Bus Width Byte Enable Encodings

Byte	BE3 (Used as BHE)	BE2 (Not Used)	BE1 (Used as A1)	BE0 (Used as BLE)
0,1	0	1	0	0
2,3	0	1	1	0
0	1	1	0	0
1	0	1	0	1
2	1	1	1	0
3	0	1	1	1

Table 14-4. 32-Bit Bus Width Byte Enable Encodings

Byte	$\overline{\text{BE}}3$	$\overline{\text{BE}}2$	$\overline{\text{BE}}1$	$\overline{\text{BE}}0$
0,1,2,3	0	0	0	0
0,1	1	1	0	0
2,3	0	0	1	1
0	1	1	1	0
1	1	1	0	1
2	1	0	1	1
3	0	1	1	1

During initialization, the bus configuration data is read from the Initialization Boot Record (IBR) assuming an 8-bit bus width; however, the IBR can be in 8-bit, 16-bit, or 32-bit physical memory.  $\overline{\text{BE}}3$  and  $\overline{\text{BE}}2$  are defined as “1” so that reading the bus configuration data works for all bus widths. Since these byte enables are ignored for actual 8-bit memory, they can be permanently defined this way for ease of implementation.



Intel designed the i960 Jx processor to drive determinate values on all address/data pins during Tw/Td write operation states. For an 8-bit bus, the processor continues to drive address on unused data pins AD31:8. For a 16-bit bus, the processor continues to drive address on unused data pins AD31:16. However, when the processor does not use the entire bus width because of data width or misalignment (i.e., 8-bit write on a 16- or 32-bit bus or a 16-bit write on a 32-bit bus), data is replicated on those unused portions of the bus.

#### 14.2.3.2 Basic Bus Accesses

The basic transaction is a read or write of one data word. The first half of [Figure 14-3](#) shows a typical timing diagram for a non-burst, 32-bit read transaction. For simplicity, no wait states are shown.

During the Ta state, the i960 Jx microprocessor transmits the address on the address/data lines. In the figure, the size bits (AD1:0) specify a single word transaction and WIDTH1:0 indicate a 32-bit wide access. The processor asserts  $\overline{ALE}$  to latch the address and drives  $\overline{ADS}$  low to denote the start of the cycle.  $\overline{BE3:0}$  specify which bytes the processor uses to read the data word. The processor brings  $\overline{W/R}$  low to denote a read operation and drives  $\overline{D/C}$  to the proper state. For data transceivers,  $\overline{DT/R}$  goes low to define the input direction.

During the Tw/Td state, the i960 Jx microprocessor deasserts  $\overline{ADS}$  and asserts  $\overline{DEN}$  to enable any data transceivers. Since this is a non-burst transaction, the processor asserts  $\overline{BLAST}$  to signify the last transfer of a transaction. The figure shows  $\overline{RDYRCV}$  assertion by external logic, so this state is a data state and the processor latches data on a rising CLKIN edge.

The Tr state follows the Tw/Td state. This allows the system components adequate time to remove their outputs from the bus before the processor drives the next address on the address/data lines. During the Tr state,  $\overline{BLAST}$ ,  $\overline{BE3:0}$  and  $\overline{DEN}$  are inactive.  $\overline{W/R}$  and  $\overline{DT/R}$  hold their previous values. The figure indicates a logical high for the  $\overline{RDYRCV}$  pin, so there is only one recovery state.

After a read, notice that the address/data bus goes to an invalid state during Ti. The processor drives valid logic levels on the address/data bus instead of allowing it to float. See [section 14.2.4, “Bus and Control Signals During Recovery and Idle States”](#) (pg. 14-22) for the values that are driven during Ti.




Figure 14-3. Non-Burst Read and Write Transactions Without Wait States, 32-Bit Bus





Figure 14-3 also shows a typical timing diagram for a non-burst, 32-bit write transaction. For the write operation,  $W/\overline{R}$  and  $DT/\overline{R}$  are high to denote the direction of the data flow. The  $D/\overline{C}$  pin is high since instruction code cannot be written. During the  $T_w/T_d$  state, the processor drives data on the bus, waiting to sample  $\overline{RDYRCV}$  low to terminate the transfer. The figure shows  $\overline{RDYRCV}$  assertion by external logic, so this state is a data state and the processor enters the recovery state.

At the end of a write, notice that the write data is driven during  $T_r$  and any subsequent  $T_i$  states. After a write, the processor will drive write data until the next  $T_a$  state. See section 14.2.4, “Bus and Control Signals During Recovery and Idle States” (pg. 14-22) for details.

### 14.2.3.3 Burst Transactions

A burst access is an address cycle followed by two to four data transfers. The i960 Jx microprocessor uses burst transactions for instruction fetching and accessing system data structures. Therefore, a system design incorporating an i960 Jx microprocessor must support burst transactions. Burst accesses can also result from instruction references to data types which exceed the width of the bus.

Maximum burst size is four data transfers, independent of bus width. A byte-wide bus has a maximum burst size of four bytes; a word-wide bus has a maximum of four words. For an 8- or 16-bit bus, this means that some bus requests may result in multiple burst accesses. For example, if a quad word load request (e.g., `ldq` instruction) is made to an 8-bit data region, it results in four, 4-byte, burst accesses. (See Table 14-6 (pg. 14-23).

Burst accesses on a 32-bit bus are always aligned to even-word boundaries. Quad-word and triple-word accesses always begin on quad-word boundaries ( $A3:2=00$ ); double-word transfers always begin on double-word boundaries ( $A2=0$ ); single-word transfers occur on single word boundaries. Figure 14-4 shows burst, stop and start addresses for a 32-bit bus.




Figure 14-4. 32-Bit Wide Data Bus Bursts





Figure 14-5. 16-Bit Wide Data Bus Bursts





**Figure 14-6. 8-Bit Wide Data Bus Bursts**

Burst accesses for a 16-bit bus are always aligned to even short-word boundaries. A four short-word burst access always begins on a four short-word boundary ( $A2=0, A1=0$ ). Two short-word burst accesses always begin on an even short-word boundary ( $A1=0$ ). Single short-word transfers occur on single short-word boundaries (see [Figure 14-5](#)).

Burst accesses for an 8-bit bus are always aligned to even byte boundaries. Four-byte burst accesses always begin on a 4-byte boundary ( $A1=0, A0=0$ ). Two-byte burst accesses always begin on an even byte boundary ( $A0=0$ ) (see [Figure 14-6](#)).

[Figure 14-7](#) illustrates a series of bus accesses resulting from a triple-word store request to 16-bit wide memory. The top half of the figure shows the initial location of 12 data bytes contained in registers  $g4$  through  $g6$ . The instruction’s task is to move this data to memory at address  $0AH$ . The top half of the figure also shows the final destination of the data.


Notice that a new 16-byte boundary begins at address  $10H$ . Since the processor stores 6 of the 12 bytes after this 16-byte boundary, the processor will split the transaction into a number of accesses. The  $i960 Jx$  processor cannot burst across 16-byte boundaries.



## EXTERNAL BUS

The processor splits the transaction into the following accesses. It performs the following bus cycles:

1. Non-burst access to transfer the first short word (contents 5678H) to address 0AH. The short word at address 08H remains unchanged.
2. Burst access to transfer the second and third short words (contents 1234H and 0FACEH) to address 0CH.
3. Burst access to transfer the fourth and fifth short words (contents 0FEEDH and 0BA98H) to address 10H.
4. Non-burst access to transfer the last short word (contents 0FEDCH) to address 14H. The short word at address 16H remains unchanged.



**Figure 14-7. Unaligned Write Transaction**






Figure 14-8. Burst Read and Write Transactions w/o Wait States, 32-bit Bus




Figure 14-9. Burst Read and Write Transactions w/o Wait States, 8-bit Bus



#### 14.2.3.4 Wait States

Wait states lengthen the microprocessor's bus cycles, allowing data transfers with slow memory and I/O devices. The 80960Jx supports three types of wait states: *address-to-data*, *data-to-data* and *turnaround* or *recovery*. All three types are controlled through the processor's  $\overline{\text{RDYRCV}}$  (Ready/Recover) pin, a synchronous input.

The processor's bus states follow the state diagram in [Figure 14.1](#). After the Ta state, the processor enters the Tw/Td state to perform a data transfer. If the memory (or I/O) system is fast enough to allow the transfer to complete during this clock (i.e., "ready"), external logic asserts  $\overline{\text{RDYRCV}}$ . The processor samples  $\overline{\text{RDYRCV}}$  low on the next rising clock edge, completing the transfer; the state is a data state. If the memory system is too slow to complete the transfer during this clock, external logic drives  $\overline{\text{RDYRCV}}$  high and the state is an address-to-data wait state. Additional wait states may be inserted in similar fashion.

If the bus transaction is a burst, the processor re-enters the Tw/Td state after the first data transfer. The processor continues to sample  $\overline{\text{RDYRCV}}$  on each rising clock edge, adding a data-to-data wait state when  $\overline{\text{RDYRCV}}$  is high and completing a transfer when  $\overline{\text{RDYRCV}}$  is low. The process continues until all transfers are finished, with  $\overline{\text{RDYRCV}}$  assertion denoting every data acquisition.

[Figure 14-10](#) illustrates a quad word burst write transaction with wait states. There are two address-to-data wait states single data-to-data wait states between transfers.




Figure 14-10. Burst Write Transactions With 2,1,1,1 Wait States, 32-bit Bus





### 14.2.3.5 Recovery States

The state following the last data transfer of an access is a recovery (Tr) state. By default, i960 Jx microprocessor bus transactions have one recovery state. External logic can cause additional recovery states to be inserted by driving the  $\overline{\text{RDYRCV}}$  pin low at the end of Tr.

Recovery wait states are an important feature for the Jx because it employs a multiplexed bus. Slow memory and I/O devices often need a long time to turn off their output drivers on read accesses before the microprocessor drives the address for the next bus access. Recovery wait states are also useful to force a delay between back-to-back accesses to I/O devices with their own specific access recovery requirements.

System ready logic is often described as normally-ready or normally-not-ready. Normally-ready logic asserts a microprocessor's input pin during all bus states, except when wait states are desired. Normally-not-ready logic deasserts a processor's input pin during all bus states, except when the processor is ready. The subtle nomenclature distinction is important for i960 Jx microprocessor systems because the active sense of the  $\overline{\text{RDYRCV}}$  pin reverses for recovery states. During the Tr state, logic 0 means "continue to recover" or "not ready"; for Tw/Td states, logic 0 means "ready". Logic must assure "ready" and "not recover" are generated to terminate an access properly. Be certain to not hang the processor with endless recovery states. Conventional ready logic implemented as normally-not-ready will operate correctly (but without adding turnaround wait states).

Figure 14-12 is a timing waveform of a read cycle followed by a write cycle, with an extra recovery state inserted into the read cycle.




Figure 14-11. Burst Read/Write Transactions with 1,0 Wait States - Extra Tr State on Read, 16-Bit Bus






Figure 14-12. Burst Read/Write Transactions with 1,0 Wait States, Extra Tr State on Read, 16-Bit Bus

#### 14.2.4 Bus and Control Signals During Recovery and Idle States

Valid bus transactions are bounded by  $\overline{ADS}$  going active at the beginning of Ta states and  $\overline{BLAST}$  going inactive at the beginning of Tr states. During Tr and Ti states, bus and control pin logic levels are defined in such a way as to avoid unnecessary pin transitions that waste power. In all cases, the bus and control pins are completely quiet for instruction fetches and data loads that are cache hits.

If the last bus cycle is a read, the address/data bus floats during all Tr states. If the last bus cycle is a write, the address/data bus freezes during Tr states. The processor drives control pins such as ALE,  $\overline{ADS}$ ,  $\overline{BLAST}$  and  $\overline{DEN}$  to their inactive states during Tr. Byte enables  $\overline{BE3:0}$  are always driven to logic high during Tr, even when the processor uses them under alternate definitions. Outputs without clearly defined active/inactive states such as A3:2, WIDTH/HLTD1:0, D/C, W/R and DT/R freeze during Tr.

When the bus enters the Ti state, the bus and control pins will likewise freeze to inactive states. The exact states of the address/data pins depend on how the processor enters the Ti state. If the processor enters Ti from a Tr ending a write cycle, the processor continues driving data on AD31:0. If the processor enters Ti from a read cycle or from a Th state, AD31:4 will be driven with the upper 28 bits of the read address. AD3:2 will be driven identically as A3:2 (the word address of the last read transfer). The processor will usually drive AD1:0 with the last SIZE information. In cases where the core cancels a previously issued bus request, AD1:0 are indeterminate.

#### 14.2.5 Data Alignment

The i960 Jx microprocessor's Bus Control Unit (BCU) directly supports both big-endian and little-endian *aligned* accesses. The processor also transparently supports both big-endian and little-endian *unaligned* accesses but with reduced performance. Unaligned accesses are broken down into a series of aligned accesses with the assistance of microcode executing on the processor.

Alignment rules for loads and stores are based on address offsets from natural data boundaries. [Table 14-5](#) lists the natural boundaries for the various data widths and [Table 14-6](#) through [Table 14-8](#) list all possible combinations of bus accesses resulting from aligned and unaligned requests. [Figure 14-13](#) and [Figure 14-14](#) also depict all the combinations for 32-bit buses. [Figure 14-15](#) is a functional waveform for a series of four accesses resulting from a misaligned double word read request.

The fault configuration word in the Process Control Block (PRCB), can configure the processor to handle unaligned accesses non-transparently by generating an OPERATION.UNALIGNED fault after executing any unaligned access. See [section 12.3.1.2, "Process Control Block \(PRCB\)"](#) (pg. 12-16).



**Table 14-5. Natural Boundaries for Load and Store Accesses**

Data Width	Natural Boundary (Bytes)
Byte	1
Short Word	2
Word	4
Double Word	8
Triple Word	16
Quad Word	16

**Table 14-6. Summary of Byte Load and Store Accesses**

Address Offset from Natural Boundary (in Bytes)	Accesses on 8-Bit Bus (WIDTH1:0=00)	Accesses on 16 Bit Bus (WIDTH1:0=01)	Accesses on 32 Bit Bus (WIDTH1:0=10)
+0 (aligned)	byte access	byte access	byte access

**Table 14-7. Summary of Short Word Load and Store Accesses**

Address Offset from Natural Boundary (in Bytes)	Accesses on 8-Bit Bus (WIDTH1:0=00)	Accesses on 16 Bit Bus (WIDTH1:0=01)	Accesses on 32 Bit Bus (WIDTH1:0=10)
+0 (aligned)	burst of 2 bytes	short-word access	short-word access
+1	2 byte accesses	2 byte accesses	2 byte accesses





Table 14-8. Summary of *n*-Word Load and Store Accesses (*n* = 1, 2, 3, 4)

Address Offset from Natural Boundary in Bytes	Accesses on 8-Bit Bus (WIDTH1:0=00)	Accesses on 16 Bit Bus (WIDTH1:0=01)	Accesses on 32 Bit Bus (WIDTH1:0=10)
+0 (aligned) ( <i>n</i> = 1, 2, 3, 4)	<ul style="list-style-type: none"> <li><i>n</i> burst(s) of 4 bytes</li> </ul>	<ul style="list-style-type: none"> <li>case <i>n</i>=1: burst of 2 short words</li> <li>case <i>n</i>=2: burst of 4 short words</li> <li>case <i>n</i>=3: burst of 4 short words burst of 2 short words</li> <li>case <i>n</i>=4: 2 bursts of 4 short words</li> </ul>	<ul style="list-style-type: none"> <li>burst of <i>n</i> word(s)</li> </ul>
+1 ( <i>n</i> = 1, 2, 3, 4) +5 ( <i>n</i> = 2, 3, 4) +9 ( <i>n</i> = 3, 4) +13 ( <i>n</i> = 3, 4)	<ul style="list-style-type: none"> <li>byte access</li> <li>burst of 2 bytes</li> <li><i>n</i>-1 burst(s) of 4 bytes</li> <li>byte access</li> </ul>	<ul style="list-style-type: none"> <li>byte access</li> <li>short-word access</li> <li><i>n</i>-1 burst(s) of 2 short words</li> <li>byte access</li> </ul>	<ul style="list-style-type: none"> <li>byte access</li> <li>short-word access</li> <li><i>n</i>-1 word access(es)</li> <li>byte access</li> </ul>
+2 ( <i>n</i> = 1, 2, 3, 4) +6 ( <i>n</i> = 2, 3, 4) +10 ( <i>n</i> = 3, 4) +14 ( <i>n</i> = 3, 4)	<ul style="list-style-type: none"> <li>burst of 2 bytes</li> <li><i>n</i>-1 burst(s) of 4 bytes</li> <li>burst of 2 bytes</li> </ul>	<ul style="list-style-type: none"> <li>short-word access</li> <li><i>n</i>-1 burst(s) of 2 short words</li> <li>short-word access</li> </ul>	<ul style="list-style-type: none"> <li>short-word access</li> <li><i>n</i>-1 word access(es)</li> <li>short-word access</li> </ul>
+3 ( <i>n</i> = 1, 2, 3, 4) +7 ( <i>n</i> = 2, 3, 4) +11 ( <i>n</i> = 3, 4) +15 ( <i>n</i> = 3, 4)	<ul style="list-style-type: none"> <li>byte access</li> <li><i>n</i>-1 burst(s) of 4 bytes</li> <li>burst of 2 bytes</li> <li>byte access</li> </ul>	<ul style="list-style-type: none"> <li>byte access</li> <li><i>n</i>-1 burst(s) of 2 short words</li> <li>short-word access</li> <li>byte access</li> </ul>	<ul style="list-style-type: none"> <li>byte access</li> <li><i>n</i>-1 word access(es)</li> <li>short-word access</li> <li>byte access</li> </ul>
+4 ( <i>n</i> = 2, 3, 4) +8 ( <i>n</i> = 3, 4) +12 ( <i>n</i> = 3, 4)	<ul style="list-style-type: none"> <li><i>n</i> burst(s) of 4 bytes</li> </ul>	<ul style="list-style-type: none"> <li><i>n</i> burst(s) of 2 short words</li> </ul>	<ul style="list-style-type: none"> <li><i>n</i> word access(es)</li> </ul>







Figure 14-13. Summary of Aligned and Unaligned Accesses (32-Bit Bus)



F\_XL029A

Figure 14-14. Summary of Aligned and Unaligned Accesses (32-Bit Bus) (Continued)








Figure 14-15. Accesses Generated by Double Word Read Bus Request, Misaligned One Byte From Quad Word Boundary, 32-Bit Bus, Little Endian



**14.2.6 Byte Ordering and Bus Accesses**

The default byte-order for both instruction and data accesses is programmed in the DLMCON register to be either little- or big-endian. On the i960 Jx processor, DLMCON.be controls the default byte order for internal (on-chip data ram and data cache) accesses as well as external accesses. The programming of DLMCON is discussed in [section 13.6.2, “Selecting the Byte Order”](#) (pg. 13-12).

The processor handles the byte data type the same regardless of byte ordering. [Table 14-11](#) shows byte data 0xDD being transferred on 8, 16 and 32 bit buses.

For the short word data type, assume that a hexadecimal value of 0xCCDD is stored in one of the processor’s internal registers. [Table 14-10](#) shows how this short word is transferred on the bus to either a little endian or big endian memory region. Note that the short word goes out on different data lines on a 32-bit bus depending upon whether address line A1 is odd or even. In this example, the transfer is assumed to be aligned.

For the word data type, assume that a hexadecimal value of 0xAABBCCDD is stored in an internal processor register, where 0xAA is the word’s most significant byte and 0xDD is the least significant byte. [Table 14-9](#) shows how this word is transferred on the bus to an aligned address in either little endian or big endian memory.

The i960 Jx processor supports multi-word big endian data types with individual word accesses. Bytes in each word are stored in big-endian order; however, words are stored in little-endian order. Consider [Figure 14-16](#), which illustrates a double word store to big endian memory.

**Table 14-9. Byte Ordering on Bus Transfers, Word Data Type**

Word Data Type			Bus Pins (AD31:0)							
Bus Width	Addr Bits A1, A0	Xfer	Little Endian				Big Endian			
			31:24	23:16	15:8	7:0	31:24	23:16	15:8	7:0
32 bit	00	1st	AA	BB	CC	DD	DD	CC	BB	AA
16 bit	00	1st	--	--	CC	DD	--	--	BB	AA
	10	2nd	--	--	AA	BB	--	--	DD	CC
8 bit	00	1st	--	--	--	DD	--	--	--	AA
	01	2nd	--	--	--	CC	--	--	--	BB
	10	3rd	--	--	--	BB	--	--	--	CC
	11	4th	--	--	--	AA	--	--	--	DD



Table 14-10. Byte Ordering on Bus Transfers, Short-Word Data Type

Short-Word Data Type			Bus Pins (AD31:0)							
Bus Width	Addr Bits A1, A0	Xfer	Little Endian				Big Endian			
			31:24	23:16	15:8	7:0	31:24	23:16	15:8	7:0
32 bit	00	1st	--	--	CC	DD	--	--	DD	CC
	10	1st	CC	DD	--	--	DD	CC	--	--
16 bit	X0	1st	--	--	CC	DD	--	--	DD	CC
8 bit	X0	1st	--	--	--	DD	--	--	--	CC
	X1	2nd	--	--	--	CC	--	--	--	DD

Table 14-11. Byte Ordering on Bus Transfers, Byte Data Type

Byte Data Type			Bus Pins (AD31:0)			
Bus Width	Addr Bits A1, A0	Xfer	Little and Big Endian			
			31:24	23:16	15:8	7:0
32 bit	00	1st	--	--	--	DD
	01	1st	--	--	DD	--
	10	1st	--	DD	--	--
	11	1st	DD	--	--	--
16 bit	X0	1st	--	--	--	DD
	X1	1st	--	--	DD	--
8 bit	XX	1st	--	--	--	DD




Figure 14-16. Multi-Word Access to Big-Endian Memory Space

### 14.2.7 Atomic Bus Transactions

The atomic instructions, **atadd** and **atmod**, consist of a load and store request to the same memory location. Atomic instructions require indivisible, read-modify-write access to memory. That is, another bus agent must not access the target of the atomic instruction between read and write cycles. Atomic instructions are necessary to implement software semaphores.

For atomic bus accesses, the 80960Jx processor asserts the  $\overline{\text{LOCK}}$  pin during the first Ta of the read operation and deasserts  $\overline{\text{LOCK}}$  in the last data transfer of the write operation.  $\overline{\text{LOCK}}$  is deasserted at the same clock edge that  $\overline{\text{BLAST}}$  is asserted. The i960Jx processor does not assert  $\overline{\text{LOCK}}$  except while a read-modify-write operation is in progress. While  $\overline{\text{LOCK}}$  is asserted, the processor can perform other, non-atomic, accesses such as fetches. However, the 80960Jx processor will not acknowledge HOLD requests. This behavior is an enhancement over earlier i960 microprocessors. [Figure 14-17](#) illustrates locked read/write accesses associated with an atomic instruction.






Figure 14-17. The  $\overline{\text{LOCK}}$  Signal

### 14.2.8 Bus Arbitration

The i960 Jx processor can share the bus with other bus masters, using its built-in arbitration protocol. The protocol assumes two bus masters: a default bus master (typically the 80960Jx) that controls the bus and another that requests bus control when it performs an operation (e.g., a DMA controller). More than two bus masters may exist on the bus, but this configuration requires external arbitration logic

Three processor signal pins comprise the bus arbitration pin group.

### 14.2.8.1 HOLD/HOLDA Protocol

In most cases, the i960 Jx processor controls the bus; an I/O peripheral (e.g., a communications controller) requests bus control. The processor and I/O peripheral device exchange bus control with two signals, HOLD and HOLDA.

HOLD is an i960 Jx processor synchronous input signal which indicates that the alternate master needs the bus. HOLD may be asserted at any time so long as the transition meets the processors setup and hold requirements. HOLDA (hold acknowledge) is the processor's output which indicates surrender of the bus. When the i960 Jx processor asserts HOLDA, it enters the Th (hold) state (see [Figure 14.1](#)). If the last bus state was Ti or the last Tr of a bus transaction, the processor is guaranteed to assert HOLDA and float the bus on the same clock edge in which it recognizes HOLD. Similarly, the processor deasserts HOLDA on the same edge in which it recognizes the deassertion of HOLD. Thus, bus latency is no longer than it takes the processor to finish any bus access in progress.

If the bus is in hold and the 80960Jx needs to regain the bus to perform a transaction, the processor does not deassert HOLDA. In many cases, however, it will assert the BSTAT pin (see section [14.2.8.2, BSTAT Signal](#)).

Unaligned load and store bus requests are broken into multiple accesses and the processor can relinquish the bus between those transactions. When the alternate bus master gives control of the bus back to the 80960Jx, the processor will immediately enter a Ta state to continue those accesses and respond to any other bus requests. If no requests are pending, the processor will enter the idle state.

[Figure 14-18](#) illustrates a HOLD/HOLDA arbitration sequence.






Figure 14-18. Arbitration Timing Diagram for a Bus Master

The HOLD/HOLDA arbitration functions during processor reset. The bus controller acknowledges HOLD while  $\overline{\text{RESET}}$  is asserted because the bus is idle. If  $\overline{\text{RESET}}$  is asserted while HOLDA is asserted (the processor has acknowledged the HOLD), the processor remains in the HOLDA state. The processor does not continue reset activities until HOLD is removed and the processor removes HOLDA.

### 14.2.8.2 BSTAT Signal

The i960 Jx microprocessor extends the HOLD/HOLDA protocol with a bus status (BSTAT) signal. In simplest terms, assertion of the BSTAT output pin indicates that the CPU may soon stall unless it obtains (or retains) control of the bus. This indication is a useful input to arbitration logic, whether or not the 80960 Jx is the primary bus master.

The processor asserts BSTAT when one or more of the following conditions are true:

- The bus queue in the bus control unit (BCU) becomes full for any reason.
- An instruction fetch request is pending or being serviced on the bus. This behavior promotes performance by supporting instruction cache fills.

## EXTERNAL BUS

- A load request has been issued to the BCU. This behavior promotes performance by supporting early data loading.
- A special operation is underway that requires emptying the bus queue. Examples of such operations are execution of the HALT instruction and register stores that control logical or physical memory configuration.

The processor can assert BSTAT on any rising CLKIN edge. Although BSTAT activation suggests bus starvation, it does not necessarily imply that the processor definitely stall or that it is currently stalled.

When the 80960Jx is the primary bus master and asserts BSTAT, arbitration logic can work more intelligently to anticipate and prevent processor bus stalls. Depending on the importance of the alternate bus master's task, ownership of the bus can be modulated. If the bus is in hold, control can be relinquished back to the microprocessor immediately or after an optimal delay. Of course, BSTAT can be ignored completely if the loss in processor bandwidth can be tolerated.

When the 80960Jx is not the primary bus master, the BSTAT signal becomes the means to request the bus from the primary master. As described above, BSTAT will be activated for all loads and fetches, but store requests do not activate BSTAT unless they fill the bus queue. If the processor needs priority access to the bus to perform store operations, replace store instructions with the atomic modify (**atmod**) instruction, using a mask operand of all one's. **atmod** is a read-modify-write instruction, so the processor will assert BSTAT when the load transaction is posted to the bus queue. When the load begins, LOCK# is asserted, which blocks recognition of hold requests until the store portion of **atmod** completes.

### 14.3 BUS APPLICATIONS

The i960Jx microprocessor is a cost-effective building block for a wide spectrum of embedded systems. This section describes common interfaces for the 80960Jx to external memory and I/O devices.

#### 14.3.1 System Block Diagrams


Block diagrams in [Figure 14-19](#) through [Figure 14-21](#) are generalized diagrams with bus topologies representative of a number of potential 80960Jx systems. These diagrams do not represent any particular i960Jx processor-based applications.

In most i960Jx processor systems, the 80960Jx is the primary master of the local bus. A number of memory and I/O devices typically interface to the processor, either directly or through buffers and transceivers. An example of such a system might be a laser beam printer.






Systems with multiple I/O channels frequently use dual-ported memory to link several identical I/O devices to the local bus, as in [Figure 14-19](#). These systems are more complex, but performance and flexibility improve because bus traffic is partitioned away from the i960 Jx processor's local bus. An example of such a system might be a network hub.



**Figure 14-19. Generalized 80960Jx System with 80960 Local Bus**

A more elaborate system would connect the 80960Jx's bus to a backplane through bus interface logic as shown in [Figure 14-20](#). The backplane bus (or system bus) connects to multiple high performance I/O devices (often with DMA) and large buffer memory for caching packets of data from disk drives or LANs. Backplane buses can connect to other microprocessor local buses, too, creating a loosely coupled multiprocessor system for resource sharing.



**Figure 14-20. Generalized 80960Jx System with 80960 Local Bus and Backplane Bus**



Buses such as the PCI (Peripheral Component Interconnect) local bus connect to the 80960 bus through a bridge chip, which employs DMA, FIFOs and mailboxes for bus-to-bus communication. The PCI local bus can connect shared buffer memory and high performance I/O devices. The bandwidth of the PCI local bus is particularly appropriate for bridge interfacing to high-end processors such as the Pentium (R) microprocessor, as illustrated in Figure 14-21. In this way, the i960Jx can improve the performance of complex systems such as servers by sparing the main system CPU and its local memory the task of buffering low-level I/O.




Figure 14-21. 80960Jx System with 80960 Local Bus, PCI Local Bus and Local Bus for High End Microprocessor



### 14.3.1.1 Memory Subsystems

Memory systems for the i960 Jx processor include a mix of non-volatile and volatile devices including ROM, DRAM, SRAM or flash memory. The circuit designer may take advantage of programmable bus width to optimize the number of devices in each memory array. For example, the processor can boot from a single, slow, 8-bit ROM device, then execute from code loaded to a faster, wider and larger RAM array.

All systems must contain burstable memory, since the processor employs burst transactions for instruction fetches and stack operations. Bursting cannot be turned off on the i960Jx processor.

### 14.3.1.2 I/O Subsystems

I/O subsystems vary widely according to the needs of specific applications. Individual peripheral devices may be as generic as discrete logic I/O ports or as specialized as an ISDN controller.

Typical peripherals for desktop/server intelligent I/O applications are Small Computer System Interface controllers supporting SCSI-1 (8-bit) or SCSI-2 (8/16/32-bit) standards.

For network applications such as ATM adapters, smart hubs and routers, typical peripherals include controllers for older protocols such as Ethernet and FDDI and controllers for newer protocols such as ATM (Asynchronous Transfer Mode) and Fibre Channel.

Typical peripherals for non-impact printer controllers include printer video ports, engine command/status ports, asynchronous serial controllers, IEEE 1284 parallel ports, LocalTalk(TM) ports and PCMCIA memory card controllers.





15

## TEST FEATURES





## CHAPTER 15 TEST FEATURES

This chapter describes the i960<sup>®</sup> Jx processor's test features, including ONCE (On-Circuit Emulation) and Boundary Scan (JTAG). Together these two features create a powerful environment for design debug and fault diagnosis.

### 15.1 ON-CIRCUIT EMULATION (ONCE)

On-circuit emulation aids board-level testing. This feature allows a mounted i960 Jx processor to electrically “remove” itself from a circuit board. This allows for system-level testing where a remote tester exercises the processor system. In ONCE mode, the processor presents a high impedance on every pin, except for the JTAG Test Data Output (TDO). All pullup transistors present on input pins are also disabled and internal clocks stop. In this state the processor's power demands on the circuit board are nearly eliminated. Once the processor is electrically removed, a functional tester such as an In-Circuit Emulator (ICE) system can emulate the mounted processor and execute a test of the i960 Jx processor system.

#### 15.1.1 Entering/Exiting ONCE Mode

The i960 Jx processor uses the dual function  $\overline{\text{LOCK/ONCE}}$  pin for ONCE. The  $\overline{\text{LOCK/ONCE}}$  pin is an input while  $\overline{\text{RESET}}$  is asserted. The i960 Jx processor uses this pin as an output when the ONCE mode conditions are not present.

ONCE mode is entered by asserting (low) the  $\overline{\text{LOCK/ONCE}}$  pin while the processor is in the reset state, or by executing the HIGHZ JTAG private instruction. The  $\overline{\text{LOCK/ONCE}}$  pin state is latched on the  $\overline{\text{RESET}}$  signal's rising edge.

- To enter ONCE mode, an external tester drives the  $\overline{\text{ONCE}}$  pin low (overcoming the internal pull-up resistor) and initiates a reset cycle.
- To exit ONCE mode, perform a hard reset with the  $\overline{\text{ONCE}}$  pin deasserted (high) prior to the rising edge of  $\overline{\text{RESET}}$ . It is not necessary to cycle power when exiting ONCE mode.

For specific timing of the  $\overline{\text{LOCK/ONCE}}$  pin and the characteristics of the on-circuit emulation mode, see related documents in [section 1.4, “Related Documents”](#) (pg. 1-10).

## TEST FEATURES

### 15.2 BOUNDARY SCAN (JTAG)

The i960 Jx processor provides test features compatible with IEEE Standard Test Access Port and Boundary Scan Architecture (IEEE Std. 1149.1). JTAG ensures that components function correctly, connections between components are correct, and components interact correctly on the printed circuit board.

#### 15.2.1 Boundary Scan Architecture

Boundary scan test logic consists of a Boundary-Scan register and support logic. These are accessed through a Test Access Port (TAP). The TAP provides a simple serial interface that allows all processor signal pins to be driven and/or sampled, thereby providing the direct control and monitoring of processor pins at the system level.

This mode of operation is valuable for design debugging and fault diagnosis since it permits examination of connections not normally accessible to the test system. The following subsections describe the boundary scan test logic elements: TAP controller, Instruction register, Test Data registers and TAP elements.

##### 15.2.1.1 TAP Controller

The TAP controller is a 16 state machine, which provides the internal control signals to the instruction register and the test data registers. The state of the TAP controller is determined by the logic present on the Test Mode Select (TMS) pin on the rising edge of TCK. See [Figure 15-2](#) for the state diagram of the TAP controller.

##### 15.2.1.2 Instruction Register

The instruction register (IR) holds instruction codes shifted through the Test Data Input (TDI) pin. The instruction codes are used to select the specific test operation to be performed and the test data register to be accessed.

##### 15.2.1.3 Test Data Registers

The four test data registers are:

- Device ID register (see [section 15.3.2.1, “Device Identification Register”](#) (pg. 15-6)).
- Bypass register (see [section 15.3.2.2, “Bypass Register”](#) (pg. 15-6)).
- RUNBIST register (see [section 15.3.2.3, “RUNBIST Register”](#) (pg. 15-7)).
- Boundary-Scan register (see [section 15.3.2.4, “Boundary-Scan Register”](#) (pg. 15-7)).





15.2.1.4 TAP Elements

The Test Access Port (TAP) contains a TAP controller, an instruction register, a group of test data registers, and the TAP pins as shown in the block diagram in Figure 15-1. The TAP is the general-purpose port that provides access to the test data registers and instruction registers through the TAP controller.




Figure 15-1. Test Access Port Block Diagram






Figure 15-2. TAP Controller State Diagram



The i960 Jx processor’s TAP is composed of four input connections (TMS, TCK,  $\overline{\text{TRST}}$  and TDI) and one output connection (TDO). These pins are described in [Table 15-1](#).

**Table 15-1. TAP Controller Pin Definitions**

Pin Name	Mnemonic	Type	Definition
Test Clock	TCK	Input	Clock input for the TAP controller, the instruction register, and the test data registers. The JTAG unit will retain its state when TCK is stopped at “0” or “1”.
Test Mode Select	TMS	Input	Controls the operation of the TAP controller. The TMS input is pulled high when not being driven. TMS is sampled on the rising edge of TCK.
Test Data In	TDI	Input	Serial data input to the instruction and test data registers. Data at TDI is sampled on the rising edge of TCK. Like TMS, TDI is pulled high when not being driven. Data shifted from TDI through a register to TDO appears non-inverted at TDO.
Test Data Out	TDO	Output	Used for serial data output. Data at TDO is driven at the falling edge of TCK and provides an inactive (high-Z) state when scanning is not in progress. The non-shift inactive state is provided to support parallel connection of TDO outputs at the board or module level.
Asynchronous Reset	$\overline{\text{TRST}}$	Input	Provides asynchronous initialization of the test logic. $\overline{\text{TRST}}$ is pulled high when not being driven. Assertion of this pin puts the TAP controller in the Test_Logic_Reset (initial) state. For minimum pulse width specifications, see related documents in <a href="#">section 1.4, “Related Documents” (pg. 1-10)</a> .

### 15.3 TAP REGISTERS

The instruction and test data registers are separate shift-register paths connected in parallel. The TAP controller determines which one of these registers is connected between the TDI and TDO pins.

#### 15.3.1 Instruction Register (IR)

The Instruction Register (IR) is a parallel-loadable, master/slave-configured 4-bit wide, serial-shift register with latched outputs. Data is loaded into the IR serially through the TDI pin clocked by the rising edge of TCK when the TAP controller is in the Shift\_IR state. The shifted-in instruction becomes active upon latching from the master-stage to the slave-stage in the Update\_IR state. At that time the IR outputs along with the TAP finite state machine outputs are decoded to select and control the test data register selected by that instruction. Upon latching, all actions caused by any previous instructions must terminate.

The instruction determines the test to be performed, the test data register to be accessed, or both (see [Table 15-2](#)). The IR is four bits wide. When the IR is selected in the Shift\_IR state, the most significant bit is connected to TDI, and the least significant bit is connected to TDO. TDI is shifted into IR on each rising edge of TCK, as long as TMS remains asserted. When the processor enters



## TEST FEATURES

the Capture\_IR TAP controller state, fixed parallel data (0001<sub>2</sub>) is captured. During Shift\_IR, when a new instruction is shifted in through TDI, the value 0001<sub>2</sub> is always shifted out through TDO least significant bit first. This helps identify instructions in a long chain of serial data from several devices.

Upon activation of the  $\overline{\text{TRST}}$  reset pin, the latched instruction will asynchronously change to the **idcode** instruction. If the TAP controller moved into the Test\_Logic\_Reset state other than by reset activation, the opcode will change as TDI is shifted, and will become active on the falling edge of TCK. See [Figure 15-4](#) for an example of loading the instruction register.

### 15.3.2 TAP Test Data Registers

The i960 Jx processor contains a device identification register and three test data registers (Bypass, Boundary-Scan and RUNBIST). Each test data register selected by the TAP controller is connected serially between TDI and TDO. TDI is connected to the test data register's most significant bit. TDO is connected to the least significant bit. Data is shifted one bit position within the register towards TDO on each rising edge of TCK. The following sections describe each of the test data registers. See [Figure 15-5](#) for an example of loading the data register.

#### 15.3.2.1 Device Identification Register

The Device Identification register is a 32-bit register containing the manufacturer's identification code, part number code and version code in the format shown in [Figure 12-8](#) (pg. 12-22). The format of the register is discussed in [Section 12.4, DEVICE IDENTIFICATION ON RESET](#) (pg. 12-22). The identification register is selected only by the idcode instruction. When the TAP controller's Test\_Logic\_Reset state is entered, idcode is automatically loaded into the instruction register. The Device Identification register has a fixed parallel input value that is loaded in the Capture\_DR state. For specific device identification numbers, see [section 1.4, "Related Documents"](#) (pg. 1-10).

#### 15.3.2.2 Bypass Register

The required Bypass Register, a one-bit shift register, provides the shortest path between TDI and TDO when a **bypass** instruction is in effect. This allows rapid movement of test data to and from other components on the board. This path can be selected when no test operation is being performed. While the bypass register is selected, data is transferred from TDI to TDO without inversion.

Any instruction that does not make use of another test data register may select the Bypass register as its active TDI to TDO path.



### 15.3.2.3 RUNBIST Register

The RUNBIST register is a one-bit register that contains the result of the execution of the **runbist** instruction execution. The **runbist** instruction runs the built-in self-test (BIST) program resident inside the processor. After the built-in self-test completes, the processor must be recycled through the reset state to begin normal operation. See [section 12.2.2, “Self Test Function \(STEST, FAIL\)” \(pg. 12-6\)](#) for details of the Built-In-Self-Test algorithm.

### 15.3.2.4 Boundary-Scan Register

The Boundary-Scan register is a required set of serial-shiftable register cells, configured in master/slave stages and connected between each of the i960 Jx processor’s pins and on-chip system logic. Pins NOT in the Boundary-Scan chain are power, ground and JTAG pins.

The Boundary-Scan register cells are dedicated logic and do not have any system function. Data may be loaded into the Boundary-Scan register master-cells from the device input pins and output pin-drivers in parallel by the mandatory **sample/preload** and **extest** instructions. Parallel loading takes place on the rising edge of TCK in the Capture\_DR state.

Data may be scanned into the Boundary-Scan register serially via the TDI serial-input pin, clocked by the rising edge of TCK in the Shift\_DR state. When the required data has been loaded into the master-cell stages, it is driven into the system logic at input pins or onto the output pins on the falling edge of TCK in the Update\_DR state. Data may also be shifted out of the Boundary-Scan register by means of the TDO serial-output pin at the falling edge of TCK.

### 15.3.3 Boundary Scan Instruction Set

The i960 Jx processor supports three mandatory boundary scan instructions **bypass**, **sample/preload** and **extest**. The i960 Jx processor also contains two additional public instructions **idcode** and **runbist**. Table 15-2 lists the i960 Jx processor's boundary scan instruction codes.

Table 15-2. Boundary Scan Instruction Set

Instruction Code	Instruction Name	Instruction Code	Instruction Name
0000 <sub>2</sub>	<b>extest</b>	1000 <sub>2</sub>	private
0001 <sub>2</sub>	<b>sampre</b>	1001 <sub>2</sub>	not used
0010 <sub>2</sub>	<b>idcode</b>	1010 <sub>2</sub>	not used
0011 <sub>2</sub>	not used	1011 <sub>2</sub>	private
0100 <sub>2</sub>	private	1100 <sub>2</sub>	private
0101 <sub>2</sub>	not used	1101 <sub>2</sub>	not used
0110 <sub>2</sub>	not used	1110 <sub>2</sub>	not used
0111 <sub>2</sub>	<b>runbist</b>	1111 <sub>2</sub>	<b>bypass</b>

### 15.3.4 IEEE Required Instructions

Instruction / Requisite	Opcode	Description
<b>extest</b> IEEE 1149.1 Required	0000 <sub>2</sub>	<b>extest</b> initiates testing of external circuitry, typically board-level interconnects and off chip circuitry. <b>extest</b> connects the Boundary-Scan register between TDI and TDO in the Shift_IR state only. When <b>extest</b> is selected, all output signal pin values are driven by values shifted into the Boundary-Scan register and may change only on the falling-edge of TCK in the Update_DR state. Also, when <b>extest</b> is selected, all system input pin states must be loaded into the Boundary-Scan register on the rising-edge of TCK in the Capture_DR state. Values shifted into input latches in the Boundary-Scan register are never used by the processor's internal logic.
<b>sampre</b> IEEE 1149.1 Required	0001 <sub>2</sub>	<b>sample/preload</b> performs two functions: <ul style="list-style-type: none"> <li>When the TAP controller is in the Capture-DR state, the <b>sample</b> instruction occurs on the rising edge of TCK and provides a snapshot of the component's normal operation without interfering with that normal operation. The instruction causes Boundary-Scan register cells associated with outputs to sample the value being driven by or to the processor.</li> <li>When the TAP controller is in the Update-DR state, the <b>preload</b> instruction occurs on the falling edge of TCK. This instruction causes the transfer of data held in the Boundary-Scan cells to the slave register cells. Typically the slave latched data is then applied to the system outputs by means of the <b>extest</b> instruction.</li> </ul>



Instruction / Requisite	Opcode	Description
<b>idcode</b> IEEE 1149.1 Optional	0010 <sub>2</sub>	<p><b>idcode</b> is used in conjunction with the device identification register. It connects the identification register between TDI and TDO in the Shift_DR state. When selected, <b>idcode</b> parallel-loads the hard-wired identification code (32 bits) on TDO into the identification register on the rising edge of TCK in the Capture_DR state.</p> <p><b>NOTE:</b> The device identification register is not altered by data being shifted in on TDI.</p>
<b>bypass</b> IEEE 1149.1 Required	1111 <sub>2</sub>	<p><b>bypass</b> instruction selects the Bypass register between TDI and TDO pins while in SHIFT_DR state, effectively bypassing the processor's test logic. 0<sub>2</sub> is captured in the CAPTURE_DR state. This is the only instruction that accesses the Bypass register. While this instruction is in effect, all other test data registers have no effect on the operation of the system. Test data registers with both test and system functionality perform their system functions when this instruction is selected.</p>
<b>runbist</b> i960 Jx Processor Optional	0111 <sub>2</sub>	<p><b>runbist</b> selects the one-bit RUNBIST register, loads a value of 1 into it and connects it to TDO. It also initiates the processor's built-in self test (BIST) feature which is able to detect approximately 82% of the stuck-at faults on the device. The processor AC/DC specifications for V<sub>CC</sub> and CLKIN must be met and <b>RESET</b> must be de-asserted prior to executing <b>runbist</b>.</p> <p>After loading <b>runbist</b> instruction code into the instruction register, the TAP controller must be placed in the Run-Test/Idle state. <b>bist</b> begins on the first rising edge of TCK after the Run-Test/Idle state is entered. The TAP controller must remain in the Run-Test/Idle state until <b>bist</b> is completed. <b>runbist</b> requires approximately 414,000 core cycles to complete <b>bist</b> and report the result to the RUNBIST register's. The results are stored in bit 0 of the RUNBIST register. After the report completes, the value in the RUNBIST register is shifted out on TDO during the Shift-DR state. A value of 0 being shifted out on TDO indicates <b>bist</b> completed successfully. A value of 1 indicates a failure occurred. After <b>bist</b> completes, the processor must be recycled through the reset state to begin normal operation.</p>

### 15.3.5 TAP Controller

The TAP controller is a 16-state synchronous finite state machine that controls the sequence of test logic operations. The TAP can be controlled via a bus master. The bus master can be either automatic test equipment or a component (i.e. PLD) that interfaces to the Test Access Port (TAP). The TAP controller changes state only in response to a rising edge of TCK or power-up. The value of the test mode state (TMS) input signal at a rising edge of TCK controls the sequence of state changes. The TAP controller is automatically initialized on powerup. In addition, the TAP controller can be initialized by applying a high signal level on the TMS input for five TCK periods.

Behavior of the TAP controller and other test logic in each controller state is described in the following subsections. For greater detail on the state machine and the public instructions, refer to IEEE 1149.1 Standard Test Access Port and Boundary-Scan Architecture Document.



## TEST FEATURES

### 15.3.5.1 Test Logic Reset State

In this state, test logic is disabled to allow normal operation of the i960 Jx processor. Test logic is disabled by loading the IDCODE register. No matter what the state of the controller, it enters Test-Logic-Reset state when the TMS input is held high (1) for at least five rising edges of TCK. The controller remains in this state while TMS is high. The TAP controller is also forced to enter this state by enabling  $\overline{\text{TRST}}$ .

If the controller exits the Test-Logic-Reset controller states as a result of an erroneous low signal on the TMS line at the time of a rising edge on TCK (for example, a glitch due to external interference), it returns to the test logic reset state following three rising edges of TCK with the TMS line at the intended high logic level. Test logic operation is such that no disturbance is caused to on-chip system logic operation as the result of such an error.

### 15.3.5.2 Run-Test/Idle State

The TAP controller enters the Run-Test/Idle state between scan operations. The controller remains in this state as long as TMS is held low. In the Run-Test/Idle state the **runbist** instruction is performed; the result is reported in the RUNBIST register. Instructions that do not call functions generate no activity in the test logic while the controller is in this state. The instruction register and all test data registers retain their current state. When TMS is high on the rising edge of TCK, the controller moves to the Select-DR-Scan state.

### 15.3.5.3 Select-DR-Scan State

The Select-DR-Scan state is a temporary controller state. The test data registers selected by the current instruction retain their previous state. If TMS is held low on the rising edge of TCK when the controller is in this state, the controller moves into the Capture-DR state and a scan sequence for the selected test data register is initiated. If TMS is held high on the rising edge of TCK, the controller moves into the Select-IR-Scan state.

The instruction does not change while the TAP controller is in this state.

### 15.3.5.4 Capture-DR State

When the controller is in this state and the current instruction is **sample/preload**, the Boundary-Scan register captures input pin data on the rising edge of TCK. Test data registers that do not have parallel input are not changed. Also if the **sample/preload** instruction is not selected while in this state, the Boundary-Scan registers retain their previous state.

The instruction does not change while the TAP controller is in this state.





If TMS is high on the rising edge of TCK, the controller enters the Exit1-DR. If TMS is low on the rising edge of TCK, the controller enters the Shift-DR state.

#### 15.3.5.5 Shift-DR State

In this controller state, the test data register, which is connected between TDI and TDO as a result of the current instruction, shifts data one bit position nearer to its serial output on each rising edge of TCK. Test data registers that the current instruction selects but does not place in the serial path, retain their previous value during this state.

The instruction does not change while the TAP controller is in this state.

If TMS is high on the rising edge of TCK, the controller enters the Exit1-DR state. If TMS is low on the rising edge of TCK, the controller remains in the Shift-DR state.

#### 15.3.5.6 Exit1-DR State

This is a temporary controller state. When the TAP controller is in the Exit1-DR state and TMS is held high on the rising edge of TCK, the controller enters the Update-DR state, which terminates the scanning process. If TMS is held low on the rising edge of TCK, the controller enters the Pause-DR state.

The instruction does not change while the TAP controller is in this state. All test data registers selected by the current instruction retain their previous value during this state.

#### 15.3.5.7 Pause-DR State

The Pause-DR state allows the test controller to temporarily halt the shifting of data through the test data register in the serial path between TDI and TDO. The test data register selected by the current instruction retains its previous value during this state. The instruction does not change in this state.

The controller remains in this state as long as TMS is low. When TMS goes high on the rising edge of TCK, the controller moves to the Exit2-DR state.

#### 15.3.5.8 Exit2-DR State

This is a temporary state. If TMS is held high on the rising edge of TCK, the controller enters the Update-DR state, which terminates the scanning process. If TMS is held low on the rising edge of TCK, the controller enters the Shift-DR state.

The instruction does not change while the TAP controller is in this state. All test data registers selected by the current instruction retain their previous value during this state.

## TEST FEATURES

### 15.3.5.9 Update-DR State

The Boundary-Scan register is provided with a latched parallel output. This output prevents changes at the parallel output while data is shifted in response to the **extest**, **sample/preload** instructions. When the Boundary-Scan register is selected while the TAP controller is in the Update-DR state, data is latched onto the Boundary-Scan register's parallel output from the shift-register path on the falling edge of TCK. The data held at the latched parallel output does not change unless the controller is in this state.

While the TAP controller is in this state, all of the test data register's shift-register bit positions selected by the current instruction retain their previous values.

The instruction does not change while the TAP controller is in this state.

When the TAP controller is in this state and TMS is held high on the rising edge of TCK, the controller enters the Select-DR-Scan state. If TMS is held low on the rising edge of TCK, the controller enters the Run-Test/Idle state.

### 15.3.5.10 Select-IR Scan State

This is a temporary controller state. The test data registers selected by the current instruction retain their previous state. In this state, if TMS is held low on the rising edge of TCK, the controller moves into the Capture-IR state and a scan sequence for the instruction register is initiated. If TMS is held high on the rising edge of TCK, the controller moves to the Test-Logic-Reset state.

The instruction does not change in this state.

### 15.3.5.11 Capture-IR State

When the controller is in the Capture-IR state, the shift register contained in the instruction register loads the fixed value  $0001_2$  on the rising edge of TCK.

The test data register selected by the current instruction retains its previous value during this state. The instruction does not change in this state. While in this state, holding TMS high on the rising edge of TCK causes the controller to enter the Exit1-IR state. If TMS is held low on the rising edge of TCK, the controller enters the Shift-IR state.

### 15.3.5.12 Shift-IR State

When the controller is in this state, the shift register contained in the instruction register is connected between TDI and TDO and shifts data one bit position nearer to its serial output on each rising edge of TCK. The test data register selected by the current instruction retains its previous value during this state. The instruction does not change.



If TMS is held high on the rising edge of TCK, the controller enters the Exit1-IR state. If TMS is held low on the rising edge of TCK, the controller remains in the Shift-IR state.

#### 15.3.5.13 Exit1-IR State

This is a temporary state. If TMS is held high on the rising edge of TCK, the controller enters the Update-IR state, which terminates the scanning process. If TMS is held low on the rising edge of TCK, the controller enters the Pause-IR state.

The test data register selected by the current instruction retains its previous value during this state.

The instruction does not change and the instruction register retains its state.

#### 15.3.5.14 Pause-IR State

The Pause-IR state allows the test controller to temporarily halt the shifting of data through the instruction register. The test data registers selected by the current instruction retain their previous values during this state.

The instruction does not change and the instruction register retains its state.

The controller remains in this state as long as TMS is held low. When TMS goes high on the rising edges of TCK, the controller moves to the Exit2-IR state.

#### 15.3.5.15 Exit2-IR State

This is a temporary state. If TMS is held high on the rising edge of TCK, the controller enters the Update-IR state, which terminates the scanning process. If TMS is held low on the rising edge of TCK, the controller enters the Shift-IR state.

This test data register selected by the current instruction retains its previous value during this state. The instruction does not change and the instruction register retains its state.

#### 15.3.5.16 Update-IR State

The instruction shifted into the instruction register is latched onto the parallel output from the shift-register path on the falling edge of TCK. Once latched, the new instruction becomes the current instruction. Test data registers selected by the current instruction retain their previous values.

If TMS is held high on the rising edge of TCK, the controller enters the Select-DR-Scan state. If TMS is held low on the rising edge of TCK, the controller enters the Run-Test/Idle state.

## TEST FEATURES

### 15.3.6 Boundary-Scan Register

The Boundary-Scan register contains a cell for each pin as well as cells for control of I/O and HIGHZ pins.

Table 15-2 shows the bit order of the i960 Jx processor Boundary-Scan register. All table cells that contain “CTL” select the direction of bidirectional pins or HIGHZ output pins. If a “1” is loaded into the control cell, the associated pin(s) are HIGHZ or selected as input.

**Table 15-3. Boundary Scan Register Bit Order**

Bit	Signal	Input/Output	Bit	Signal	Input/Output	Bit	Signal	Input/Output
0	RDYRCV (TDI)	I	24	DEN	O	48	AD17	I/O
1	HOLD	I	25	HOLDA	O	49	AD16	I/O
2	XINT0	I	26	ALE	O	50	AD15	I/O
3	XINT1	I	27	LOCK/ONCE cell	Enable cell <sup>1</sup>	51	AD14	I/O
4	XINT2	I	28	LOCK/ONCE	I/O	52	AD13	I/O
5	XINT3	I	29	BSTAT	O	53	AD12	I/O
6	XINT4	I	30	BE0	O	54	AD cells	Enable cell <sup>1</sup>
7	XINT5	I	31	BE1	O	55	AD11	I/O
8	XINT6	I	32	BE2	O	56	AD10	I/O
9	XINT7	I	33	BE3	O	57	AD9	I/O
10	NMI	I	34	AD31	I/O	58	AD8	I/O
11	FAIL	I	35	AD30	I/O	59	AD7	I/O
12	ALE	O	36	AD29	I/O	60	AD6	I/O
13	WIDTH/HLTD1	1	37	AD28	I/O	61	AD5	I/O
14	WIDTH/HLTD0	1	38	AD27	I/O	62	AD4	I/O
15	A2	O	39	AD26	I/O	63	AD3	I/O
16	A3	O	40	AD25	I/O	64	AD2	I/O
17	CONTROL1	Enable cell <sup>1</sup>	41	AD24	I/O	65	AD1	I/O
18	CONTROL2	Enable cell <sup>1</sup>	42	AD23	I/O	66	AD0	I/O
19	BLAST	O	43	AD22	I/O	67	CLKIN	I
20	D/C	O	44	AD21	I/O	68	RESET	I
21	ADS	O	45	AD20	I/O	69	STEST (TDO)	I
22	W/R	O	46	AD19	I/O			
23	DT/R	O	47	AD18	I/O			

1. Enable cells are active low.



### 15.3.6.1 Example

In the example that follows, two command actions are described. The example starts in the reset state, a new instruction is loaded and executed. See [Figure 15-3](#) for a JTAG example. The steps are:

1. Load the **sample/preload** instruction into the Instruction Register:
  - 1.1. Select the Instruction register scan.
  - 1.2. Use the Shift-IR state four times to read the least through most significant instruction bits into the instruction register (we do not care that the old instruction is being shifted out of the TDO pin).
  - 1.3. Enter the Update-IR state to make the instruction take effect.
  - 1.4. Exit the Instruction register.
2. Capture and shift the data onto the TDO pin:
  - 2.1. Select the Data register scan state.
  - 2.2. Capture the pin information into the n-stage Boundary-Scan register.
  - 2.3. Enter and stay in the shift-DR state for n times while recording the TDO values as the inputs sampled. As the data sampled were shifting in the TDI was being read into the Boundary-Scan register. This could later be written the output pins.
  - 2.4. Pass through the Exit1-DR and Update-DR to continue.

This example does not make use of the pause states. Those states would be more useful where we do not control the clock directly. The pause states let the clock tick without affecting the shift registers.

The old instruction was *abcd* in the example. It is known that the original value will be the ID code since the example starts from the reset state. Other times it will represent the previous opcode. The new instruction opcode is  $0001_2$  (**sample/preload**). All pins are captured into the serial Boundary-Scan register and the values are output to the TDO pin.

The clock signal drawn at the top of the diagram is drawn as a stable symmetrical clock. This is not in practice the most common case. Instead the clocking is usually done by a program writing to a port bit. The TMS and TDI signals are written by software and then the software makes the clock go high. The software typically will often lower the clock input quickly. The program can then read the TDO pin.




Figure 15-3. JTAG Example






Figure 15-4. Timing diagram illustrating the loading of Instruction Register




Figure 15-5. Timing diagram illustrating the loading of Data Register

### 15.3.7 Boundary Scan Description Language Example

Boundary-Scan Description Language (BSDL) [Example 15-1](#) meets the de facto standard means of describing essential features of ANSI/IEEE 1149.1-1993 compliant devices.





## Example 15-1. Boundary Scan Description Language Example (Sheet 1 of 4)

```

-- i960@ Jx Processor BSDL Model

-- The following list describes all of the pins that are contained in the i960 Jx
-- microprocessor.

entity JX_Processor is
  generic(PHYSICAL_PIN_MAP : string := "PGA_14x14");
port(TDI          : in bit;
     RDYRCVBAR    : in bit;
     Reserved     : in bit;
     Reserved     : in bit;
     Reserved     : in bit;
     TRSTBAR      : in bit;
     TCK          : in bit;
     TMS          : in bit;
     HOLD         : in bit;
     XINTBARX     : in bit_vector(0 to 7);
     NMIBAR       : in bit;
     Reserved     : in bit;
     Reserved     : in bit;
     Reserved     : in bit;
     LODRVHIDRVBAR : out bit;
     FAILBAR      : out bit;
     ALEBAR       : out bit;
     TDO          : out bit;
     WIDTH        : out bit_vector(1 downto 0);
     A32          : out bit_vector(0 to 1);
     Reserved     : out bit;
     Reserved     : out bit;
     Reserved     : out bit;
     Reserved     : out bit;
     BLASTBAR     : out bit;
     DCBAR        : out bit;
     ADSBAR       : out bit;
     WRBAR        : out bit;
     DTRBAR       : out bit;
     DENBAR       : out bit;
     HOLDA        : out bit;
     ALE          : out bit;
     LOCKONCEBAR  : inout bit;
     BSTAT        : out bit;
     BEBAR        : out bit_vector(0 to 3);
     Reserved     : in bit;
     Reserved     : in bit;
     Reserved     : in bit;
     Reserved     : inout bit_vector(7 downto 0);
     AD           : inout bit_vector(31 downto 0);
     CLKIN        : in bit;
     Reserved     : in bit;
     Reserved     : in bit;
     Reserved     : in bit;
     RESETBAR     : in bit;
     Reserved     : in bit;
     STEST        : in bit;
     VCC          : linkage bit_vector(0 to 28);
     VSS          : linkage bit_vector(0 to 28);

```

**Example 15-1. Boundary Scan Description Language Example (Sheet 2 of 4)**

```

AVCC          : linkage bit;
NC            : linkage bit_vector(1 to 3));
use STD_1149_1_1990.all;
use i960JX_a.all;
--This list describes the physical pin layout of all signals
attribute PIN_MAP of JX_Processor : entity is PHYSICAL_PIN_MAP;
constant PGA_14x14 : PIN_MAP_STRING :=          -- Define PinOut of PGA
"TDI          : F16,"&
"RDYRCVBAR   : E15,"&
"TRSTBAR     : C17,"&
"TCK         : C16,"&
"TMS         : B17,"&
"HOLD        : C15,"&
"XINTBARX    : (B16, C14, B15, C13, B14, A15, A14, C12),"&
"NMIBAR      : B12,"&
"FAILBAR     : B09,"&
"ALEBAR      : C08,"&
"TDO         : C07,"&
"WIDTH       : (C06, B06),"&
"A32         : (A04, C05),"&
"BLASTBAR    : B03,"&
"DCBAR       : C02,"&
"ADSBAR      : C03,"&
"WRBAR       : B01,"&
"DTRBAR      : B02,"&
"DENBAR      : E03,"&
"HOLDA       : D02,"&
"ALE         : C01,"&
"LOCKONCEBAR : D01,"&
"BSTAT       : F03,"&
"BEBAR       : (E01, E02, G03, H03),"&
"AD          : (P03, R02, Q03, R03, S03, R04, S04, Q05, Q06, Q07,"&
"             Q08, R09, S09, Q09, Q10, Q11, Q12, S14, R14, Q13,"&
"             S15, R15, Q14, R16, Q15, R17, Q16, P15, Q17, P16,"&
"             M15, N15),"&
"CLKIN       : J17,"&
"RESETBAR    : G15,"&
"STEST       : F17,"&
"VCC         : (S13, S12, S11, S10, S08, S07, S06, S05, N17, M17," &
"             M01, L17, L01, K17, K01, J01, H17, H01, G17, G01," &
"             F01, E17, A13, A11, A10, A08, A07, A06, A05), " &
"VSS         : (R13, R12, R11, R10, R08, R07, R06, R05, N16, N02," &
"             M02, L16, L02, K16, K02, J16, J02, H16, H02, G16," &
"             G02, F02, E16, B13, B11, B10, B08, B07, B05)," &
"AVCC        : L15 ";
attribute Tap_Scan_In   of TDI   : signal is true;
attribute Tap_Scan_Mode of TMS   : signal is true;
attribute Tap_Scan_Out  of TDO   : signal is true;
attribute Tap_Scan_Reset of TRSTBAR : signal is true;
attribute Tap_Scan_Clock of TCK   : signal is (33.0e6, BOTH);
attribute Instruction_Length of JX_Processor: entity is 4;
attribute Instruction_Opcode of JX_Processor: entity is
"BYPASS (1111)," &
"EXTEST (0000)," &
"SAMPLE (0001)," &
"IDCODE (0010)," &

```

Example 15-1. Boundary Scan Description Language Example (Sheet 3 of 4)

```

"RUNBIST (0111)," &
"Reserved (1100, 1011)";
attribute Instruction_Capture of JX_Processor: entity is "0001";
-- there is no Instruction_Disable attribute for JX_Processor
attribute Instruction_Private of JX_Processor: entity is "Reserved" ;
--attribute Instruction_Usage of JX_Processor: entity is
-- "RUNBIST (registers Runbist;" &
-- "result 0;" &
-- "clock CLK in Run_Test_Idle;"&
-- "length 524288)";
-- attribute Idcode_Register of JX_Processor: entity is
-- "0000" & --version, A-step
-- "0000001010100001" & --part number
-- "0000001001" & --manufacturers identity
-- "1"; --required by the standard
-- attribute Idcode_Register of JX_Processor: entity is
-- "0010" & --version, B-step
-- "0000001010110001" & --part number B0primeprime
-- "0000001001" & --manufacturers identity
-- "1"; --required by the standard
attribute Idcode_Register of JX_Processor: entity is
"0000" & --version,
"1000100000100000" & --part number ??
"0000001001" & --manufacturers identity
"1"; --required by the standard
attribute Register_Access of JX_Processor: entity is
"Runbist[1] (RUNBIST)," &
"Bypass";
--{*****}
--{ The first cell, cell 0, is closest to TD0 }
--{ BC_4:Input BC_1: Output3, Bidirectional }
--{*****}
attribute Boundary_Cells of JX_Processor: entity is "CBSC_1, BC_1";
attribute Boundary_Length of JX_Processor: entity is 70;
attribute Boundary_Register of JX_Processor: entity is
"0 (BC_1, STEST, input, X)," &
"1 (BC_1, RESETBAR, input, X)," &
"2 (BC_1, CLKIN, input, X)," &
"3 (CBSC_1, AD(0), bidir, X, 15, 1, Z)," &
"4 (CBSC_1, AD(1), bidir, X, 15, 1, Z)," &
"5 (CBSC_1, AD(2), bidir, X, 15, 1, Z)," &
"6 (CBSC_1, AD(3), bidir, X, 15, 1, Z)," &
"7 (CBSC_1, AD(4), bidir, X, 15, 1, Z)," &
"8 (CBSC_1, AD(5), bidir, X, 15, 1, Z)," &
"9 (CBSC_1, AD(6), bidir, X, 15, 1, Z)," &
"10 (CBSC_1, AD(7), bidir, X, 15, 1, Z)," &
"11 (CBSC_1, AD(8), bidir, X, 15, 1, Z)," &
"12 (CBSC_1, AD(9), bidir, X, 15, 1, Z)," &
"13 (CBSC_1, AD(10), bidir, X, 15, 1, Z)," &
"14 (CBSC_1, AD(11), bidir, X, 15, 1, Z)," &
"15 (BC_1, *, control, 1)," &
"16 (CBSC_1, AD(12), bidir, X, 15, 1, Z)," &
"17 (CBSC_1, AD(13), bidir, X, 15, 1, Z)," &
"18 (CBSC_1, AD(14), bidir, X, 15, 1, Z)," &
"19 (CBSC_1, AD(15), bidir, X, 15, 1, Z)," &
"20 (CBSC_1, AD(16), bidir, X, 15, 1, Z)," &

```



**Example 15-1. Boundary Scan Description Language Example (Sheet 4 of 4)**

```

"21 (CBSC_1, AD(17), bidir, X, 15, 1, Z)," &
"22 (CBSC_1, AD(18), bidir, X, 15, 1, Z)," &
"23 (CBSC_1, AD(19), bidir, X, 15, 1, Z)," &
"24 (CBSC_1, AD(20), bidir, X, 15, 1, Z)," &
"25 (CBSC_1, AD(21), bidir, X, 15, 1, Z)," &
"26 (CBSC_1, AD(22), bidir, X, 15, 1, Z)," &
"27 (CBSC_1, AD(23), bidir, X, 15, 1, Z)," &
"28 (CBSC_1, AD(24), bidir, X, 15, 1, Z)," &
"29 (CBSC_1, AD(25), bidir, X, 15, 1, Z)," &
"30 (CBSC_1, AD(26), bidir, X, 15, 1, Z)," &
"31 (CBSC_1, AD(27), bidir, X, 15, 1, Z)," &
"32 (CBSC_1, AD(28), bidir, X, 15, 1, Z)," &
"33 (CBSC_1, AD(29), bidir, X, 15, 1, Z)," &
"34 (CBSC_1, AD(30), bidir, X, 15, 1, Z)," &
"35 (CBSC_1, AD(31), bidir, X, 15, 1, Z)," &
"36 (BC_1, BEBAR(3), output3, X, 51, 1, Z)," &
"37 (BC_1, BEBAR(2), output3, X, 51, 1, Z)," &
"38 (BC_1, BEBAR(1), output3, X, 51, 1, Z)," &
"39 (BC_1, BEBAR(0), output3, X, 51, 1, Z)," &
"40 (BC_1, BSTAT, output3, X, 52, 1, Z)," &
"41 (CBSC_1, LOCKONCEBAR, bidir, X, 42, 1, Z)," &
"42 (BC_1, *, control, 1)," &
"43 (BC_1, ALE, output3, X, 51, 1, Z)," &
"44 (BC_1, HOLDA, output3, X, 52, 1, Z)," &
"45 (BC_1, DENBAR, output3, X, 51, 1, Z)," &
"46 (BC_1, DTRBAR, output3, X, 51, 1, Z)," &
"47 (BC_1, WRBAR, output3, X, 51, 1, Z)," &
"48 (BC_1, ADSBAR, output3, X, 51, 1, Z)," &
"49 (BC_1, DCBAR, output3, X, 51, 1, Z)," &
"50 (BC_1, BLASTBAR, output3, X, 51, 1, Z)," &
"51 (BC_1, *, control, 1)," &
"52 (BC_1, *, control, 1)," &
"53 (BC_1, A32(1), output3, X, 51, 1, Z)," &
"54 (BC_1, A32(0), output3, X, 51, 1, Z)," &
"55 (BC_1, WIDTH(0), output3, X, 51, 1, Z)," &
"56 (BC_1, WIDTH(1), output3, X, 51, 1, Z)," &
"57 (BC_1, ALEBAR, output3, X, 51, 1, Z)," &
"58 (BC_1, FAILBAR, output3, X, 52, 1, Z)," &
"59 (BC_1, NMIBAR, input, X)," &
"60 (BC_1, XINTBARX(7), input, X)," &
"61 (BC_1, XINTBARX(6), input, X)," &
"62 (BC_1, XINTBARX(5), input, X)," &
"63 (BC_1, XINTBARX(4), input, X)," &
"64 (BC_1, XINTBARX(3), input, X)," &
"65 (BC_1, XINTBARX(2), input, X)," &
"66 (BC_1, XINTBARX(1), input, X)," &
"67 (BC_1, XINTBARX(0), input, X)," &
"68 (BC_1, HOLD, input, X)," &
"69 (BC_1, RDYRCVBAR, input, X)";
end JX_Processor;

```





A

# CONSIDERATIONS FOR WRITING PORTABLE CODE





This appendix describes the aspects of the microprocessor that are implementation-dependent. The following information is intended as a guide for writing application code that is directly portable to other i960<sup>®</sup> architecture implementations.

## A.1 CORE ARCHITECTURE

All i960 microprocessor family products are based on the core architecture definition. An i960 processor can be thought of as consisting of two parts: the core architecture implementation and implementation-specific features. The core architecture defines the following mechanisms and structure:

- Programming environment: global and local registers, literals, processor state registers, data types, memory addressing modes, etc.
- Implementation-independent instruction set.
- Procedure call mechanism.
- Mechanism for servicing interrupts and the interrupt and process priority structure.
- Mechanism for handling faults and the implementation-independent fault types and subtypes.

Implementation-specific features are one or all of:

- Additions to the instruction set beyond the instructions defined by the core architecture.
- Extensions to the register set beyond the global, local and processor-state registers that are defined by the core architecture.
- On-chip program or data memory.
- Integrated peripherals that implement features not defined explicitly by the core architecture.

Code is directly portable (object-code compatible) when it does not depend on implementation-specific instructions, mechanisms or registers. The aspects of this microprocessor that are implementation dependent are described below. Those aspects not described below are part of the core architecture.



## CONSIDERATIONS FOR WRITING PORTABLE CODE

### A.2 ADDRESS SPACE RESTRICTIONS

Address space properties that are implementation-specific to this microprocessor are described in the subsections that follow.

#### A.2.1 Reserved Memory

Addresses in the range FF00 0000H to FFFF FFFFH are reserved by the i960 architecture. The i960 Jx processor cannot access this memory, so any use of reserved memory by other i960 processor code is not portable to the i960 Jx processor.

#### A.2.2 Initialization Boot Record

The i960 Jx processor uses a section just below the reserved address space for the initialization boot record; see [section 12.3.1.1, “Initialization Boot Record \(IBR\)” \(pg. 12-13\)](#). This differs from the i960 Cx processor, which requires that user to place the Initialization Boot Record (IBR) in a section of reserved memory.

The initialization boot record may not exist or may be structured differently for other implementations of the i960 architecture.

#### A.2.3 Internal Data RAM

Internal data RAM — an i960 Jx processor implementation-specific feature — is mapped to the first 1 Kbytes of the processor’s address space (0000H – 03FFH). The on-chip data RAM may be used to cache interrupt vectors and may be protected against user and supervisor mode writes. Code that relies on these special features is not directly portable to all i960 processor implementations.

#### A.2.4 Instruction Cache

The i960 architecture allows instructions to be cached on-chip in a non-transparent fashion. This means that the cache may not detect modification of the program memory by loads, stores or alteration by external agents. Each implementation of the i960 architecture that uses an integrated instruction cache provides a mechanism to purge the cache or some other method that forces consistency between external memory and internal cache.

This feature is implementation dependent. Application code that supports modification of the code space must use this implementation-specific feature and, therefore, is not object-code portable to all i960 processor implementations.





The i960 JA processor has a 2-Kbyte instruction cache; the JF and JD have a 4-Kbyte instruction cache; the 80960JT has a 16-Kbyte instruction cache. The instruction cache is purged using the system control (**sysctl**) or instruction cache control (**icctl**) instruction. These instructions are not available on all i960 processors.

An **icctl** or **sysctl** instruction is issued with a configure-instruction-cache message type to select the load-and-lock mechanism. When the lock option is selected, the processor loads the cache starting at an address specified as an operand to the instruction.

The instruction cache supports locking code into half of the cache. The unlocked portion functions as a direct-mapped cache. Refer to [section 4.4, “INSTRUCTION CACHE” \(pg. 4-4\)](#) for a description of cache configuration.

The i960 JA processor has a 1-Kbyte data cache; the i960 JF and JD processors have a 2-Kbyte data cache and the 80960JT has a 4-Kbyte data cache. With respect to data accesses on a region-by-region basis, external memory is configured as either cacheable or non-cacheable. A bit in the memory region table entry defines whether or not data accesses are cacheable. This makes it very easy to partition a system into non-cacheable regions (for I/O or shared data in a multiprocessor system) and cacheable regions (local system memory) with no external hardware logic. To maintain data cache coherency, the i960 Jx processor implements a simple single processor coherency mechanism. Also, by software control, the data cache can be globally enabled, globally disabled or globally invalidated. A data access is either:

- Explicitly defined as cacheable or non-cacheable—through the memory region table
- Implicitly defined as non-cacheable—by the nature of the access; all atomic accesses (**atmod**, **atadd**) are implicitly defined as non-cacheable data accesses

The data cache indirectly supports unaligned accesses. Microcode execution breaks unaligned accesses into aligned accesses that are cacheable or non-cacheable according to the same rules as aligned accesses. An unaligned access could be only partially in the data cache and be a combination of hits and misses. The data cache supports both big-endian and little-endian data types.

### A.3 Data and Data Structure Alignment

The i960 architecture does not define how to handle loads and stores to non-aligned addresses. Therefore, code that generates non-aligned addresses may not be compatible with all i960 processor implementations. The i960 Jx processor automatically handles non-aligned load and store requests in microcode.

The address boundaries on which an operand begins can affect processor performance. Operands that span more word boundaries than necessary suffer a cost in speed due to extra bus cycles.

## CONSIDERATIONS FOR WRITING PORTABLE CODE

Alignment of architecturally defined data structures in memory is implementation dependent. See [section 3.4, “ARCHITECTURALLY DEFINED DATA STRUCTURES” \(pg. 3-11\)](#). Code that relies on specific alignment of data structures in memory is not portable to every i960 processor type.

Stack frames in the i960 architecture are aligned on  $(SALIGN*16)$ -byte boundaries, where SALIGN is an implementation-specific parameter. For the i960Jx processors, SALIGN = 1, so stack frames are aligned on 16-byte boundaries. The low-order N bits of the Frame Pointer are ignored and are always interpreted to be zero. The N parameter is defined by the following expression:  $SALIGN*16 = 2^N$ . Thus for the i960 Jx processors, N is 4.

### A.4 RESERVED LOCATIONS IN REGISTERS AND DATA STRUCTURES

Some register and data structure fields are defined as reserved locations. A reserved field may be used by future implementations of the i960 architecture. For portability and compatibility, code should initialize reserved locations to zero. When an implementation uses a reserved location, the implementation-specific feature is activated by a value of 1 in the reserved field. Setting the reserved locations to 0 guarantees that the features are disabled.

### A.5 INSTRUCTION SET

The i960 architecture defines a comprehensive instruction set. Code that uses only the architecturally-defined instruction set is object-level portable to other implementations of the i960 architecture. Some implementations may favor a particular code ordering to optimize performance. This special ordering, however, is never required by an implementation. The following subsections describe implementation-dependent instruction set properties.

#### A.5.1 Instruction Timing

An objective of the i960 architecture is to allow micro-architectural advances to translate directly into increased performance. The architecture does not restrict parallel or out-of-order instruction execution, nor does it define the time required to execute any instruction or function. Code that depends on instruction execution times, therefore, is not portable to all i960 processor architecture implementations.



## A.5.2 Implementation-Specific Instructions

A

Most of the processor's instruction set is defined by the core architecture. Several instructions are specific to the i960 Jx processor. These instructions are either functional extensions to the instruction set or instructions that control implementation-specific functions. [CHAPTER 6, INSTRUCTION SET REFERENCE](#) denotes each implementation-specific instruction.

- **dcctl** Data cache control
- **icctl** Instruction cache control
- **intctl** Interrupt control
- **halt** Halt CPU
- **inten** Global interrupt enable
- **intdis** Global interrupt disable
- **sysctl** System control

Application code using implementation-specific instructions is not directly portable to the entire i960 processor family. Attempted execution of an unimplemented instruction results in an OPERATION.INVALID\_OPCODE fault.

The i960 Jx and Hx processors introduce several new core instructions. These instructions may or may not be supported on other i960 processors. The new core instructions include:

- **ADD<cc>** Conditional add
- **bswap** Byte swap
- **COMPARE** Byte and short compares
- **eshro** Extended shift right ordinal
- **SEL<cc>** Conditional select
- **SUB<cc>** Conditional subtract

## A.6 EXTENDED REGISTER SET

The i960 architecture defines a way to address an extended set of 32 registers in addition to the 16 global and 16 local registers. Some or all of these registers may be implemented on a specific i960 processor. There are no extended registers implemented on the i960 Jx processors.

## A.7 INITIALIZATION

The i960 architecture does not define an initialization mechanism. The way that an i960-based product is initialized is implementation dependent. Code that accesses locations in initialization data structures is not portable to other i960 processor implementations.

The i960 Jx processors use an initialization boot record (IBR) and a process control block (PRCB) to hold initial configuration and a first instruction pointer.

## CONSIDERATIONS FOR WRITING PORTABLE CODE

### A.8 MEMORY CONFIGURATION

The i960 Jx processors employ Physical Memory Control (PMCON) and Logical Memory Control (LMCON) registers to control bus width, byte order and the data cache. This capability is analogous to the MCON register scheme employed by the i960 Cx processor. Memory configurations, like the bus control unit, are implementation specific.

### A.9 INTERRUPTS

The i960 architecture defines the interrupt servicing mechanism. This includes priority definition, interrupt table structure and interrupt context switching that occurs when an interrupt is serviced. The core architecture does not define the means for requesting interrupts (external pins, software, etc.) or for posting interrupts (i.e., saving pending interrupts).

The method for requesting interrupts depends on the implementation. The i960 Jx processors have an interrupt controller that manages nine external interrupt pins. The organization of these pins and the registers of the interrupt controller are implementation specific. Code that configures the interrupt controller is not directly portable to other i960 implementations.

On the i960Jx processors, interrupts may also be requested in software with the **sysctl** instruction. This instruction and the software request mechanism are implementation specific.

Posting interrupts is also implementation specific. Different implementations may optimize interrupt posting according to interrupt type and interrupt controller configuration. A pending priorities and pending interrupts field is provided in the interrupt table for interrupt posting. However, the i960 Jx processors post hardware-requested interrupts internally in the IPND register instead. Code that requests interrupts by setting bits in the pending priorities and pending interrupts field of the interrupt table is not portable. Also, application code that expects interrupts to be posted in the interrupt table is not object-code portable to all i960-based products.

The i960 Jx processors do not store a resumption record for suspended instructions in the interrupt or fault record. Portable programs must tolerate interrupt stack frames with and without these resumption records.

### A.10 OTHER i960 Jx PROCESSOR IMPLEMENTATION-SPECIFIC FEATURES

Subsections that follow describe additional implementation-specific features of the i960 Jx processors. These features do not relate directly to application code portability.



### A.10.1 Data Control Peripheral Units

**A**

The bus controller and interrupt controller are implementation-specific extensions to the core architecture. Operation, setup and control of these units is not a part of the core architecture. Other implementations of the i960 architecture are free to augment or modify such system integration features.

### A.10.2 Timers

The i960 Jx processor contains two 32-bit timers that are implementation-specific extensions to the i960 architecture. Code involving operation, setup and control of the timers may or may not be directly portable to other i960 processors.

### A.10.3 Fault Implementation

The architecture defines a subset of fault types and subtypes that apply to all implementations of the architecture. Other fault types and subtypes may be defined by implementations to detect errant conditions that relate to implementation-specific features. For example, the i960 Jx microprocessor provides an OPERATION.UNALIGNED fault for detecting non-aligned memory accesses. Future i960 processor implementations that generate this fault are expected to assign the same fault type and subtype numbers to the fault.

## A.11 BREAKPOINTS

Breakpoint registers are not defined in the i960 architecture. The i960 Jx processor implements two instruction and two data breakpoint registers.





# B

## OPCODES AND EXECUTION TIMES









# APPENDIX B OPCODES AND EXECUTION TIMES



## B.1 INSTRUCTION REFERENCE BY OPCODE

This section lists the instruction encoding for each i960® Jx processor instruction. Instructions are grouped by instruction format and listed by opcode within each format.

Table B-1. Miscellaneous Instruction Encoding Bits

M3	M2	M1	S2	S1	T	Description
<b>REG Format</b>						
x	x	0	x	0	—	<i>src1</i> is a global or local register
x	x	1	x	0	—	<i>src1</i> is a literal
x	x	0	x	1	—	reserved
x	x	1	x	1	—	reserved
x	0	x	0	x	—	<i>src2</i> is a global or local register
x	1	x	0	x	—	<i>src2</i> is a literal
x	0	x	1	x	—	reserved
x	1	x	1	x	—	reserved
0	x	x	x	x	—	<i>src/dst</i> is a global or local register
1	x	x	x	x	—	reserved
<b>COBR Format</b>						
—	—	0	0	—	x	<i>src1</i> , <i>src2</i> and <i>dst</i> are global or local registers
—	—	1	0	—	x	<i>src1</i> is a literal, <i>src2</i> and <i>dst</i> are global or local registers
—	—	0	1	—	x	reserved
—	—	1	1	—	x	reserved





Table B-2. REG Format Instruction Encodings (Sheet 1 of 4)

Opcode	Mnemonic	Cycles to Execute	Opcode (11 - 4)		Mode			Opcode (3-0)		Special Flags		src1
			src/dst	src2	13	12	11	10 ... 7	6	5	4 ... 0	
58:0	<b>notbit</b>	1	0101 1000	dst	src	M3	M2	M1	0000	S2	S1	bitpos
58:1	<b>and</b>	1	0101 1000	dst	src2	M3	M2	M1	0001	S2	S1	src1
58:2	<b>andnot</b>	1	0101 1000	dst	src2	M3	M2	M1	0010	S2	S1	src1
58:3	<b>setbit</b>	1	0101 1000	dst	src	M3	M2	M1	0011	S2	S1	bitpos
58:4	<b>notand</b>	1	0101 1000	dst	src2	M3	M2	M1	0100	S2	S1	src1
58:6	<b>xor</b>	1	0101 1000	dst	src2	M3	M2	M1	0110	S2	S1	src1
58:7	<b>or</b>	1	0101 1000	dst	src2	M3	M2	M1	0111	S2	S1	src1
58:8	<b>nor</b>	1	0101 1000	dst	src2	M3	M2	M1	1000	S2	S1	src1
58:9	<b>xnor</b>	1	0101 1000	dst	src2	M3	M2	M1	1001	S2	S1	src1
58:A	<b>not</b>	1	0101 1000	dst		M3	M2	M1	1010	S2	S1	src
58:B	<b>ornot</b>	1	0101 1000	dst	src2	M3	M2	M1	1011	S2	S1	src1
58:C	<b>clrbt</b>	1	0101 1000	dst	src	M3	M2	M1	1100	S2	S1	bitpos
58:D	<b>notor</b>	1	0101 1000	dst	src2	M3	M2	M1	1101	S2	S1	src1
58:E	<b>nand</b>	1	0101 1000	dst	src2	M3	M2	M1	1110	S2	S1	src1
58:F	<b>alterbit</b>	1	0101 1000	dst	src	M3	M2	M1	1111	S2	S1	bitpos
59:0	<b>addo</b>	1	0101 1001	dst	src2	M3	M2	M1	0000	S2	S1	src1
59:1	<b>addi</b>	1	0101 1001	dst	src2	M3	M2	M1	0001	S2	S1	src1
59:2	<b>subo</b>	1	0101 1001	dst	src2	M3	M2	M1	0010	S2	S1	src1
59:3	<b>subi</b>	1	0101 1001	dst	src2	M3	M2	M1	0011	S2	S1	src1
59:4	<b>cmpob</b>	1	0101 1001		src2	M3	M2	M1	0100	S2	S1	src1
59:5	<b>cmpib</b>	1	0101 1001		src2	M3	M2	M1	0101	S2	S1	src1
59:6	<b>cmpos</b>	1	0101 1001		src2	M3	M2	M1	0110	S2	S1	src1
59:7	<b>cmpis</b>	1	0101 1001		src2	M3	M2	M1	0111	S2	S1	src1
59:8	<b>shro</b>	1	0101 1001	dst	src	M3	M2	M1	1000	S2	S1	len
59:A	<b>shrdi</b>	6	0101 1001	dst	src	M3	M2	M1	1010	S2	S1	len
59:B	<b>shri</b>	1	0101 1001	dst	src	M3	M2	M1	1011	S2	S1	len
59:C	<b>shlo</b>	1	0101 1001	dst	src	M3	M2	M1	1100	S2	S1	len
59:D	<b>rotate</b>	1	0101 1001	dst	src	M3	M2	M1	1101	S2	S1	len
59:E	<b>shli</b>	1	0101 1001	dst	src	M3	M2	M1	1110	S2	S1	len
5A:0	<b>cmpo</b>	1	0101 1010		src2	M3	M2	M1	0000	S2	S1	src1
5A:1	<b>cmpi</b>	1	0101 1010		src2	M3	M2	M1	0001	S2	S1	src1

1. Execution time based on function performed by instruction.



Table B-2. REG Format Instruction Encodings (Sheet 2 of 4)

Opcode	Mnemonic	Cycles to Execute	Opcode (11 - 4)	src/dst	src2	Mode			Special Flags		src1	
						13	12	11	10 ...7	6		5
5A:2	<b>concmpo</b>	1	0101 1010		src2	M3	M2	M1	0010	S2	S1	src1
5A:3	<b>concmpi</b>	1	0101 1010		src2	M3	M2	M1	0011	S2	S1	src1
5A:4	<b>cmpinco</b>	1	0101 1010	dst	src2	M3	M2	M1	0100	S2	S1	src1
5A:5	<b>cmpinci</b>	1	0101 1010	dst	src2	M3	M2	M1	0101	S2	S1	src1
5A:6	<b>cmpdeco</b>	1	0101 1010	dst	src2	M3	M2	M1	0110	S2	S1	src1
5A:7	<b>cmpdeci</b>	1	0101 1010	dst	src2	M3	M2	M1	0111	S2	S1	src1
5A:C	<b>scanbyte</b>	1	0101 1010		src2	M3	M2	M1	1100	S2	S1	src1
5A:D	<b>bswap</b>	7	0101 1010	dst		M3	M2	M1	1101	S2	S1	src1
5A:E	<b>chkbit</b>	1	0101 1010		src	M3	M2	M1	1110	S2	S1	bitpos
5B:0	<b>addc</b>	1	0101 1011	dst	src2	M3	M2	M1	0000	S2	S1	src1
5B:2	<b>subc</b>	1	0101 1011	dst	src2	M3	M2	M1	0010	S2	S1	src1
5B:4	<b>intdis</b>	1	0101 1011			M3	M2	M1	0100	S2	S1	
5B:5	<b>inten</b>	1	0101 1011			M3	M2	M1	0101	S2	S1	
5C:C	<b>mov</b>	1	0101 1100	dst		M3	M2	M1	1100	S2	S1	src
5D:8	<b>eshro</b>	11	0101 1101	dst	src2	M3	M2	M1	1000	S2	S1	src1
5D:C	<b>movl</b>	4	0101 1101	dst		M3	M2	M1	1100	S2	S1	src
5E:C	<b>movt</b>	5	0101 1110	dst		M3	M2	M1	1100	S2	S1	src
5F:C	<b>movq</b>	6	0101 1111	dst		M3	M2	M1	1100	S2	S1	src
61:0	<b>atmod</b>	24	0110 0010	dst	src2	M3	M2	M1	0000	S2	S1	src1
61:2	<b>atadd</b>	24	0110 0010	dst	src2	M3	M2	M1	0010	S2	S1	src1
64:0	<b>spanbit</b>	6	0110 0100	dst		M3	M2	M1	0000	S2	S1	src
64:1	<b>scanbit</b>	5	0110 0100	dst		M3	M2	M1	0001	S2	S1	src
64:5	<b>modac</b>	10	0110 0100	mask	dst	M3	M2	M1	0101	S2	S1	mask
65:0	<b>modify</b>	6	0110 0101	src/dst	src	M3	M2	M1	0000	S2	S1	mask
65:1	<b>extract</b>	7	0110 0101	src/dst	len	M3	M2	M1	0001	S2	S1	bitpos
65:4	<b>modtc</b>	10	0110 0101	mask	src	M3	M2	M1	0100	S2	S1	dst
65:5	<b>modpc</b>	17	0110 0101	src/dst	dst	M3	M2	M1	0101	S2	S1	mask
65:8	<b>intctl</b>	12-16	0110 0101	dst		M3	M2	M1	1000	S2	S1	src1
65:9	<b>sysctl</b>	10-100 <sup>1</sup>	0110 0101	src/dst	src2	M3	M2	M1	1001	S2	S1	src1
65:B	<b>icctl</b>	10-100 <sup>1</sup>	0110 0101	src/dst	src2	M3	M2	M1	1011	S2	S1	src1
65:C	<b>dcctl</b>	10-100 <sup>1</sup>	0110 0101	src/dst	src2	M3	M2	M1	1100	S2	S1	src1

1. Execution time based on function performed by instruction.





Table B-2. REG Format Instruction Encodings (Sheet 3 of 4)

Opcode	Mnemonic	Cycles to Execute	Opcode (11 - 4)	src/dst	src2	Mode			Opcode (3-0)		Special Flags		src1
						13	12	11	10 ... 7	6	5	4 ... 0	
65:D	<b>halt</b>	∞	0110 0101			M3	M2	M1	1101	S2	S1	src1	
66:0	<b>calls</b>	30	0110 0110			M3	M2	M1	0000	S2	S1	src	
66:B	<b>mark</b>	8	0110 0110			M3	M2	M1	1011	S2	S1		
66:C	<b>fmark</b>	8	0110 0110			M3	M2	M1	1100	S2	S1		
66:D	<b>flushreg</b>	15	0110 0110			M3	M2	M1	1101	S2	S1		
66:F	<b>syncf</b>	4	0110 0110			M3	M2	M1	1111	S2	S1		
67:0	<b>emul</b>	7	0110 0111	dst	src2	M3	M2	M1	0000	S2	S1	src1	
67:1	<b>ediv</b>	40	0110 0111	dst	src2	M3	M2	M1	0001	S2	S1	src1	
70:1	<b>mulo</b>	2-4	0111 0000	dst	src2	M3	M2	M1	0001	S2	S1	src1	
70:8	<b>remo</b>	40	0111 0000	dst	src2	M3	M2	M1	1000	S2	S1	src1	
70:B	<b>divo</b>	40	0111 0000	dst	src2	M3	M2	M1	1011	S2	S1	src1	
74:1	<b>muli</b>	2-4	0111 0100	dst	src2	M3	M2	M1	0001	S2	S1	src1	
74:8	<b>remi</b>	40	0111 0100	dst	src2	M3	M2	M1	1000	S2	S1	src1	
74:9	<b>modi</b>	40	0111 0100	dst	src2	M3	M2	M1	1001	S2	S1	src1	
74:B	<b>divi</b>	38	0111 0100	dst	src2	M3	M2	M1	1011	S2	S1	src1	
78:0	<b>addono</b>	1	0111 1000	dst	src2	M3	M2	M1	0000	S2	S1	src1	
78:1	<b>addino</b>	1	0111 1000	dst	src2	M3	M2	M1	0001	S2	S1	src1	
78:2	<b>subono</b>	1	0111 1000	dst	src2	M3	M2	M1	0010	S2	S1	src1	
78:3	<b>subino</b>	1	0111 1000	dst	src2	M3	M2	M1	0011	S2	S1	src1	
78:4	<b>selno</b>	1	0111 1000	dst	src2	M3	M2	M1	0100	S2	S1	src1	
79:0	<b>addog</b>	1	0111 1001	dst	src2	M3	M2	M1	0000	S2	S1	src1	
79:1	<b>addig</b>	1	0111 1001	dst	src2	M3	M2	M1	0001	S2	S1	src1	
79:2	<b>subog</b>	1	0111 1001	dst	src2	M3	M2	M1	0010	S2	S1	src1	
79:3	<b>subig</b>	1	0111 1001	dst	src2	M3	M2	M1	0011	S2	S1	src1	
79:4	<b>selg</b>	1	0111 1001	dst	src2	M3	M2	M1	0100	S2	S1	src1	
7A:0	<b>addoe</b>	1	0111 1010	dst	src2	M3	M2	M1	0000	S2	S1	src1	
7A:1	<b>addie</b>	1	0111 1010	dst	src2	M3	M2	M1	0001	S2	S1	src1	
7A:2	<b>suboe</b>	1	0111 1010	dst	src2	M3	M2	M1	0010	S2	S1	src1	
7A:3	<b>subie</b>	1	0111 1010	dst	src2	M3	M2	M1	0011	S2	S1	src1	
7A:4	<b>sele</b>	1	0111 1010	dst	src2	M3	M2	M1	0100	S2	S1	src1	
7B:0	<b>addoge</b>	1	0111 1011	dst	src2	M3	M2	M1	0000	S2	S1	src1	

1. Execution time based on function performed by instruction.



Table B-2. REG Format Instruction Encodings (Sheet 4 of 4)

Opcode	Mnemonic	Cycles to Execute	Opcode (11 - 4)	src/dst	src2	Mode			Special Flags		src1	
						13	12	11	10 ...7	6		5
7B:1	<b>addige</b>	1	0111 1011	dst	src2	M3	M2	M1	0001	S2	S1	src1
7B:2	<b>suboge</b>	1	0111 1011	dst	src2	M3	M2	M1	0010	S2	S1	src1
7B:3	<b>subige</b>	1	0111 1011	dst	src2	M3	M2	M1	0011	S2	S1	src1
7B:4	<b>selge</b>	1	0111 1011	dst	src2	M3	M2	M1	0100	S2	S1	src1
7C:0	<b>addol</b>	1	0111 1100	dst	src2	M3	M2	M1	0000	S2	S1	src1
7C:1	<b>addil</b>	1	0111 1100	dst	src2	M3	M2	M1	0001	S2	S1	src1
7C:2	<b>subol</b>	1	0111 1100	dst	src2	M3	M2	M1	0010	S2	S1	src1
7C:3	<b>subil</b>	1	0111 1100	dst	src2	M3	M2	M1	0011	S2	S1	src1
7C:4	<b>sell</b>	1	0111 1100	dst	src2	M3	M2	M1	0100	S2	S1	src1
7D:0	<b>addone</b>	1	0111 1101	dst	src2	M3	M2	M1	0000	S2	S1	src1
7D:1	<b>addine</b>	1	0111 1101	dst	src2	M3	M2	M1	0001	S2	S1	src1
7D:2	<b>subone</b>	1	0111 1101	dst	src2	M3	M2	M1	0010	S2	S1	src1
7D:3	<b>subine</b>	1	0111 1101	dst	src2	M3	M2	M1	0011	S2	S1	src1
7D:4	<b>selne</b>	1	0111 1101	dst	src2	M3	M2	M1	0100	S2	S1	src1
7E:0	<b>addole</b>	1	0111 1110	dst	src2	M3	M2	M1	0000	S2	S1	src1
7E:1	<b>addile</b>	1	0111 1110	dst	src2	M3	M2	M1	0001	S2	S1	src1
7E:2	<b>subole</b>	1	0111 1110	dst	src2	M3	M2	M1	0010	S2	S1	src1
7E:3	<b>subile</b>	1	0111 1110	dst	src2	M3	M2	M1	0011	S2	S1	src1
7E:4	<b>selle</b>	1	0111 1110	dst	src2	M3	M2	M1	0100	S2	S1	src1
7F:0	<b>addoo</b>	1	0111 1111	dst	src2	M3	M2	M1	0000	S2	S1	src1
7F:1	<b>addio</b>	1	0111 1111	dst	src2	M3	M2	M1	0001	S2	S1	src1
7F:2	<b>suboo</b>	1	0111 1111	dst	src2	M3	M2	M1	0010	S2	S1	src1
7F:3	<b>subio</b>	1	0111 1111	dst	src2	M3	M2	M1	0011	S2	S1	src1
7F:4	<b>sello</b>	1	0111 1111	dst	src2	M3	M2	M1	0100	S2	S1	src1

1. Execution time based on function performed by instruction.





Table B-3. COBR Format Instruction Encodings

Opcode	Mnemonic	Cycles to Execute	Opcode	src1	src2	M	Displacement	T	S2
			31 ..... 24	23 . 19	18... 14	13	12 ..... 2	1	0
20	<b>testno</b>	4	0010 0000	<i>dst</i>		M1		T	S2
21	<b>testg</b>	4	0010 0001	<i>dst</i>		M1		T	S2
22	<b>teste</b>	4	0010 0010	<i>dst</i>		M1		T	S2
23	<b>testge</b>	4	0010 0011	<i>dst</i>		M1		T	S2
24	<b>testl</b>	4	0010 0100	<i>dst</i>		M1		T	S2
25	<b>testne</b>	4	0010 0101	<i>dst</i>		M1		T	S2
26	<b>testle</b>	4	0010 0110	<i>dst</i>		M1		T	S2
27	<b>testo</b>	4	0010 0111	<i>dst</i>		M1		T	S2
30	<b>bbc</b>	2 + 1 <sup>1</sup>	0011 0000	<i>bitpos</i>	<i>src</i>	M1	<i>targ</i>	T	S2
31	<b>cmpobg</b>	2 + 1	0011 0001	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
32	<b>cmpobe</b>	2 + 1	0011 0010	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
33	<b>cmpobge</b>	2 + 1	0011 0011	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
34	<b>cmpobl</b>	2 + 1	0011 0100	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
35	<b>cmpobne</b>	2 + 1	0011 0101	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
36	<b>cmpoble</b>	2 + 1	0011 0110	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
37	<b>bbs</b>	2 + 1	0011 0111	<i>bitpos</i>	<i>src</i>	M1	<i>targ</i>	T	S2
38	<b>cmpibno</b>	2 + 1	0011 1000	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
39	<b>cmpibg</b>	2 + 1	0011 1001	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
3A	<b>cmpibe</b>	2 + 1	0011 1010	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
3B	<b>cmpibge</b>	2 + 1	0011 1011	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
3C	<b>cmpibl</b>	2 + 1	0011 1100	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
3D	<b>cmpibne</b>	2 + 1	0011 1101	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
3E	<b>cmpible</b>	2 + 1	0011 1110	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2
3F	<b>cmpibo</b>	2 + 1	0011 1111	<i>src1</i>	<i>src2</i>	M1	<i>targ</i>	T	S2

1. Indicates that it takes 2 cycles to execute the instruction plus an additional cycle to fetch the target instruction if the branch is taken.



Table B-4. CTRL Format Instruction Encodings

Opcode	Mnemonic	Cycles to Execute	Opcode	displacement	T	0
			31.....24	23.....2	1	0
08	<b>b</b>	1 + 1 <sup>1</sup>	0000 1000	<i>targ</i>	T	0
09	<b>call</b>	7	0000 1001	<i>targ</i>	T	0
0A	<b>ret</b>	6	0000 1010		T	0
0B	<b>bal</b>	1 + 1	0000 1011	<i>targ</i>	T	0
10	<b>bnob</b>	1 + 1	0001 0000	<i>targ</i>	T	0
11	<b>bg</b>	1 + 1	0001 0001	<i>targ</i>	T	0
12	<b>be</b>	1 + 1	0001 0010	<i>targ</i>	T	0
13	<b>bge</b>	1 + 1	0001 0011	<i>targ</i>	T	0
14	<b>bl</b>	1 + 1	0001 0100	<i>targ</i>	T	0
15	<b>bne</b>	1 + 1	0001 0101	<i>targ</i>	T	0
16	<b>ble</b>	1 + 1	0001 0110	<i>targ</i>	T	0
17	<b>bo</b>	1 + 1	0001 0111	<i>targ</i>	T	0
18	<b>faultno</b>	13	0001 1000		T	0
19	<b>faultg</b>	13	0001 1001		T	0
1A	<b>faulte</b>	13	0001 1010		T	0
1B	<b>faultge</b>	13	0001 1011		T	0
1C	<b>faultl</b>	13	0001 1100		T	0
1D	<b>faultne</b>	13	0001 1101		T	0
1E	<b>faultle</b>	13	0001 1110		T	0
1F	<b>faulto</b>	13	0001 1111		T	0

**B**

1. Indicates that it takes 1 cycle to execute the instruction plus an additional cycle to fetch the target instruction if the branch is taken.

Table B-5. Cycle Counts for sysctl Operations

Operation	Cycles to Execute
Post Interrupt	20
Purge I-cache	19
Enable I-cache	20
Disable I-cache	22
Software Reset	329+bus
Load Control Register Group	26
Request Breakpoint Resource	21-22





**Table B-6. Cycle Counts for icctl Operations**

Operation	Cycles to Execute
Disable I-cache	18
Enable I-cache	16
Invalidate I-cache	18
Load and Lock I-cache	5193
I-cache Status Request	21
I-cache Locking Status	20

**Table B-7. Cycle Counts for dcctl Operations**

Operation	Cycles to Execute
Disable D-cache	18
Enable D-cache	18
Invalidate D-cache	19
Load and Lock D-cache	19
D-cache Status Request	16
Quick Invalidate D-cache	14

**Table B-8. Cycle Counts for intctl Operations**

Operation	Cycles to Execute
Disable Interrupts	13
Enable Interrupts	13
Interrupt Status Request	8





Table B-9. MEM Format Instruction Encodings

31 .....24	23 ...19	18 .....14	13..... 12	11.....0		
<b>Opcode</b>	<b>src/dst</b>	<b>ABASE</b>	<b>Mode</b>	<b>Offset</b>		
31 .....24	23 ...19	18 .....14	13..... 12..11 ..... 10	9..... 7	6.. 5	4 ..... 0
<b>Opcode</b>	<b>src/dst</b>	<b>ABASE</b>	<b>Mode</b>	<b>Scale</b>	<b>00</b>	<b>Index</b>
<b>Displacement</b>						



**Effective Address**

<i>efa</i> =	offset	<i>opcode</i>	<i>dst</i>		0	0			<i>offset</i>
	offset( <i>reg</i> )	<i>opcode</i>	<i>dst</i>	<i>reg</i>	1	0			<i>offset</i>
	( <i>reg</i> )	<i>opcode</i>	<i>dst</i>	<i>reg</i>	0	1	0	0	00
	<i>disp</i> + 8 (IP)	<i>opcode</i>	<i>dst</i>		0	1	0	1	00
		<i>displacement</i>							
	( <i>reg1</i> )[ <i>reg2</i> * <i>scale</i> ]	<i>opcode</i>	<i>dst</i>	<i>reg1</i>	0	1	1	1	<i>scale</i> 00 <i>reg2</i>
	<i>disp</i>	<i>opcode</i>	<i>dst</i>		1	1	0	0	00
		<i>displacement</i>							
	<i>disp</i> ( <i>reg</i> )	<i>opcode</i>	<i>dst</i>	<i>reg</i>	1	1	0	1	00
		<i>displacement</i>							
	<i>disp</i> [ <i>reg</i> * <i>scale</i> ]	<i>opcode</i>	<i>dst</i>		1	1	1	0	<i>scale</i> 00 <i>reg</i>
		<i>displacement</i>							
	<i>disp</i> ( <i>reg1</i> )[ <i>reg2</i> * <i>scale</i> ]	<i>opcode</i>	<i>dst</i>	<i>reg1</i>	1	1	1	1	<i>scale</i> 00 <i>reg2</i>
		<i>displacement</i>							

Opcode	Mnemonic	Cycles to Execute	Opcode	Mnemonic	Cycles to Execute
80	<b>ldob</b>	(See Note 1.)	9A	<b>stl</b>	(See Note 1.)
82	<b>stob</b>	(See Note 1.)	A0	<b>ldt</b>	(See Note 1.)
84	<b>bx</b>	4-7	A2	<b>stt</b>	(See Note 1.)
85	<b>balx</b>	5-8			
86	<b>callx</b>	9-12	B0	<b>ldq</b>	(See Note 1.)
88	<b>ldos</b>	(See Note 1.)	B2	<b>stq</b>	(See Note 1.)
8A	<b>stos</b>	(See Note 1.)	C0	<b>ldib</b>	(See Note 1.)
8C	<b>lda</b>	(See Note 1.)	C2	<b>stib</b>	(See Note 1.)
90	<b>ld</b>	(See Note 1.)	C8	<b>ldis</b>	(See Note 1.)
92	<b>st</b>	(See Note 1.)	CA	<b>stis</b>	(See Note 1.)
98	<b>ldl</b>	(See Note 1.)			

1. The number of cycles required to execute these instructions is based on the addressing mode used (see Table B-10).





**Table B-10. Addressing Mode Performance**

Mode	Assembler Syntax	Memory Format	Number of Instruction words	Cycles to Execute
Absolute Offset	exp	MEMA	1	1
Absolute Displacement	exp	MEMB	2	2
Register Indirect	(reg)	MEMB	1	1
Register Indirect with Offset	exp(reg)	MEMA	1	1
Register Indirect with Displacement	exp(reg)	MEMB	2	2
Index with Displacement	exp[reg*scale]	MEMB	2	2
Register Indirect with Index	(reg)[reg*scale]	MEMB	1	6
Register Indirect with Index + Displacement	exp(reg)[reg*scale]	MEMB	2	6
Instruction Pointer with Displacement	exp(IP)	MEMB	2	6





C

MACHINE-LEVEL  
INSTRUCTION FORMATS






## APPENDIX C MACHINE-LEVEL INSTRUCTION FORMATS

This appendix describes the encoding format for instructions used by the i960<sup>®</sup> processors. Included is a description of the four instruction formats and how the addressing modes relate to these formats. Refer also to [APPENDIX B, OPCODES AND EXECUTION TIMES](#).



### C.1 GENERAL INSTRUCTION FORMAT

The i960 architecture defines four basic instruction encoding formats: REG, COBR, CTRL and MEM (see [Figure C-1](#)). Each instruction uses one of these formats, which is defined by the instruction's opcode field. All instructions are one word long and begin on word boundaries. MEM format instructions are encoded in one of two sub-formats: MEMA or MEMB. MEMB supports an optional second word to hold a displacement value. The following sections describe each format's instruction word fields.



**Figure C-1. Instruction Formats**





**Table C-1. Instruction Field Descriptions**

Instruction Field	Description
Opcode	The opcode of the instruction. Opcode encodings are defined in <a href="#">section 6.1.8, “Opcode and Instruction Format”</a> (pg. 6-6).
<i>src1</i>	An input to the instruction. This field specifies a value or address. In one case of the COBR format, this field is used to specify a register in which a result is stored.
<i>src2</i>	An input to the instruction. This field specifies a value or address.
<i>src/dst</i>	Depending on the instruction, this field can be (1) an input value or address, (2) the register where the result is stored, or (3) both of the above.
abase	A register whose register’s value is used in computing a memory address.
INDEX	A register whose register’s value is used in computing a memory address.
<i>displacement</i>	A signed two’s complement number.
Offset	An unsigned positive number.
Optional Displacement	A signed two’s complement number used in the two-word MEMB format.
MODE	A specification of how a memory address for an operand is computed and, for MEMB, specifies whether the instruction contains a second word to be used as a displacement.
SCALE	A specification of how a register’s contents are multiplied for certain addressing modes (i.e., for indexing).
M1, M2, M3	These fields further define the meaning of the SRC 1, SRC 2, and <i>src/dst</i> fields respectively as shown in <a href="#">and Table C-3</a> .

When a particular instruction is defined as not using a particular field, the field is ignored.

**C.2 REG FORMAT**

REG format is used for operations performed on data contained in registers. Most of the i960 processor family’s instructions use this format.

The opcode for the REG instructions is 12 bits long (three hexadecimal digits) and is split between bits 7 through 10 and bits 24 through 31. For example, the **addi** opcode is 591H. Here, bits 24 through 31 contain 59H and bits 7 through 10 contain 1H.

*src1* and *src2* fields specify the instruction’s source operands. Operands can be global or local registers or literals. Mode bits (M1 for *src1* and M2 for *src2*) and the instruction type determine what an operand specifies. [Table C-2](#) shows this relationship.



**Table C-2. Encoding of *src1* and *src2* in REG Format**

M1 or M2	Src1 or Src2 Operand Value	Register Number	Literal Value
0	00000 ... 01111	r0 ... r15	NA
	10000 ... 11111	g0 ... g15	NA
1	00000 ... 11111	NA	0 ... 31



The *src/dst* field can specify a source operand, a destination operand or both, depending on the instruction. Here again, mode bit M3 determines how this field is used. If M3 is clear, the *src/dst* operand is a global or local register that is encoded as shown in [Table C-3](#).

When a literal is specified, it is always an unsigned 5-bit value that is zero-extended to a 32-bit value and used as the operand. When the instruction defines an operand to be larger than 32 bits, values specified by literals are zero-extended to the operand size.

**Table C-3. Encoding of *src/dst* in REG Format**

M3	<i>src/dst</i>	<i>src Only</i>	<i>dst Only</i>
0	g0 ... g15	g0 ... g15	g0 ... g15
	r0 ... r15	r0 ... r15	r0 ... r15
1	Reserved	Reserved	Reserved

### C.3 COBR FORMAT

The COBR format is used primarily for compare-and-branch instructions. The test-if instructions also use the COBR format. The COBR opcode field is eight bits (two hexadecimal digits).

The *src1* and *src2* fields specify source operands for the instruction. The *src1* field can specify either a global or local register or a literal as determined by mode bit M1. The *src2* field can only specify a global or local register. [Table C-4](#) shows the M1, *src1* relationship and [Table C-4](#) shows the S2, *src2* relationship:

**Table C-4. Encoding of *src1* in COBR Format**

M1	<i>src1</i>
0	g0 ... g15 r0 ... r15
1	Literal



Table C-5. Encoding of *src2* in COBR Format

<b>S2</b>	<b><i>src2</i></b>
0	g0 ... g15 r0 ... r15
1	reserved

The *displacement* field contains a signed two's complement number that specifies a word displacement. The processor uses this value to compute the address of a target instruction to which the processor branches as a result of the comparison. The displacement field's value can range from  $-2^{10}$  to  $2^{10} - 1$ . To determine the target instruction's IP, the processor converts the displacement value to a word displacement (i.e., multiplies the value by 4). It then adds the resulting word displacement to the IP of the current instruction.

#### C.4 CTRL FORMAT

The CTRL format is used for instructions that branch to a new IP, including the **BRANCH<cc>**, **bal**, **ret** and **call** instructions. Note that **balx**, **bx** and **callx** do not use this format. The CTRL opcode field is eight bits (two hexadecimal digits).

A branch target address is specified with the displacement field in the same manner as COBR format instructions. The displacement field specifies a word displacement as a signed, two's complement number in the range  $-2^{21}$  to  $2^{21} - 1$ . The processor ignores the **ret** instruction's displacement field.

#### C.5 MEM FORMAT

The MEM format is used for instructions that require a memory address to be computed. These instructions include the **LOAD**, **STORE** and **lda** instructions. Also, the extended versions of the branch, branch-and-link and call instructions (**bx**, **balx** and **callx**) use this format.

The two MEM-format encodings are MEMA and MEMB. MEMB can optionally add a 32-bit displacement (contained in a second word) to the instruction. Bit 12 of the instruction's first word determines whether MEMA (clear) or MEMB (set) is used.

The opcode field is eight bits long for either encoding. The *src/dst* field specifies a global or local register. For load instructions, *src/dst* specifies the destination register for a word loaded into the processor from memory or, for operands larger than one word, the first of successive destination registers. For store instructions, this field specifies the register or group of registers that contain the source operand to be stored in memory.





The mode field determines the address mode used for the instruction. Table C-6 summarizes the addressing modes for the two MEM-format encodings. Fields used in these addressing modes are described in the following sections.

**Table C-6. Addressing Modes for MEM Format Instructions**

Format	MODE	Addressing Mode	Address Computation	# of Instr Words
MEMA	00	Absolute Offset	offset	1
	10	Register Indirect with Offset	(abase) + offset	1
MEMB	0100	Register Indirect	(abase)	1
	0101	IP with Displacement	(IP) + displacement + 8	2
	0110	Reserved	reserved	NA
	0111	Register Indirect with Index	(abase) + (index) * 2 <sup>scale</sup>	1
	1100	Absolute Displacement	displacement	2
	1101	Register Indirect with Displacement	(abase) + displacement	2
	1110	Index with Displacement	(index) * 2 <sup>scale</sup> + displacement	2
1111	Register Indirect with Index and Displacement	(abase) + (index) * 2 <sup>scale</sup> + displacement	2	



**NOTE:**

In these address computations, a field in parentheses indicates that the value in the specified register is used in the computation.

Usage of a reserved encoding may cause generation of an OPERATION.INVALID\_OPCODE fault.

**C.5.1 MEMA Format Addressing**

The MEMA format provides two addressing modes:

- Absolute offset
- Register indirect with offset

The *offset* field specifies an unsigned byte offset from 0 to 4096. The *abase* field specifies a global or local register that contains an address in memory.

For the absolute-offset addressing mode (MODE = 00), the processor interprets the *offset* field as an offset from byte 0 of the current process address space; the *abase* field is ignored. Using this addressing mode along with the **lda** instruction allows a constant in the range 0 to 4096 to be loaded into a register.





For the register-indirect-with-offset addressing mode (MODE = 10), *offset* field value is added to the address in the abase register. Clearing the offset value creates a register indirect addressing mode; however, this operation can generally be carried out faster by using the MEMB version of this addressing mode.

**C.5.2 MEMB Format Addressing**

The MEMB format provides the following seven addressing modes:

- absolute displacement
- register indirect
- register indirect with displacement
- register indirect with displacement
- register indirect with index and displacement
- index with displacement
- IP with displacement

The abase and index fields specify local or global registers, the contents of which are used in address computation. When the index field is used in an addressing mode, the processor automatically scales the index register value by the amount specified in the SCALE field. Table C-7 gives the encoding of the scale field. The optional displacement field is contained in the word following the instruction word. The displacement is a 32-bit signed two’s complement value.

**Table C-7. Encoding of Scale Field**

Scale	Scale Factor (Multiplier)
000	1
001	2
010	4
011	8
100	16
101 to 111	Reserved

**NOTE:**  
Usage of a reserved encoding causes an unpredictable result.

For the IP with displacement mode, the value of the displacement field plus eight is added to the address of the current instruction.





D

# REGISTER AND DATA STRUCTURES





## APPENDIX D REGISTER AND DATA STRUCTURES

This appendix is a compilation of all register and data structure figures described throughout the manual. Following each figure is a reference that indicates the section that discusses the figure.

**Table D-1. Register and Data Structures (Sheet 1 of 2)**



Fig.	Register / Data Structure	Where Defined in the manual	Page
D-1	AC (Arithmetic Controls) Register	Section 3.7.2, "Arithmetic Controls (AC) Register" (pg. 3-18)	D-3
D-2	PC (Process Controls) Register	Section 3.7.3, "Process Controls (PC) Register" (pg. 3-21)	D-4
D-3	Procedure Stack Structure and Local Registers	Section 7.1.1, "Local Registers and the Procedure Stack" (pg. 7-2)	D-5
D-4	System Procedure Table	Section 7.5.1, "System Procedure Table" (pg. 7-15)	D-6
D-5	PFP (Previous Frame Pointer) Register (r0)	Section 7.8, "RETURNS" (pg. 7-20)	D-7
D-6	Fault Table and Fault Table Entries	Section 8.3, "FAULT TABLE" (pg. 8-4)	D-8
D-7	Fault Record	Section 8.5, "FAULT RECORD" (pg. 8-6)	D-9
D-8	TC (Trace Controls) Register	Section 9.1.1, "Trace Controls (TC) Register" (pg. 9-2)	D-10
D-9	BPCON (Breakpoint Control) Register	section 9.2.7.4, "Breakpoint Control Register" (pg. 9-7)	D-10
D-10	DAB (Data Address Breakpoint) Register Format	Section 9.2.7.5, "Data Address Breakpoint (DAB) Registers" (pg. 9-9)	D-11
D-11	IPB (Instruction Breakpoint) Register Format	Section 9.2.7.6, "Instruction Breakpoint (IPB) Registers" (pg. 9-10)	D-11
D-12	TMR0-1 (Timer Mode Register)	Section 10.1.1, "Timer Mode Registers (TMR0, TMR1)" (pg. 10-3)	D-12
D-13	TCR0-1 (Timer Count Register)	Section 10.1.2, "Timer Count Register (TCR0, TCR1)" (pg. 10-6)	D-12
D-14	TRR0-1 (Timer Reload Register)	Section 10.1.3, "Timer Reload Register (TRR0, TRR1)" (pg. 10-7)	D-13
D-15	Interrupt Table	Section 11.4, "INTERRUPT TABLE" (pg. 11-4)	D-14
D-16	Storage of an Interrupt Record on the Interrupt Stack	Section 11.5, "INTERRUPT STACK AND INTERRUPT RECORD" (pg. 11-7)	D-15
D-17	ICON (Interrupt Control) Register	Section 11.7.4, "Interrupt Control Register (ICON)" (pg. 11-22)	D-16
D-18	IMAP0-IMAP2 (Interrupt Mapping) Registers	Section 11.7.5, "Interrupt Mapping Registers (IMAP0-IMAP2)" (pg. 11-23)	D-17
D-19	IMSK (Interrupt Mask) Registers	Section 11.7.5.1, "Interrupt Mask (IMSK) and Interrupt Pending (IPND) Registers" (pg. 11-25)	D-18
D-20	Interrupt Pending (IPND) Register	Section 11.7.5.1, "Interrupt Mask (IMSK) and Interrupt Pending (IPND) Registers" (pg. 11-25)	D-19
D-21	Initial Memory Image (IMI) and Process Control Block (PRCB)	Section 12.3.1, "Initial Memory Image (IMI)" (pg. 12-10)	D-20




**Table D-1. Register and Data Structures (Sheet 2 of 2)**

<b>Fig.</b>	<b>Register / Data Structure</b>	<b>Where Defined in the manual</b>	<b>Page</b>
D-22	Process Control Block Configuration Words	Section 12.3.1.2, "Process Control Block (PRCB)" (pg. 12-16)	D-21
D-23	Control Table	Section 12.3.3, "Control Table" (pg. 12-20)	D-22
D-24	IEEE 1149.1 Device Identification Register	Section 12.4, "DEVICE IDENTIFICATION ON RESET" (pg. 12-22)	D-23
D-25	PMCON Register Bit Description	Section 13.3, "Programming the Physical Memory Attributes (PMCON Registers)" (pg. 13-4)	D-23
D-26	BCON (Bus Control) Register	Section 13.4.1, "Bus Control (BCON) Register" (pg. 13-6)	D-24
D-27	DLMCON (Default Logical Memory Configuration) Register	Section 13.6, "Programming the Logical Memory Attributes" (pg. 13-8)	D-24
D-28	LMADR0:1 Logical Memory Template Starting Address Registers	Section 13.6, "Programming the Logical Memory Attributes" (pg. 13-8)	D-25
D-29	LMMR0:1 (Logical Memory Mask Registers)	Section 13.6, "Programming the Logical Memory Attributes" (pg. 13-8)	D-25



D.1 REGISTERS



D

Figure D-1. AC (Arithmetic Controls) Register

Section 3.7.2, "Arithmetic Controls (AC) Register" (pg. 3-18)






Figure D-2. PC (Process Controls) Register

Section 3.7.3, "Process Controls (PC) Register" (pg. 3-21)









Figure D-3. Procedure Stack Structure and Local Registers

Section 7.1.1, "Local Registers and the Procedure Stack" (pg. 7-2)






**Figure D-4. System Procedure Table**

Section 7.5.1, "System Procedure Table" (pg. 7-15)






**D**

**Figure D-5. PFP (Previous Frame Pointer) Register (r0)**

Section 7.8, "RETURNS" (pg. 7-20)






**Figure D-6. Fault Table and Fault Table Entries**

Section 8.3, "FAULT TABLE" (pg. 8-4)






**D**

**Figure D-7. Fault Record**


Section 8.5.1, "Fault Record Description" (pg. 8-7)





**Figure D-8. TC (Trace Controls) Register**


Section 9.1.1.1, "Trace Controls (TC) Register" (pg. 9-2)



**Figure D-9. BPCON (Breakpoint Control) Register**

Section 9.2.7.4, "Breakpoint Control Register" (pg. 9-7)






**D**

**Figure D-10. DAB (Data Address Breakpoint) Register Format**


Section 9.2.7.5, “Data Address Breakpoint (DAB) Registers” (pg. 9-9)



**Figure D-11. IPB (Instruction Breakpoint) Register Format**


Section 9.2.7.6, “Instruction Breakpoint (IPB) Registers” (pg. 9-10)





**Figure D-12. TMR0-1 (Timer Mode Register)**

Section 10.1.1, "Timer Mode Registers (TMR0, TMR1)" (pg. 10-3)




**Figure D-13. TCR0-1 (Timer Count Register)**

Section 10.1.2, "Timer Count Register (TCR0, TCR1)" (pg. 10-6)







**Figure D-14. TRR0-1 (Timer Reload Register)**

Section 10.1.3, "Timer Reload Register (TRR0, TRR1)" (pg. 10-7)







Figure D-15. Interrupt Table

Section 11.4, "INTERRUPT TABLE" (pg. 11-4)





**D**

**Figure D-16. Storage of an Interrupt Record on the Interrupt Stack**

Section 11.5, "INTERRUPT STACK AND INTERRUPT RECORD" (pg. 11-7)






Figure D-17. ICON (Interrupt Control) Register

Section 11.7.4, "Interrupt Control Register (ICON)" (pg. 11-22)









Figure D-19. IMSK (Interrupt Mask) Registers

Section 11.7.5.1, "Interrupt Mask (IMSK) and Interrupt Pending (IPND) Registers" (pg. 11-25)






**D**

**Figure D-20. Interrupt Pending (IPND) Register**

Section 11.7.5.1, "Interrupt Mask (IMSK) and Interrupt Pending (IPND) Registers" (pg. 11-25)






**Figure D-21. Initial Memory Image (IMI) and Process Control Block (PRCB)**

Section 12.3.1, "Initial Memory Image (IMI)" (pg. 12-10)





**D**



**Figure D-22. Process Control Block Configuration Words**


Section 12.3.1.2, "Process Control Block (PRCB)" (pg. 12-16)

31		0
	Reserved (Initialize to 0)	00H
	Reserved (Initialize to 0)	04H
	Reserved (Initialize to 0)	08H
	Reserved (Initialize to 0)	0CH
	Interrupt Map 0 (IMAP0)	10H
	Interrupt Map 1 (IMAP1)	14H
	Interrupt Map 2 (IMAP2)	18H
	Interrupt Configuration (ICON)	1CH
	Physical Memory Region 0:1 Configuration (PMCON0_1)	20H
	Reserved (Initialize to 0)	24H
	Physical Memory Region 2:3 Configuration (PMCON2_3)	28H
	Reserved (Initialize to 0)	2CH
	Physical Memory Region 4:5 Configuration (PMCON4_5)	30H
	Reserved (Initialize to 0)	34H
	Physical Memory Region 6:7 Configuration (PMCON6_7)	38H
	Reserved (Initialize to 0)	3CH
	Physical Memory Region 8:9 Configuration (PMCON8_9)	40H
	Reserved (Initialize to 0)	44H
	Physical Memory Region 10:11 Configuration (PMCON10_11)	48H
	Reserved (Initialize to 0)	4CH
	Physical Memory Region 12:13 Configuration (PMCON12_13)	50H
	Reserved (Initialize to 0)	54H
	Physical Memory Region 14:15 Configuration (PMCON14_15)	58H
	Reserved (Initialize to 0)	5CH
	Reserved (Initialize to 0)	60H
	Reserved (Initialize to 0)	64H
	Trace Controls (TC)	68H
	Bus Configuration Control (BCON)	6CH

**Figure D-23. Control Table**

Section 12.3.3, "Control Table" (pg. 12-20)






**D**

**Figure D-24. IEEE 1149.1 Device Identification Register**

Section 12.4, "DEVICE IDENTIFICATION ON RESET" (pg. 12-22)



**Figure D-25. PMCON Register Bit Description**

Section 13.1.1, "Physical Memory Attributes" (pg. 13-1)






Figure D-26. BCON (Bus Control) Register

Section 13.4.1, “Bus Control (BCON) Register” (pg. 13-6)






Figure D-27. DLMCON (Default Logical Memory Configuration) Register

Section 13.6, “Programming the Logical Memory Attributes” (pg. 13-8)



**D****Figure D-28. LMADR0:1 Logical Memory Template Starting Address Registers**

Section 13.6, "Programming the Logical Memory Attributes" (pg. 13-8)

**Figure D-29. LMMR0:1 (Logical Memory Mask Registers)**

Section 13.6, "Programming the Logical Memory Attributes" (pg. 13-8)







# GLOSSARY

I





<b>Address Space</b>	An array of bytes used to store program code, data, stacks and system data structures required to execute a program. Address space is <i>linear</i> – also called <i>flat</i> – and byte addressable, with addresses running contiguously from 0 to $2^{32} - 1$ . It can be mapped to read-write memory, read-only memory and memory-mapped I/O. i960® architecture does not define a dedicated, addressable I/O space.
<b>Address</b>	A 32-bit value in the range 0 to FFFF FFFFH used to reference in memory a single byte, half-word (2 bytes), word (4 bytes), double-word (8 bytes), triple-word (12 bytes) or quad-word (16 bytes). Choice depends on the instruction used.
<b>Arithmetic Controls (AC) Register</b>	A 32-bit register that contains flags and masks used in controlling the various arithmetic and comparison operations that the processor performs. Flags and masks contained in this register include the condition code flags, integer-overflow flag and mask bit and the no-imprecise-faults (NIF) bit. All unused bits in this register are reserved and must be set to 0.
<b>Asynchronous Faults</b>	Faults that occur with no direct relationship to a particular instruction in the instruction stream. When an asynchronous fault occurs, the address of the faulting instruction in the fault record and the saved IP are undefined. i960 core architecture does not define any fault types that are asynchronous.
<b>Big Endian</b>	The bus controller reads or writes a data word's least-significant byte to the bus' eight most-significant data lines (D31:24). Big endian systems store the least-significant byte at the highest byte address in memory. So, if a big endian ordered word is stored at address 600, the least-significant byte is stored at address 603 and the most-significant byte at address 600. Compare with little endian.
<b>Condition Code Flags</b>	AC register bits 0, 1 and 2. The condition code flags indicate the results of certain instructions – usually compare instructions. Other instructions, such as conditional branch instructions, examine these flags and perform functions according to their state. Once the processor sets the condition code flags, they remain unchanged until the processor executes another instruction that uses these flags to store results.
<b>Execution Mode Flag</b>	PC register bit 1. This flag determines whether the processor is operating in user mode (0) or supervisor mode (1).
<b>Fault Call</b>	An implicit call to a fault handling procedure. The processor performs fault calls automatically without any intervention from software. It gets pointers to fault handling procedures from the fault table.

<b>Fault Table</b>	An architecture-defined data structure that contains pointers to fault handling procedures. Each fault table entry is associated with a particular fault type. When the processor generates a fault, it uses the fault table to select the proper fault handling procedure for the type of fault condition detected.
<b>Fault</b>	An event that the processor generates to indicate that, while executing the program, a condition arose that could cause the processor to go down a wrong and possibly disastrous path. One example of a fault condition is a divisor operand of zero in a divide operation; another example is an instruction with an invalid opcode.
<b>Frame Pointer (FP)</b>	The address of the first byte in the current (topmost) stack frame of the procedure stack. The FP is contained in global register g15.
<b>Frame</b>	See Stack Frame.
<b>Global Registers</b>	A set of 16 general-purpose registers (g0 through g15) whose contents are preserved across procedure boundaries. Global registers are used for general storage of data and addresses and for passing parameters between procedures.
<b>Guarded Memory Unit (GMU)</b>	A section of the processor that monitors all of the processor's memory transactions and can prevent accesses to predefined address regions or warn the user program if accesses occur.
<b>Hardware Reset</b>	The assertion of the RESET# pin; equivalent to powerup.
<b>IBR</b>	See Initialization Boot Record.
<b>IMI</b>	See Initial Memory Image.
<b>Imprecise Faults</b>	Faults that are allowed to be generated out-of-order from where they occur in the instruction stream. When an imprecise fault is generated, the processor indicates the address of the faulting instruction, but it does not guarantee that software can to recover from the fault and resume execution of the program with no break in the program's control flow. The NIF bit in the arithmetic controls register determines whether all faults must be precise (1) or some faults are allowed to be imprecise (0).
<b>Initialization Boot Record (IBR)</b>	One of three IMI components, IBR is the primary data structure required to initialize the processor. IBR is 12-word structure which must be located at address FFFF FF00H.
<b>Initial Memory Image (IMI)</b>	Comprises the minimum set of data structures the processor needs to initialize its system. Performs three functions for the processor: 1) provides initial configuration information for the core and integrated peripherals; 2) provides pointers to system data structures and the first instruction to be executed after processor initialization; 3) provides checksum words that the processor uses in self-test at startup. See also IBR, PRCB and System Data Structures.



<b>Instruction Cache</b>	A memory array used for temporary storage of instructions fetched from main memory. Its purpose is to streamline instruction execution by reducing the number of instruction fetches required to execute a program.
<b>Instruction Pointer (IP)</b>	A 32-bit register that contains the address (in the address space) of the instruction currently being executed. Since instructions are required to be aligned on word boundaries in memory, the IP's two least-significant bits are always zero.
<b>Integer Overflow Flag</b>	AC register bit 8. When integer overflow faults are masked, the processor sets the integer overflow flag whenever integer overflow occurs to indicate that the fault condition has occurred even though the fault has been masked. If the fault is not masked, the fault is allowed to occur and the flag is not set.
<b>Integer Overflow Mask Bit</b>	AC register bit 12. This bit masks the integer overflow fault.
<b>Interrupt Call</b>	An implicit call to a interrupt handling procedure. The processor performs interrupt calls automatically without any intervention from software. It gets vectors (pointers) to interrupt handling procedures from the interrupt table.
<b>Interrupt Stack</b>	Stack the processor uses when it executes interrupt handling procedures.
<b>Interrupt Table</b>	A data structure that contains vectors to interrupt handling procedures and fields for storing pending interrupts. When the processor receives an interrupt, it uses the vector number that accompanies the interrupt to locate an interrupt vector in the interrupt table. The interrupt table's pending interrupt fields contain bits that indicate priorities and vector numbers of interrupts waiting to be serviced.
<b>Interrupt Vector</b>	A pointer to an interrupt handling procedure. In the i960 architecture, interrupts vectors are stored in the interrupt table.
<b>Interrupt</b>	An event that causes program execution to be suspended temporarily to allow the processor to handle a more urgent chore.
<b>Leaf Procedure</b>	Leaf procedures call no other procedures. They are called "leaf procedures" because they reside at the "leaves" of the call tree.
<b>Literals</b>	A set of 32 ordinal values ranging from 0 to 31 (5 bits) that can be used as operands in certain instructions.
<b>Little Endian</b>	The bus controller reads or writes a data word's least-significant byte to the bus' eight least-significant data lines (D7:0). Little endian systems store a word's least-significant byte at the lowest byte address in memory. For example, if a little endian ordered word is stored at address 600, the least-significant byte is stored at address 600 and the most-significant byte at address 603. Compare with big endian.

<b>Local Call</b>	A procedure call that does not require a switch in the current execution mode or a switch to another stack. Local calls can be made explicitly through the <b>call</b> , <b>callx</b> and <b>calls</b> instructions and implicitly through the fault call mechanism.
<b>Local Registers</b>	A set of 16 general-purpose data registers (r0 through r15) whose contents are associated with the procedure currently being executed. Local registers hold the local variables for a procedure. Each time a procedure is called, the processor automatically allocates a new set of local registers for that procedure and saves the local registers for the calling procedure.
<b>Memory</b>	Array to which address space is mapped. Memory can be read-write, read-only or a combination of the two. A memory address is generally synonymous with an address in the address space.
<b>Memory-Mapped Register (MMR)</b>	A 32-bit register located in memory used to control specific sections of the processor. All MMRs reside inside the processor. These registers can be manipulated like any other register, but their contents affect the processor's behavior directly.
<b>“Natural” Fill Policy</b>	The processor fetches only the amount of data that is requested by a load (i.e., a word, long word, etc.) on a data cache miss. Exceptions are byte and short word accesses, which are always promoted to words.
<b>No Imprecise Faults (NIF) Bit</b>	AC register bit 15. This flag determines whether or not imprecise faults are allowed to occur. If set, all faults are required to be precise; if clear, certain faults can be imprecise.
<b>Non Maskable Interrupt (NMI)</b>	Provides an interrupt that cannot be masked and has a higher priority than priority-31 interrupts and priority-31 process priority. The core services NMI requests immediately.
<b>Parallel Faults</b>	A condition which occurs when multiple execution units, executing instructions in parallel, report multiple faults simultaneously. Setting the NIF bit prohibits execution conditions which could cause parallel faults.
<b>Pending Interrupt</b>	An interrupt that the processor saves to be serviced at a later time. When the processor receives an interrupt, it compares the interrupt's priority with the priority of the current processing task. If the priority of the interrupt is equal to or less than that of the current task, the processor saves the interrupt's priority and vector number in the pending interrupt fields of the interrupt table, then continues work on the current processing task.
<b>PFP</b>	See Previous Frame Pointer.
<b>Pointer</b>	An address in the address space (or memory). The term pointer generally refers to the first byte of a procedure or data structure or a specific byte location in a stack.



<b>PRCB</b>	See Process Control Block.
<b>Precise Faults</b>	Faults generated in the order in which they occur in the instruction stream and with sufficient fault information to allow software to recover from the faults without altering program's control flow. The AC register NIF bit and the <b>syncf</b> instruction allow software to force all faults to be precise.
<b>Previous Frame Pointer (PFP)</b>	The address of the previous stack frame's first byte. It is contained in bits 4 through 31 of local register r0.
<b>Priority Field</b>	PC register bits 16 through 20. This field determines processor priority (from 0 to 31). When the processor is in the executing state, it sets its priority according to this value. It also uses this field to determine whether to service an interrupt immediately or to save the interrupt for later service.
<b>Priority</b>	A value from 0 to 31 that indicates the priority of a program or interrupt; highest priority is 31. The processor stores the priority of the task (program or interrupt) that it is currently working on in the priority field of the PC register. See also NMI.
<b>Process Control Block (PRCB)</b>	One of three (IMI) components, PRCB contains base addresses for system data structures and initial configuration information for the core and integrated peripherals.
<b>Process Controls (PC) Register</b>	A 32-bit register that contains miscellaneous pieces of information used to control processor activity and show current processor state. Flags and fields in this register include the trace enable bit, execution mode flag, trace fault pending flag, state flag, priority field and internal state field. All unused bits in this register are reserved and must be set to 0.
<b>Register Scoreboarding</b>	Internal flags that indicate a particular register or group of registers is being used in an operation. This feature enables the processor to execute some instructions in parallel and out-of-order. When the processor begins executing an instruction, it sets the scoreboard flag for the destination register in use by that instruction. If the instructions that follow do not use scoreboarded registers, the processor can execute one or more of those instructions concurrently with the first instruction.
<b>Return Instruction Pointer (RIP)</b>	The address of the instruction following a call or branch-and-link instruction that the processor is to execute after returning from the called procedure. The RIP is contained in local register r2. When the processor executes a procedure call, it sets the RIP to the address of the instruction immediately following the procedure call instruction.
<b>Return Type Field</b>	Bits 0, 1 and 2 of local register r0. When a procedure call is made using the integrated call and return mechanism, this field indicates the call type: local, supervisor, interrupt or fault. The processor uses this information to select the proper return mechanism when returning from the called procedure.

## GLOSSARY

<b>RIP</b>	See Return Instruction Pointer.
<b>Software Reset</b>	Re-running of the Reset microcode without physically asserting the RESET# pin or removing power from the CPU.
<b>SP</b>	See Stack Pointer.
<b>Special Function Registers (SFRs)</b>	A 32-bit register (sf0-sf4) used to control specific sections of the processor. These registers can be manipulated like any other register, but their contents affect the processor's behavior directly.
<b>Stack Frame</b>	A block of bytes on a stack used to store local variables for a specific procedure. Another term for a stack frame is an <i>activation record</i> . Each procedure that the processor calls has its own stack frame associated with it. A stack frame is always aligned on a 64-byte boundary. The first 64 bytes in a stack frame are reserved for storage of the local registers associated with the procedure. The frame pointer (FP) and stack pointer (SP) for a particular frame indicate location and boundaries of a stack frame within a stack.
<b>Stack Pointer (SP)</b>	The address of the last byte in the current (topmost) frame of the procedure stack. The SP is contained in local register r1.
<b>Stack</b>	A contiguous array of bytes in the address space that grows from low addresses to high addresses. It consists of contiguous frames, one frame for each active procedure. i960 architecture defines three stacks: local, supervisor and interrupt.
<b>State Flag</b>	PC register bit 10. This flag indicates to software that the processor is currently executing a program (0) or servicing an interrupt (1).
<b>State</b>	The type of task that the processor is currently working on: a program or an interrupt handling procedure. The processor sets the PC register state flag to indicate its current state.
<b>Status and Control Registers</b>	A set of four 32-bit registers that contain status and control information used in controlling program flow. These registers include the instruction pointer (IP), AC register, PC register and TC register.
<b>Supervisor Call</b>	A system call (made with the <b>calls</b> instruction) where the entry type of the called procedure is 102. If the processor is in user mode when a supervisor call is made, it switches to the supervisor stack and to supervisor mode.
<b>Supervisor Mode</b>	One of two execution modes – user and supervisor – that the processor can use. The processor uses the supervisor stack when in supervisor mode. Also, while in supervisor mode, software is allowed to execute supervisor mode instructions such as <b>sysctl</b> and <b>modpc</b> .



<b>Supervisor Stack Pointer</b>	The address of the first byte of the supervisor stack. The supervisor stack pointer is contained in bytes 12 through 15 of the system procedure table and the trace table.
<b>Supervisor Stack System Call</b>	The procedure stack that the processor uses when in supervisor mode. An explicit procedure call made with the <b>calls</b> instruction. The two types of system calls are a system-local call and system-supervisor call. On a system call, the processor gets a pointer to the system procedure through the system procedure table.
<b>System Data Structures</b>	One of three IMI components. The following system data structures contain values the processor requires for initialization: PRCB, IBR, system procedure table, control table, interrupt table.
<b>System Procedure Table</b>	An architecturally-defined data structure that contains pointers to system procedures and (optionally) to fault handling procedures. It also contains the supervisor stack pointer and the trace control flag.
<b>Trace Table</b>	An architecturally-defined data structure that contains pointers to trace-fault-handling procedures. The trace table has the same structure as the system procedure table.
<b>Trace Control Bit</b>	Bit 0 of byte 12 of the system procedure table. This bit specifies the new value of the trace enable bit when a supervisor call causes a switch from user mode to supervisor mode. Setting this bit to 1 enables tracing; setting it to 0 disables tracing.
<b>Trace Controls (TC) Register</b>	A 32-bit register that controls processor tracing facilities. This register contains one event bit and one mode bit for each trace fault subtype (i.e., instruction, branch, call, return, prereturn, supervisor and breakpoint). The mode bits enable the various tracing modes; the event flags indicate that a particular type of trace event has been detected. All the unused bits in this register are reserved and must be set to 0.
<b>Trace Enable Bit</b>	PC register bit 0. This bit determines whether trace faults are to be generated (1) or not generated (0).
<b>Trace Fault Pending Flag</b>	PC register bit 10. This flag indicates that a trace event has been detected (1) but not yet generated. Whenever the processor detects a trace fault at the same time that it detects a non-trace fault, it sets the trace fault pending flag then calls the fault handling procedure for the non-trace fault. On return from the fault procedure for the non-trace fault, the processor checks the trace fault pending flag. If set, it generates the trace fault and handles it.

## GLOSSARY

<b>Tracing</b>	The ability of the processor to detect execution of certain instruction types, such as branch, call and return. When tracing is enabled, the processor generates a fault whenever it detects a trace event. A trace fault handler can then be designed to call a debug monitor to provide information on the trace event and its location in the instruction stream.
<b>User Mode</b>	One of two execution modes – user and supervisor – that the processor can be in. When the processor is in user mode, it uses the local stack and is not allowed to use the <b>modpc</b> instruction or any other implementation-defined instruction that is designed to be used only in supervisor mode.
<b>Vector Number</b>	The number of an entry in the interrupt table where an interrupt vector is stored. The vector number also indicates the priority of the interrupt.
<b>Vector</b>	See Interrupt Vector.







# INDEX





**A**

- absolute
  - displacement addressing mode 2-7
  - memory addressing mode 2-7
  - offset addressing mode 2-7
- AC 3-18
- AC register, see Arithmetic Controls (AC) register
- access faults 3-7
- access types
  - restrictions 3-6
- ADD 6-7**
- add
  - conditional instructions 6-7
  - integer instruction 6-11
  - ordinal instruction 6-11
  - ordinal with carry instruction 6-10
- addc 6-10**
- addi 6-11**
- addie 6-7**
- addig 6-7**
- addige 6-7**
- addil 6-7**
- addile 6-7**
- addine 6-7**
- addino 6-7**
- addio 6-7**
- addo 6-11**
- addoe 6-7**
- addog 6-7**
- addoge 6-7**
- addol 6-7**
- addole 6-7**
- addone 6-7**
- addono 6-7**
- addoo 6-7**
- address space restrictions
  - data structure alignment A-4
  - instruction cache A-2
  - internal data RAM A-2
  - reserved memory A-2
  - stack frame alignment A-4
- addressing mode
  - examples 2-8
  - register indirect 2-7
- addressing registers and literals 3-4
- alignment, registers and literals 3-4
- alterbit 6-12**
- and 6-13**
- andnot 6-13**
- architecture reserved memory space 12-9
- argument list 7-13
- Arithmetic Controls (AC) Register 3-18
- Arithmetic Controls (AC) register 3-18
  - condition code flags 3-19
  - initial image 12-19
  - initialization 3-18
  - integer overflow flag 3-20
  - integer overflow mask bit 3-20
  - no imprecise faults bit 3-20
- arithmetic instructions 5-7
  - add, subtract, multiply or divide 5-8
  - extended-precision instructions 5-10
  - remainder and modulo instructions 5-8
  - shift and rotate instructions 5-9
- arithmetic operations and data types 5-7
- atadd 3-15, 4-9, 6-14**
- atmod 3-8, 3-15, 4-9, 6-15**
- atomic access 3-14
- atomic add instruction 6-14
- atomic instructions 5-18
- Atomic instructions (LOCK signal) 14-30
- atomic modify instruction 6-15
- atomic operations 14-30
- atomic-read-modify-write sequence 3-6

**B**

- b 6-16**
- bal 6-17**
- balx 6-17**
- basic bus states 14-2
- bbc 6-19**
- bbs 6-19**
- BCON register, see Bus Control (BCON) register
- BCU, see Bus Controller Unit
- be 6-21**
- bg 6-21**
- bge 3-20, 6-21**

- big endian byte order 2-4
- big-endian byte order
  - selecting
    - little endian byte order
      - selecting 13-12
- bit definition 1-9
- bit field instructions 5-11
- bit instructions 5-11
- bit ordering 2-4
- bits and bit fields 2-3
- bi** 6-21
- ble** 6-21
- bne** 6-21
- bno** 6-21
- bo** 6-21
- boundary conditions
  - internal memory locations 13-13
  - internal memory-mapped locations 13-7
  - LMT boundaries 13-14
  - logical data template ranges 13-13
- Boundary Scan
  - test logic 15-2
- Boundary Scan (JTAG) 15-1
- Boundary Scan Architecture 15-2
- Boundary-Scan register 15-7
- BPCON 9-8
- branch
  - and link extended instruction 6-17
  - and link instruction 6-17
  - check bit and branch if clear set instruction 6-19
  - check bit and branch if set instruction 6-19
  - conditional instructions 6-21
  - extended instruction 6-16
  - instruction 6-16
- branch instructions, overview 5-14
  - compare and branch instructions 5-15
  - conditional branch instructions 5-15
  - unconditional branch instructions 5-14
- branch-and-link 7-1
  - returning from 7-21
- branch-and-link instruction 7-1
- branch-if-greater-or-equal instruction 3-20
- breakpoint
  - registers A-7
  - resource request message 9-7
- Breakpoint Control (BPCON) register 9-8, D-10
  - programming 9-8
- Breakpoint Control Register (BPCON) 9-8
- bswap** 6-23
- built-in self test 12-2
- bus confidence self test 12-6
- Bus Control (BCON) register 13-6
  - BCON.irp bit 4-2
  - BCON.sirp bit 4-1
- Bus Control Unit (BCU) 14-22
  - changing byte order dynamically 13-14
  - selecting byte order 13-12
- Bus Controller
  - boundary conditions 13-7
  - compared to previous i960 processors 13-3
  - logical memory attributes 13-2
  - memory attributes 13-1
  - physical memory attributes 13-1, 13-4
- Bus Controller Unit (BCU) 13-1
  - bus width 13-5
  - PMCON initialization 13-5
- bus controller unit (BCU) 14-2
- bus master
  - arbitration timing diagram 14-33
- bus signal groups 14-4
- bus snooping 4-5, 4-10
- bus states with arbitration 14-3
- bus transactions
  - basic read 14-9
  - basic write 14-11
  - burst transactions 14-11
  - bus width 14-7
  - data width 14-7
- bus width
  - programming with PMCON register 13-5
- bx** 6-16
- byte instructions 5-11
- byte order
  - changing dynamically 13-14
  - selecting 13-12
- byte order, little or big endian 2-4
- byte swap instruction 6-23



## C

- cache
  - data
    - cache coherency and non-cacheable accesses 4-9
    - described 4-6
    - enabling and disabling 4-6
    - fill policy 4-8
    - partial-hit multi-word data accesses 4-7
    - visibility 4-10
    - write policy 4-8
  - instruction
    - enabling and disabling 4-4
    - loading and locking instruction 4-5
    - visibility 4-5
  - load-and-lock mechanism 4-5
  - local register 3-17, 4-2
  - stack frame 3-17, 4-2
- cacheable writes (stores) 4-8
- caching of interrupt-handling procedure 11-36
- caching of local register sets
  - frame fills 7-7
  - frame spills 7-7
  - mapping to the procedure stack 7-11
  - updating the register cache 7-11
- call
  - extended instruction 6-27
  - instruction 6-24
  - system instruction 6-25
- call** 6-24, 7-2, 7-6
- call and return instructions 5-16
- call and return mechanism 7-1, 7-2
  - explicit calls 7-1
  - implicit calls 7-1
  - local register cache 7-3
  - local registers 7-2
  - procedure stack 7-3
  - register and stack management 7-4
    - frame pointer 7-4
    - previous frame pointer 7-5
    - return type field 7-5
    - stack pointer 7-4
  - stack frame 7-2
- call and return operations 7-5
- call operation 7-6
  - return operation 7-7
- calls** 3-24, 6-25, 7-2, 7-6
- call-trace mode 9-3
- callx** 6-27, 7-2, 7-6
- carry conditions 3-19
- check bit instruction 6-29
- chkbit** 6-29
- clear bit instruction 6-30
- clock input (CLKIN) 12-34
- clrbt** 6-30
- cmpdeci** 6-31
- cmpdeco** 6-31
- cmpi** 5-12, 6-33
- cmpib** 5-12
- cmpibe** 6-35
- cmpibg** 6-35
- cmpibge** 6-35
- cmpibl** 6-35
- cmpible** 6-35
- cmpibne** 6-35
- cmpibno** 6-35
- cmpibo** 6-35
- cmpinci** 6-32
- cmpinco** 6-32
- cmpis** 5-12
- cmpo** 5-12, 6-33
- cmpobe** 6-35
- cmpobg** 6-35
- cmpobge** 6-35
- cmpobl** 6-35
- cmpoble** 6-35
- cmpobne** 6-35
- cold reset 11-28, 12-3
- compare
  - and branch conditional instructions 6-35
  - and conditional compare instructions 5-12
  - and decrement integer instruction 6-31
  - and decrement ordinal instruction 6-31
  - and increment integer instruction 6-32
  - and increment ordinal instruction 6-32
  - integer conditional instruction 6-38
  - integer instruction 6-33
  - ordinal conditional instruction 6-38
  - ordinal instruction 6-33

## INDEX

- comparison instructions, overview
  - compare and increment or decrement instructions 5-13
  - test condition instructions 5-13
- concmpi** 6-38
- concmpo** 6-38
- conditional branch instructions 3-19
- conditional fault instructions 5-17
- control registers 3-1, 3-7
  - memory-mapped 3-6
  - overview 1-6
- control table 3-1, 3-7, 3-12
  - alignment 3-15
- Control Table Valid (CTV) bit 13-6
- core architecture
  - and software portability A-1
- D**
- DAB 9-10
- Data Address Breakpoint (DAB) Register Format 9-10
- Data Address Breakpoint (DAB) registers 9-9
  - programming 9-8
- data alignment in external memory 3-15
- data cache
  - cache coherency and non-cacheable accesses 4-9
  - coherency
    - I/O and bus masters 4-10
  - control instruction 6-40
  - described 4-6
  - enabling and disabling 4-6
  - fill policy 1-4, 4-8
  - overview 1-4
  - partial-hit multi-word data accesses 4-7
  - visibility 4-10
  - write policy 4-8
- Data Cache Enable (DCEN) bit 13-12
- data control peripheral units A-7
- data movement instructions 5-5
  - load address instruction 5-6
  - load instructions 5-5
  - move instructions 5-6
- data RAM 3-16
- Data Register
  - timing diagram 15-18
- data structures
  - control table 3-1, 3-7, 3-12
  - fault table 3-1, 3-12
  - Initialization Boot Record (IBR) 3-1, 3-11
  - interrupt stack 3-1, 3-12
  - interrupt table 3-1, 3-12
  - literals 3-4
  - local stack 3-1
  - Process Control Block (PRCB) 3-1, 3-11
  - supervisor stack 3-1, 3-12
  - system procedure table 3-1, 3-12
  - user stack 3-12
- data types
  - bits and bit fields 2-3
  - integers 2-2
  - literals 2-4
  - ordinals 2-2
  - supported 2-1
  - triple and quad words 2-3
- dcctl** 3-23, 4-6, 4-10, 6-40
- DCEN bit, see Data Cache Enable (DCEN) bit
- debug
  - overview 9-1
- debug instructions 5-18
- decoupling capacitors 12-36
- Default Logical Memory Configuration (DLMCON)
  - register 13-3
    - DLMCON.be bit 4-4
- design considerations
  - high frequency 12-38
  - interference 12-40
  - latchup 12-39
  - line termination 12-38
- Device ID register 15-6
- device ID Register 12-22
- device ID register D-23
- DEVICEID register location 3-3
- divi** 6-47
- divide integer instruction 6-47
- divide ordinal instruction 6-47
- divo** 6-47
- DLMCON registers



**E**

**ediv** 6-48  
 8-bit bus width byte enable encodings 14-8  
 8-bit wide data bus bursts 14-13  
 electromagnetic interference (EMI) 12-40  
 electrostatic interference (ESI) 12-40  
**emul** 6-49  
 endianism  
   changing dynamically 13-14  
   selecting 13-12  
**eshro** 6-50  
 explicit calls 7-1  
 extended addressing instructions 5-14  
 extended divide instruction 6-48  
 extended multiply instruction 6-49  
 extended shift right ordinal instruction 6-50  
 external bus  
   overview 1-6  
 external buses  
   data alignment 14-22  
 external interrupt (XINT) signals 11-18  
 external memory requirements 3-14  
**extract** 6-51

**F**

FAIL# pin 12-6  
 fault  
   OPERATION.UNIMPLEMENTED 4-1  
 fault conditional instructions 6-52  
 fault conditions 8-1  
 fault handling  
   data structures 8-1  
   fault record 8-2, 8-6  
   fault table 8-2, 8-4  
   fault type and subtype numbers 8-3  
   fault types 8-4  
   local calls 8-2  
   multiple fault conditions 8-9  
   procedure invocation 8-6  
   return instruction pointer (RIP) 8-14  
   stack usage 8-6  
   supervisor stack 8-2  
   system procedure table 8-2  
   system-local calls 8-2

  system-supervisor calls 8-2  
   user stack 8-2  
 fault record 8-6  
   address-of-faulting-instruction field 8-7  
   fault subtype field 8-7  
   location 8-6, 8-8  
   structure 8-7  
 fault table 3-1, 3-12, 8-4  
   alignment 3-15  
   local-call entry 8-6  
   location 8-4  
   system-call entry 8-6  
 fault type and subtype numbers 8-3  
 fault types 8-4  
**faulte** 6-52  
**faultg** 6-52  
**faultge** 6-52  
**faulti** 6-52  
**faultle** 6-52  
**faultne** 6-52  
**faultno** 6-52  
**faulto** 6-52  
 faults A-7  
   AC.nif bit 8-20  
   access 3-7  
   ARITHMETIC.INTEGER\_OVERFLOW 6-91  
   ARITHMETIC.OVERFLOW 6-8, 6-11, 6-47,  
     6-84, 6-101, 6-107, 6-112  
   ARITHMETIC.ZERO\_DIVIDE 6-47, 6-48,  
     6-76, 6-91  
   CONSTRAINT.RANGE 6-53  
   controlling precision of (**syncf**) 8-20  
   imprecise 5-24  
   OPERATION.INVALID\_OPERAND 6-45  
   overview 1-7  
   PROTECTION.LENGTH 6-26  
   TRACE.MARK 6-55, 6-74  
   TYPE.MISMATCH 6-45, 6-57, 6-64, 6-67,  
     6-68, 6-69, 6-78  
 field definition 1-9  
 flag definition 1-9  
 floating point 3-19  
 flush local registers instruction 6-54  
**flushreg** 6-54, 7-11

- fmark** 6-55
- force mark instruction 6-55
- FP, see Frame Pointer
- frame fills 7-7
- Frame Pointer (FP) 7-4
  - location 3-3
- frame spills 7-7
- G**
- global registers 3-1, 3-2
  - overview 1-9
- H**
- halt** 3-23, 6-56
- halt CPU instruction 6-56
- hardware breakpoint resources 9-5
  - requesting access privilege 9-6
- high priority interrupts 4-3
- HOLD/HOLDA protocol 14-32
- I**
- IBR, see initialization boot record
- icctl** 1-4, 3-23, 4-4, 4-5, 4-6, A-3
- ICON 11-22
- IEEE Standard Test Access Port 15-2
- IEEE Std. 1149.1 15-2
- IMAP0-IMAP2 11-24
- IMI 12-1, 12-10
- implementation-specific features A-1
- implicit calls 7-1, 8-2
- imprecise faults 5-24
- IMSK 11-26
- index with displacement addressing mode 2-8
- indivisible access 3-14
- inequalities (greater than, equal or less than)
  - conditions 3-19
- Initial Memory Image (IMI) 12-1
- initial memory image (IMI) 12-10
- initialization 12-1, 12-2
  - CLKIN 12-34
  - code example 12-23
  - hardware requirements 12-34
  - MON960 12-23
  - power and ground 12-34
  - software 6-114
- Initialization Boot Record (IBR) 3-1, 3-11, 12-1, 12-13, 12-15
  - alignment 3-15
- initialization data structures 3-11
- initialization mechanism A-5
- initialization requirements
  - architecture reserved memory space 12-9
  - control table 12-21, D-22
  - data structures 12-10
  - Process Control Block 12-16
- Instruction Breakpoint (IBP) registers 9-10
- Instruction Breakpoint (IPB) Register Format 9-10
- instruction breakpoint modes
  - programming 9-11
- instruction cache 3-16
  - coherency 4-5
  - configuration 3-16
  - enabling and disabling 4-4, 12-19
  - locking instructions 4-5
  - overview 1-4
  - visibility 4-5
- instruction formats 5-3
  - assembly language format 5-1
  - instruction encoding format 5-2
- instruction optimizations 5-20
- Instruction Pointer (IP) Register 3-17
- Instruction Pointer (IP) register 3-17
- Instruction Register (IR) 15-2, 15-5
  - timing diagram 15-17
- Instruction set
  - atmod** 3-8
  - sysctl** 3-8
- instruction set
  - 6-7**
  - ADD 6-7**
  - addc** 6-10
  - addi** 6-11
  - addie** 6-7
  - addig** 6-7
  - addige** 6-7
  - addil** 6-7
  - addile** 6-7
  - addine** 6-7
  - addino** 6-7





**addo** 6-11  
**addoe** 6-7  
**addog** 6-7  
**addoge** 6-7  
**addol** 6-7  
**addole** 6-7  
**addone** 6-7  
**addono** 6-7  
**addoo** 6-7  
**alterbit** 6-12  
**and** 6-13  
**andnot** 6-13  
**atadd** 3-15, 4-9, 6-14  
**atmod** 3-15, 4-9, 6-15  
**b** 6-16  
**bal** 6-17  
**balx** 6-17  
**bbc** 6-19  
**bbs** 6-19  
**be** 6-21  
**bg** 6-21  
**bge** 3-20, 6-21  
**bl** 6-21  
**ble** 6-21  
**bne** 6-21  
**bnop** 6-21  
**bo** 6-21  
**bswap** 6-23  
**bx** 6-16  
**call** 6-24, 7-2, 7-6  
**calls** 3-24, 6-25, 7-2, 7-6  
**callx** 6-27, 7-2, 7-6  
**chkbit** 6-29  
**clrbt** 6-30  
**cmpdeci** 6-31  
**cmpdeco** 6-31  
**cmpi** 5-12, 6-33  
**cmpib** 5-12  
**cmpibe** 6-35  
**cmpibg** 6-35  
**cmpibge** 6-35  
**cmpibl** 6-35  
**cmpible** 6-35  
**cmpibne** 6-35  
**cmpibno** 6-35  
**cmpibo** 6-35  
**cmpinci** 6-32  
**cmpinco** 6-32  
**cmpis** 5-12  
**cmpo** 5-12, 6-33  
**cmpobe** 6-35  
**cmpobg** 6-35  
**cmpobge** 6-35  
**cmpobl** 6-35  
**cmpoble** 6-35  
**cmpobne** 6-35  
**concmpi** 6-38  
**concmpo** 6-38  
**dcctl** 3-23, 4-6, 4-10, 6-40  
**divi** 6-47  
**divo** 6-47  
**ediv** 6-48  
**emul** 6-49  
**eshro** 6-50  
**extract** 6-51  
**faulte** 6-52  
**faultg** 6-52  
**faultge** 6-52  
**faultl** 6-52  
**faultle** 6-52  
**faultne** 6-52  
**faultno** 6-52  
**faulto** 6-52  
**flushreg** 6-54  
**fmark** 6-55  
**halt** 3-23, 6-56  
**icctl** 1-4, 3-23, 4-4, 4-5, 4-6, A-3  
implementation-specific A-5  
**intctl** 3-23, 6-66  
**intdis** 3-23, 6-68  
**inten** 3-23, 6-69  
**ld** 2-2, 3-15, 6-70  
**lda** 6-73  
**ldib** 2-2, 6-70  
**ldis** 2-2, 6-70  
**ldl** 3-4, 4-7, 6-70  
**ldob** 2-2, 6-70  
**ldos** 2-2, 6-70

- ldq** 3-16, 4-7, 6-70
- ldt** 4-7, 6-70
- mark** 6-74
- modac** 3-18, 6-75
- modi** 6-76
- modify** 6-77
- modpc** 3-21, 3-22, 3-23, 6-78, 9-3
- modtc** 6-80, 9-2
- mov** 6-81
- movl** 6-81
- movq** 6-81
- movt** 6-81
- muli** 6-84
- mulo** 6-84
- nand** 6-85
- nor** 6-86
- not** 6-87
- notand** 6-87
- notbit** 6-88
- notor** 6-89
- or** 6-90
- ornot** 6-90
- remi** 6-91
- remo** 6-91
- ret** 6-92
- rotate** 6-94
- scanbit** 6-95
- scanbyte** 6-96
- sele** 5-6, 6-97
- selg** 5-6, 6-97
- selge** 5-6, 6-97
- sell** 5-6, 6-97
- selle** 5-6, 6-97
- selne** 5-6, 6-97
- selno** 5-6, 6-97
- selo** 5-6, 6-97
- setbit** 6-99
- shli** 6-100
- shlo** 6-100
- shrdi** 6-100
- shri** 6-100
- shro** 6-100
- spanbit** 6-103
- st** 2-2, 3-15, 6-104
- stib** 2-2, 6-104
- stis** 2-2, 6-104
- stl** 3-15, 4-7, 6-104
- stob** 2-2, 6-104
- stos** 2-2
- stq** 3-16, 4-7, 6-104
- stt** 4-7, 6-104
- subc** 6-108
- subi** 6-112
- subie** 6-109
- subig** 6-109
- subige** 6-109
- subil** 6-109
- subile** 6-109
- subine** 6-109
- subino** 6-109
- subio** 6-109
- subo** 6-112
- suboe** 6-109
- subog** 6-109
- suboge** 6-109
- subol** 6-109
- subole** 6-109
- subone** 6-109
- subono** 6-109
- suboo** 6-109
- syncf** 6-113, 8-20
- sysctl** 1-4, 3-23, 4-4, 4-5, 4-6, 6-114, 9-6, A-3
- teste** 6-118
- testg** 6-118
- testge** 6-118
- testl** 6-118
- testle** 6-118
- testne** 6-118
- testno** 6-118
- testo** 6-118
- timing A-4
- xnor** 6-120
- xor** 6-120
- Instruction Trace Event 6-4
- instructions
  - conditional branch 3-19
- instruction-trace mode 9-3



- intctl** 3-23, 6-66
- intdis** 3-23, 6-68
- integer flow masking 5-23
- integers 2-2
  - data truncation 2-2
  - sign extension 2-2
- inten** 3-23, 6-69
- internal data RAM 3-16, 4-1
  - location 3-16
  - modification 4-1
  - overview 1-4
  - size 4-1
- internal self test program 12-6
- interrupt
  - timer 11-9
- Interrupt Control (ICON) Register 11-22
- Interrupt Control (ICON) register 1-5
  - memory-mapped addresses 11-21
- interrupt controller 11-1
  - configuration 11-31
  - interrupt pins 11-18
  - overview 11-2
  - program interface 11-2
  - programmer interface 11-21
  - setup 11-31
- Interrupt Controller Unit (ICU) 1-5
- interrupt handling procedures 11-31
  - AC and PC registers 11-31
  - address space 11-31
  - global registers 11-31
  - instruction cache 11-31
  - interrupt stack 11-31
  - local registers 11-31
  - location 11-31
  - supervisor mode 11-31
- Interrupt Mask (IMSK) register
  - atomic-read-modify-write sequence 3-6
- Interrupt Map Control (IMAP0-IMAP2) registers 1-5
- Interrupt Mapping (IMAP0-IMAP2) Registers 11-24
- Interrupt Mapping (IMAP0-IMAP2) registers 11-23
- interrupt mask
  - saving 11-17
- Interrupt Mask (IMSK) register 1-5, 11-25, D-18
- Interrupt Mask (IMSK) Registers 11-26
- Interrupt Pending (IPND) Register 11-25
- Interrupt Pending (IPND) register 1-5, 11-25
  - atomic-read-modify-write sequence 3-6
- interrupt performance
  - caching of interrupt-handling 11-36
  - interrupt stack 11-36
  - local register cache 11-36
- interrupt pins
  - dedicated mode 11-8
  - expanded mode 11-8
  - mixed mode 11-8
- interrupt posting 11-2
- interrupt procedure pointer 11-5
- interrupt record 11-7
  - location 11-7
- interrupt request management 11-8
- interrupt requests
  - sysctl 11-9
- interrupt sequencing of operations 11-28
- interrupt servicing mechanism A-6
- interrupt stack 3-1, 3-12, 11-7, 11-36
  - alignment 3-15
  - structure 11-7
- interrupt table 3-1, 3-12, 11-4
  - alignment 3-15, 11-4
  - caching mechanism 11-6
  - location 11-4
  - pending interrupts 11-5
  - vector entries 11-5
- interrupt vectors
  - caching 4-1
- interrupts
  - dedicated mode 11-14
  - dedicated mode posting 11-14
  - expanded mode 11-15
  - function 11-1
  - global disable instruction 6-68
  - global enable and disable instruction 6-66
  - global enable instruction 6-69
  - high priority 4-3
  - internal RAM 11-35
  - interrupt context switch 11-32

- interrupt handling procedures 11-31
- interrupt record 11-7
- interrupt stack 11-7
- interrupt table 11-4
- masking hardware interrupts 11-18
- mixed mode 11-17
- Non-Maskable Interrupt (NMI) 11-3, 11-8
- overview 11-1
- physical characteristics 11-18
- posting 11-2
- priority handling 11-11
- priority-31 interrupts 11-3, 11-18
- programmable options 11-19
- restoring r3 11-18
- servicing 11-3
- sysctl** 11-9
- vector caching 11-35
- IP 3-17
- IP register, see Instruction Pointer (IP) register
- IP with displacement addressing mode 2-8
- IPB 9-10
- IPND 11-25

**L**

- ld** 2-2, 3-15, 6-70
- lda** 6-73
- ldib** 2-2, 6-70
- ldis** 2-2, 6-70
- ldl** 3-4, 4-7, 6-70
- ldob** 2-2, 6-70
- ldos** 2-2, 6-70
- ldq** 3-16, 4-7, 6-70
- ldt** 4-7, 6-70
- leaf procedures 7-1
- literal addressing and alignment 3-5
- literals 2-4, 3-1, 3-4
  - addressing 3-4
- little endian byte order 2-4, 3-16
- LMADR register
- LMCON registers
- load address instruction 6-73
- load instructions 5-5, 6-70
- load-and-lock mechanism 4-5
- local calls 7-2, 7-14, 8-2

- call** 7-2
- callx** 7-2
- local register cache 7-3
  - overview 1-5, 3-17, 4-2
- local registers 3-1, 7-2
  - allocation 3-3, 7-2
  - management 3-3
  - overview 1-9
  - usage 7-2
- local stack 3-1
- logical data templates
  - effective range 13-11
- logical instructions 5-10
- Logical Memory Address (LMADR) register 13-3
- Logical Memory Address (LMADR) registers
  - programming 13-8
- Logical Memory Configuration (LMCON) registers
  - 13-3
- Logical Memory Mask (LMMR) registers
  - programming 13-8
- Logical Memory Templates (LMTs)
  - accesses across boundaries 13-14
  - boundary conditions 13-13
  - enabling 13-12
  - enabling and disabling data caching 13-12
  - modifying 13-14
  - overlapping ranges 13-13
  - values after reset 13-13

**M**

- mark** 6-74
- Mark Trace Event 6-4
- memory
  - internal data RAM 3-16
- memory address space 3-1



- external memory requirements 3-14
  - atomic access 3-14
  - big endian byte order 3-16
  - data alignment 3-15
  - data block sizes 3-15
  - data block storage 3-16
  - indivisible access 3-14
  - instruction alignment in external memory 3-15
  - little endian byte order 3-16
  - reserved memory 3-14
- location 3-13
- management 3-13
- memory addressing modes
  - absolute 2-7
  - examples 2-8
  - index with displacement 2-8
  - IP with displacement 2-8
  - overview 2-6
  - register indirect 2-7
- memory-mapped control registers 3-6
- Memory-Mapped Registers (MMR) 3-6, 3-14
- MMR, see Memory-Mapped Registers (MMR)
- modac** 3-18, 6-75
- modi** 6-76
- modify** 6-77
- modify arithmetic controls instruction 6-75
- modify process controls instruction 6-78
- modify trace controls instruction 6-80, 9-2
- modpc** 3-21, 3-22, 3-23, 6-78, 9-3
- modtc** 6-80, 9-2
- modulo integer instruction 6-76
- mov** 6-81
- move instructions 6-81
- movl** 6-81
- movq** 6-81
- movt** 6-81
- muli** 6-84
- mulo** 6-84
- multiple fault conditions 8-9
- multiply integer instruction 6-84
- multiply ordinal instruction 6-84

**N**

- nand** 6-85

- NMI, see Non-Maskable Interrupt (NMI)
- No Imprecise Faults (AC.nif) bit 8-15, 8-20
- Non-Maskable Interrupt (NMI) 11-3, 11-8
  - signal 11-18
- nor** 6-86
- not** 6-87
- notand** 6-87
- notbit** 6-88
- notor** 6-89

**O**

- On-Circuit Emulation (ONCE) mode 12-1, 15-1
- OPERATION.UNIMPLEMENTED 4-1
- or** 6-90
- ordinals 2-2
  - sign and sign extension 2-3
- ornot** 6-90
- output pins 12-37
- overflow conditions 3-19

**P**

- parameter passing 7-12
  - argument list 7-13
  - by reference 7-12
  - by value 7-12
- PC 3-21
- PC register, see Process Controls (PC) register
- pending interrupts 11-5
  - encoding 11-5
  - interrupt procedure pointer 11-5
  - pending priorities field 11-5
- performance optimization 5-20
- PFP r0 7-20
- Physical Memory Configuration (PMCON) registers
  - 13-1
    - application modification 13-7
    - initial values 13-5
- PMCON registers
- power and ground planes 12-35
- powerup/reset initialization
  - timer powerup 10-11
- PRCB, see Processor Control Block (PRCB)
- prereturn-trace mode 9-4
- Previous Frame Pointer (PFP) 3-1, 7-4, 7-5

## INDEX

- location 3-3
  - r0 7-20
  - Previous Frame Pointer Register (PFP) (r0) 7-20
  - priority-31 interrupts 11-3, 11-18
  - procedure calls
    - branch-and-link 7-1
    - call and return mechanism 7-1
    - leaf procedures 7-1
  - procedure stack 7-3
    - growth 7-3
  - Process Control Block (PRCB) 3-1, 3-11, 4-4, 12-1, 12-16
    - alignment 3-15
    - configuration 12-16
    - register cache configuration word 12-19
  - Process Controls (PC) Register 3-21
  - Process Controls (PC) register 3-21
    - execution mode flag 3-21
    - initialization 3-22
    - modification 3-22
    - modpc 3-22
    - priority field 3-21
    - processor state flag 3-21
    - trace enable bit 3-22
    - trace fault pending flag 3-22
  - processor initialization 12-1
  - processor management instructions 5-19
  - processor state registers 3-1, 3-17
    - Arithmetic Controls (AC) register 3-18
    - Instruction Pointer (IP) register 3-17
    - Process Controls (PC) register 3-21
    - Trace Controls (TC) register 3-23
  - programming
    - logical memory attributes 13-13
- R**
- r0 Previous Frame Pointer (PFP) 7-20
  - RAM 3-11
    - internal data
      - described 4-1
  - RAM, internal data 3-16
  - region boundaries
    - bus transactions across 13-7
  - register
    - access 11-27
    - addressing 3-4
    - addressing and alignment 3-5
    - Breakpoint Control (BPCON) 9-7
    - cache 3-17, 4-2
    - control 3-7
      - memory-mapped 3-6
    - DEVICEID
      - memory location 3-3
    - global 3-2
    - indirect addressing mode
      - register-indirect-with-displacement 2-7
      - register-indirect-with-index 2-7
      - register-indirect-with-index-and-displacement 2-8
      - register-indirect-with-offset 2-7
    - Interrupt Control (ICON) 11-21
    - Interrupt Mapping (IMAP0-IMAP2) 11-23
    - Interrupt Mask (IMSK) 11-25
    - Interrupt Pending (IPND) 11-25
    - local
      - allocation 3-3
      - management 3-3
    - processor-state 3-17
    - scoreboarding
      - example 3-4
    - TCRx 10-6
- Registers
- Arithmetic Controls (AC) Register 3-18
  - Breakpoint Control Register (BPCON) 9-8
  - Data Address Breakpoint (DAB) Register Format 9-10
  - Instruction Breakpoint (IPB) Register Format 9-10
  - Instruction Pointer (IP) Register 3-17
  - Interrupt Control (ICON) Register 11-22
  - Interrupt Mapping (IMAP0-IMAP2) Registers 11-24
  - Interrupt Mask (IMSK) register 11-26
  - Interrupt Pending (IPND) Register 11-25
  - Previous Frame Pointer Register (PFP) (r0) 7-20
  - Process Controls (PC) Register 3-21
  - Timer Count Register (TCR0, TCR1) 10-6
  - Timer Mode Register (TMR0, TMR1) 10-3
  - Timer Reload Register (TRR0, TRR1) 10-7

Trace Controls (TC) Register 3-23, 9-2

registers

- Boundary-Scan 15-7
- Bus Control (BCON) 13-6
- device ID 12-22, D-23
- Instruction 15-5
- Interrupt Control (ICON) 1-5
- Interrupt Map Control (IMAP0-IMAP2) 1-5
- Interrupt Mask (IMSK) 1-5
- Interrupt Pending (IPND) 1-5, D-15
- Logical Memory Templates (LMTs) 13-13
- naming conventions 1-9

re-initialization

- software 6-114

remainder integer instruction 6-91

remainder ordinal instruction 6-91

**remi** 6-91

**remo** 6-91

reserved locations A-4

reserved memory 1-9

reserving frames in the local register cache 11-36

reset operation

- register values 12-5

reset state 12-3

**ret** 6-92

Return Instruction Pointer (RIP) 7-4

- location 3-3

return operation 7-7

return type field 7-5

RIP, see Return Instruction Pointer (RIP)

ROM 3-11

**rotate** 6-94

Run Built-In Self-Test (RUNBIST) register 15-7

**S**

SALIGN A-4

saving the interrupt mask 11-17

**scanbit** 6-95

**scanbyte** 6-96

**sele** 5-6, 6-97

select based on equal instruction 5-6

select based on less or equal instruction 5-6

select based on not equal instruction 5-6

select based on ordered instruction 5-6

select based on unordered 5-6

select instructions 6-120

self test (STEST) pin 12-6

**selg** 5-6, 6-97

**selge** 5-6, 6-97

**sell** 5-6, 6-97

**selle** 5-6, 6-97

**selne** 5-6, 6-97

**selno** 5-6, 6-97

**selo** 5-6, 6-97

**setbit** 6-99

shift instructions 6-100

**shli** 6-100

**shlo** 6-100

**shrdi** 6-100

**shri** 6-100

**shro** 6-100

sign extension

- integers 2-2
- ordinals 2-3

single processor as bus master 14-32

16-bit bus width byte enable encodings 14-8

16-bit wide data bus bursts 14-12

software re-initialization 6-114

SP, see Stack Pointer

**spanbit** 6-103

*src/dst* parameter encodings 9-7

**st** 2-2, 3-15, 6-104

stack frame

- allocation 7-2

stack frame cache 3-17, 4-2

Stack Pointer (SP) 7-4

- location 3-3

stacks 3-11

STEST 12-6

**stib** 2-2, 6-104

**stis** 2-2, 6-104

**stl** 3-15, 4-7, 6-104

**stob** 2-2, 6-104

store instructions 5-5, 6-104

**stos** 2-2

**stq** 3-16, 4-7, 6-104

**stt** 4-7, 6-104

**subc** 6-108

- subi** 6-112
  - subie** 6-109
  - subig** 6-109
  - subige** 6-109
  - subil** 6-109
  - subile** 6-109
  - subine** 6-109
  - subino** 6-109
  - subio** 6-109
  - subo** 6-112
  - suboe** 6-109
  - subog** 6-109
  - suboge** 6-109
  - subol** 6-109
  - subole** 6-109
  - subone** 6-109
  - subono** 6-109
  - suboo** 6-109
  - subtract
    - conditional instructions 6-109
    - integer instruction 6-112
    - ordinal instruction 6-112
    - ordinal with carry instruction 6-108
  - supervisor calls 7-2
  - supervisor mode resources 3-23
  - Supervisor Stack 7-17
  - supervisor stack 3-1, 3-12
    - alignment 3-15
  - supervisor-trace mode 9-3
  - syncf** 6-113, 8-20
  - synchronize faults instruction 6-113
  - sysctl** 1-4, 3-8, 3-23, 4-4, 4-5, 4-6, 6-114, 9-6, A-3
  - system calls 7-2, 7-15
    - calls** 7-2
      - system-local 7-2, 8-2
      - system-supervisor 7-2, 8-2
  - system control instruction 6-114
  - system procedure table 3-1, 3-12, 7-15
    - alignment 3-15
- T**
- TC 3-23, 9-2
  - TCR0, TCR1 10-6
  - Test Access Port (TAP) controller 15-2
    - architecture 15-3
    - Asynchronous Reset Input (TRST) pin 15-5
    - block diagram 15-3
    - Serial Test Data Output (TDO) pin 15-5
    - state diagram 15-4
    - Test Clock (TCK) pin 15-5
    - Test Mode Select (TMS) pin 15-5
  - test features 15-2
  - test instructions 6-118
  - Test Mode Select (TMS) line 15-2
  - teste** 6-118
  - testg** 6-118
  - testge** 6-118
  - testl** 6-118
  - testle** 6-118
  - testne** 6-118
  - testno** 6-118
  - testo** 6-118
  - 32-bit bus width byte enable encodings 14-8
  - 32-bit wide data bus bursts 14-12
  - timer
    - interrupts 11-9
    - memory-mapped addresses 10-2
  - Timer Count Register (TCR0, TCR1) 10-6
  - Timer Count Register (TCRx) 10-6
    - address and access type 3-11
  - Timer Mode Register
    - timer mode control bit summary 10-8
  - Timer Mode Register (TMR0, TMR1) 10-3
  - Timer Mode Register (TMRx)
    - address and access type 3-11
    - terminal count 10-4
    - timer clock encodings 10-6
  - Timer Reload Register (TRR0, TRR1) 10-7
  - Timer Reload Register (TRRx)
    - address and access type 3-11
  - timers
    - overview 1-6
  - TMR0, TMR1 10-3
  - Trace Controls (TC) Register 3-23, 9-2
  - Trace Controls (TC) register 3-23, 9-2
  - trace events 9-1
    - hardware breakpoint registers 9-1





**mark** and **fmark** 9-1  
PC and TC registers 9-1  
trace-fault-pending flag 9-3  
TRR), TRR1 10-7  
true/false conditions 3-19  
TTL input pins 12-37  
two-word burst write transaction 14-14

## U

unordered numbers 3-19  
user space family registers and tables 3-11  
user stack 3-12, 7-19  
alignment 3-15  
user supervisor protection model 3-23  
supervisor mode resources 3-23  
usage 3-24

## V

vector entries 11-5  
NMI 11-5  
structure 11-5

## W

warm reset 11-28, 12-3  
words  
triple and quad 2-3

## X

$\overline{\text{XINT}}$ , see external interrupt ( $\overline{\text{XINT}}$ ) signals 11-18  
**xnor** 6-120  
**xor** 6-120

